

# TECHNICAL MANUAL

## INVERTER MULTI-SPLIT SYSTEM RESIDENTIAL AIR-CONDITIONERS (Split system, air to air heat pump type)

### (OUTDOOR UNIT)

SCM40ZM-S	SCM71ZM-S
45ZM-S	80ZM-S
50ZM-S	100ZM-S
60ZM-S	125ZM-S

### (INDOOR UNIT)

#### Wall mounted type

SRK20ZMX-S  
25ZMX-S  
35ZMX-S  
50ZMX-S  
60ZMX-S

#### Floor standing type

SRF25ZMX-S  
35ZMX-S  
50ZMX-S

#### Ceiling concealed type

SRR25ZM-S  
35ZM-S  
50ZM-S  
60ZM-S

SRK20ZM-S  
25ZM-S  
35ZM-S  
50ZM-S  
SRK71ZR-S

#### 4way ceiling cassette type

FDTC25VF  
35VF  
50VF  
60VF

#### Ceiling suspended type

FDEN50VF

Duct connected Low/Middle static pressure type  
FDUM50VF

## CONTENTS

<b>1. OUTDOOR UNITS</b>	<b>8</b>
<b>1.1 Specifications</b>	<b>8</b>
<b>1.2 Exterior dimensions</b>	<b>16</b>
<b>1.3 Electrical wiring</b>	<b>21</b>
<b>1.4 Noise level</b>	<b>26</b>
<b>1.5 Application data</b>	<b>30</b>
(1) Models SCM40ZM-S, 45ZM-S	30
(2) Models SCM50ZM-S, 60ZM-S	34
(3) Models SCM71ZM-S, 80ZM-S	38
(4) Models SCM100ZM-S, 125ZM-S	42
<b>2. INDOOR UNITS</b>	<b>46</b>
<b>2.1 Specifications</b>	<b>46</b>
(1) Wall mounted type (SRK)	46
(2) Floor standing type (SRF)	56
(3) Ceiling concealed type (SRR)	59
(4) 4way ceiling cassette type (FDTC)	63
(5) Ceiling suspended type (FDEN)	67
(6) Duct connected Low/Middle static pressure type (FDUM)	68
<b>2.2 Exterior dimensions</b>	<b>69</b>
(1) Wall mounted type (SRK)	69
(2) Floor standing type (SRF)	72
(3) Ceiling concealed type (SRR)	73
(4) 4way ceiling cassette type (FDTC)	75
(5) Ceiling suspended type (FDEN)	76
(6) Duct connected Low/Middle static pressure type (FDUM)	77
(7) Remote control	78
<b>2.3 Electrical wiring</b>	<b>81</b>
(1) Wall mounted type (SRK)	81
(2) Floor standing type (SRF)	84
(3) Ceiling concealed type (SRR)	85
(4) 4way ceiling cassette type (FDTC)	86
(5) Ceiling suspended type (FDEN)	87
(6) Duct connected Low/Middle static pressure type (FDUM)	88

<b>2.4 Noise level</b>	<b>89</b>
(1) Wall mounted type (SRK)	89
(2) Floor standing type (SRF)	94
(3) Ceiling concealed type (SRR)	95
(4) 4way ceiling cassette type (FDTC)	101
(5) Ceiling suspended type (FDEN)	103
(6) Duct connected Low/Middle static pressure type (FDUM)	104
<b>2.5 Characteristics of fan</b>	<b>105</b>
<b>2.6 Application data</b>	<b>107</b>
(1) Wall mounted type (SRK)	107
(2) Floor standing type (SRF)	119
(3) Ceiling concealed type (SRR)	123
(4) 4way ceiling cassette type (FDTC)	127
(5) Ceiling suspended type (FDEN)	133
(6) Duct connected Low/Middle static pressure type (FDUM)	137
<b>3. PIPING SYSTEMS</b>	<b>142</b>
<b>4. RANGE OF USAGE &amp; LIMITATIONS</b>	<b>147</b>
<b>5. TABLE OF INDOOR UNIT COMBINATIONS</b>	<b>149</b>
(1) Model SCM40ZM-S	149
(2) Model SCM45ZM-S	150
(3) Model SCM50ZM-S	152
(4) Model SCM60ZM-S	154
(5) Model SCM71ZM-S	158
(6) Model SCM80ZM-S	164
(7) Model SCM100ZM-S	172
(8) Model SCM125ZM-S	184
<b>6. SELECTION CHARTS</b>	<b>206</b>
<b>7. OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER</b>	<b>207</b>
<b>7.1 SRK,SRF and SRR series</b>	<b>207</b>
<b>7.1.1 Operation control function by wireless remote control</b>	<b>207</b>
<b>7.1.2 Operation control function by indoor control</b>	<b>210</b>
(1) Unit ON/OFF button	210
(2) Auto restart function	211
(3) Installing two air-conditioners in the same room	211

(4) Selection of the annual cooling function .....	212
(5) High power operation .....	213
(6) Economy operation .....	213
(7) Flap and louver control (SRK and SRF series only) .....	214
(8) Air outlet selection (SRF series only) .....	216
(9) 3D auto operation (SRK series only) .....	217
(10) Timer operation .....	218
(11) Night setback .....	218
(12) Installation location setting (SRK series only) .....	218
(13) Determining the operating mode .....	219
(14) Drain pump abnormalities detection (SRR series only) .....	219
(15) Outline of dry (dehumidifying) operation .....	219
(16) Outline of automatic operation .....	220
(17) Operation permission/prohibition control .....	221
(18) External control (remote display)/control of input signal .....	221
(19) Hot keep operation .....	222
(20) Frost prevention control .....	222
(21) Heating high pressure control .....	223
(22) Heating overload protective control .....	223
(23) Indoor fan motor protection .....	223
<b>7.2 FDTC, FDEN and FDUM series .....</b>	<b>224</b>
<b>7.2.1 Remote control (Option parts) .....</b>	<b>224</b>
<b>7.2.2 Operation control function by the wired remote control .....</b>	<b>227</b>
<b>7.2.3 Operation control function by the indoor control .....</b>	<b>230</b>
(1) Auto operation .....	230
(2) Operations of functional items during cooling/heating .....	231
(3) Dehumidifying operation .....	231
(4) Timer operation .....	232
(5) Remote control display during the operation stop .....	233
(6) Hot start (Cold draft prevention at heating) .....	233
(7) Hot keep .....	233
(8) Auto swing control .....	234
(9) Thermostat operation .....	235
(10) Filter sign .....	236

(11) Compressor inching prevention control .....	236
(12) Drain pump control .....	237
(13) Drain pump abnormalities detection .....	237
(14) Operation check/drain pump test run operation mode .....	237
(15) Cooling, dehumidifying frost protection .....	238
(16) Heating overload protection .....	238
(17) Anomalous fan motor .....	239
(18) Plural unit control - Control of 16 units group by one remote control .....	239
(19) High ceiling control .....	239
(20) Abnormal temperature thermistor (return air/indoor heat exchanger) wire/short-circuit detection .....	240
(21) External input/output control (CnT or CnTA) .....	240
(22) Operation permission/prohibition .....	242
(23) Selection of cooling/heating external input function .....	243
(24) Room temperature detection temperature compensation during heating .....	244
(25) Return air temperature compensation .....	244
(26) High power operation (RC-EX1A only) .....	244
(27) Energy-saving operation (RC-EX1A only) .....	244
(28) Warm-up control (RC-EX1A only) .....	244
(29) Home leave mode (RC-EX1A only) .....	245
(30) Auto temp. setting (RC-EX1A only) .....	245
(31) Fan circulator operation (RC-EX1A only) .....	245
(32) The operation judgment is executed every 5 minutes (RC-EX1A only) ....	245
(33) Auto fan speed control (RC-EX1A only) .....	245
(34) IU overload alarm (RC-EX1A only) .....	245
(35) Peak-cut time (RC-EX1A only) .....	245
<b>7.3 Outdoor units .....</b>	<b>246</b>
<b>7.3.1 Outline of heating operation .....</b>	<b>246</b>
(1) Summary .....	246
(2) Operation of major functional components in heating mode .....	246
(3) Defrost operation .....	247
<b>7.3.2 Outline of cooling operation .....</b>	<b>248</b>
(1) Summary .....	248
(2) Operation of major functional components in cooling mode .....	248
<b>7.3.3 Protective control function .....</b>	<b>249</b>

(1) Cooling overload protective control .....	249
(2) Cooling high pressure control .....	249
(3) Cooling low outdoor temperature protective control .....	250
(4) Heating high pressure control .....	250
(5) Heating overload protective control .....	251
(6) Heating low outdoor temperature protective control .....	251
(7) Refrigeration cycle system protective control .....	252
(8) Crankcase heater .....	252
(9) Inching prevention .....	252
(10) Compressor overheat protection .....	253
(11) Current safe .....	253
(12) Current cut .....	254
(13) Outdoor unit failure .....	254
(14) Discharge pipe sensor disconnection protection control .....	254
(15) Regulation of outdoor air flow .....	255
(16) Serial signal transmission error protection .....	255
(17) Rotor lock .....	255
(18) Outdoor fan motor protection .....	255
(19) Outdoor fan control at low outdoor temperature .....	255
(20) Outdoor unit fan control at overload .....	257
(21) Anomalous power transistor .....	257
(22) Power transistor overheat protection .....	257
(23) Control of the flowing noise of refrigerant during cooling operation .....	257
<b>8. MAINTENANCE DATA .....</b>	<b>258</b>
<b>8.1 SRK, SRF and SRR series .....</b>	<b>258</b>
(1) Cautions .....	258
(2) Items to check before troubleshooting .....	258
(3) Troubleshooting procedure (If the air-conditioner does not run at all) .....	258
(4) Troubleshooting procedure (If the air-conditioner runs) .....	259
(5) Self-diagnosis table .....	260
(6) Service mode (Trouble mode access function) .....	262
(7) Inspection procedures corresponding to detail of trouble .....	272
(8) Phenomenon observed after shortcircuit, wire breakage on sensor .....	277
(9) Checking the indoor electrical equipment .....	278



(10) How to make sure of wireless remote control .....	279
(11) Inspection procedure for blown fuse on the indoor and outdoor PCB ....	279
(12) Outdoor unit inspection points .....	280
<b>8.2 FDTC, FDEN and FDUM series .....</b>	<b>286</b>
<b>8.2.1 Diagnosing of microcomputer circuit .....</b>	<b>286</b>
(1) Selfdiagnosis function .....	286
(2) Troubleshooting procedure .....	290
(3) Troubleshooting at the indoor unit .....	290
(4) Check of anomalous operation data with the remote control .....	297
(5) Inverter checker for diagnosis of inverter output .....	299
(6) Outdoor unit inspection points .....	299
<b>8.2.2 Troubleshooting flow .....</b>	<b>300</b>
(1) List of troubles .....	300
(2) Troubleshooting .....	301
<b>9. TABLE OF FUNCTIONS CONNECTED WIRED REMOTE CONTROL (RC-E5) .....</b>	<b>348</b>
<b>10. COMPONENT REPLACEMENT .....</b>	<b>350</b>
<b>10.1 Models SCM71ZM-S, 80ZM-S .....</b>	<b>350</b>
<b>10.2 Models SCM100ZM-S, 125ZM-S .....</b>	<b>362</b>
<b>11. CHECKING PROCEDURE .....</b>	<b>374</b>
<b>11.1 Models SCM71ZM-S, 80ZM-S .....</b>	<b>374</b>
<b>11.2 Models SCM100ZM-S, 125ZM-S .....</b>	<b>379</b>
<b>12. OPTION PARTS .....</b>	<b>384</b>
<b>12.1 Wired remote control .....</b>	<b>384</b>
<b>12.2 Wireless kit .....</b>	<b>398</b>
(1) FDTC series (RCN-TC-24W-ER) .....	398
(2) FDEN series (RCN-E1R) .....	400
(3) FDUM series (RCN-KIT3-E) .....	404
<b>12.3 Simple wired remote control (RCH-E3) .....</b>	<b>406</b>
<b>12.4 Interface kit (SC-BIKN-E) .....</b>	<b>412</b>
<b>12.5 Superlink E board (SC-ADNA-E) .....</b>	<b>416</b>
<b>12.6 Ceiling concealed type (SRR) option parts .....</b>	<b>418</b>
<b>12.7 OA spacer (FDTC only) .....</b>	<b>421</b>
<b>12.8 Duct joint (FDTC only) .....</b>	<b>425</b>
<b>12.9 Filter kit (FDUM only) .....</b>	<b>426</b>

**13. TECHNICAL INFORMATION .....428**

(1) Model SCM40ZM-S .....	428
(2) Model SCM45ZM-S .....	430
(3) Model SCM50ZM-S .....	432
(4) Model SCM60ZM-S .....	436
(5) Model SCM71ZM-S .....	440
(6) Model SCM80ZM-S .....	446
(7) Model SCM100ZM-S .....	452

**■ Table of models**

Model \ Capacity	20	25	35	50	60	71
Wall mounted type (SRK * * ZMX-S)	○	○	○	○	○	
Wall mounted type (SRK * * ZM-S)	○	○	○	○		
Wall mounted type (SRK * * ZR-S)						○
Floor standing type (SRF)		○	○	○		
Ceiling concealed type (SRR)		○	○	○	○	
4way ceiling cassette type (FDTC)		○	○	○	○	
Ceiling suspended type (FDEN)				○		
Duct connected Low/Middle static pressure type (FDUM)				○		
Outdoor unit to be combined (SCM)	SCM40ZM-S, 45ZM-S, 50ZM-S, 60ZM-S, 71ZM-S, 80ZM-S, 100ZM-S, 125ZM-S					

**■ How to read the model name****Outdoor unit****Example: SCM 60 Z M-S****Indoor unit****Example: SRK 20 Z MX-S**

# 1. OUTDOOR UNITS

## 1.1 Specifications

Adapted to **RoHS** directive

Item				Model	SCM40ZM-S
Cooling capacity (1)				W	4000 (1800 (Min.)–5900 (Max.))
Heating capacity (1)				W	4500 (1400 (Min.)–6900 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling	kW	0.84 (0.49–1.90)	
		Heating		0.90 (0.47–2.30)	
	Running current	Cooling	A	3.9 / 3.7 / 3.5 (220 / 230 / 240 V)	
		Heating		4.1 / 4.0 / 3.8 (220 / 230 / 240 V)	
	Inrush current				4.1 / 4.0 / 3.8 (220 / 230 / 240 V)
	Max current (5)				14
	COP	Cooling		4.76	
		Heating		5.00	
	Noise level	Cooling	Sound level	dB (A)	47
			Power level	dB	60
		Heating	Sound level	dB (A)	48
			Power level	dB	62
Exterior dimensions (Height x Width x Depth)				mm	640 x 850 x 290
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	47
Refrigerant equipment	Compressor type & Q'ty				RM-T5113MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.45 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 2 (Pre-Charged up to the piping length of 30m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
	Device control				Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	34
	Air flow	Cooling	m³/min	40.0	
		Heating		40.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 2 Gas line: ϕ 9.52 (3/8") × 2
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 30
	Vertical height difference between outdoor unit and indoor unit				Max. 15 (Outdoor unit is higher) Max. 15 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	25
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Installation sheet, Elbow, Grommet
Indoor unit to be combined					SRK20,25,35ZMX-S SRK20,25,35ZM-S SRF25,35ZMX-S SRR25,35ZM-S FDTC25,35VF
Number of connectable indoor units					2
Total of indoor units				kW	Max. 6

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.

Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating	20°C	—	7°C	6°C	


(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 30m connecting piping.

(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284 

Adapted to RoHS directive

Item				Model	SCM45ZM-S
Cooling capacity (1)				W	4500 (1800 (Min.)–6400 (Max.))
Heating capacity (1)				W	5600 (1400 (Min.)–7400 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling		kW	1.04 (0.49–2.14)
		Heating			1.20 (0.47–2.57)
	Running current	Cooling		A	4.8 / 4.6 / 4.4 (220 / 230 / 240 V)
		Heating			5.5 / 5.3 / 5.1 (220 / 230 / 240 V)
	Inrush current				5.5 / 5.3 / 5.1 (220 / 230 / 240 V)
	Max current (5)				14
	COP		Cooling		4.33
			Heating		4.67
	Noise level	Cooling	Sound level	dB (A)	47
			Power level	dB	60
		Heating	Sound level	dB (A)	49
			Power level	dB	62
Exterior dimensions (Height x Width x Depth)				mm	640 x 850 x 290
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	47
Refrigerant equipment	Compressor type & Q'ty				RM-T5113MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.45 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 2 (Pre-Charged up to the piping length of 30m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
	Device control				Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	34
	Air flow	Cooling	m³/min	40.0	
		Heating		40.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 2 Gas line: ϕ 9.52 (3/8") × 2
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 30
	Vertical height difference between outdoor unit and indoor unit				Max. 15 (Outdoor unit is higher) Max. 15 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	25
Connection wiring	Size x Core number				1.5mm <sup>2</sup> x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Installation sheet, Elbow, Grommet
Indoor unit to be combined					SRK20,25,35ZMX-S SRK20,25,35ZM-S SRF25,35ZMX-S SRR25,35ZM-S FDTC25,35VF
Number of connectable indoor units					2
Total of indoor units				kW	Max. 7

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.


Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating	20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 30m connecting piping.  
(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284 

Adapted to RoHS directive

Item				Model	SCM50ZM-S
Cooling capacity (1)				W	5000 (1800 (Min.)–7100 (Max.))
Heating capacity (1)				W	6000 (1400 (Min.)–7500 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling	kW	1.08 (0.50–2.15)	
		Heating		1.31 (0.48–2.58)	
	Running current	Cooling	A	5.0 / 4.7 / 4.5 (220 / 230 / 240 V)	
		Heating		6.0 / 5.8 / 5.5 (220 / 230 / 240 V)	
	Inrush current			6.0 / 5.8 / 5.5 (220 / 230 / 240 V)	
	Max current (5)			15	
	COP	Cooling		4.63	
		Heating		4.58	
	Noise level	Cooling	Sound level	dB (A)	49
			Power level	dB	62
	Noise level	Heating	Sound level	dB (A)	52
			Power level	dB	65
Exterior dimensions (Height x Width x Depth)				mm	640 x 850 x 290
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	48
Refrigerant equipment	Compressor type & Q'ty				RM-T5113MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.45 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 2.5 (Pre-Charged up to the piping length of 40m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
Device control					Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	34
	Air flow	Cooling	m³/min	41.0	
		Heating		41.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 3 Gas line: ϕ 9.52 (3/8") × 3
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 40
	Vertical height difference between outdoor unit and indoor unit				Max. 15 (Outdoor unit is higher) Max. 15 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	25
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Union : ( ϕ 9.52→ ϕ 12.7 ) × 1, Installation sheet, Elbow, Grommet
Indoor unit to be combined					SRK20,25,35,50ZMX-S SRK20,25,35,50ZM-S SRF25,35,50ZMX-S SRR25,35,50ZM-S FDTC25,35,50VF FDEN50VF,FDUM50VF
Number of connectable indoor units					Min. 2–Max. 3
Total of indoor units				kW	Max. 8.5

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.

Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating	20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 40m connecting piping.

(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284A

Adapted to RoHS directive

Item				Model	SCM60ZM-S
Cooling capacity (1)				W	6000 (1800 (Min.)–7500 (Max.))
Heating capacity (1)				W	6800 (1500 (Min.)–7800 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling	kW	1.43 (0.50–2.39)	
		Heating		1.51 (0.60–3.00)	
	Running current	Cooling	A	6.8 / 6.5 / 6.2 (220 / 230 / 240 V)	
		Heating		7.1 / 6.8 / 6.6 (220 / 230 / 240 V)	
	Inrush current			7.1 / 6.8 / 6.6 (220 / 230 / 240 V)	
	Max current (5)			17	
	COP	Cooling		4.2	
		Heating		4.5	
	Noise level	Cooling	Sound level	dB(A)	50
			Power level	dB	63
		Heating	Sound level	dB(A)	52
			Power level	dB	65
Exterior dimensions (Height x Width x Depth)				mm	640 x 850 x 290
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	49
Refrigerant equipment	Compressor type & Q'ty				RM-T5118MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.675 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 2.5 (Pre-Charged up to the piping length of 40m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
Device control					Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	34
	Air flow	Cooling	m³/min	42.0	
		Heating		42.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 3 Gas line: ϕ 9.52 (3/8") × 3
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 40
	Vertical height difference between outdoor unit and indoor unit				Max. 15 (Outdoor unit is higher) Max. 15 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	25
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Union : ( ϕ 9.52→ ϕ 12.7) × 2, Installation sheet, Elbow, Grommet
Indoor unit to be combined					SRK20,25,35,50,60ZMX-S SRK20,25,35,50ZM-S SRF25,35,50ZMX-S SRR25,35,50,60ZM-S FDTC25,35,50,60VF FDEN50VF,FDUM50VF
Number of connectable indoor units					Min. 2–Max. 3
Total of indoor units				kW	Max. 11

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.


Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
Cooling		27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating		20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 40m connecting piping.  
(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284 

Adapted to RoHS directive

Item				Model	SCM71ZM-S
Cooling capacity (1)				W	7100 (1800 (Min.)–8800 (Max.))
Heating capacity (1)				W	8600 (1500 (Min.)–9400 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling	kW	1.74 (0.48–2.75)	
		Heating		2.00 (0.60–3.35)	
	Running current	Cooling	A	8.0 / 7.6 / 7.3 (220 / 230 / 240 V)	
		Heating		9.2 / 8.8 / 8.4 (220 / 230 / 240 V)	
	Inrush current			9.2 / 8.8 / 8.4 (220 / 230 / 240 V)	
	Max current (5)			20	
	COP	Cooling		4.08	
		Heating		4.30	
	Noise level	Cooling	Sound level	dB (A)	52
			Power level	dB	65
	Noise level	Heating	Sound level	dB (A)	54
			Power level	dB	66
Exterior dimensions (Height x Width x Depth)				mm	750 x 880 x 340
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	62
Refrigerant equipment	Compressor type & Q'ty				RM-T5118MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.675 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 3.15 (Pre-Charged up to the piping length of 40m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
	Device control				Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	86
	Air flow	Cooling	m³/min	56.0	
		Heating		56.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 4 Gas line: ϕ 9.52 (3/8") × 4
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 70
	Vertical height difference between outdoor unit and indoor unit				Max. 20 (Outdoor unit is higher) Max. 20 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
	Recommended breaker size				A
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Union : ( ϕ 9.52→ ϕ 12.7) × 2, Installation sheet, Elbow, Grommet × 2
Indoor unit to be combined					SRK20,25,35,50,60ZMX-S SRK20,25,35,50ZM-S SRF25,35,50ZMX-S SRR25,35,50,60ZM-S FDTC25,35,50,60VF FDEN50VF,FDUM50VF
Number of connectable indoor units					Min. 2–Max. 4
Total of indoor units				kW	Max. 12.5

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.

Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
Cooling		27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating		20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 40m connecting piping.

(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284A

Adapted to RoHS directive

Item				Model	SCM80ZM-S
Cooling capacity (1)				W	8000 (1800 (Min.)–9200 (Max.))
Heating capacity (1)				W	9300 (1500 (Min.)–9800 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling	kW	2.16 (0.48–2.83)	
		Heating		2.26 (0.60–3.43)	
	Running current	Cooling	A	9.9 / 9.4 / 9.0 (220 / 230 / 240 V)	
		Heating		10.4 / 10.0 / 9.5 (220 / 230 / 240 V)	
	Inrush current				10.4 / 10.0 / 9.5 (220 / 230 / 240 V)
	Max current (5)				20
	COP	Cooling		3.70	
		Heating		4.12	
	Noise level	Cooling	Sound level	dB(A)	54
			Power level	dB	66
		Heating	Sound level	dB(A)	54
			Power level	dB	66
Exterior dimensions (Height x Width x Depth)				mm	750 x 880 x 340
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	62
Refrigerant equipment	Compressor type & Q'ty				RM-T5118MDE2 (Twin rotary type) x 1
	Motor (Starting method)			kW	1.4 (Line starting)
	Refrigerant oil			ℓ	0.675 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 3.15 (Pre-Charged up to the piping length of 40m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
	Device control				Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	86
	Air flow	Cooling	m³/min	56.0	
		Heating		56.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") x 4 Gas line: ϕ 9.52 ( 3/8") x 4
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 70
	Vertical height difference between outdoor unit and indoor unit				Max. 20 (Outdoor unit is higher) Max. 20 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	25
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Union : ( ϕ 9.52→ ϕ 12.7) x 2, Installation sheet, Elbow, Grommet x 2
Indoor unit to be combined					SRK20,25,35,50,60ZMX-S SRK20,25,35,50ZM-S SRF25,35,50ZMX-S SRR25,35,50,60ZM-S FDTC25,35,50,60VF FDEN50VF,FDUM50VF
Number of connectable indoor units					Min. 2–Max. 4
Total of indoor units				kW	Max. 13.5

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.


Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
Cooling		27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating		20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 40m connecting piping.  
(Purging is not required even for the short piping.)

(5) Current value at maximum number of indoor units connected.

RWC000Z284 

Adapted to RoHS directive

Item				Model	SCM100ZM-S
Cooling capacity (1)				W	10000 (1800 (Min.)–12000 (Max.))
Heating capacity (1)				W	12000 (1500 (Min.)–13500 (Max.))
Power source					1 Phase, 220–240 V, 50Hz
Operation data (1)	Power consumption	Cooling		kW	2.86 (0.65–4.03)
		Heating			2.93 (0.70–3.40)
	Running current	Cooling		A	13.0 / 12.4 / 11.9 (220 / 230 / 240 V)
		Heating			13.3 / 12.8 / 12.2 (220 / 230 / 240 V)
	Inrush current				13.3 / 12.8 / 12.2 (220 / 230 / 240 V)
	Max current (6)				28
	COP		Cooling		3.50
			Heating		4.10
	Noise level	Cooling	Sound level	dB (A)	56
			Power level	dB	68
		Heating	Sound level	dB (A)	59
			Power level	dB	71
Exterior dimensions (Height x Width x Depth)				mm	945 x 970 x 370
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent
Net weight				kg	92
Refrigerant equipment	Compressor type & Q'ty				RM-T5126MDE21 (Twin rotary type) x 1
	Motor (Starting method)			kW	4.0 (Line starting)
	Refrigerant oil			ℓ	1.0 (DIAMOND FREEZE MA68)
	Refrigerant (4)			kg	R410A 6.00 (Pre-Charged up to the piping length of 50m)
	Heat exchanger				M fins & inner grooved tubing
	Refrigerant control				Capillary tubes + Electronic expansion valve
	Device control				Microcomputer control
Air handling equipment	Fan type & Q'ty				Propeller fan x 1
	Motor			W	86
	Air flow	Cooling	m³/min	75.0	
		Heating		75.0	
Shock & vibration absorber					Cushion rubber (for compressor)
Electric heater					Crank case heater (220V 20W)
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 5 Gas line: ϕ 9.52 (3/8") × 5
	Connecting method				Flare connecting
	Insulation for piping				Necessary (Both sides), independent
	Length for one indoor unit			m	Max. 25
	Total length for all rooms				Max. 90
	Vertical height difference between outdoor unit and indoor unit				Max. 20 (Outdoor unit is higher) Max. 20 (Outdoor unit is lower)
	Height difference of the indoor units				Max. 25
Recommended breaker size				A	30
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)
	Connecting method				Terminal block (Screw fixing type)
IP number					IPX4
Accessories (included)					Union, Installation sheet, Elbow, Grommet × 2
Indoor unit to be combined					SRK20,25,35,50,60ZMX-S,SRK20,25,35,50ZM-S,71ZR-S SRF25,35,50ZMX-S SRR25,35,50,60ZM-S FDTC25,35,50,60VF FDEN50VF,FDUM50VF
Number of connectable indoor units					Min. 2–Max. 5 (5)
Total of indoor units				kW	Max. 16.0

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.

Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating	20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 50m connecting piping.

(Purging is not required even for the short piping.)

(5) Minimum number of connectable indoor units is vary from the kind of connected indoor unit.  
Check combination sheet.

(6) Current value at maximum number of indoor units connected.

RWC000Z284A

Adapted to RoHS directive

Item				Model	SCM125ZM-S	
Cooling capacity (1)				W	12500 (1800 (Min.)–14000 (Max.))	
Heating capacity (1)				W	13500 (1500 (Min.)–14000 (Max.))	
Power source					1 Phase, 220–240 V, 50Hz	
Operation data (1)	Power consumption	Cooling		kW	3.90 (0.65–4.80)	
		Heating			3.25 (0.70–3.42)	
	Running current	Cooling		A	17.7 / 17.0 / 16.3 (220 / 230 / 240 V)	
		Heating			14.8 / 14.1 / 13.6 (220 / 230 / 240 V)	
	Inrush current				17.7 / 17.0 / 16.3 (220 / 230 / 240 V)	
	Max current (6)				29	
	COP		Cooling		3.21	
			Heating		4.15	
	Noise level	Cooling	Sound level		dB (A)	57
			Power level		dB	69
		Heating	Sound level		dB (A)	60
			Power level		dB	72
Exterior dimensions (Height x Width x Depth)				mm	945 x 970 x 370	
Exterior appearance (Munsell color)					Stucco white (4.2Y 7.5/1.1) near equivalent	
Net weight				kg	92	
Refrigerant equipment	Compressor type & Q'ty				RM-T5126MDE21 (Twin rotary type) x 1	
	Motor (Starting method)			kW	4.0 (Line starting)	
	Refrigerant oil			ℓ	1.0 (DIAMOND FREEZE MA68)	
	Refrigerant (4)			kg	R410A 6.00 (Pre-Charged up to the piping length of 50m)	
	Heat exchanger				M fins & inner grooved tubing	
	Refrigerant control				Capillary tubes + Electronic expansion valve	
	Device control				Microcomputer control	
Air handling equipment	Fan type & Q'ty				Propeller fan x 1	
	Motor			W	86	
	Air flow	Cooling		m³/min	75.0	
		Heating			82.0	
Shock & vibration absorber					Cushion rubber (for compressor)	
Electric heater					Crank case heater (220V 20W)	
Safety devices					Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Outdoor fan motor error protection, Heating & Cooling overload protection	
Installation data	Refrigerant piping size (O.D)			mm	Liquid line: ϕ 6.35 (1/4") × 6 Gas line: ϕ 9.52 (3/8") × 6	
	Connecting method				Flare connecting	
	Insulation for piping				Necessary (Both sides), independent	
	Length for one indoor unit			m	Max. 25	
	Total length for all rooms				Max. 90	
	Vertical height difference between outdoor unit and indoor unit				Max. 20 (Outdoor unit is higher) Max. 20 (Outdoor unit is lower)	
	Height difference of the indoor units				Max. 25	
Recommended breaker size				A	30	
Connection wiring	Size x Core number				1.5mm² x 4 cores (Including earth cable)	
	Connecting method				Terminal block (Screw fixing type)	
IP number					IPX4	
Accessories (included)					Union, Installation sheet, Elbow, Grommet x 2	
Indoor unit to be combined					SRK20,25,35,50,60ZMX-S,SRK20,25,35,50ZM-S,71ZR-S SRF25,35,50ZMX-S SRR25,35,50,60ZM-S FDTC25,35,50,60VF FDEN50VF,FDUM50VF	
Number of connectable indoor units					Min. 2–Max. 6 (5)	
Total of indoor units				kW	Max. 19.5	

Note (1) The data are measured at the following conditions.

The pipe length for one indoor unit is 7.5m.

Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS C 9612
Heating	20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.


(3) The operation data are applied to the 220/230/240V districts respectively.

(4) The refrigerant quantity to be charged includes the refrigerant in 50m connecting piping.

(Purging is not required even for the short piping.)




(5) Minimum number of connectable indoor units is vary from the kind of connected indoor unit.  
Check combination sheet.

(6) Current value at maximum number of indoor units connected.

RWC000Z284 


RWC000Z280

Symbol	Content	
A	Service valve connection (gas side)	φ 9.52 (3 / 8") (Flare)
B	Service valve connection (liquid side)	φ 6.35 (1 / 4") (Flare)
C	Pipe / cable draw-out hole	
D	Drain discharge hole	φ 20 x 3 places
E	Anchor bolt hole	M10 x 4 places



#### Note

- (1) It must not be surrounded by walls on four sides.
- (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subjected to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1.2m or more space above the unit.
- (5) A wall in front of the blower outlet must not exceed the unit's height.
- (6) The model name label is attached on the service panel.



Minimum installation space

Dimensions	Examples of Installation	I
L1		600
L2		100
L3		100




Unit:mm

## 1.2 Exterior dimensions

Models SCM40ZM-S, 45ZM-S


RWC000Z281

Symbol	Content
A	Service valve connection (gas side) $\phi 9.52 (3/8")$ (Flare)
B	Service valve connection (liquid side) $\phi 6.35 (1/4")$ (Flare)
C	Pipe / cable draw-out hole
D	Drain discharge hole $\phi 20 \times 3$ places
E	Anchor bolt hole M10 x 4 places



#### Note

- (1) It must not be surrounded by walls on four sides.
- (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subjected to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1.2m or more space above the unit.
- (5) A wall in front of the blower outlet must not exceed the unit's height.
- (6) The model name label is attached on the service panel.



Minimum installation space

Dimensions	Examples of Installation	I
L1		600
L2		100
L3		100

Unit:mm

Models SCM50ZM-S, 60ZM-S







Diagram illustrating a closed-loop recirculation system with no obstacles (Service space for electrical parts). The system includes an Intake (L2), Intake (L3), and Outlet (L1) ports. The flow is indicated by arrows: Intake (L2) → Intake (L3) → Outlet (L1) → Intake (L2). The text "No obstacles (Service space for electrical parts)" is present.

Examples of Installation	I
L1	600
L2	100
L3	100

## Models SCM71ZM-S, 80ZM-S



- (1) It must not be surrounded by walls on the four sides.
- (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1m or more space above the unit.
- (5) A wall in front of the blower outlet must not exceed the units height.
- (6) The model name label is attached on the rear panel.




### Minimum installation space

Examples of installation Dimensions	I	II	III
L1	Open	Open	500
L2	300	5	Open
L3	150	300	150

Unit:mm



RWC00002279



Symbol	Content
A	Service valve connection (gas side) $\phi 9.52 (3/8")$ (Flare)
B	Service valve connection (liquid side) $\phi 6.35 (1/4")$ (Flare)
C	Pipe/cable draw-out hole
D	Drain discharge hole $\phi 20 \times 3$ places
E	Anchor bolt hole M10 $\times 4$ places

#### Notes

- (1) It must not be surrounded by walls on the four sides.
- (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1m or more space above the unit.
- (5) A wall in front of the blower outlet must not exceed the units height.
- (6) The model name label is attached on the rear panel.




Examples of installation Dimensions	I	II	III
L1	Open	Open	500
L2	300	5	Open
L3	150	300	150

Unit:mm

Model SCM125ZM-S

## 1.3 Electrical wiring

Models SCM40ZM-S, 45ZM-S




Indication lamp	Color	Function
LED e (1)	Red	Warning lamp
Self diagnosis function by led e		
1-Time flash		Current cut
2-Time flash		Trouble of outdoor unit
3-Time flash		Over current
4-Time flash		Transmission error
5-Time flash		Over heat of compressor
6-Time flash		Error of signal transmission
7-Time flash		Lock of compressor
8-Time flash		Sensor error (Except discharge pipe sensor)
Light on		Outdoor fan motor error
Four sec light and four sec off		Discharge pipe sensor error
Caution • When the compressor does not run immediately after hitting on the button, wait for 5 to 10 minutes. (There is possibility of delayed start.)  • High voltage is produced in the control box. don't touch electrical parts in the control box for 5 minutes after cutting power source.		

Color Marks

Mark	Color	Mark	Color
BK	Black	YE	Yellow
RD	Red	Y/G	Yellow/Green
WH	White		
OR	Orange		
BR	Brown		

Meaning of Marks

Item	Description	Item	Description
CNA-CN20S	Connector	R	Reactor
20S	4 Way valve (coil)	TB1-TB3	Terminal block
CM	Compressor motor	Tho-R	Heat exchanger sensor (outdoor unit)
EEV A, EEV B	Electric expansion valve (coil)	Tho-A	Outdoor air temp. sensor
FMO	Fan motor	Tho-D	Discharge pipe temp. sensor
HEATER	Crank case heater	Tho-S	Suction pipe temp. sensor



Indication lamp	Color	Function
LED e (1)	Red	Warning lamp
Self diagnosis function by led e		
1-Time flash		Current cut
2-Time flash		Trouble of outdoor unit
3-Time flash		Over current
4-Time flash		Transmission error
5-Time flash		Over heat of compressor
6-Time flash		Error of signal transmission
7-Time flash		Lock of compressor
8-Time flash		Sensor error (Except discharge pipe sensor)
Light on		Outdoor fan motor error
Four sec light and four sec off		Discharge pipe sensor error
Caution • When the compressor does not run immediately after hitting on the button, wait for 5 to 10 minutes. (There is possibility of delayed start.)		
• High voltage is produced in the control box. don't touch electrical parts in the control box for 5 minutes after cutting power source.		


#### Color Marks

Mark	Color	Mark	Color
BK	Black	BR	Brown
BL	Blue	YE	Yellow
RD	Red	Y/G	Yellow/Green
WH	White		
OR	Orange		

#### Meaning of Marks

Item	Description	Item	Description
CNA-CN20S	Connector	R	Reactor
20S	4 Way valve (coil)	TB1,TB2	Terminal block
CM	Compressor motor	Tho-R	Heat exchanger sensor (outdoor unit)
EEV A,EEV B	Electric expansion valve (coil)	Tho-A	Outdoor air temp. sensor
EEV C		Tho-D	Discharge pipe temp. sensor
FMO	Fan motor	Tho-S	Suction pipe temp. sensor
HEATER	Crank case heater		

Models SCM50ZM-S, 60ZM-S




Indication lamp	Color	Function
LED e (1)	Red	Warning lamp
Self diagnosis function by led e		
1-Time flash		Current cut
2-Time flash		Trouble of outdoor unit
3-Time flash		Over current
4-Time flash		Transmission error
5-Time flash		Over heat of compressor
6-Time flash		Error of signal transmission
7-Time flash		Lock of compressor
8-Time flash		Sensor error (Except discharge pipe sensor)
Light on		Outdoor fan motor error
Four sec light and four sec off		Discharge pipe sensor error
Caution • When the compressor does not run Immediately after hitting on the button,wait for 5 to 10 minutes. (There is possibility of delayed start.)		
• High voltage is produced in the control box. don't touch electrical parts in the control box for 5 minutes after cutting power source.		

Color Marks

Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
BR	Brown	YE	Yellow
GN	Green	Y/G	Yellow/Green
OR	Orange		

Meaning of Marks

Item	Description	Item	Description
CNA-CN20S	Connector	R	Reactor
20S	4 Way valve (coil)	TB1-5	Terminal block
CM	Compressor motor	Tho-R	Heat exchanger sensor (outdoor unit)
EEV A,EEV B	Electric expansion valve (coil)	Tho-A	Outdoor air temp. sensor
EEV C,EEV D		Tho-D	Discharge pipe temp. sensor
FMO	Fan motor	Tho-S	Suction pipe temp. sensor
HEATER	Crank case heater		




Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
PK	Pink
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green

- Ⓒ Before you turn on power, please carefully read the installation manual and the operation manual supplied with the unit.
- Ⓒ Please check the following points before operation.
- ① This unit is designed exclusively for use with R410A. Do not use any refrigerant other than R410A.
- ② To protect the compressor, turn on power for the air-conditioner 6 hours before operation so as warm up sufficiently the dome temperature of compressor.
- ③ Open the service valves of liquid pipe at first. Secondly open the one of gas pipe. Before you operate the unit, make sure again that the service valves are in open position.
- ④ Please note that the pressure valves detected at the charge port in the unit and the gas service valves are different during the cooling operation and the heating operation. High pressure is replaced with the low pressure depending on whether it is in the cooling or heating operation.

INDICATION LAMP	COLOR	FUNCTION
LED E (1)	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1-TIME FLASH	CURRENT CUT	
2-TIME FLASH	TROUBLE OF OUTDOOR UNIT	
3-TIME FLASH	OVER CURRENT	
4-TIME FLASH	TRANSMISSION ERROR	
5-TIME FLASH	OVER HEAT OF COMPRESSOR	
6-TIME FLASH	ERROR OF SIGNAL TRANSMISSION	
8-TIME FLASH	SENSOR ERROR (EXCEPT DISCHARGE PIPE SENSOR)	
LIGHT ON	OUTDOOR FAN MOTOR ERROR	
FOUR SEC LIGHT AND FOUR SEC OFF	DISCHARGE PIPE SENSOR ERROR	

Note(1) ※used only at our factory.



1. Instructions for correct operation

- Before you turn on power, please carefully read the installation manual and the operation manual supplied with the unit.
- Please check the following points before operation.
  - This unit is designed exclusively for use with R410A. Do not use any refrigerant other than R410A.
  - To protect the compressor, turn on power for the air-conditioner 6 hours before operation so as warm up sufficiently the dome temperature of compressor.
- Open the service valves of liquid pipe at first. Secondarily open the one of gas pipe. Before you operate the unit, make sure again that the service valves are in open position.
- Please note that the pressure valves detected at the charge port in the unit and the gas service valves are different during the cooling operation and the heating operation. High pressure is replaced with the low pressure depending on whether it is in the cooling or heating operation.

2. Error indication

INDICATION LAMP	COLOR	FUNCTION
LED E (1)	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1-TIME FLASH		CURRENT CUT
2-TIME FLASH		TROUBLE OF OUTDOOR UNIT
3-TIME FLASH		OVER CURRENT
4-TIME FLASH		TRANSMISSION ERROR
5-TIME FLASH		OVER HEAT OF COMPRESSOR
6-TIME FLASH		ERROR OF SIGNAL TRANSMISSION
8-TIME FLASH		SENSOR ERROR (EXCEPT DISCHARGE PIPE SENSOR)
LIGHT ON		OUTDOOR FAN MOTOR ERROR
FOUR SEC LIGHT AND FOUR SEC OFF		DISCHARGE PIPE SENSOR ERROR

Note(1) ※used only at our factory.

Mark	Name
AF/MODULE	Active filter module
CH	Crankcase heater
CM	Compressor motor
CNA-Z	Connector
CT	Current sensor
DS	Diode stack
EEV	Electronic expansion coil
EEV-H	Electronic expansion coil (For heating)
F	Fuse
FM	Fan motor
HPS	High pressure sensor
IPM	Intelligent power module
L	Reactor
LED1	Indicator lamp (Red-Inspection indicator)
LED2	Indicator lamp (Green-Microcomputer normally indicator)
LED3	Indicator lamp (Green-For service)
TB	Terminal block
Tho-A	Thermistor (outdoor air temperature)
Tho-D	Thermistor (discharge pipe)
Tho-R	Thermistor (heat exchanger)
Tho-S	Thermistor (suction pipe)
Tho-AF	Thermistor (power transistor)
TR	Trance former
20S	4-way valve coil

Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
PK	Pink
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green


## 1.4 Noise level

- Mike position: at highest noise level in position as mentioned below  
Distance from front side 1m.

**Model SCM40ZM-S**

Noise Level	Cooling	47 dB(A)
	Heating	48 dB(A)


Condition	ISO-T1,JIS C 9612
-----------	-------------------



**Model SCM45ZM-S**

Noise Level	Cooling	47 dB(A)
	Heating	49 dB(A)


Condition	ISO-T1,JIS C 9612
-----------	-------------------



**Model SCM50ZM-S**

Noise Level	Cooling	49 dB(A)
	Heating	52 dB(A)


Condition	ISO-T1, JIS C 9612
-----------	--------------------



**Model SCM60ZM-S**

Noise Level	Cooling	50 dB(A)
	Heating	52 dB(A)


Condition	ISO-T1, JIS C 9612
-----------	--------------------



**Model SCM71ZM-S**

Noise	Cooling	52 dB(A)
Level	Heating	54 dB(A)


Condition	ISO-T1,JIS C 9612
-----------	-------------------



**Model SCM80ZM-S**

Noise	Cooling	54 dB(A)
Level	Heating	54 dB(A)


Condition	ISO-T1,JIS C 9612
-----------	-------------------



**Model SCM100ZM-S**

Noise	Cooling	56 dB(A)
Level	Heating	59 dB(A)


Condition	ISO-T1,JIS C 9612
-----------	-------------------



**Model SCM125ZM-S**

Noise	Cooling	57 dB(A)
Level	Heating	60 dB(A)

Condition	ISO-T1,JIS C 9612
-----------	-------------------



# 1.5 Application data

## (1) Models SCM40ZM-S, 45ZM-S

RPC012A915B

MULTI TYPE AIR-CONDITIONER  
R410A REFRIGERANT USED

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 107.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚡ CAUTION**.
  - ⚠ WARNING**: Wrong installation would cause serious consequences such as injuries or death.
  - ⚡ CAUTION**: Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:



Never do it under any circumstances.



Always do it according to the instruction.

## ⚠ WARNING

- |   |   |   |
|---|---|---|
| <p><b>⚠</b></p> <ul style="list-style-type: none"> <li>• <b>Installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li> <li>• <b>Install the system in full accordance with the installation manual.</b><br/>Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>• <b>Be sure to use only for household and residence.</b><br/>If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b><br/>If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</li> <li>• <b>Use the original accessories and the specified components for installation.</b><br/>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>• <b>Install the unit in a location with good support.</b><br/>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>• <b>Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.</b><br/>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b><br/>If the refrigerant comes into contact with naked flames, poisonous gas is produced.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b><br/>Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li> <li>• <b>Tighten the flare nut by torque wrench with specified method.</b><br/>If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li> <li>• <b>Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.</b><br/>If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant.</li> <li>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b><br/>Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</li> <li>• <b>Be sure to shut off the power before starting electrical work.</b><br/>Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</li> <li>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b><br/>Unconformable cables can cause electric leak, anomalous heat production or fire.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:25A) with a contact separation of at least 3mm.</b></li> <li>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b><br/>Incorrect installation may result in overheating and fire.</li> <li>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b><br/>Loose connections or cable mountings can cause anomalous heat production or fire.</li> <li>• <b>Be sure to fix up the service panels.</b><br/>Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.</li> <li>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b><br/>If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li> <li>• <b>Stop the compressor before removing the pipe after shutting the service valve on pump down work.</b><br/>If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.</li> <li>• <b>Only use prescribed option parts. The installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.</li> <li>• <b>Be sure to wear protective goggles and gloves while at work.</b></li> <li>• <b>Earth leakage breaker must be installed.</b><br/>If the earth leakage breaker is not installed, it can cause electric shocks.</li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b><br/>If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li> <li>• <b>Do not processing, splice the power cord, or share a socket with other power plugs.</b><br/>This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li> </ul>   | <ul style="list-style-type: none"> <li>• <b>Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.</b><br/>This may cause fire or heating.</li> <li>• <b>Do not run the unit with removed panels or protections.</b><br/>Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li> </ul>   | <ul style="list-style-type: none"> <li>• <b>Do not perform any change of protective device itself or its setup condition.</b><br/>The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</li> </ul>  |

## ⚡ CAUTION

- |  |   |  |
|--|---|--|
| <p><b>⚡</b></p> <ul style="list-style-type: none"> <li>• <b>Carry out the electrical work for ground lead with care.</b><br/>Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</li> </ul>  | <ul style="list-style-type: none"> <li>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b><br/>Using the incorrect one could cause the system failure and fire.</li> <li>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b><br/>The isolator should be locked in OFF state in accordance with EN60204-1.</li> <li>• <b>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></li> <li>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b></li> </ul> | <ul style="list-style-type: none"> <li>• <b>When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Do not install the unit in the locations listed below.</b> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> </ul>   | <ul style="list-style-type: none"> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p>  |

## ⚠ CAUTION



### Do not install the outdoor unit in the locations listed below.

- Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.
- Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.
- Locations where vibration can be amplified and transmitted due to insufficient strength of structure.
- Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).
- Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
- Locations where drainage cannot run off safely.
- Locations where drainage can affect surrounding environment and cause a claim.

### Do not install the unit near the location where leakage of combustible gases can occur.

If leaked gases accumulate around the unit, it can cause fire.

### Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are

handled.

Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.

### Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.

Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.

### Do not install the outdoor unit in a location where insects and small animals can inhabit.

Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.

### Do not use the base flange for outdoor unit which is corroded or damaged due to long periods of operation.

Using an old and damaged base flange can cause the unit falling down and cause personal injury.

### Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.

Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.

### Do not touch any buttons with wet hands.

It can cause electric shocks.

### Do not touch any refrigerant pipes with your hands when the system is in operation.

During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.

### Do not touch the suction or aluminum fin on the outdoor unit.

This may cause injury.

### Do not put anything on the outdoor unit and operating unit.

This may cause damage the objects or injury due to falling to the object.

### Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.

### Do not clean up the unit with water.

## Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

Accessories for outdoor unit	Q'ty
① Grommet (Heat pump type only)	1
② Drain elbow (Heat pump type only)	1

Option parts	Q'ty
Ⓐ Sealing plate	1
Ⓑ Sleeve	1
Ⓒ Inclination plate	1
Ⓓ Putty	1
Ⓔ Drain hose (extension hose)	1
① Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
9 Wrench key (Hexagon) [4m/m]	
10 Vacuum pump	
11 Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)	
12 Gauge manifold (Designed specifically for R410A)	
13 Charge hose (Designed specifically for R410A)	
14 Flaring tool set (Designed specifically for R410A)	
15 Gas leak detector (Designed specifically for R410A)	
16 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	
1 Plus headed driver	
2 Knife	
3 Saw	
4 Tape measure	
5 Hammer	
6 Spanner wrench	
7 Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)]	
8 Hole core drill (65mm in diameter)	

## 1 SELECTION OF INSTALLATION LOCATION

### Install at location that meets the following conditions after getting approval from the customer.

Be careful of the following conditions and choose an installation place.

- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is not applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- A place where no TV set or radio receiver is placed within 1m.
- (If electrical interference is caused, seek a place less likely to cause the problem)
- If a operation is conducted when the outdoor air temperature is  $-5^{\circ}\text{C}$  lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- Where it is likely that the unit is subjected to strong winds, provide wind guards according to the following guidelines. Strong winds can cause performance degradation, an accidental stop due to a rise of high pressure and a broken fan.


Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

### ① Installation Space (on a flat surface)

⊙ Blowing out port and suction port on the back side of the unit can be installed at a distance of 10cm from walls.


(In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.)

○ When the unit is installed, the space of the following dimension and above shall be secured.




## Installation

### ① Anchor bolt fixed position



### ② Notabilia for installation



- In installing the unit, fix the unit's legs with bolts specified on the above.
  - The protrusion of an anchor bolt on the front side must be kept within 15 mm.
  - Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
  - Refer to the above illustrations for information regarding concrete foundations.
  - Install the unit in a level area. (With a gradient of 5 mm or less.)
- Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

## 2 INSTALLATION OF OUTDOOR UNIT

### Drainage

- Execute drain piping by using a drain elbow and drain grommets, where water drained from the outdoor unit is a problem.
- There are 2 drain holes provided on the bottom plate of an outdoor unit to discharge condensed water.
- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an option part) or concrete blocks.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)

Connection of the power source cable and the connecting cables for indoor and outdoor units.

- This multi-type room air-conditioner receives its power from outside.
- To ensure correct connections, mark each ends of the cables with number, A and B. It is important to use the same number the corresponding cables and pipes.
- An earth leakage breaker and a circuit breaker must be installed. Their capacities are 25A.


- ① Remove the service panel. (Remove the screw of the service panel.)
- ② Remove the terminal cover. (Remove the screw of the terminal cover.)
- ③ Connect the power source cable and the connection wire securely to the terminal block.

[POWER SOURCE CODE]  
CENELEC code for cables requiring fields cables. H05RNR3G4.0  
[INTERCONNECTING WIRING CODE]  
CENELEC code for cables requiring fields cables. H05RNR4G1.5

- 1) In wiring, make sure that the wire terminal numbers of outdoor unit terminal block are match to the wire terminal numbers of indoor unit terminal block.
- 2) Terminal number A of the outdoor unit is used for A indoor unit and terminal number B for B indoor unit respectively.

- ④ After connecting the wire, use wiring clamps to secure the wiring.
- ⑤ Fit the terminal cover and the service panel.



- Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.



### Main fuse specification

Specification	Part No.
250V 15A	SSA564A136

The screw of the service panel is tightened securely.




## 3 CONNECTION OF REFRIGERANT PIPINGS

[Connection of pipes]

NOTE

- Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected.
- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct service valves.



- Remove the flared nuts. (on both liquid and gas sides)

- Install the removed flared nuts to the pipes to be connected, then flare the pipes.

### CAUTION


Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.

### CAUTION

Do not apply refrigerating machine oil to the flared surface.


Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool	
		Clutch type	Wing nut type
φ6.35	0.0~0.5	1.0~1.5	1.5~2.0
φ9.52	0.0~0.5	1.0~1.5	1.5~2.0

Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use. If a conventional flare tool is used, please use copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.



### Connection

Outdoor



- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side : 14.0~18.0N·m (1.4~1.8kgf·m)  
Gas side (φ9.52): 34.0~42.0N·m (3.4~4.2kgf·m)

### Gas Leakage Test

- Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.

[Limit]

piping length	one indoor unit all indoor unit	MAX 25m MAX 30m
height difference		
length of chargeless refrigerant pipe	30m	


**4 AIR PURGING**

NOTE : Fully open the service valves (on both liquid and gas sides) after completing air purging.


- Since the system uses service ports differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Remove the cap on both gas and liquid sides before starting operation.
- After completing the operation, do not forget to tighten the cap (gas may leak).

**Procedure**


- (1) Secure all flare nuts on both indoor and outdoor sides to prevent leaks from the pipes.
- (2) Connect the service valves, charge hose, manifold valve and vacuum pump as shown in the right figure.
- (3) Fully open the handle Lo for the manifold valve, and pump a vacuum for 15 minutes. Ensure that the meter is indicating -0.1MPa (-76cmHg).
- (4) After vacuuming, fully open the service valve (both liquid and gas sides) with a hexagon wrench.



- (5) Remove the charge hose from service port.
- (6) Repeat the above steps (1) ~ (5) for all connected indoor units.
- (7) Ensure that there are no gas leaks from the joints in the indoor and outdoor units.




Service valve for room B  
Service valve for room A




Securely tighten the service valve cap and the check joint blind nut after adjustment.

Service valve size (mm)	Service valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)
φ 6.35 (1/4")	20~30	10~12
φ 9.52 (3/8")		

**5 HEAT INSULATION FOR JOINTS****Heat insulation for joints**

Cover the joint with insulation material for the indoor unit and tape it.

**Finish and fixing**



Apply exterior tape and shape along the place where the pipes will be routed. Secure to the wall with a pipe clamp. Be careful not to damage the pipes and the wires.

**7 BEWARE OF WRONG CONNECTIONS IN REFRIGERANT PIPING AND WIRING**

- Make sure to match the piping and wiring from each unit to the outdoor unit.
- Be careful because if connections are wrong, normal operation cannot be achieved and may damage the compressor.

**[Correct connections]****[Example of wrong connections]**

—— Piping  
----- Wiring

**EARTHING WORK**

- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

**6 TEST RUN AND HANDLING INSTRUCTIONS****Installation test check points**

Check the following points again after completion of the installation, and before turning on the power.

Conduct a test run again and ensure that the unit operates properly.

At the same time, explain to the customer how to use the unit and how to take care of the unit following the installation manual.

If the compressor does not operate after the operation has started, wait for 5-10 minutes. (This may be due to delayed start.)

(Three-minutes restart preventive timer)

When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3minutes. This is to protect the unit and it is not a malfunction.

**After installation**

- ☐ The power source voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.
- ☐ Each indoor and outdoor unit is properly connected (no wrong wiring or piping).
- ☐ Service valve is fully open.
- ☐ Refrigerant has been additionally charged (when the total pipe length exceeds the refrigerant charged pipe length).
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.
- ☐ Earthing work has been conducted properly.
- ☐ The screw of the service panel is tightened securely.

**Test run**

- ☐ Air-conditioning and heating are normal.
- ☐ No abnormal noise.
- ☐ Water drains smoothly.
- ☐ Protective functions are not working.
- ☐ Operation of the unit has been explained to the customer.
- ☐ The remote control is normal.

**Operation of indicator lamps**

INDICATION LAMP	COLOR	FUNCTION
LED E (1)	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1 TIME FLASH	CURRENT CUT	
2 TIME FLASH	TROUBLE OF OUTDOOR UNIT	
3 TIME FLASH	OVER CURRENT	
4 TIME FLASH	TRANSMISSION ERROR IN OUTDOOR UNIT PCB	
5 TIME FLASH	OVER HEAT OF COMPRESSOR	
6 TIME FLASH	ERROR OF SIGNAL TRANSMISSION	
7 TIME FLASH	LOCK OF COMPRESSOR	
8 TIME FLASH	SENSOR ERROR	
LIGHT ON	OUTDOOR FAN MOTOR ERROR	
4 SEC LIGHT AND 4 SEC OFF	DISCHARGE PIPE SENSOR COMING OFF	

## (2) Models SCM50ZM-S, 60ZM-S

RPC012A916D

MULTI TYPE AIR-CONDITIONER  
R410A REFRIGERANT USED



- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 107.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS




- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚠ CAUTION**.
  - ⚠ WARNING**: Wrong installation would cause serious consequences such as injuries or death.
  - ⚠ CAUTION**: Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:

	Never do it under any circumstances.		Always do it according to the instruction.
---	--------------------------------------	---	--

## ⚠ WARNING

	<p><b>• Installation must be carried out by the qualified installer.</b> If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</p> <p><b>• Install the system in full accordance with the installation manual.</b> Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</p> <p><b>• Be sure to use only for household and residence.</b> If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</p> <p><b>• When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b> If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</p> <p><b>• Use the original accessories and the specified components for installation.</b> If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</p> <p><b>• Install the unit in a location with good support.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</p> <p><b>• Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</p> <p><b>• Ventilate the working area well in the event of refrigerant leakage during installation.</b> If the refrigerant comes into contact with naked flames, poisonous gas is produced.</p>	<p><b>• Use the prescribed pipes, flare nuts and tools for R410A.</b> Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</p> <p><b>• Tighten the flare nut by torque wrench with specified method.</b> If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</p> <p><b>• Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.</b> If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant.</p> <p><b>• The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b> Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</p> <p><b>• Be sure to shut off the power before starting electrical work.</b> Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</p> <p><b>• Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b> Unconformable cables can cause electric leak, anomalous heat production or fire.</p>	<p><b>• This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:25A) with a contact separation of at least 3mm.</b></p> <p><b>• Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b> Incorrect installation may result in overheating and fire.</p> <p><b>• Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b> Loose connections or cable mountings can cause anomalous heat production or fire.</p> <p><b>• Be sure to fix up the service panels.</b> Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.</p> <p><b>• Be sure to switch off the power source in the event of installation, inspection or servicing.</b> If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</p> <p><b>• Stop the compressor before removing the pipe after shutting the service valve on pump down work.</b> If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.</p> <p><b>• Only use prescribed option parts. The installation must be carried out by the qualified installer.</b> If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.</p> <p><b>• Be sure to wear protective goggles and gloves while at work.</b></p> <p><b>• Earth leakage breaker must be installed.</b> If the earth leakage breaker is not installed, it can cause electric shocks.</p>
	<p><b>• Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b> If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</p> <p><b>• Do not processing, splice the power cord, or share a socket with other power plugs.</b> This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</p>	<p><b>• Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.</b> This may cause fire or heating.</p> <p><b>• Do not run the unit with removed panels or protections.</b> Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</p>	<p><b>• Do not perform any change of protective device itself or its setup condition.</b> The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</p>

## ⚠ CAUTION

	<p><b>• Carry out the electrical work for ground lead with care.</b> Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</p>		
	<p><b>• Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b> Using the incorrect one could cause the system failure and fire.</p> <p><b>• Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b> The isolator should be locked in OFF state in accordance with EN60204-1.</p> <p><b>• After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></p> <p><b>• Secure a space for installation, inspection and maintenance specified in the manual.</b></p>	<p>Insufficient space can result in accident such as personal injury due to falling from the installation place.</p> <p><b>• Take care when carrying the unit by hand.</b> If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.</p> <p><b>• Dispose of any packing materials correctly.</b> Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.</p> <p><b>• Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.</b> Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.</p>	<p><b>• When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></p>
	<p><b>• Do not install the unit in the locations listed below.</b></p> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> </ul>	<ul style="list-style-type: none"> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> </ul>	<ul style="list-style-type: none"> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p>

**CAUTION**

- **Do not install the outdoor unit in the locations listed below.**
  - Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.
  - Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.
  - Locations where vibration can be amplified and transmitted due to insufficient strength of structure.
  - Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).
  - Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
  - Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim.
- **Do not install the unit near the location where leakage of combustible gases can occur.**  
If leaked gases accumulate around the unit, it can cause fire.
- **Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are**

**handled.**

- Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.
- **Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.**  
Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
- **Do not install the outdoor unit in a location where insects and small animals can inhabit.**  
Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.
- **Do not use the base frame for outdoor unit which is corroded or damaged due to long periods of operation.**  
Using an old and damage base frame can cause the unit falling down and cause personal injury.

- **Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.**

Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.

- **Do not touch any buttons with wet hands.**  
It can cause electric shocks.
- **Do not touch any refrigerant pipes with your hands when the system is in operation.**  
During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.
- **Do not touch the suction or aluminum fin on the outdoor unit.**  
This may cause injury.
- **Do not put anything on the outdoor unit and operating unit.**  
This may cause damage the objects or injury due to falling to the object.
- **Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.**
- **Do not clean up the unit with water.**

**Check before installation work**

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

Accessories for outdoor unit	Q'ty
① Grommet (Heat pump type only)	1
② Drain elbow (Heat pump type only)	1
③ Variable diameter joint	SCM50 1 SCM60 2

Note: Provide flare nuts when using the variable diameter joint (for  $\phi 12.7$ ).

Option parts	Q'ty
④ Sealing plate	1
⑤ Sleeve	1
⑥ Inclination plate	1
⑦ Putty	1
⑧ Drain hose (extension hose)	1
⑨ Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
9 Wrench key (Hexagon) [4m/m]	
10 Vacuum pump	
11 Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)	
12 Gauge manifold (Designed specifically for R410A)	
13 Charge hose (Designed specifically for R410A)	
14 Flaring tool set (Designed specifically for R410A)	
15 Gas leak detector (Designed specifically for R410A)	
16 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	

**CAUTION** • This model requires a minimum of 2 indoor units.**1 SELECTION OF INSTALLATION LOCATION****Install at location that meets the following conditions after getting approval from the customer.**

Be careful of the following conditions and choose an installation place.

- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is not applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- A place where no TV set or radio receiver is placed within 1m.
- (If electrical interference is caused, seek a place less likely to cause the problem)
- If a operation is conducted when the outdoor air temperature is  $-5^{\circ}\text{C}$  lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- Where it is likely that the unit is subjected to strong winds, provide wind guards according to the following guidelines. Strong winds can cause performance degradation, an accidental stop due to a rise of high pressure and a broken fan.




Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

**① Installation Space (on a flat surface)**

- Blowing out port and suction port on the back side of the unit can be installed at a distance of 10cm from walls.

(In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.)

- When the unit is installed, the space of the following dimension and above shall be secured.

**Installation****① Anchor bolt fixed position****② Notabilia for installation**

- In installing the unit, fix the unit's legs with bolts specified on the above.
  - The protrusion of an anchor bolt on the front side must be kept within 15 mm.
  - Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
  - Refer to the above illustrations for information regarding concrete foundations.
  - Install the unit in a level area. (With a gradient of 5 mm or less.)
- Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

## 2 INSTALLATION OF OUTDOOR UNIT

### Drainage

- Execute drain piping by using a drain elbow and drain grommets, where water drained from the outdoor unit is a problem.
- There are 2 drain holes provided on the bottom plate of an outdoor unit to discharge condensed water.
- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an option part) or concrete blocks.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)

Connection of the power source cable and the connecting cables for indoor and outdoor units.


- This multi-type room air-conditioner receives its power from outside.
- To ensure correct connections, mark each ends of the cables with number, A to C. It is important to use the same number the corresponding cables and pipes.
- An earth leakage breaker and a circuit breaker must be installed. Their capacities are 25A.

- ① Remove the service panel. (Remove the screw of the service panel.)
- ② Remove the terminal cover. (Remove the screw of the terminal cover.)
- ③ Connect the power source cable and the connection wire securely to the terminal block.

[POWER SOURCE CODE]  
CENELEC code for cables requiring fields cables. H05RNR3G4.0  
[INTERCONNECTING WIRING CODE]  
CENELEC code for cables requiring fields cables. H05RNR4G1.5

- 1) In wiring, make sure that the wire terminal numbers of outdoor unit terminal block are match to the wire terminal numbers of indoor unit terminal block.
- 2) Terminal number A of the outdoor unit is used for A indoor unit and terminal number B for B indoor unit respectively.
- ④ After connecting the wire, use wiring clamps to secure the wiring.
- ⑤ Fit the terminal cover and the service panel.



- Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.



Main fuse specification

	Specification	Part No.
SCM50	250V 15A	SSA564A136
SCM60	250V 20A	SSA564A136A

The screw of the service panel is tightened securely.




## 3 CONNECTION OF REFRIGERANT PIPINGS

- Regarding the change in the sizes of gas side pipes (usage of the variable joints); If a 5.0, 6.0 kw class indoor unit (gas side pipe 12.7) is going to be connected to the service valves (9.52), variable joints available as accessories must be applied to the gas side service valves.
- Securely fit the copper packing between the service valve and the variable diameter joint to prevent shifting.

[Connection of pipes]

NOTE

- Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected.
- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct service valves.



○ Remove the flared nuts. (on both liquid and gas sides)

○ Install the removed flared nuts to the pipes to be connected, then flare the pipes.

### CAUTION


Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.

### CAUTION

Do not apply refrigerating machine oil to the flared surface.

### Connection

Outdoor




- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side : 14.0~18.0N·m (1.4~1.8kgf·m)  
Gas side (φ9.52): 34.0~42.0N·m (3.4~4.2kgf·m)  
(φ12.7): 49.0~61.0N·m (4.9~6.1kgf·m)

Gas Leakage Test

- Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.


[Examples of use of variable diameter joints]

- Connection of indoor unit of Class 5.0 to A unit.



Copper pipe diameter	Clutch type flare tool for R410A	Measurement B (mm)	
		Conventional (R22) flare tool Clutch type	Wing nut type
φ6.35	0.0~0.5	1.0~1.5	1.5~2.0
φ9.52	0.0~0.5	1.0~1.5	1.5~2.0
φ12.7	0.0~0.5	1.0~1.5	2.0~2.5

Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.  
If a conventional flare tool is used, please use copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.



[Limit]

piping length	one indoor unit all indoor unit	MAX 25m MAX 40m
height difference	MAX 15m MAX 25m MAX 15m	indoor unit outdoor unit indoor unit
length of chargeless refrigerant pipe	40m	


#### 4 AIR PURGING

NOTE : Fully open the service valves (on both liquid and gas sides) after completing air purging.



- Since the system uses service ports differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Remove the cap on both gas and liquid sides before starting operation.
- After completing the operation, do not forget to tighten the cap (gas may leak).

#### Procedure

- (1) Secure all flare nuts on both indoor and outdoor sides to prevent leaks from the pipes.
- (2) Connect the service valves, charge hose, manifold valve and vacuum pump as shown in the right figure.
- (3) Fully open the handle Lo for the manifold valve, and pump a vacuum for 15 minutes. Ensure that the meter is indicating -0.1MPa (-76cmHg).
- (4) After vacuuming, fully open the service valve (both liquid and gas sides) with a hexagon wrench.



- (5) Remove the charge hose from service port.
- (6) Repeat the above steps (1) ~ (5) for all connected indoor units.
- (7) Ensure that there are no gas leaks from the joints in the indoor and outdoor units.




Securely tighten the service valve cap and the check joint blind nut after adjustment.

Service valve size (mm)	Service valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)
φ 6.35 (1/4")	20~30	10~12
φ 9.52 (3/8")		
φ 12.7 (1/2")	25~35	


#### 5 HEAT INSULATION FOR JOINTS

Heat insulation for joints



Cover the joint with insulation material for the indoor unit and tape it.

Finish and fixing



Apply exterior tape and shape along the place where the pipes will be routed. Secure to the wall with a pipe clamp. Be careful not to damage the pipes and the wires.



#### 7 BEWARE OF WRONG CONNECTIONS IN REFRIGERANT PIPING AND WIRING

- Make sure to match the piping and wiring from each unit to the outdoor unit.
- Be careful because if connections are wrong, normal operation cannot be achieved and may damage the compressor.

[Correct connections]

[Example of wrong connections]

— Piping  
- - - - - Wiring



#### EARTHING WORK

- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

#### 6 TEST RUN AND HANDLING INSTRUCTIONS

##### Installation test check points

Check the following points again after completion of the installation, and before turning on the power.  
Conduct a test run again and ensure that the unit operates properly.  
At the same time, explain to the customer how to use the unit and how to take care of the unit following the installation manual.  
If the compressor does not operate after the operation has started, wait for 5-10 minutes. (This may be due to delayed start.)  
(Three-minutes restart preventive timer)  
When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3minutes. This is to protect the unit and it is not a malfunction.

##### After installation

- ☐ The power source voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.
- ☐ Each indoor and outdoor unit is properly connected (no wrong wiring or piping).
- ☐ Service valve is fully open.
- ☐ Refrigerant has been additionally charged (when the total pipe length exceeds the refrigerant charged pipe length).
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.
- ☐ Earthing work has been conducted properly.
- ☐ The screw of the service panel is tightened securely.

##### Test run

- ☐ Air-conditioning and heating are normal.
- ☐ No abnormal noise.
- ☐ Water drains smoothly.
- ☐ Protective functions are not working.
- ☐ Operation of the unit has been explained to the customer.
- ☐ The remote control is normal.

##### Operation of indicator lamps

INDICATION LAMP	COLOR	FUNCTION
LED E (1)	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1 TIME FLASH	CURRENT CUT	
2 TIME FLASH	TROUBLE OF OUTDOOR UNIT	
3 TIME FLASH	OVER CURRENT	
4 TIME FLASH	TRANSMISSION ERROR IN OUTDOOR UNIT PCB	
5 TIME FLASH	OVER HEAT OF COMPRESSOR	
6 TIME FLASH	ERROR OF SIGNAL TRANSMISSION	
7 TIME FLASH	LOCK OF COMPRESSOR	
8 TIME FLASH	SENSOR ERROR	
LIGHT ON	OUTDOOR FAN MOTOR ERROR	
4 SEC LIGHT AND 4 SEC OFF	DISCHARGE PIPE SENSOR COMING OFF	

### (3) Models SCM71ZM-S, 80ZM-S

RPC012A913C

MULTI TYPE AIR-CONDITIONER  
R410A REFRIGERANT USED

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 107.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.



## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels. **⚠ WARNING** and **⚡ CAUTION**.
- **⚠ WARNING**: Wrong installation would cause serious consequences such as injuries or death.
- **⚡ CAUTION**: Wrong installation might cause serious consequences depending on circumstances.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:




	Never do it under any circumstances.		Always do it according to the instruction.
---	--------------------------------------	---	--

- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

### ⚠ WARNING

	<p><b>Installation must be carried out by the qualified installer.</b> If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</p> <p><b>Install the system in full accordance with the installation manual.</b> Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</p> <p><b>Be sure to use only for household and residence.</b> If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</p> <p><b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b> If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</p> <p><b>Use the original accessories and the specified components for installation.</b> If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</p> <p><b>Install the unit in a location with good support.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</p> <p><b>Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</p> <p><b>Ventilate the working area well in the event of refrigerant leakage during installation.</b> If the refrigerant comes into contact with naked flames, poisonous gas is produced.</p>	<p><b>Use the prescribed pipes, flare nuts and tools for R410A.</b> Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</p> <p><b>Tighten the flare nut by torque wrench with specified method.</b> If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</p> <p><b>Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.</b> If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant.</p> <p><b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b> Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</p> <p><b>Be sure to shut off the power before starting electrical work.</b> Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</p> <p><b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b> Unconformable cables can cause electric leak, anomalous heat production or fire.</p>	<p><b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:25A) with a contact separation of at least 3mm.</b></p> <p><b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b> Incorrect installation may result in overheating and fire.</p> <p><b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b> Loose connections or cable mountings can cause anomalous heat production or fire.</p> <p><b>Be sure to fix up the service panels.</b> Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.</p> <p><b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b> If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</p> <p><b>Stop the compressor before removing the pipe after shutting the service valve on pump down work.</b> If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.</p> <p><b>Only use prescribed optional parts. The installation must be carried out by the qualified installer.</b> If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.</p> <p><b>Be sure to wear protective goggles and gloves while at work.</b></p> <p><b>Earth leakage breaker must be installed.</b> If the earth leakage breaker is not installed, it can cause electric shocks.</p>
	<p><b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b> If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</p> <p><b>Do not processing, splice the power cord, or share a socket with other power plugs.</b> This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</p>	<p><b>Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.</b> This may cause fire or heating.</p> <p><b>Do not run the unit with removed panels or protections.</b> Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</p>	<p><b>Do not perform any change of protective device itself or its setup condition.</b> The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</p>

### ⚡ CAUTION

	<p><b>Carry out the electrical work for ground lead with care.</b> Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</p>
	<p><b>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b> Using the incorrect one could cause the system failure and fire.</p> <p><b>Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations.</b> The isolator should be locked in OFF state in accordance with EN60204-1.</p> <p><b>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></p> <p><b>Secure a space for installation, inspection and maintenance specified in the manual.</b></p> <p>Insufficient space can result in accident such as personal injury due to falling from the installation place.</p> <p><b>Take care when carrying the unit by hand.</b> If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.</p> <p><b>Dispose of any packing materials correctly.</b> Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.</p> <p><b>Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.</b> Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.</p>
	<p><b>Do not install the unit in the locations listed below.</b></p> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p>

## ⚠ CAUTION



### Do not install the outdoor unit in the locations listed below.

- Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.
- Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.
- Locations where vibration can be amplified and transmitted due to insufficient strength of structure.
- Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).
- Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
- Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim.
- Do not install the unit near the location where leakage of combustible gases can occur.**  
If leaked gases accumulate around the unit, it can cause fire.
- Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are**

### handled.

Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.

### Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.

Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.

### Do not install the outdoor unit in a location where insects and small animals can inhabit.

Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.

### Do not use the base flange for outdoor unit which is corroded or damaged due to long periods of operation.

Using an old and damaged base flange can cause the unit falling down and cause personal injury.

### Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.

Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.

### Do not touch any buttons with wet hands.

It can cause electric shocks.

### Do not touch any refrigerant pipes with your hands when the system is in operation.

During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.

### Do not touch the suction or aluminum fin on the outdoor unit.

This may cause injury.

### Do not put anything on the outdoor unit and operating unit.

This may cause damage the objects or injury due to falling to the object.

### Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.

### Do not clean up the unit with water.

## Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

Accessories for outdoor unit	Q'ty
① Grommet (Heat pump type only)	2
② Drain elbow (Heat pump type only)	1
③ Variable diameter joint $\phi 9.52 \Rightarrow \phi 12.7$	2

Note: Provide flare nuts when using the variable diameter joint (for  $\phi 12.7$ ).

Option parts	Q'ty
Ⓐ Sealing plate	1
Ⓑ Sleeve	1
Ⓒ Inclination plate	1
Ⓓ Putty	1
Ⓔ Drain hose (extension hose)	1
Ⓕ Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	Q'ty
1 Plus headed driver	1
2 Knife	1
3 Saw	1
4 Tape measure	1
5 Hammer	1
6 Spanner wrench	1
7 Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)]	1
8 Hole core drill (65mm in diameter)	1

9 Wrench key (Hexagon) [4m/m]	1
10 Vacuum pump	1
11 Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)	1
12 Gauge manifold (Designed specifically for R410A)	1
13 Charge hose (Designed specifically for R410A)	1
14 Flaring tool set (Designed specifically for R410A)	1
15 Gas leak detector (Designed specifically for R410A)	1
16 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	1

## CAUTION • This model requires a minimum of 2 indoor units.

## 1 SELECTION OF INSTALLATION LOCATION

### Install at location that meets the following conditions after getting approval from the customer.

Be careful of the following conditions and choose an installation place.

- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is not applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- A place where no TV set or radio receiver is placed within 1m.
- (If electrical interference is caused, seek a place less likely to cause the problem)
- If a operation is conducted when the outdoor air temperature is  $-5^{\circ}\text{C}$  lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- Where it is likely that the unit is subjected to strong winds, provide wind guards according to the following guidelines. Strong winds can cause performance degradation, an accidental stop due to a rise of high pressure and a broken fan.


Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

### ① Installation Space (on a flat surface)

- Blowing out port and suction port on the back side of the unit can be installed at a distance of 10cm from walls.


(In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.)

- When the unit is installed, the space of the following dimension and above shall be secured.




## Installation

### ① Anchor bolt fixed position



### ② Notabilia for installation



- In installing the unit, fix the unit's legs with bolts specified on the above.
  - The protrusion of an anchor bolt on the front side must be kept within 15 mm.
  - Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
  - Refer to the above illustrations for information regarding concrete foundations.
  - Install the unit in a level area. (With a gradient of 5 mm or less.)
- Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

## 2 INSTALLATION OF OUTDOOR UNIT

### Drainage

- Execute drain piping by using a drain elbow and drain grommets, where water drained from the outdoor unit is a problem.
- There are 3 drain holes provided on the bottom plate of an outdoor unit to discharge condensed water.
- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an option part) or concrete blocks.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)

Connection of the power source cable and the connecting cables for indoor and outdoor units.

- This multi-type room air-conditioner receives its power from outside.
- To ensure correct connections, mark each ends of the cables with number, A to D. It is important to use the same number the corresponding cables and pipes.
- An earth leakage breaker and a circuit breaker must be installed. Their capacities are 25A.


- ① Remove the service panel. (Remove the 2 sets screws of the service panel.)
- ② Remove the terminal cover. (Remove the 2 sets screws of the terminal cover.)
- ③ Connect the power source cable and the connection wire securely to the terminal block.

[POWER SOURCE CODE]  
CENELEC code for cables requiring fields cables. H05RNR3G4.0  
[INTERCONNECTING WIRING CODE]  
CENELEC code for cables requiring fields cables. H05RNR4G1.5

- 1) In wiring, make sure that the wire terminal numbers of outdoor unit terminal block are match to the wire terminal numbers of indoor unit terminal block.
- 2) Terminal number A of the outdoor unit is used for A indoor unit and terminal number B for B indoor unit respectively.

- ④ After connecting the wire, use wiring clamps to secure the wiring.
- ⑤ Fit the terminal cover and the service panel.



- Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.



### Main fuse specification

Specification	Part No.
250V 20A	SSA564A136A

The screw of the service panel is tightened securely.




## 3 CONNECTION OF REFRIGERANT PIPINGS

- Regarding the change in the sizes of gas side pipes (usage of the variable joints); If a 5.0, 6.0 kw class indoor unit (gas side pipe 12.7) is going to be connected to the service valves (9.52), variable joints available as accessories must be applied to the gas side service valves.
- Securely fit the copper packing between the service valve and the variable diameter joint to prevent shifting.

[Connection of pipes]

### NOTE

- Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected.
- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct service valves.



- Remove the flared nuts. (on both liquid and gas sides)
- Install the removed flared nuts to the pipes to be connected, then flare the pipes.

### CAUTION


Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.

### CAUTION

Do not apply refrigerating machine oil to the flared surface.

[Examples of use of variable diameter joints]


- Connection of indoor unit of Class 5.0 to A unit.



Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool Clutch type	Wing nut type
φ6.35	0.0~0.5	1.0~1.5	1.5~2.0
φ9.52	0.0~0.5	1.0~1.5	1.5~2.0
φ12.7	0.0~0.5	1.0~1.5	2.0~2.5


Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.

If a conventional flare tool is used, please use copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.



## Connection

### Outdoor



- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side : 14.0~18.0N·m (1.4~1.8kgf·m)  
Gas side (φ9.52): 34.0~42.0N·m (3.4~4.2kgf·m)  
(φ12.7): 49.0~61.0N·m (4.9~6.1kgf·m)

- When the total refrigerant pipe length for all the rooms exceeds the length of the uncharged pipe (40m), additional refrigerant is required. (If 40m or less, additional charge is not required.)  
Additional charge amount per meter = 20g/m

### Gas Leakage Test

- Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.

[Limit]

piping length	one indoor unit all indoor unit	MAX 25m MAX 70m
height difference		
length of chargeless refrigerant pipe	40m	


## 4 AIR PURGING

NOTE : Fully open the service valves (on both liquid and gas sides) after completing air purging.



- Since the system uses service ports differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Remove the cap on both gas and liquid sides before starting operation.
- After completing the operation, do not forget to tighten the cap (gas may leak).

### Procedure

- (1) Secure all flare nuts on both indoor and outdoor sides to prevent leaks from the pipes.
- (2) Connect the service valves, charge hose, manifold valve and vacuum pump as shown in the right figure.
- (3) Fully open the handle Lo for the manifold valve, and pump a vacuum for 15 minutes. Ensure that the meter is indicating -0.1MPa (-76cmHg).
- (4) After vacuuming, fully open the service valve (both liquid and gas sides) with a hexagon wrench.



- (5) Remove the charge hose from service port.
- (6) Repeat the above steps (1) ~ (5) for all connected indoor units.
- (7) Ensure that there are no gas leaks from the joints in the indoor and outdoor units.




Securely tighten the service valve cap and the check joint blind nut after adjustment.

Service valve size (mm)	Service valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)
φ 6.35 (1/4")	20~30	10~12
φ 9.52 (3/8")		
φ 12.7 (1/2")	25~35	


## 5 HEAT INSULATION FOR JOINTS

### Heat insulation for joints



Cover the joint with insulation material for the indoor unit and tape it.

### Finish and fixing




Apply exterior tape and shape along the place where the pipes will be routed. Secure to the wall with a pipe clamp. Be careful not to damage the pipes and the wires.

## 7 BEWARE OF WRONG CONNECTIONS IN REFRIGERANT PIPING AND WIRING

- Make sure to match the piping and wiring from each unit to the outdoor unit.
- Be careful because if connections are wrong, normal operation cannot be achieved and may damage the compressor.

[Correct connections]

[Example of wrong connections]



## EARTHING WORK

- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephonenumber, etc.)

## 6 TEST RUN AND HANDLING INSTRUCTIONS

### Installation test check points

Check the following points again after completion of the installation, and before turning on the power.  
Conduct a test run again and ensure that the unit operates properly.  
At the same time, explain to the customer how to use the unit and how to take care of the unit following the installation manual.  
If the compressor does not operate after the operation has started, wait for 5-10 minutes. (This may be due to delayed start.)  
(Three-minutes restart preventive timer)  
When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3minutes. This is to protect the unit and it is not a malfunction.

### After installation

- ☐ The power source voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.
- ☐ Each indoor and outdoor unit is properly connected (no wrong wiring or piping).
- ☐ Service valve is fully open.
- ☐ Refrigerant has been additionally charged (when the total pipe length exceeds the refrigerant charged pipe length).
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.
- ☐ Earthing work has been conducted properly.
- ☐ The screw of the service panel is tightened securely.

### Test run

- ☐ Air-conditioning and heating are normal.
- ☐ No abnormal noise.
- ☐ Water drains smoothly.
- ☐ Protective functions are not working.
- ☐ Operation of the unit has been explained to the customer.
- ☐ The remote control is normal.

### Operation of indicator lamps

INDICATION LAMP	COLOR	FUNCTION
LED E (1)	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1 TIME FLASH	CURRENT CUT	
2 TIME FLASH	TROUBLE OF OUTDOOR UNIT	
3 TIME FLASH	OVER CURRENT	
4 TIME FLASH	TRANSMISSION ERROR IN OUTDOOR UNIT PCB	
5 TIME FLASH	OVER HEAT OF COMPRESSOR	
6 TIME FLASH	ERROR OF SIGNAL TRANSMISSION	
7 TIME FLASH	LOCK OF COMPRESSOR	
8 TIME FLASH	SENSOR ERROR	
LIGHT ON	OUTDOOR FAN MOTOR ERROR	
4 SEC LIGHT AND 4 SEC OFF	DISCHARGE PIPE SENSOR COMING OFF	

## (4) Models SCM100ZM-S, 125ZM-S

RPC012A918B

MULTI TYPE AIR-CONDITIONER  
R410A REFRIGERANT USED

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 107.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚡ CAUTION**.
  - ⚠ WARNING**: Wrong installation would cause serious consequences such as injuries or death.
  - ⚡ CAUTION**: Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:



## ⚠ WARNING

- |   |   |   |
|---|---|---|
| <p><b>⚠</b></p> <ul style="list-style-type: none"> <li>• <b>Installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li> <li>• <b>Install the system in full accordance with the installation manual.</b><br/>Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>• <b>Be sure to use only for household and residence.</b><br/>If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b><br/>If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</li> <li>• <b>Use the original accessories and the specified components for installation.</b><br/>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>• <b>Install the unit in a location with good support.</b><br/>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>• <b>Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.</b><br/>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b><br/>If the refrigerant comes into contact with naked flames, poisonous gas is produced.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b><br/>Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li> <li>• <b>Tighten the flare nut by torque wrench with specified method.</b><br/>If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li> <li>• <b>Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.</b><br/>If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant.</li> <li>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b><br/>Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</li> <li>• <b>Be sure to shut off the power before starting electrical work.</b><br/>Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</li> <li>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b><br/>Unconformable cables can cause electric leak, anomalous heat production or fire.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:30A) with a contact separation of at least 3mm.</b></li> <li>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b><br/>Incorrect installation may result in overheating and fire.</li> <li>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b><br/>Loose connections or cable mountings can cause anomalous heat production or fire.</li> <li>• <b>Be sure to fix up the service panels.</b><br/>Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.</li> <li>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b><br/>If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li> <li>• <b>Stop the compressor before removing the pipe after shutting the service valve on pump down work.</b><br/>If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.</li> <li>• <b>Only use prescribed option parts. The installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.</li> <li>• <b>Be sure to wear protective goggles and gloves while at work.</b></li> <li>• <b>Earth leakage breaker must be installed.</b><br/>If the earth leakage breaker is not installed, it can cause electric shocks.</li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b><br/>If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li> <li>• <b>Do not processing, splice the power cord, or share a socket with other power plugs.</b><br/>This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li> </ul>   | <ul style="list-style-type: none"> <li>• <b>Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.</b><br/>This may cause fire or heating.</li> <li>• <b>Do not run the unit with removed panels or protections.</b><br/>Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li> </ul>   | <ul style="list-style-type: none"> <li>• <b>Do not perform any change of protective device itself or its setup condition.</b><br/>The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</li> </ul>  |

## ⚡ CAUTION

- |  |   |  |
|--|---|--|
| <p><b>⚡</b></p> <ul style="list-style-type: none"> <li>• <b>Carry out the electrical work for ground lead with care.</b><br/>Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</li> </ul>  | <ul style="list-style-type: none"> <li>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b><br/>Using the incorrect one could cause the system failure and fire.</li> <li>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b><br/>The isolator should be locked in OFF state in accordance with EN60204-1.</li> <li>• <b>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></li> <li>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b></li> </ul> | <ul style="list-style-type: none"> <li>• <b>When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Do not install the unit in the locations listed below.</b> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> </ul>   | <ul style="list-style-type: none"> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p>  |

## ⚠ CAUTION

- Do not install the outdoor unit in the locations listed below.**

  - Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.
  - Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.
  - Locations where vibration can be amplified and transmitted due to insufficient strength of structure.
  - Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).
  - Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
  - Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim.
  - Do not install the unit near the location where leakage of combustible gases can occur.**  
If leaked gases accumulate around the unit, it can cause fire.
  - Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are**

**handled.**  
Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.

  - Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.**  
Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
  - Do not install the outdoor unit in a location where insects and small animals can inhabit.**  
Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.
  - Do not use the base flange for outdoor unit which is corroded or damaged due to long periods of operation.**  
Using an old and damaged base flange can cause the unit falling down and cause personal injury.

- Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.**  
Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.
  - Do not touch any buttons with wet hands.**  
It can cause electric shocks.
  - Do not touch any refrigerant pipes with your hands when the system is in operation.**  
During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.
  - Do not touch the suction or aluminum fin on the outdoor unit.**  
This may cause injury.
  - Do not put anything on the outdoor unit and operating unit.**  
This may cause damage the objects or injury due to falling to the object.
  - Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.**
  - Do not clean up the unit with water.**

### Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

Accessories for outdoor unit	Q'ty
① Grommet (Heat pump type only)	2
② Drain elbow (Heat pump type only)	1
③ Variable diameter joint $\phi 9.52 \Rightarrow \phi 12.7$	3
④ Variable diameter joint $\phi 9.52 \Rightarrow \phi 15.88$	2

Note: Provide flare nuts when using the variable diameter joint (for  $\phi 12.7$ ,  $\phi 15.88$ ).

Option parts	Q'ty
Ⓐ Sealing plate	1
Ⓑ Sleeve	1
Ⓒ Inclination plate	1
Ⓓ Putty	1
Ⓔ Drain hose (extension hose)	1
Ⓘ Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
9 Wrench key (Hexagon) [4m/m]	
10 Vacuum pump	
11 Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)	
12 Gauge manifold (Designed specifically for R410A)	
13 Charge hose (Designed specifically for R410A)	
14 Flaring tool set (Designed specifically for R410A)	
15 Gas leak detector (Designed specifically for R410A)	
16 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	
1 Plus headed driver	
2 Knife	
3 Saw	
4 Tape measure	
5 Hammer	
6 Spanner wrench	
7 Torque wrench [14.0~82.0N-m (1.4~8.2kgf-m)]	
8 Hole core drill (65mm in diameter)	

### CAUTION

- This model requires normally a minimum of 4 indoor units.
- This model requires a minimum of 3 indoor units in case of SRK71ZR-S, SRK-ZMX-S, FDEN type combination only.
- This model requires a minimum of 2 indoor units in case of SRK71ZR-S type only.

## 1 SELECTION OF INSTALLATION LOCATION

Install at location that meets the following conditions after getting approval from the customer.

Be careful of the following conditions and choose an installation place.


- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is not applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- A place where no TV set or radio receiver is placed within 1m. (If electrical interference is caused, seek a place less likely to cause the problem)
- If a operation is conducted when the outdoor air temperature is  $-5^{\circ}\text{C}$  lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- Where it is likely that the unit is subjected to strong winds, provide wind guards according to the following guidelines. Strong winds can cause performance degradation, an accidental stop due to a rise of high pressure and a broken fan.

Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

### ① Installation Space (on a flat surface)

- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or large space in the above.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space consciously so that short-circuiting may not occur.
- When piling snow can bury the outdoor unit, provide proper snow guards.


Examples of installation Dimensions	I	II	III
L1	Open	Open	500
L2	300	5	Open
L3	150	300	150




### Installation

- In installing the unit, fix the unit's legs with bolts specified on the right.
- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the right illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.) Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

### ① Anchor bolt fixed position




### ② Notabilia for installation



## 2 INSTALLATION OF OUTDOOR UNIT

### Drainage

- Execute drain piping by using a drain elbow and drain grommets, where water drained from the outdoor unit is a problem.
- There are 3 drain holes provided on the bottom plate of an outdoor unit to discharge condensed water.
- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an optional part) or concrete blocks.
- Connect a drain elbow as shown in the illustration and close the other two drain holes with grommets.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)



### Connection of the power source cable and the connecting cables for indoor and outdoor units.



- This multi-type room air-conditioner receives its power from outside.
  - To ensure correct connections, mark each ends of the cables with number, A to F (5 rooms unit A to E). It is important to use the same number the corresponding cables and pipes.
  - An earth leakage breaker and a circuit breaker must be installed. Their capacities are 30A.
- ① Remove the service panel. (Remove the screw of the service panel.)
  - ② Remove the terminal cover. (Remove the screw of the terminal cover.)
  - ③ Connect the power source cable and the connection wire securely to the terminal block.

[POWER SOURCE CODE]  
CENELEC code for cables requiring fields cables. H05RN3G5.5  
[INTERCONNECTING WIRING CODE]  
CENELEC code for cables requiring fields cables. H05RN4G1.5

- 1) In wiring, make sure that the wire terminal numbers of outdoor unit terminal block are match to the wire terminal numbers of indoor unit terminal block.
- 2) Terminal number A of the outdoor unit is used for A indoor unit and terminal number B for B indoor unit respectively.

- ④ After connecting the wire, use wiring clamps to secure the wiring.
- ⑤ Fit the terminal cover and the service panel.

- Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.




## 3 CONNECTION OF REFRIGERANT PIPINGS

- Regarding the change in the sizes of gas side pipes (usage of the variable joints): If a 5.0, 6.0 kW class indoor unit (gas side pipe 12.7) or 7.1 kW class indoor unit (gas side pipe 15.88) is going to be connected to the service valves (9.52), variable joints available as accessories must be applied to the gas side service valves.
- Securely fit the copper packing between the service valve and the variable diameter joint to prevent shifting.

### [Connection of pipes]

#### NOTE

- Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected.
- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct service valves.



- Remove the flared nuts. (on both liquid and gas sides)

- Install the removed flared nuts to the pipes to be connected, then flare the pipes.

### CAUTION


Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.

### CAUTION

Do not apply refrigerating machine oil to the flared surface.

### Connection

#### Outdoor



- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side : 14.0~18.0N·m (1.4~1.8kgf·m)  
Gas side (φ9.52): 34.0~42.0N·m (3.4~4.2kgf·m)  
(φ12.7): 49.0~61.0N·m (4.9~6.1kgf·m)  
(φ15.88): 68.0~82.0N·m (6.8~8.2kgf·m)


- When the total refrigerant pipe length for all the rooms exceeds the length of the uncharged pipe (50m), additional refrigerant is required. (If 50m or less, additional charge is not required.)  
Additional charge amount per meter = 20g/m

#### Gas Leakage Test

- Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.


### [Examples of use of variable diameter joints]

- Connection of indoor unit of Class 5.0 or 7.1 to A unit.



Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool Clutch type	Wing nut type
φ 6.35	0.0~0.5	1.0~1.5	1.5~2.0
φ 9.52	0.0~0.5	1.0~1.5	1.5~2.0
φ 12.7	0.0~0.5	1.0~1.5	2.0~2.5
φ 15.88	0.0~0.5	1.0~1.5	2.0~2.5

Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use. If a conventional flare tool is used, please use copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.



### [Limit]

piping length	one indoor unit all indoor unit	MAX 25m MAX 90m
height difference	<div> <div>MAX 25m (between the indoor unit)</div> <div>MAX 20m</div> </div>	<div> <div>indoor unit</div> <div>indoor unit</div> <div>indoor unit</div> <div>indoor unit</div> <div>indoor unit</div> </div>
length of chargeless refrigerant pipe	50m	


## 4 AIR PURGING

**NOTE :** Fully open the service valves (on both liquid and gas sides) after completing air purging.



- Since the system uses service ports differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Remove the cap on both gas and liquid sides before starting operation.
- After completing the operation, do not forget to tighten the cap (gas may leak).

### Procedure

- Secure all flare nuts on both indoor and outdoor sides to prevent leaks from the pipes.
- Connect the service valves, charge hose, manifold valve and vacuum pump as shown in the right figure.
- Fully open the handle Lo for the manifold valve, and pump a vacuum for 15 minutes. Ensure that the meter is indicating -0.1MPa (-76cmHg).
- After vacuuming, fully open the service valve (both liquid and gas sides) with a hexagon wrench.



- Remove the charge hose from service port.
- Repeat the above steps (1) ~ (5) for all connected indoor units.
- Ensure that there are no gas leaks from the joints in the indoor and outdoor units.




Securely tighten the service valve cap and the check joint blind nut after adjustment.


Service valve size (mm)	Service valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)
φ 6.35 (1/4")	20~30	10~12
φ 9.52 (3/8")	25~35	
φ 12.7 (1/2")	30~40	
φ 15.88 (5/8")		

## 5 HEAT INSULATION FOR JOINTS

Heat insulation for joints



Finish and fixing




Apply exterior tape and shape along the place where the pipes will be routed. Secure to the wall with a pipe clamp. Be careful not to damage the pipes and the wires.


## 7 BEWARE OF WRONG CONNECTIONS IN REFRIGERANT PIPING AND WIRING

- Make sure to match the piping and wiring from each unit to the outdoor unit.
- Be careful because if connections are wrong, normal operation cannot be achieved and may damage the compressor.

[Correct connections]



[Example of wrong connections]



## EARTHING WORK

- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

## 6 TEST RUN AND HANDLING INSTRUCTIONS

### Installation test check points

Check the following points again after completion of the installation, and before turning on the power.

Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the installation manual.

If the compressor does not operate after the operation has started, wait for 5-10 minutes. (This may be due to delayed start.)

(Three-minutes restart preventive timer)

When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3minutes. This is to protect the unit and it is not a malfunction.

### After installation

- The power source voltage is correct as the rating.
- No gas leaks from the joints of the service valve.
- Power cables and crossover wires are securely fixed to the terminal board.
- Each indoor and outdoor unit is properly connected (no wrong wiring or piping).
- Service valve is fully open.
- Refrigerant has been additionally charged (when the total pipe length exceeds the refrigerant charged pipe length).
- The pipe joints for indoor and outdoor pipes have been insulated.
- Earthing work has been conducted properly.
- The screw of the service panel is tightened securely.

### Test run

- Air-conditioning and heating are normal.
- No abnormal noise.
- Water drains smoothly.
- Protective functions are not working.
- Operation of the unit has been explained to the customer.
- The remote control is normal.

### Operation of indicator lamps

INDICATION LAMP	COLOR	FUNCTION
LED 1	RED	WARNING LAMP
SELF DIAGNOSIS FUNCTION BY LED E		
1 TIME FLASH	CURRENT CUT	
2 TIME FLASH	TROUBLE OF OUTDOOR UNIT	
4 TIME FLASH	TRANSMISSION ERROR IN OUTDOOR UNIT PCB	
5 TIME FLASH	OVER HEAT OF COMPRESSOR	
6 TIME FLASH	ERROR OF SIGNAL TRANSMISSION	
8 TIME FLASH	SENSOR ERROR	
LIGHT ON	OUTDOOR FAN MOTOR ERROR	
4 SEC LIGHT AND 4 SEC OFF	DISCHARGE PIPE SENSOR COMING OFF	

## 2. INDOOR UNITS

### 2.1 Specifications

#### (1) Wall mounted type (SRK)


##### (a) Models SRK20, 25, 35, 50, 60ZMX-S

Adapted to **RoHS** directive

Item			Model	SRK20ZMX-S				
Power source				1 Phase, 220–240 V, 50Hz				
Operation data	Nominal cooling capacity (range)		kW	2.0				
	Nominal heating capacity (range)		kW	3.0				
	Sound power level	Cooling	dB(A)	53				
		Heating		54				
	Sound pressure level	Cooling		Hi: 39 Me: 30 Lo: 24 ULo: 21				
		Heating		Hi: 38 Me: 33 Lo: 25 ULo: 21				
Silent mode sound pressure level				—				
Exterior dimensions (Height x Width x Depth)			mm	309 x 890 x 220				
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent				
Net weight			kg	13.5				
Heat exchanger				Louver fins & inner grooved tubing				
Fan type & Q'ty				Tangential fan x 1				
Fan motor (Starting method)			W	30 x1 (Direct drive)				
Air flow	Cooling	m³/min	Hi: 11.5 Me: 8.0 Lo: 6.3 ULo: 5.0					
	Heating		Hi: 12.0 Me: 9.5 Lo: 7.0 ULo: 6.3					
Available external static pressure			Pa	0				
Outside air intake				Not possible				
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2				
Shock & vibration absorber				Rubber sleeve (for fan motor)				
Operation control	Remote control			Wireless remote control				
	Room temperature control			Microcomputer thermostat				
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green, ECONO: Blue				
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection				
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 9.52 ( 3/8" )				
	Connecting method			Flare connection				
	Attached length of piping		m	Liquid line : 0.55 / Gas line : 0.49				
	Insulation for piping			Necessary (Both sides), independent				
	Drain hose			Hose connectable ( VP 16 )				
Drain pump, max lift height			mm	—				
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )				
IP number				IPX0				
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )				
Option parts				Interface kit ( SC-BIKN-E )				
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.				
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards		
		DB	WB	DB	WB			
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1		
	Heating	20°C	—	7°C	6°C			
(2) This air-conditioner is manufactured and tested in conformity with the ISO.								
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.								

Adapted to **RoHS** directive

Item			Model	SRK25ZMX-S			
Power source				1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	2.5			
	Nominal heating capacity (range)		kW	3.4			
	Sound power level	Cooling	dB(A)	55			
		Heating		58			
	Sound pressure level	Cooling		Hi: 41   Me: 31   Lo: 25   ULo: 22			
		Heating		Hi: 41   Me: 34   Lo: 27   ULo: 21			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	309 x 890 x 220			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	13.5			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Tangential fan x 1			
Fan motor (Starting method)			W	30 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 12.5   Me: 9.0   Lo: 6.3   ULo: 5.0				
	Heating		Hi: 13.0   Me: 10.0   Lo: 7.5   ULo: 6.3				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green, ECONO: Blue			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" )   Gas line: $\phi$ 9.52 ( 3/8" )			
	Connecting method			Flare connection			
	Attached length of piping		m	Liquid line : 0.55 / Gas line : 0.49			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )			
Option parts				Interface kit ( SC-BIKN-E )			
Note (1) The data are measured at the following conditions.							
The pipe length is 7.5m.							
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards	
		DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1	
	Heating	20°C	—	7°C	6°C		
(2) This air-conditioner is manufactured and tested in conformity with the ISO.							
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.							


RWA000Z252 

Adapted to **RoHS** directive

Item			Model	SRK35ZMX-S		
Power source				1 Phase, 220–240 V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	3.5		
	Nominal heating capacity (range)		kW	4.5		
	Sound power level	Cooling	dB(A)	58		
		Heating		59		
	Sound pressure level	Cooling		Hi: 43   Me: 33   Lo: 25   ULo: 22		
		Heating		Hi: 42   Me: 35   Lo: 27   ULo: 22		
Silent mode sound pressure level				—		
Exterior dimensions (Height x Width x Depth)			mm	309 x 890 x 220		
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent		
Net weight			kg	13.5		
Heat exchanger				Louver fins & inner grooved tubing		
Fan type & Q'ty				Tangential fan x 1		
Fan motor (Starting method)			W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 13.5   Me: 9.5   Lo: 6.5   ULo: 5.0			
	Heating		Hi: 14.0   Me: 11.0   Lo: 8.0   ULo: 6.5			
Available external static pressure			Pa	0		
Outside air intake				Not possible		
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2		
Shock & vibration absorber				Rubber sleeve (for fan motor)		
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green, ECONO: Blue		
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection		
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" )   Gas line: $\phi$ 9.52 ( 3/8" )		
	Connecting method			Flare connection		
	Attached length of piping		m	Liquid line : 0.55 / Gas line : 0.49		
	Insulation for piping			Necessary (Both sides), independent		
	Drain hose			Hose connectable ( VP 16 )		
Drain pump, max lift height			mm	—		
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )		
IP number				IPX0		
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )		
Option parts				Interface kit ( SC-BIKN-E )		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation \ Item	Indoor air temperature		Outdoor air temperature		Standards	
	DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.						


Adapted to **RoHS** directive

Item			Model	SRK50ZMX-S			
Power source				1 Phase, 220~240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	5.0			
	Nominal heating capacity (range)		kW	5.8			
	Sound power level	Cooling	dB(A)	60			
		Heating		64			
	Sound pressure level	Cooling		Hi: 47   Me: 40   Lo: 27   ULo: 25			
		Heating		Hi: 48   Me: 40   Lo: 33   ULo: 26			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	309 x 890 x 220			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	13.5			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Tangential fan x 1			
Fan motor (Starting method)			W	30 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 13.5   Me: 11.0   Lo: 8.0   ULo: 7.0				
	Heating		Hi: 17.0   Me: 14.5   Lo: 10.5   ULo: 8.0				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green, ECONO: Blue			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" )   Gas line: ϕ 12.7 ( 1/2" )			
	Connecting method			Flare connection			
	Attached length of piping		m	Liquid line : 0.55 / Gas line : 0.49			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1			
Option parts				Interface kit ( SC-BIKN-E )			
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.			
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards	
		DB	WB	DB	WB		
		Cooling	27°C	19°C	35°C		24°C
		Heating	20°C	—	7°C	6°C	ISO5151-T1
(2) This air-conditioner is manufactured and tested in conformity with the ISO.							
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.							

RWA000Z252 

Adapted to **RoHS** directive


Item			Model	SRK60ZMX-S		
Power source				1 Phase, 220–240 V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	6.0		
	Nominal heating capacity (range)		kW	6.8		
	Sound power level	Cooling	dB(A)	62		
		Heating		64		
	Sound pressure level	Cooling		Hi: 51 Me: 41 Lo: 29 ULo: 25		
		Heating		Hi: 48 Me: 41 Lo: 34 ULo: 27		
Silent mode sound pressure level				—		
Exterior dimensions (Height x Width x Depth)			mm	309 x 890 x 220		
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent		
Net weight			kg	13.5		
Heat exchanger				Louver fins & inner grooved tubing		
Fan type & Q'ty				Tangential fan x 1		
Fan motor (Starting method)			W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 14.5 Me: 12.5 Lo: 8.5 ULo: 7.0			
	Heating		Hi: 17.5 Me: 15.0 Lo: 11.0 ULo: 8.5			
Available external static pressure			Pa	0		
Outside air intake				Not possible		
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2		
Shock & vibration absorber				Rubber sleeve (for fan motor)		
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green, ECONO: Blue		
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection		
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" ) Gas line: $\phi$ 12.7 ( 1/2" )		
	Connecting method			Flare connection		
	Attached length of piping		m	Liquid line : 0.55 / Gas line : 0.49		
	Insulation for piping			Necessary (Both sides), independent		
	Drain hose			Hose connectable ( VP 16 )		
Drain pump, max lift height			mm	—		
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )		
IP number				IPX0		
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )		
Option parts				Interface kit ( SC-BIKN-E )		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.						

RWA000Z252 

**(b) Models SRK20, 25, 35, 50ZM-S, 71ZR-S**

Adapted to RoHS directive

Item			Model	SRK20ZM-S				
Power source				1 Phase, 220~240 V, 50Hz				
Operation data	Nominal cooling capacity (range)		kW	2.0				
	Nominal heating capacity (range)		kW	3.0				
	Sound power level	Cooling	dB(A)	49				
		Heating		52				
	Sound pressure level	Cooling		Hi: 33   Me: 27   Lo: 24   ULo: 21				
		Heating		Hi: 36   Me: 31   Lo: 24   ULo: 21				
Silent mode sound pressure level				—				
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229				
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent				
Net weight			kg	9.5				
Heat exchanger				Louver fins & inner grooved tubing				
Fan type & Q'ty				Tangential fan x 1				
Fan motor (Starting method)			W	30 x1 (Direct drive)				
Air flow	Cooling	m³/min	Hi: 7.8   Me: 5.6   Lo: 5.3   ULo: 4.8					
	Heating		Hi: 9.8   Me: 6.3   Lo: 5.0   ULo: 4.5					
Available external static pressure			Pa	0				
Outside air intake				Not possible				
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2				
Shock & vibration absorber				Rubber sleeve (for fan motor)				
Operation control	Remote control			Wireless remote control				
	Room temperature control			Microcomputer thermostat				
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green				
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection				
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: φ 6.35 ( 1/4" )   Gas line: φ 9.52 ( 3/8" )				
	Connecting method			Flare connection				
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40				
	Insulation for piping			Necessary (Both sides), independent				
	Drain hose			Hose connectable ( VP 16 )				
Drain pump, max lift height			mm	—				
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )				
IP number				IPX0				
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )				
Option parts				Interface kit ( SC-BIKN-E )				
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.				
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards		
		DB	WB	DB	WB			
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1		
	Heating	20°C	—	7°C	6°C			
(2) This air-conditioner is manufactured and tested in conformity with the ISO.								
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.								

RWA000Z253 

Adapted to **RoHS** directive

Item			Model	SRK25ZM-S		
Power source				1 Phase, 220–240 V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	2.5		
	Nominal heating capacity (range)		kW	3.4		
	Sound power level	Cooling	dB(A)	50		
		Heating		55		
	Sound pressure level	Cooling		Hi: 34 Me: 28 Lo: 24 ULo: 21		
		Heating		Hi: 39 Me: 31 Lo: 24 ULo: 21		
Silent mode sound pressure level				—		
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229		
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent		
Net weight			kg	9.5		
Heat exchanger				Louver fins & inner grooved tubing		
Fan type & Q'ty				Tangential fan x 1		
Fan motor (Starting method)			W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 7.9 Me: 6.0 Lo: 5.3 ULo: 5.0			
	Heating		Hi: 10.6 Me: 6.5 Lo: 5.1 ULo: 4.6			
Available external static pressure			Pa	0		
Outside air intake				Not possible		
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2		
Shock & vibration absorber				Rubber sleeve (for fan motor)		
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green		
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection		
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 9.52 ( 3/8" )		
	Connecting method			Flare connection		
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40		
	Insulation for piping			Necessary (Both sides), independent		
	Drain hose			Hose connectable ( VP 16 )		
Drain pump, max lift height			mm	—		
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )		
IP number				IPX0		
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )		
Option parts				Interface kit ( SC-BIKN-E )		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation \ Item	Indoor air temperature		Outdoor air temperature		Standards	
	DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.						

Adapted to **RoHS** directive

Item			Model	SRK35ZM-S			
Power source				1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	3.5			
	Nominal heating capacity (range)		kW	4.5			
	Sound power level	Cooling	dB(A)	58			
		Heating		59			
	Sound pressure level	Cooling		Hi: 42   Me: 32   Lo: 26   ULo: 22			
		Heating		Hi: 43   Me: 37   Lo: 25   ULo: 22			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	9.5			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Tangential fan x 1			
Fan motor (Starting method)			W	30 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 10.1   Me: 6.4   Lo: 5.4   ULo: 5.0				
	Heating		Hi: 12.8   Me: 9.4   Lo: 6.1   ULo: 4.8				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" )      Gas line: $\phi$ 9.52 ( 3/8" )			
	Connecting method			Flare connection			
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires		Size x Core number		1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )			
Option parts				Interface kit ( SC-BIKN-E )			


Note (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
Cooling		27°C	19°C	35°C	24°C	ISO5151-T1
Heating		20°C	—	7°C	6°C	

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.

RWA000Z253 

Adapted to **RoHS** directive

Item			Model	SRK50ZM-S		
Power source				1 Phase, 220–240 V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	5.0		
	Nominal heating capacity (range)		kW	5.8		
	Sound power level	Cooling	dB(A)	60		
		Heating		61		
	Sound pressure level	Cooling		Hi: 46 Me: 37 Lo: 28 ULo: 25		
		Heating		Hi: 45 Me: 37 Lo: 31 ULo: 27		
Silent mode sound pressure level				—		
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229		
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent		
Net weight			kg	9.5		
Heat exchanger				Louver fins & inner grooved tubing		
Fan type & Q'ty				Tangential fan x 1		
Fan motor (Starting method)			W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 11.3 Me: 7.8 Lo: 6.0 ULo: 5.3			
	Heating		Hi: 13.5 Me: 10.2 Lo: 7.5 ULo: 6.2			
Available external static pressure			Pa	0		
Outside air intake				Not possible		
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2		
Shock & vibration absorber				Rubber sleeve (for fan motor)		
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green		
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection		
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" ) Gas line: $\phi$ 12.7 ( 1/2" )		
	Connecting method			Flare connection		
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40		
	Insulation for piping			Necessary (Both sides), independent		
	Drain hose			Hose connectable ( VP 16 )		
Drain pump, max lift height			mm	—		
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )		
IP number				IPX0		
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )		
Option parts				Interface kit ( SC-BIKN-E )		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation \ Item	Indoor air temperature		Outdoor air temperature		Standards	
	DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.						

Adapted to **RoHS** directive

Item			Model	SRK71ZR-S			
Power source				1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	7.1			
	Nominal heating capacity (range)		kW	8.0			
	Sound power level	Cooling	dB(A)	58			
		Heating		60			
	Sound pressure level	Cooling		Hi: 44   Me: 41   Lo: 37   ULo: 25			
		Heating		Hi: 46   Me: 39   Lo: 35   ULo: 28			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	339 x 1197 x 262			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	15.5			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Tangential fan x 1			
Fan motor (Starting method)			W	56 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 20.5   Me: 18.6   Lo: 16.2   ULo: 10.4				
	Heating		Hi: 25.5   Me: 19.8   Lo: 17.3   ULo: 13.3				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 2			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" )   Gas line: $\phi$ 15.88 ( 5/8" )			
	Connecting method			Flare connection			
	Attached length of piping		m	Liquid line : 0.78 / Gas line : 0.72			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )			
Option parts				Interface kit ( SC-BIKN-E )			
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.			
<div>Operation \ Item</div>		Indoor air temperature		Outdoor air temperature		Standards	
		DB	WB	DB	WB		
Cooling		27°C	19°C	35°C	24°C	ISO5151-T1	
Heating		20°C	—	7°C	6°C	ISO5151-H1	
Heating (H2)		20°C	—	2°C	1°C	ISO5151-H2	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.							
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.							

RWA000Z262

## (2) Floor standing type (SRF)

Adapted to RoHS directive


Item			Model	SRF25ZMX-S			
Power source				1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	2.5			
	Nominal heating capacity (range)		kW	3.4			
	Sound power level	Cooling	dB(A)	51			
		Heating		51			
	Sound pressure level	Cooling		Hi: 40 Me: 32 Lo: 29 ULo: 26			
		Heating		Hi: 40 Me: 35 Lo: 33 ULo: 28			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	600 x 860 x 238			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	18			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Turbo fan x 1			
Fan motor (Starting method)			W	40 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 9.0 Me: 7.6 Lo: 6.7 ULo: 5.8				
	Heating		Hi: 10.5 Me: 8.2 Lo: 7.7 ULo: 6.6				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 1			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, Air outlet selection: Green, ECONO: Green			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 9.52 ( 3/8" )			
	Connecting method			Flare connection			
	Attached length of piping		m	—			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )			
Option parts				Interface kit ( SC-BIKN-E )			
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.			
Item Operation		Indoor air temperature		Outdoor air temperature		Standards	
		DB	WB	DB	WB		
Cooling		27°C	19°C	35°C	24°C	ISO5151-T1	
Heating		20°C	—	7°C	6°C		
(2) This air-conditioner is manufactured and tested in conformity with the ISO.							
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.							

The pipe length is 7.5m.

ISO5151-T1

Adapted to **RoHS** directive

Item			Model	SRF35ZMX-S			
Power source				1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	3.5			
	Nominal heating capacity (range)		kW	4.5			
	Sound power level	Cooling	dB(A)	52			
		Heating		52			
	Sound pressure level	Cooling		Hi: 41 Me: 34 Lo: 32 ULo: 28			
		Heating		Hi: 41 Me: 36 Lo: 35 ULo: 31			
Silent mode sound pressure level				—			
Exterior dimensions (Height x Width x Depth)			mm	600 x 860 x 238			
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent			
Net weight			kg	19			
Heat exchanger				Louver fins & inner grooved tubing			
Fan type & Q'ty				Turbo fan x 1			
Fan motor (Starting method)			W	40 x1 (Direct drive)			
Air flow	Cooling	m³/min	Hi: 9.2 Me: 7.8 Lo: 7.3 ULo: 6.4				
	Heating		Hi: 10.7 Me: 8.3 Lo: 8.1 ULo: 7.4				
Available external static pressure			Pa	0			
Outside air intake				Not possible			
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 1			
Shock & vibration absorber				Rubber sleeve (for fan motor)			
Operation control	Remote control			Wireless remote control			
	Room temperature control			Microcomputer thermostat			
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, Air outlet selection: Green, ECONO: Green			
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection			
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 9.52 ( 3/8" )			
	Connecting method			Flare connection			
	Attached length of piping		m	—			
	Insulation for piping			Necessary (Both sides), independent			
	Drain hose			Hose connectable ( VP 16 )			
Drain pump, max lift height			mm	—			
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )			
IP number				IPX0			
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )			
Option parts				Interface kit ( SC-BIKN-E )			
Note (1) The data are measured at the following conditions.				The pipe length is 7.5m.			
Operation \ Item		Indoor air temperature		Outdoor air temperature		Standards	
		DB	WB	DB	WB		
Cooling		27°C	19°C	35°C	24°C	ISO5151-T1	
Heating		20°C	—	7°C	6°C		
(2) This air-conditioner is manufactured and tested in conformity with the ISO.							
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.							

RWB000Z056 

Adapted to **RoHS** directive

Model			SRF50ZMX-S			
Power source			1 Phase, 220–240 V, 50Hz			
Operation data	Nominal cooling capacity (range)		kW	5.0		
	Nominal heating capacity (range)		kW	5.8		
	Sound power level	Cooling	dB(A)	58		
		Heating		58		
	Sound pressure level	Cooling	dB(A)	Hi: 46 Me: 42 Lo: 35 ULo: 32		
		Heating		Hi: 47 Me: 41 Lo: 39 ULo: 33		
Silent mode sound pressure level			—			
Exterior dimensions (Height x Width x Depth)			mm	600 x 860 x 238		
Exterior appearance ( Munsell color )				Fine snow ( 8.0Y 9.3/0.1 ) near equivalent		
Net weight			kg	19		
Heat exchanger				Louver fins & inner grooved tubing		
Fan type & Q'ty				Turbo fan x 1		
Fan motor (Starting method)			W	40 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 11.5 Me: 9.6 Lo: 7.4 ULo: 6.6			
	Heating		Hi: 12.0 Me: 10.0 Lo: 9.4 ULo: 7.6			
Available external static pressure			Pa	0		
Outside air intake				Not possible		
Air filter, Quality / Quantity				Polypropylene net ( washable ) x 1		
Shock & vibration absorber				Rubber sleeve (for fan motor)		
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, Air outlet selection: Green, ECONO: Green		
Safety equipments				Frost protection, Serial signal error protection, Indoor fan motor error protection		
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 12.7 ( 1/2" )		
	Connecting method			Flare connection		
	Attached length of piping		m	—		
	Insulation for piping			Necessary (Both sides), independent		
	Drain hose			Hose connectable ( VP 16 )		
Drain pump, max lift height			mm	—		
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )		
IP number				IPX0		
Standard accessories				Mounting kit, Clean filter ( Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1 )		
Option parts				Interface kit ( SC-BIKN-E )		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.						

## (3) Ceiling concealed type (SRR)

Model			SRR25ZM-S
Power source			1 Phase, 220–240 V, 50Hz
Operation data	Nominal cooling capacity (range)	kW	2.5
	Nominal heating capacity (range)	kW	3.4
	Sound power level	Cooling	56
		Heating	59
	Sound pressure level ①	Cooling	Hi: 37 Me: 33 Lo: 30 ULo: 24
		Heating	Hi: 40 Me: 37 Lo: 34 ULo: 28
	Sound pressure level ②	Cooling	Hi: 31 Me: 28 Lo: 26 ULo: 21
		Heating	Hi: 33 Me: 30 Lo: 28 ULo: 23
	Sound pressure level ③	Cooling	Hi: 39 Me: 35 Lo: 32 ULo: 25
		Heating	Hi: 44 Me: 41 Lo: 38 ULo: 31
Silent mode sound pressure level		—	
Exterior dimensions (Height x Width x Depth)		mm	200 x 750 x 500
Exterior appearance ( Munsell color )			—
Net weight		kg	20.5
Heat exchanger			Louver fins & inner grooved tubing
Fan type & Q'ty			Centrifugal fan x 2
Fan motor (Starting method)		W	51 x1 (Direct drive)
Air flow	Cooling	m³/min	Hi: 9.5 Me: 8.0 Lo: 6.5 ULo: 4.5
	Heating		Hi: 10.0 Me: 9.0 Lo: 8.0 ULo: 6.0
Available external static pressure		Pa	35 (Initial static pressure with air filter:5Pa)
Outside air intake			Not possible
Air filter, Quality / Quantity			Polypropylene net x 1
Shock & vibration absorber			Cushion rubber (for fan motor)
Operation control	Remote control		Wireless remote control
	Room temperature control		Microcomputer thermostat
	Operation display		RUN: Green, TIMER: Yellow, HI POWER: Green, ECONO: Green
Safety equipments			Drain error protection, Frost protection, Serial signal error protection, Indoor fan motor error protection
Installation data	Refrigerant piping size ( O.D )	mm	Liquid line: ϕ 6.35 ( 1/4" ) Gas line: ϕ 9.52 ( 3/8" )
	Connecting method		Flare connection
	Insulation for piping		Necessary (Both sides), independent
	Drain hose		Hose connectable ( VP 25 )
Drain pump, max lift height		mm	Built-in, MAX600
Interconnecting wires	Size x Core number		1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )
IP number			IPX0
Standard accessories			Mounting kit, Joint for drain piping
Option parts			Wired remote control, Interface kit ( SC-BIKN-E ), Bottom air inlet kit


Note (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air temperature		Standards	Note
	DB	WB	DB	WB		
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1	Non-duct (with air filter)
Heating	20°C	—	7°C	6°C		

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.

(4) Mike positions of measuring sound pressure level of indoor unit is shown below.



RWA000Z263

			Model	SRR35ZM-S
Power source				1 Phase, 220–240 V, 50Hz
Operation data	Nominal cooling capacity (range)		kW	3.5
	Nominal heating capacity (range)		kW	4.5
	Sound power level	Cooling	dB(A)	57
		Heating		60
	Sound pressure level ①	Cooling		Hi: 38 Me: 34 Lo: 31 ULo: 25
		Heating		Hi: 42 Me: 38 Lo: 35 ULo: 29
	Sound pressure level ②	Cooling		Hi: 33 Me: 30 Lo: 27 ULo: 22
		Heating		Hi: 34 Me: 32 Lo: 29 ULo: 24
	Sound pressure level ③	Cooling		Hi: 40 Me: 37 Lo: 33 ULo: 27
Heating		Hi: 45 Me: 42 Lo: 39 ULo: 33		
Silent mode sound pressure level				—
Exterior dimensions (Height x Width x Depth)			mm	200 x 750 x 500
Exterior appearance ( Munsell color )				—
Net weight			kg	20.5
Heat exchanger				Louver fins & inner grooved tubing
Fan type & Q'ty				Centrifugal fan x 2
Fan motor (Starting method)			W	51 x1 (Direct drive)
Air flow	Cooling	m³/min		Hi: 10.0 Me: 8.5 Lo: 7.0 ULo: 5.0
	Heating		Hi: 10.5 Me: 9.5 Lo: 8.5 ULo: 6.5	
Available external static pressure			Pa	35 (Initial static pressure with air filter:5Pa)
Outside air intake				Not possible
Air filter, Quality / Quantity				Polypropylene net x 1
Shock & vibration absorber				Cushion rubber (for fan motor)
Operation control	Remote control			Wireless remote control
	Room temperature control			Microcomputer thermostat
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, ECONO: Green
Safety equipments				Drain error protection, Frost protection, Serial signal error protection, Indoor fan motor error protection
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: $\phi$ 6.35 ( 1/4" ) Gas line: $\phi$ 9.52 ( 3/8" )
	Connecting method			Flare connection
	Insulation for piping			Necessary (Both sides), independent
	Drain hose			Hose connectable ( VP 25 )
Drain pump, max lift height			mm	Built-in, MAX600
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )
IP number				IPX0
Standard accessories				Mounting kit, Joint for drain piping
Option parts				Wired remote control, Interface kit ( SC-BIKN-E ), Bottom air inlet kit

Note (1) The data are measured at the following conditions.

Operation \ Item	Indoor air temperature		Outdoor air temperature		Standards	Note
	DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C		
Heating	20°C	—	7°C	6°C	ISO5151-T1	Non-duct (with air filter)

The pipe length is 5m.


(2) This air-conditioner is manufactured and tested in conformity with the ISO.


(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.

(4) Mike positions of measuring sound pressure level of indoor unit is shown below.

External static pressure for ②, ③ : 10Pa

RWA000Z263

Item			Model	SRR50ZM-S	
Power source				1 Phase, 220~240 V, 50Hz	
Operation data	Nominal cooling capacity (range)		kW	5	
	Nominal heating capacity (range)		kW	5.8	
	Sound power level	Cooling	dB(A)	59	
		Heating		61	
	Sound pressure level ①	Cooling		Hi: 41 Me: 37 Lo: 34 ULo: 29	
		Heating		Hi: 43 Me: 39 Lo: 37 ULo: 32	
	Sound pressure level ②	Cooling		Hi: 35 Me: 33 Lo: 30 ULo: 25	
		Heating		Hi: 38 Me: 36 Lo: 33 ULo: 28	
	Sound pressure level ③	Cooling		Hi: 41 Me: 37 Lo: 34 ULo: 29	
Heating		Hi: 46 Me: 43 Lo: 40 ULo: 34			
Silent mode sound pressure level				—	
Exterior dimensions (Height x Width x Depth)			mm	200 x 950 x 500	
Exterior appearance ( Munsell color )				—	
Net weight			kg	24	
Heat exchanger				Louver fins & inner grooved tubing	
Fan type & Q'ty				Centrifugal fan x 3	
Fan motor (Starting method)			W	85 x1 (Direct drive)	
Air flow	Cooling	m³/min		Hi: 13.5 Me: 11.0 Lo: 10.0 ULo: 7.5	
	Heating		Hi: 14.0 Me: 12.5 Lo: 11.0 ULo: 8.5		
Available external static pressure			Pa	50 (Initial static pressure with air filter:5Pa)	
Outside air intake				Not possible	
Air filter, Quality / Quantity				Polypropylene net x 1	
Shock & vibration absorber				Cushion rubber (for fan motor)	
Operation control	Remote control			Wireless remote control	
	Room temperature control			Microcomputer thermostat	
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, ECONO: Green	
Safety equipments				Drain error protection, Frost protection, Serial signal error protection, Indoor fan motor error protection	
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ6.35 ( 1/4" ) Gas line: ϕ12.7 ( 1/2" )	
	Connecting method			Flare connection	
	Insulation for piping			Necessary (Both sides), independent	
	Drain hose			Hose connectable ( VP 25 )	
Drain pump, max lift height			mm	Built-in, MAX600	
Interconnecting wires	Size x Core number			1.5mm² x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )	
IP number				IPX0	
Standard accessories				Mounting kit, Joint for drain piping	
Option parts				Wired remote control, Interface kit ( SC-BIKN-E ), Bottom air inlet kit	
Note (1) The data are measured at the following conditions.					
The pipe length is 5m.					
(4) Mike positions of measuring sound pressure level of indoor unit is shown below.					
					
① ② ③ ④					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m					
Air - Unit - Return duct - Supply duct					
1.5m 2m 1.5m</					



RWA000Z263

Item			Model	SRR60ZM-S
Power source				1 Phase, 220–240 V, 50Hz
Operation data	Nominal cooling capacity (range)		kW	6.0
	Nominal heating capacity (range)		kW	6.8
	Sound power level	Cooling	dB(A)	60
		Heating		63
	Sound pressure level ①	Cooling		Hi: 44 Me: 38 Lo: 35 ULo: 30
		Heating		Hi: 45 Me: 41 Lo: 38 ULo: 33
	Sound pressure level ②	Cooling		Hi: 37 Me: 34 Lo: 32 ULo: 27
		Heating		Hi: 39 Me: 37 Lo: 34 ULo: 29
	Sound pressure level ③	Cooling		Hi: 42 Me: 39 Lo: 36 ULo: 30
Heating		Hi: 47 Me: 44 Lo: 41 ULo: 35		
Silent mode sound pressure level				—
Exterior dimensions (Height x Width x Depth)			mm	200 x 950 x 500
Exterior appearance ( Munsell color )				—
Net weight			kg	24
Heat exchanger				Louver fins & inner grooved tubing
Fan type & Q'ty				Centrifugal fan x 3
Fan motor (Starting method)			W	85 x1 (Direct drive)
Air flow	Cooling	m <sup>3</sup> /min		Hi: 14.5 Me: 11.5 Lo: 10.5 ULo: 8.0
	Heating		Hi: 15.0 Me: 13.0 Lo: 11.5 ULo: 9.0	
Available external static pressure			Pa	50 (Initial static pressure with air filter:5Pa)
Outside air intake				Not possible
Air filter, Quality / Quantity				Polypropylene net x 1
Shock & vibration absorber				Cushion rubber (for fan motor)
Operation control	Remote control			Wireless remote control
	Room temperature control			Microcomputer thermostat
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, ECONO: Green
Safety equipments				Drain error protection, Frost protection, Serial signal error protection, Indoor fan motor error protection
Installation data	Refrigerant piping size ( O.D )		mm	Liquid line: ϕ6.35 ( 1/4" ) Gas line: ϕ12.7 ( 1/2" )
	Connecting method			Flare connection
	Insulation for piping			Necessary (Both sides), independent
	Drain hose			Hose connectable ( VP 25 )
Drain pump, max lift height			mm	Built-in, MAX600
Interconnecting wires	Size x Core number			1.5mm <sup>2</sup> x 4 cores ( Including earth cable ) / Terminal block ( Screw fixing type )
IP number				IPX0
Standard accessories				Mounting kit, Joint for drain piping
Option parts				Wired remote control, Interface kit ( SC-BIKN-E ), Bottom air inlet kit

Note (1) The data are measured at the following conditions.


Operation \ Item	Indoor air temperature		Outdoor air temperature		Standards	Note
	DB	WB	DB	WB		
	Cooling	27°C	19°C	35°C		
Heating	20°C	—	7°C	6°C	ISO5151-T1	Non-duct (with air filter)

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.

The pipe length is 5m.

(4) Mike positions of measuring sound pressure level of indoor unit is shown below.



External static pressure for ②, ③ : 10Pa

RWA000Z263

## (4) 4way ceiling cassette type (FDTC)

Adapted to RoHS directive

Model		FDTC25VF	
Item		Panel TC-PSA-25W-E	
Power source		1 Phase, 220~240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	2.5	3.4
Sound power level	dB(A)	Cooling : 56 Heating : 56	
Sound pressure level		Cooling P-Hi : 38 Hi : 36 Me : 32 Lo : 29 Heating P-Hi : 39 Hi : 38 Me : 33 Lo : 29.5	
Exterior dimensions Height x Width x Depth	mm	Unit 248 × 570 × 570 Panel 35 × 700 × 700	
Exterior appearance (Munsell color)		Plaster white (6.8Y8.9/0.2) near equivalent	
Net weight	kg	UNIT 15 PANEL 3.5	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Turbo fan × 1	
Motor <Starting method>	W	33 < Direct line start >	
Air flow (Standard)	m <sup>3</sup> /min	Cooling P-Hi : 10 Hi : 9 Me : 8 Lo : 6.5 Heating P-Hi : 10.5 Hi : 9.5 Me : 8.5 Lo : 7	
Available external static pressure	Pa	0	
Outdoor air intake		Not possible	
Air filter, Q'ty		Pocket plastic net × 1 (Washable)	
Shock & vibration absorber		Rubber sleeve (for fan motor)	
Insulation (Noise & heat)		Polyurethane form	
Remote control		Wired : RC-E5, RC-EX1A (option) Wireless : RCN-TC-24W-ER (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Overload protection for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line : φ 6.35 (1/4")	
		Gas line : φ 9.52 (3/8")	
Connecting method		Flare piping	
Drain pump		Built-in Drain pump	
Drain		Hose connectable with VP20	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Mounting kit, Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.

(5) When wireless remote control is used, fan is 3 speed setting(Hi-Me-Lo) only.

Adapted to RoHS directive

Model		FDTC35VF	
Item		Panel TC-PSA-25W-E	
Power source		1 Phase, 220-240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	3.5	4.5
Sound power level	dB(A)	Cooling : 58 Heating : 58	
Sound pressure level		Cooling P-Hi : 41 Hi : 40 Me : 36 Lo : 30 Heating P-Hi : 43 Hi : 42 Me : 35 Lo : 32	
Exterior dimensions Height x Width x Depth	mm	Unit 248 × 570 × 570 Panel 35 × 700 × 700	
Exterior appearance (Munsell color)		Plaster white (6.8Y8.9/0.2) near equivalent	
Net weight	kg	UNIT 15 PANEL 3.5	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Turbo fan × 1	
Motor <Starting method>	W	33 < Direct line start >	
Air flow (Standard)	m <sup>3</sup> /min	Cooling P-Hi : 11 Hi : 9.5 Me : 9 Lo : 7 Heating P-Hi : 11.5 Hi : 10.0 Me : 9 Lo : 8	
Available external static pressure	Pa	0	
Outdoor air intake		Not possible	
Air filter, Q'ty		Pocket plastic net × 1 (Washable)	
Shock & vibration absorber		Rubber sleeve (for fan motor)	
Insulation (Noise & heat)		Polyurethane form	
Remote control		Wired : RC-E5, RC-EX1A (option) Wireless : RCN-TC-24W-ER (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Overload protection for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line : $\phi$ 6.35 (1/4") Gas line : $\phi$ 9.52 (3/8")	
Connecting method		Flare piping	
Drain pump		Built-in Drain pump	
Drain		Hose connectable with VP20	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Mounting kit, Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.


Item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.

(5) When wireless remote control is used, fan is 3 speed setting(Hi-Me-Lo) only.

RWA000Z234 

Adapted to **RoHS** directive

Model		FDTC50VF	
Item		Panel TC-PSA-25W-E	
Power source		1 Phase, 220-240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	5.0	5.8
Sound power level	dB(A)	Cooling : 60 Heating : 60	
Sound pressure level		Cooling P-Hi : 47 Hi : 42 Me : 36 Lo : 30 Heating P-Hi : 47 Hi : 42 Me : 36 Lo : 32	
Exterior dimensions Height x Width x Depth	mm	Unit 248 × 570 × 570 Panel 35 × 700 × 700	
Exterior appearance (Munsell color)		Plaster white (6.8Y8.9/0.2) near equivalent	
Net weight	kg	UNIT 15 PANEL 3.5	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Turbo fan × 1	
Motor <Starting method>	W	33 < Direct line start >	
Air flow (Standard)	m <sup>3</sup> /min	Cooling P-Hi : 13.5 Hi : 11.5 Me : 9 Lo : 7 Heating P-Hi : 13.5 Hi : 11.5 Me : 9 Lo : 8	
Available external static pressure	Pa	0	
Outdoor air intake		Not possible	
Air filter, Q'ty		Pocket plastic net × 1 (Washable)	
Shock & vibration absorber		Rubber sleeve (for fan motor)	
Insulation (Noise & heat)		Polyurethane form	
Remote control		Wired : RC-E5, RC-EX1A (option) Wireless : RCN-TC-24W-ER (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Overload protection for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line : $\phi$ 6.35 (1/4") Gas line : $\phi$ 12.7 (1/2")	
Connecting method		Flare piping	
Drain pump		Built-in Drain pump	
Drain		Hose connectable with VP20	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Mounting kit, Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.

(5) When wireless remote control is used, fan is 3 speed setting(Hi-Me-Lo) only.

Adapted to RoHS directive

Model		FDTC60VF	
Item		Panel TC-PSA-25W-E	
Power source		1 Phase, 220-240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	6.0	6.8
Sound power level	dB(A)	Cooling : 60 Heating : 60	
Sound Pressure Level		Cooling P-Hi : 47 Hi : 46 Me : 39 Lo : 30 Heating P-Hi : 47 Hi : 46 Me : 39 Lo : 32	
Exterior dimensions Height x Width x Depth	mm	Unit 248 × 570 × 570 Panel 35 × 700 × 700	
Exterior appearance (Munsell color)		Plaster white (6.8Y8.9/0.2) near equivalent	
Net weight	kg	UNIT 15 PANEL 3.5	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Turbo fan × 1	
Motor <Starting method>	W	33 < Direct line start >	
Air flow (Standard)	m³/min	Cooling P-Hi : 13.5 Hi : 13.5 Me : 10 Lo : 7 Heating P-Hi : 13.5 Hi : 13.5 Me : 10 Lo : 8	
Available external static pressure	Pa	0	
Outdoor air intake		Not possible	
Air filter, Q'ty		Pocket plastic net × 1 (Washable)	
Shock & vibration absorber		Rubber sleeve (for fan motor)	
Insulation (Noise & heat)		Polyurethane form	
Remote control		Wired : RC-E5, RC-EX1A (option) Wireless : RCN-TC-24W-ER (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Overload protection for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line : $\phi$ 6.35 (1/4") Gas line : $\phi$ 12.7 (1/2")	
Connecting method		Flare piping	
Drain pump		Built-in Drain pump	
Drain		Hose connectable with VP20	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Mounting kit, Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.

(5) When wireless remote control is used, fan is 3 speed setting(Hi-Me-Lo) only.

## (5) Ceiling suspended type (FDEN)

Adapted to RoHS directive

Model		FDEN50VF	
Item			
Power source		1 Phase, 220–240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	5.0	5.8
Sound power level	dB(A)	60	
Sound pressure level		P-Hi : 46 Hi : 39 Me : 38 Lo : 37	
Exterior dimensions Height x Width x Depth	mm	210 × 1,070 × 690	
Exterior appearance (Munsell color)		Plaster white (6.8Y8.9/0.2) near equivalent	
Net weight	kg	28	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Centrifugal fan × 2	
Motor <Starting method>	W	25 < Direct line start >	
Air flow (Standard)	m <sup>3</sup> /min	P-Hi : 11 Hi : 10 Me : 9 Lo : 7	
Available external static pressure	Pa	0	
Outdoor air intake		Not possible	
Air filter, Q'ty		Pocket plastic net × 2 (Washable)	
Shock & vibration absorber		Rubber sleeve(for fan motor)	
Insulation (Noise & heat)		Polyurethane foam	
Remote control		wired : RC-E5, RC-EX1A (option) wireless : RCN-E1R (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Internal thermostat for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line: φ 6.35 (1/4")	
		Gas line: φ 12.7 (1/2")	
Connecting method		Flare piping	
Drain pump		—	
Drain		Hose connectable with VP20	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Mounting kit, Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.

(5) When wireless remote control is used, fan is 3 speed setting(Hi-Me-Lo) only.

**(6) Duct connected Low/Middle static pressure type (FDUM)**Adapted to **RoHS** directive

Model		FDUM50VF	
Power source		1 Phase, 220–240V, 50Hz	
Operation data		Cooling	Heating
Nominal capacity (1)	kW	5.0	5.8
Sound power level	dB(A)	60	
Sound pressure level		P-Hi : 37 Hi : 32 Me : 29 Lo : 26	
Exterior dimensions Height x Width x Depth	mm	280 x 750 x 635	
Exterior appearance (Munsell color)		—	
Net weight	kg	29	
Heat exchanger		Louver fin & inner grooved tubing	
Air handling equipment Fan type & Q'ty		Centrifugal fan x 1	
Motor <Starting method>	W	100 < Direct line start >	
Air flow (Standard)	m <sup>3</sup> /min	P-Hi : 13 Hi : 10 Me : 9 Lo : 8	
Available external static pressure	Pa	Standard:35 Max:100	
Outside air intake		Possible	
Air filter, Q'ty		Procure locally	
Shock & vibration absorber		Rubber sleeve(for fan motor)	
Insulation (Noise & heat)		Polyurethane form	
Remote control		Wired : RC-E5, RC-EX1A (option) Wireless : RCN-KIT3-E (option)	
Room temperature control		Thermostat by electronics	
Safety equipment		Overload protection for fan motor Frost protection thermostat	
Installation data Refrigerant piping size	mm	Liquid line: I/U $\phi$ 6.35 (1/4")	
		Gas line: $\phi$ 12.7 (1/2")	
Connecting method		Flare piping	
Drain pump		Built-in Drain pump	
Drain		Hose connectable with VP25	
Insulation for piping		Necessary (both Liquid & Gas lines)	
IP number		IPX0	
Standard accessories		Drain hose	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item	Indoor air temperature		Outdoor air temperature		External static pressure of indoor unit	Standards
	DB	WB	DB	WB		
Cooling	27°C	19°C	35°C	24°C	35Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		

(2) This packaged air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound pressure level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient temperature.

(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz.



(5) Static pressure of optional air filter "UM-FL1EF" is 5Pa initially.

(6) If wireless remote control is used, only 3-speed fan setting (Hi-Me-Lo) is available.

**(1) Wall mounted type (SRK)**

Unit:mm


Technical drawing of the front view of the terminal block. Dimensions include a total width of 220 mm, a mounting tab width of 3 mm, a mounting tab height of 61.5 mm, a main body height of 46.5 mm, and a lower body dimension of 61.5 mm. A label 'Terminal block' points to the main body.




Unit:mm




RLA000Z054




Symbol	Content	
A	Gas piping	Model 20, 25, 35 : $\phi 9.52$ (3/8") (Flare) 50 : $\phi 12.7$ (1/2") (Flare)
B	Liquid piping	$\phi 6.35$ (1/4") (Flare)
C	Hole on wall for right rear piping	( $\phi 65$ )
D	Hole on wall for left rear piping	( $\phi 65$ )
E	Drain hose	VP16
F	Outlet for wiring	
G	Outlet for piping (on both side)	



Wireless remote control






Wired remote control  
(Option)



Notes (1) The model name label is attached on the underside of the panel.  
(2) It takes the interface kit (SC-BIKN-E) to connect the wired remote control.  
Unit:mm


Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S

RLD0000Z002




Space for installation and service when viewing from the front


Symbol	Content	
A	Gas piping	φ 15.88 (5/8") (Flare)
B	Liquid piping	φ 6.35 (1/4") (Flare)
C	Hole on wall for right rear piping	(φ 65)
D	Hole on wall for left rear piping	(φ 65)
E	Drain hose	VP16
F	Outlet for wiring (on both side)	
G	Outlet for piping (on both side)	



Wireless remote control



Wired remote control  
(Option)



Note (1) The model name label is attached on the underside of the indoor unit.


Unit:mm

Model SRK71ZR-S


RFB000Z006

### (3) Ceiling concealed type (SRR)

#### Models SRR25ZM-S, 35ZM-S




#### Space for installation and service




RJJ000Z001

# Models SRR50ZM-S, 60ZM-S



- Notes (1) The model name label is attached on the lid of the control box.  
(2) It takes the interface kit (SC-BIKN-E) to connect the wired remote control.


## Space for installation and service




RJJ000Z002

(4) 4way ceiling cassette type (FDTC)  
Models FDTC25VF, 35VF, 50VF, 60VF





Symbol	Content	
A	Gas piping	Model 25,35 : $\phi 9.52(3/8")$ (Flare)
		50,60 : $\phi 12.7(1/2")$ (Flare)
B	Liquid piping	$\phi 6.35(1/4")$ (Flare)
C	Drain piping	VP20 (I.D.20,O.D.26) Note (2)
D	Hole for wiring	$\phi 25$
F	Suspension bolts	(M10 or M8)
G	Ducting for air outlet	(Knock out)




Make a space of 4000 or more between the units when installing more than one.



Unit:mm




- Notes (1) The model name label is attached on the control box lid.  
(2) Prepare the connecting socket (VP20) on site.  
(3) This unit is designed for 2x2 grid ceiling.  
If it is installed on a ceiling other than 2x2 grid ceiling,  
provide an inspection port on the control box side.



PJA003Z338

(5) Ceiling suspended type (FDEN)  
Model FDEN50VF



PFA003Z816/A




(7) Remote control


(a) Wireless remote control

Models SRK, SRF, SRR

(Typical example)




Models FDTC, FDEN, FDUM (Option parts)






**Model RC-EX1A**

Dimensions (Viewed from front)



Exterior appearance (Munsell color)	Pearl White (N8.5) near equivalent
--	---------------------------------------

**Installation space****Cautions for selecting installation place**

- (1) Installation surface must be flat and sufficiently strong.  
R/C case must not be deformed.
- (2) Where the R/C can detect room temperatures accurately  
This is a must when detecting room temperatures with the temperature sensor of R/C.
  - Install the R/C where it can detect the average temperature in the room.
  - Install the R/C sufficiently separated from a heat source.
  - Install the R/C where it will not be influenced by the turbulence of air when the door is opened or closed.
 Select a place where the R/C is not exposed to direct sunlight or blown by winds from the air-conditioner or temperatures on the wall surface will not deviate largely from indoor air temperatures.

**R/C cable: 0.3mm<sup>2</sup> × 2-core**

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm<sup>2</sup>. Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

< 200 m	0.5 mm <sup>2</sup> × 2-core
< 300 m	0.75 mm <sup>2</sup> × 2-core
< 400 m	1.25 mm <sup>2</sup> × 2-core
< 600 m	2.0 mm <sup>2</sup> × 2-core

Adapted to **RoHS** directive


**(1) Wall mounted type (SRK)**

Item	Description
CNE-CNY	Connector
FM <sub>i</sub>	Fan motor
SM	Flap motor
LM <sub>1,2</sub>	Louver motor
IM	Inlet motor
Th1	Room temp. sensor
Th2 <sub>1,2</sub>	Heat exchanger sensor
Th3	Humidity sensor (50, 60 only)
LS	Limit switch
DS	Diode stack
F	Fuse
T	Terminal block
Va	Varistor

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green



RWA000Z257




Item	Description
CNE-CNY	Connector
FM <sub>i</sub>	Fan motor
SM <sub>i</sub>	Flap motor
LM <sub>1,2</sub>	Louver motor
HD	Humidity sensor
Th <sub>1</sub>	Room temp. sensor
Th <sub>2,3</sub>	Heat exchanger sensor
DS	Diode stack
F	Fuse
T	Terminal block
Va	Varistor

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green

Power source  
1 Phase  
AC220-240V 50Hz

Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S

RWA0000Z406



Item	Description
CNE	Connector
CNF	
CNG	
CNM	
CNS	
CNU	
CNX	
CNY	
FM <sub>i</sub>	Fan motor
SM <sub>1</sub>	Flap motor
LM <sub>1,2</sub>	Louver motor
Th1	Room temp. sensor
Th2 <sub>1,2</sub>	Heat exchanger sensor
Th3	Humidity sensor
DS	Diode stack
F	Fuse
TB	Terminal block
Va	Varistor

Color Marks	
Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow / Green


Model SRK71ZR-S

(2) Floor standing type (SRF)  
Models SRF25ZMX-S, 35ZMX-S, 50ZMX-S

Item	Description
CNE-CN2	Connector
FM <sub>1</sub>	Fan motor
SM <sub>1,2</sub>	Flap motor
DM <sub>1</sub>	Damper motor
DM <sub>2</sub>	Damper arm motor
Th <sub>1</sub>	Room temp. sensor
Th <sub>2,1,2</sub>	Heat exchanger sensor
Th <sub>3</sub>	Humidity sensor
DS	Diode stack
F	Fuse
T	Terminal block
Va	Varistor

Color Marks

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green



RWB000Z057


(3) Ceiling concealed type (SRR)  
Models SRR25ZM-S, 35ZM-S, 50ZM-S, 60ZM-S

Item	Description
CNE	Connector
CNG	
CNS	
CNU	
CNW	
CNY	
FM <sub>i</sub>	Fan motor
Th1	Room temp. sensor
Th2 <sub>1,2</sub>	Heat exchanger sensor
DS	Diode stack
F <sub>1,2</sub>	Fuse
TB	Terminal block
DM	Drain motor
FS	Float switch
Va	Varistor

Color Marks

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green

Power source  
1 Phase  
AC220/230/240V 50Hz



RJ0000Z003

CNB-Z	Connector
DM	Drain motor
F200-203	Fuse
FM i	Fan motor
FS	Float switch
LED-2	Indication lamp (Green-Normal operation)


LED-3	Indication lamp (Red-Inspection)
LM1-4	Louver motor
SW2	Remote control communication address
SW5	Plural units Master / Slave setting
SW6	Model capacity setting
SW7-1	Operation check, Drain motor test run


TB1	Terminal block (Power source) (□ mark)
TB2	Terminal block (Signal line) (□ mark)
Thc	Thermistor (Remote control)
Th-A	Thermistor (Return air)
Th-R1,2,3	Thermistor (Heat exchanger)
X4	Relay for DM
■ mark	Closed-end connector

#### Color Marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
OR	Orange
RD	Red
WH	White
Y	Yellow
Y / GN	Yellow / Green

#### (4) 4way ceiling cassette type (FDTC) Models FDT25VF, 35VF, 50VF, 60VF





- Notes 1. --- indicates wiring on site.  
2. See the wiring diagram of outside unit about the line between indoor unit and outdoor unit.  
3. Use twin core cable (0.3mm<sup>2</sup>) at remote control line.  
4. Do not put remote control line alongside power source line.

CFI 1	Capacitor for FMI
CNB-Z	Connector
F	Fuse
FMI 1	Fan motor (with thermostat)
LED・2	Indication lamp (Green-Normal operation)
LED・3	Indication lamp (Red-Inspection)
LM	Louwer motor
SW2	Remote control communication address
SW5	Plural units Master/Slave setting
SW6	Model capacity setting
SW7-1	Operation check, Drain motor test run
TB1	Terminal block (Power source) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Thermistor (Remote control)
Thl-A	Thermistor (Return air)
Thl-R1,2,3	Thermistor (Heat exchanger)
Trl	Transformer
X1-3,6	Relay for FM
X4	Relay for DM


※When wired remote control are used only (wireless type)  
It is necessary to remove the line that is connected to the receiver.  
Remove signal line connected to the receiver from primary side of terminal block (X,Y).

## ATTENTION

- ① Insulate with tape the removed line.
- ② The LED of that removed connector will not be able to make any indication.

### Color Marks

Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
BR	Brown	Y	Yellow
OR	Orange	Y/GN	Yellow/Green
P	Pink		



- Notes
1. --- indicates wiring on site.
  2. See the wiring diagram of outside unit about the line between inside unit and outside unit.
  3. Use twin core cable (0.3mm<sup>2</sup> x2) at remote control line.
  4. Do not put remote control line alongside power source line.

(6) Duct connected Low/Middle static pressure type (FDUM)  
Model FDUM50VF

CNB-Z	Connector
DM	Drain motor
F1~3	Fuse
FM1	Fan motor (with thermostat)
FS	Float switch
L	Reactor
LED-E2	Indication lamp (Green-Normal operation)
LED-E3	Indication lamp (Red-Inspection)
SW2	Remote control communication address
SW5	Plural units Master/Slave setting
SW6	Model capacity setting
SW7-1	Operation check, Drain motor test run
SW7-3	Powerful mode Valid/Invalid
TB1	Terminal block (Power) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Thermistor (Remote control)
Th-A	Thermistor (Return air)
Th-R1,2,3	Thermistor (Heat exchanger)
■ mark	Closed-end connector

Color Marks

Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
BR	Brown	YE	Yellow
OR	Orange	YE/GN	Yellow/Green

## 2.4 Noise level

### (1) Wall mounted type (SRK)

#### Model SRK20ZMX-S


Noise Level	Cooling	39 dB(A)
	Heating	38 dB(A)

Condition	ISO-T1,JIS C 9612
-----------	-------------------

●Mike position



× ..... Cooling, ○ — Heating



#### Model SRK25ZMX-S


Noise Level	Cooling	41 dB(A)
	Heating	41 dB(A)

Condition	ISO-T1,JIS C 9612
-----------	-------------------

●Mike position



× ..... Cooling, ○ — Heating



**Model SRK35ZMX-S**


Noise	Cooling	43 dB(A)
Level	Heating	42 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position




× ..... Cooling, ○ — Heating

**Model SRK50ZMX-S**


Noise	Cooling	47 dB(A)
Level	Heating	48 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



× ..... Cooling, ○ — Heating




**Model SRK60ZMX-S**


Condition ISO-T1, JIS C 9612

Noise Level	Cooling	51 dB(A)
	Heating	48 dB(A)

●Mike position




× ..... Cooling, ○ — Heating

**Model SRK20ZM-S**


Condition ISO-T1, JIS C 9612

Noise Level	Cooling	33 dB(A)
	Heating	36 dB(A)

●Mike position



× ..... Cooling ○ — Heating




**Model SRK25ZM-S**


Noise	Cooling	34 dB(A)
Level	Heating	39 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



× ..... Cooling ○ — Heating

**Model SRK35ZM-S**


Model	SRK35ZM-S	
Noise	Cooling	42 dB(A)
Level	Heating	43 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



× ..... Cooling ○ — Heating



### Model SRK50ZM-S


Noise	Cooling	46 dB(A)
Level	Heating	45 dB(A)

Condition	ISO-T1,JIS C 9612
-----------	-------------------

●Mike position



× ..... Cooling ○ — Heating



### Model SRK71ZR-S


Noise	Cooling	44 dB(A)
Level	Heating	46 dB(A)

Condition	ISO5151-T1
-----------	------------

●Mike position



× ..... Cooling ○ — Heating




## (2) Floor standing type (SRF)

## Model SRF25ZMX-S


Noise	Cooling	40 dB(A)
Level	Heating	40 dB(A)

Condition ISO-T1, JIS C 9612

●Mike position



× ..... Cooling, ○ — Heating




## Model SRF35ZMX-S


Noise	Cooling	41 dB(A)
Level	Heating	41 dB(A)

Condition ISO-T1, JIS C 9612

●Mike position



× ..... Cooling, ○ — Heating



**Model SRF50ZMX-S**


Condition ISO-T1, JIS C 9612

Noise Level	Cooling	46 dB(A)
	Heating	47 dB(A)

●Mike position



× ..... Cooling, ○ — Heating


**(3) Ceiling concealed type (SRR)****Model SRR25ZM-S**

• Sound pressure level ①


Condition ISO5151-T1, JIS C 9612

Noise Level	Cooling	37 dB(A)
	Heating	40 dB(A)

●Mike position



× ..... Cooling, ○ — Heating




• Sound pressure level ②

Noise Level	Cooling	31 dB(A)
	Heating	33 dB(A)


Condition	ISO5151-T1, JIS C 9612
-----------	------------------------

●Mike position



External static pressure : 10Pa

× ..... Cooling, ○ — Heating




• Sound pressure level ③

Noise Level	Cooling	39 dB(A)
	Heating	40 dB(A)


Condition	ISO5151-T1, JIS C 9612
-----------	------------------------

●Mike position



External static pressure : 10Pa

× ..... Cooling, ○ — Heating





**Model SRR35ZM-S****• Sound pressure level ①**

Noise Level	Cooling	38 dB(A)
	Heating	42 dB(A)

Condition ISO5151-T1, JIS C 9612


## ●Mike position

**• Sound pressure level ②**


Noise Level	Cooling	33 dB(A)
	Heating	34 dB(A)

Condition ISO5151-T1, JIS C 9612

## ●Mike position



External static pressure : 10Pa




• Sound pressure level ③


Noise Level	Cooling	40 dB(A)
	Heating	45 dB(A)

Condition	ISO5151-T1, JIS C 9612
-----------	------------------------

●Mike position



× ..... Cooling, ○ — Heating




Model SRR50ZM-S

• Sound pressure level ①


Noise Level	Cooling	41 dB(A)
	Heating	43 dB(A)

Condition	ISO5151-T1, JIS C 9612
-----------	------------------------

●Mike position



× ..... Cooling, ○ — Heating




## • Sound pressure level ②

Noise Level	Cooling	35 dB(A)
	Heating	38 dB(A)


Condition ISO5151-T1, JIS C 9612

## ●Mike position



External static pressure : 10Pa

× ..... Cooling, ○ — Heating




## • Sound pressure level ③

Noise Level	Cooling	41 dB(A)
	Heating	46 dB(A)


Condition ISO5151-T1, JIS C 9612

## ●Mike position



External static pressure : 10Pa

× ..... Cooling, ○ — Heating





**Model SRR60ZM-S****• Sound pressure level ①**

Noise Level	Cooling	44 dB(A)
	Heating	45 dB(A)

Condition ISO5151-T1, JIS C 9612


●Mike position

**• Sound pressure level ②**


Noise Level	Cooling	37 dB(A)
	Heating	39 dB(A)

Condition ISO5151-T1, JIS C 9612

●Mike position



External static pressure : 10Pa




## • Sound pressure level ③


Noise Level	Cooling	42 dB(A)
	Heating	47 dB(A)

Condition	ISO5151-T1, JIS C 9612
-----------	------------------------

●Mike position



× ..... Cooling, ○ — Heating




## (4) 4way ceiling cassette type (FDTC)

Model FDTC25VF


Noise Level	Cooling	38 dB(A)
	Heating	39 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



× ..... Cooling, ○ — Heating



**Model FDTC35VF**

Noise	Cooling	41 dB(A)
Level	Heating	43 dB(A)


Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



1.5m  
 Mike position  
 (Center & below unit)


× ..... Cooling, ○ — Heating

**Model FDTC50VF**

Noise	Cooling	47 dB(A)
Level	Heating	47 dB(A)


Condition	ISO-T1, JIS B 8616
-----------	--------------------

●Mike position



1.5m  
 Mike position  
 (Center & below unit)

× ..... Cooling, ○ — Heating



**Model FDTC60VF**


Noise	Cooling	47 dB(A)
Level	Heating	47 dB(A)

Condition	ISO-T1, JIS B 8616
-----------	--------------------

●Mike position

Mike position  
(Center & below unit)


× ..... Cooling, ○ — Heating

**(5) Ceiling suspended type (FDEN)**  
**Model FDEN50VF**


Noise	Cooling	46 dB(A)
Level	Heating	46 dB(A)

Condition	ISO-T1, JIS B 8616
-----------	--------------------

●Mike position

Mike position  
(Front & low points)

× ..... Cooling, ○ — Heating





(6) Duct connected Low/Middle static pressure type (FDUM)

Model FDUM50VF

Noise	Cooling	37 dB(A)
Level	Heating	37 dB(A)

Condition	ISO-T1, JIS B 8616
-----------	--------------------

●Mike position




## 2.5 Characteristics of fan


### (1) Ceiling concealed type (SRR)

#### Model SRR25ZM-S

Cooling




Heating




#### Model SRR35ZM-S

Cooling




Heating




#### Model SRR50ZM-S

Cooling




Heating




#### Model SRR60ZM-S

Cooling



Heating





**(2) Duct connected Low/Middle static pressure type (FDUM)**

- Characteristic FAN (1) shows air flow vs. External Static Pressure (E.S.P.) range where settings of E.S.P. are maximum E.S.P. (100Pa), rated E.S.P., and minimum E.S.P. (10Pa).
- Characteristic FAN (2) shows air flow vs. E.S.P. curve when set fan tap is set P-Hi with each setting of E.S.P. by wired remote control.
- External Static Pressure (E.S.P.) can be set by wired remote control.
- You can set required E.S.P. by wired remote control which calculate it with the set air flow rate and pressure loss of the duct connected.

**Model FDUM50VF****Characteristic FAN(1)**

--- In case actual E.S.P. correspond to setting of E.S.P.

**Characteristic FAN(2)**

## 2.6 Application data

RKY012A011A

### (1) Wall mounted type (SRK)

#### (a) Models SRK20ZMX-S, 25ZMX-S, 35ZMX-S, 50ZMX-S, 60ZMX-S

- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, please see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, please refer to page 30.



- A wired remote control unit is supplied separately as an option part.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.

### SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
  - The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚠ CAUTION**.  
**⚠ WARNING** : Wrong installation would cause serious consequences such as injuries or death.  
**⚠ CAUTION** : Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, gloves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:

	Never do it under any circumstances.		Always do it according to the instruction.
---	--------------------------------------	---	--

<b>⚠ WARNING</b>	
	<p>• <b>Installation must be carried out by the qualified installer.</b> If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</p> <p>• <b>Install the system in full accordance with the installation manual.</b> Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</p> <p>• <b>Be sure to use only for household and residence.</b> If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</p> <p>• <b>Use the original accessories and the specified components for installation.</b> If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</p> <p>• <b>Install the unit in a location with good support.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</p> <p>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b> If the refrigerant comes into contact with naked flames, poisonous gas is produced.</p> <p>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b> If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</p> <p>• <b>After completed installation, check that no refrigerant leaks from the system.</b> If refrigerant leaks into the room and comes into contact with an open or other hot surface, poisonous gas is produced.</p> <p>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b> Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</p>
	<p>• <b>Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.</b> Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.</p> <p>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b> If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</p>
	<p>• <b>Tighten the flare nut by torque wrench with specified method.</b> If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</p> <p>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b> Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</p> <p>• <b>Be sure to shut off the power before starting electrical work.</b> Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</p> <p>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b> Unconformable cables can cause electric leak, anomalous heat production or fire.</p> <p>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm.</b></p> <p>• <b>When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.</b></p> <p>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b> Loose connections or cable mountings can cause anomalous heat production or fire.</p> <p>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b> Incorrect installation may result in overheating and fire.</p> <p>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b> If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</p> <p>• <b>Be sure to wear protective goggles and gloves while at work.</b></p> <p>• <b>Earth leakage breaker must be installed.</b> If the earth leakage breaker is not installed, it can cause electric shocks.</p>

<b>⚠ WARNING</b>	
	<p>• <b>Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.</b></p> <p>• <b>Do not run the unit with removed panels or protections.</b> Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</p>
	<p>• <b>Do not perform any change of protective device itself or its setup condition.</b> The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</p>
<b>⚠ CAUTION</b>	
	<p>• <b>Carry out the electrical work for ground lead with care.</b> Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</p>
	<p>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b> Using the incorrect one could cause the system failure and fire.</p> <p>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b> The isolator should be locked in OFF state in accordance with EN60204-1.</p> <p>• <b>Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly.</b> Improper installation of indoor unit can cause dropping water into the room and damaging personal property.</p> <p>• <b>Install the drainage pipe to run off drainage securely according to the installation manual.</b> Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.</p> <p>• <b>Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings.</b> Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.</p> <p>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b> Insufficient space can result in accident such as personal injury due to</p>
	<p>• <b>Do not install the unit in the locations listed below.</b></p> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p> <p>• <b>Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).</b></p> <ul style="list-style-type: none"> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where vibration can be amplified due to insufficient strength of structure.</li> <li>• Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).</li> <li>• Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).</li> <li>• Locations where drainage cannot run off safely.</li> </ul> <p>It can affect performance or function and etc.</p> <p>• <b>Do not install the unit near the location where leakage of combustible gases can occur.</b> If leaked gases accumulate around the unit, it can cause fire.</p> <p>• <b>Do not install the unit where corrosive gas (such as sulphurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.</b> Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</p> <p>• <b>Do not use the indoor unit at the place where water splashes may occur such as in laundries.</b> Since the indoor unit is not waterproof, it can cause electric shocks and fire.</p> <p>• <b>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</b> Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.</p> <p>• <b>Do not place any variables which will be damaged by getting wet under the indoor unit.</b> When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.</p> <p>• <b>Do not install the remote control at the direct sunlight.</b> It can cause malfunction or deformation of the remote control.</p> <p>• <b>Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.</b> It can cause the damage of the items.</p> <p>• <b>Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.</b> Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.</p> <p>• <b>Do not touch any buttons with wet hands.</b> It can cause electric shocks.</p> <p>• <b>Do not touch any refrigerant pipes with your hands when the system is in operation.</b> During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.</p>

## BEFORE INSTALLATION

- Before installation check that the power source matches the air-conditioner.

Standard accessories (Installation kit) Accessories for indoor unit		Q'ty
①	Installation board (Attached to the rear of the indoor unit)	1
②	Wireless remote control	1
③	Remote control holder	1
④	Tapping screws (for installation board ø4 X 25mm)	4
⑤	Wood screws (for remote control holder ø3.5 X 16mm)	2
⑥	Battery [R03 (AAA, Micro) 1.5V]	2
⑦	Air-cleaning filters	2
⑧	Filter holders (Attached to the front panel of indoor unit)	2
⑨	Insulation (#486 50 x 100 t3)	1

Option parts		Q'ty
Ⓐ	Sealing plate	1
Ⓑ	Sleeve	1
Ⓒ	Inclination plate	1
Ⓓ	Putty	1
Ⓔ	Drain hose (extension hose)	1
①	Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
1	Plus headed driver
2	Knife
3	Saw
4	Tape measure
5	Hammer
6	Spanner wrench
7	Torque wrench (14.0 ~ 61.0N·m (1.4 ~ 6.1kgf·m))
8	Hole core drill (65mm in diameter)
9	Wrench key (Hexagon) [4m/m]
10	Flaring tool set (Designed specifically for R410A)
11	Gas leak detector (Designed specifically for R410A)
12	Gauge for projection adjustment (Used when flare is made by using conventional flare tool)
13	Pipe bender

## SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

### Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.
- Install the indoor unit on the wall where the height from the floor is more than 1.8m.


### Wireless remote control

- A place where the air-conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.




## INSTALLATION OF INDOOR UNIT

### Installation of installation board

Look for the inside wall structures (Intermediates support or pillar and firmly install the unit after level surface has been checked.)




- Adjustment of the installation board in the horizontal direction is to be conducted with four screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.



### Drilling of holes and fixture of sleeve (Option parts)

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.




- Drill a hole with whole core drill.
- In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.

### Installing the support of piping

#### In case of piping in the right rear direction

##### Shaping of pipings




- Hold the bottom of the piping and fix direction before stretching it and shaping it.
- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.

Sufficient care must be taken not to damage the panel when connecting pipes.


#### Matters of special notice when piping from left or central/rear of the unit.

##### [Top view]


##### Left-hand-side piping




- Piping is possible in the rear, left rear, left downward, right or downward direction.



##### Right-hand-side piping




- Piping is possible in the rear, right rear, right downward, left or downward direction.



### CAUTION

Completely seal the hole on the wall with putty. Otherwise, furniture, or other, may be wetted by leaked water or dewing.

### Relation between setting plate and indoor unit



### [Drain hose changing procedures]

#### 1. Remove the drain hose



- Remove the screw and drain hose, making it rotate.
- Remove it with hand or pliers.



#### 2. Remove the drain cap.



- Insert the drain cap which was removed at procedure "2" securely using a hexagonal wrench etc.
- Insert the drain hose securely, making rotate. And install the screw.


Note: Be careful that If it is not inserted securely, water leakage may occur.

## Fixing of indoor unit




### • How to remove the indoor unit from the installation board

- 1 Push up at the marked portion of the indoor unit base lower latch, and slightly pull it toward you. (both right and left hand sides) (The indoor unit base lower latch can be removed from the installation board)
- 2 Push up the indoor unit upward. So the indoor unit will be removed from the installation board.




Since this air-conditioner has been designed to collect dew drops on the rear surface to the drain pan, do not attach the power cord above the gutter.



## Drainage

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.

**CAUTION** Go through all installation steps and check if the drainage is all right. Otherwise water leak may occur.




- Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- When the extended drain hose is indoor, securely insulate it with a heat insulator available in the market.

## CONNECTION OF REFRIGERANT PIPINGS

**Preparation** Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.



- Remove the flared nuts. (on both liquid and gas sides)




- Install the removed flared nuts to the pipes to be connected, then flared the pipes.

Dimension A  
Liquid side ø6.35 : 9.1 (mm)  
Gas side ø9.52 : 13.2 (mm)  
ø12.7 : 16.6 (mm)

### CAUTION

Do not apply refrigerating machine oil to the flared surface.


### • Flaring work



Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool Clutch type	Wing nut type
ø6.35	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø9.52	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø12.7	0.0 - 0.5	1.0 - 1.5	2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool.  
Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.  
If a conventional flare tool is used, please use a copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.

## Connection




- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side (ø6.35) : 14.0 - 18.0 N·m (1.4 - 1.8 kgf·m)  
Gas side (ø9.52) : 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m)  
(ø12.7) : 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m)

### CAUTION


Do not apply excess torque to the flared nuts.  
Otherwise, the flared nuts may check depending.

## Insulation of the connection portion

Cover the coupling with insulator and then cover it with tapes.




Use an attached insulation pad for heat insulation.



- Cover the indoor unit's flare-connected joints, after they are checked for a gas leak, with an indoor unit heat insulating material and then wrap them with a tape with an attached insulation pad placed over the heat insulating material's slit area.


## Finishing work and fixing



Cover the exterior portion with outer tape and shape the piping so it will match the contours of the route that the piping to take.  
Also fix the wiring and pipings to the wall with clamps.


## Open/close and detachment/attachment of the air inlet panel

- To open, pull the panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.  
(The panel stops at approx. 60° open position)
- To close, hold the panel at both ends of lower part to lower downward and push it slightly until the latch works.
- To remove, pull up the panel to the position shown in right illustration and pull it toward you.
- To install, insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



## How to remove and fit the front panel

- Removing
  - 1 Remove the air inlet panel.
  - 2 Remove the 5 set screws.
  - 3 Remove the 4 latches in the upper section.
  - 4 Move the lower part of the panel forward and push upwards to remove.
- Fitting
  - 1 Do remove the air filter.
  - 2 Cover the body with the front panel.
  - 3 Fit the 4 latches in the upper section.
  - 4 Tighten the 5 set screws.
  - 5 Fit the air filter.
  - 6 Fit the air inlet panel.



## ELECTRICAL WIRING WORK

### Preparation of indoor unit

#### Mounting of connecting wires

- ① Open the air inlet panel.
- ② Remove the service panel.
- ③ Remove the wiring clamp.
- ④ Connect the connecting wire securely to the terminal block.
  - 1) Connect the connection wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
  - 2) Take care not to confuse the terminal numbers for indoor and outdoor connections.
- ⑤ Fix the connecting wire by wiring clamp.
- ⑥ Attach the service panel.
- ⑦ Close the air inlet panel.

### CAUTION

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires. CENELEC code for cables Required field cables.

H05RN4G1.5 (example) or 245IEC57

H Harmonized cable type

05 300/500 volts

R Natural-and/or synth. rubber wire insulation

N Polychloroprene rubber conductors insulation


R Stranded core

4or5 Number of conductors

G One conductor of the cable is the earth conductor (yellow/green)

1.5 Section of copper wire (mm<sup>2</sup>)


The screw of the service panel is tightened securely.



• Earth wire shall be Yellow/Green (Y/G) in color and longer than other AC wires for safety reason.

### Installing the air-cleaning filters

1. Open the air inlet panel and remove the air filters.
2. Install the air-cleaning filter in the filter holders, and then install the filter holders in the air-conditioner.
  - Each air-cleaning filter can be installed in the left or right filter holder.
3. Install the air filters and close the inlet panel.




## INSTALLATION OF WIRELESS REMOTE CONTROL

### Mounting method of battery

- Uncover the wireless remote control, and mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body regularly. (Fit the poles with the indication marks, ⊕ & ⊖ without fail)


### CAUTION

Do not use new and old batteries together.



### Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.




## INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

When two air-conditioners are installed in the same room, use this setting when the two air-conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.

### Setting the wireless remote control


- ① Pull out the cover and take out batteries.
- ② Disconnect the switching line next to the battery with wire cutters.



- ③ Insert batteries. Close the cover.

### Setting an indoor unit

- ① Turn off the power source, and turn it on after 1 minute.
- ② Point the wireless remote control that was set according to the procedure described on the left side at the indoor unit and send a signal by pressing the ACL switch on the remote control. Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.
- ③ Check that the reception buzzer sound "pip" is emitted from the indoor unit. At completion of the setting, the indoor unit emits a buzzer sound "pip". (If no reception tone is emitted, start the setting from the beginning again.)



## HOW TO RELOCATE OR DISPOSE OF THE UNIT

- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

<How to pump down>

- ① Connect charge hose to check joint of outdoor unit.
- ② Liquid side : Close the liquid valve with hexagon wrench key. Gas side : Fully open the service valve (Gas side). Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the service valve (Gas side).

- Forced cooling operation  
Turn on a power source again after a while after turn off a power source. Then press continually the ON/OFF button 5 seconds or more.



## CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

- ① Remove the front panel and lid of control.
- ② Remove the control.
- ③ There is a terminal (respectively marked with CNS) for the indoor control board. In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".

## INSTALLATION TEST CHECK POINTS

### After installation

- ☐ The power source voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.
- ☐ The screw of the service panel is tightened securely.

- ☐ Service valve is fully open.
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.

### Test run

- ☐ Air-conditioning operation is normal.
- ☐ No abnormal noise.
- ☐ Water drains smoothly.
- ☐ Protective functions are not working.

- ☐ The wireless remote control is normal.
- ☐ Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)

When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

## (b) Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S



- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, please see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, please refer to page 30.

- A wired remote control unit is supplied separately as an option part.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
  - The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚠ CAUTION**.
    - ⚠ WARNING** : Wrong installation would cause serious consequences such as injuries or death.
    - ⚠ CAUTION** : Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, gloves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:



## ⚠ WARNING

- **Installation must be carried out by the qualified installer.**  
If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.
- **Install the system in full accordance with the installation manual.**  
Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.
- **Be sure to use only for household and residence.**  
If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.
- **Use the original accessories and the specified components for installation.**  
If parts other than those prescribed by us are used, It may cause water leaks, electric shocks, fire and personal injury.
- **Install the unit in a location with good support.**  
Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.
- **Ventilate the working area well in the event of refrigerant leakage during installation.**  
If the refrigerant comes into contact with naked flames, poisonous gas is produced.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).**  
If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.
- **After completed installation, check that no refrigerant leaks from the system.**  
If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.
- **Use the prescribed pipes, flare nuts and tools for R410A.**  
Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.
- **Tighten the flare nut by torque wrench with specified method.**  
If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.
- **The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.**  
Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.
- **Be sure to shut off the power before starting electrical work.**  
Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.
- **Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.**  
Unconformable cables can cause electric leak, anomalous heat production or fire.
- **This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm.**
- **When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.**
- **Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.**  
Loose connections or cable mountings can cause anomalous heat production or fire.
- **Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.**  
Incorrect installation may result in overheating and fire.
- **Be sure to switch off the power source in the event of installation, inspection or servicing.**  
If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.
- **Be sure to wear protective goggles and gloves while at work.**
- **Earth leakage breaker must be installed.**  
If the earth leakage breaker is not installed, it can cause electric shocks.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.**  
Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.**  
If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.
- **Do not processing, splice the power cord, or share a socket with other power plugs.**  
This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.
- **Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.**  
This may cause fire or heating.

## ⚠ WARNING

- **Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Groval Warming Potential (GWP)=1975.**
- **Do not run the unit with removed panels or protections.**  
Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.
- **Do not perform any change of protective device itself or its setup condition.**  
The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.

## ⚠ CAUTION

- **Carry out the electrical work for ground lead with care.**  
Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**  
Using the incorrect one could cause the system failure and fire.
- **Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.**  
The isolator should be locked in OFF state in accordance with EN60204-1.
- **Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly.**  
Improper installation of indoor unit can cause dropping water into the room and damaging personal property.
- **Install the drainage pipe to run off drainage securely according to the installation manual.**  
Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.
- **Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings.**  
Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.
- **Secure a space for installation, inspection and maintenance specified in the manual.**  
Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not install the unit in the locations listed below.**
  - Locations where carbon fiber, metal powder or any powder is floating.
  - Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.
  - Vehicles and ships.
  - Locations where cosmetic or special sprays are often used.
  - Locations with direct exposure of oil mist and steam such as kitchen and machine plant.
  - Locations where any machines which generate high frequency harmonics are used.
  - Locations with salty atmospheres such as coastlines.
  - Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).
  - Locations where the unit is exposed to chimney smoke.
  - Locations at high altitude (more than 1000m high).
  - Locations with ammoniac atmospheres (e.g. organic fertilizer).
  - Locations with calcium chloride (e.g. snow melting agent).
  - Locations where heat radiation from other heat source can affect the unit.
  - Locations without good air circulation.
  - Locations with any obstacles which can prevent inlet and outlet air of the unit.
  - Locations where short circuit of air can occur (in case of multiple units installation).
  - Locations where strong air blows against the air outlet of outdoor unit.
  - Locations where something located above the unit could fall. It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).**
  - Locations with any obstacles which can prevent inlet and outlet air of the unit.
  - Locations where vibration can be amplified due to insufficient strength of structure.
  - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).
  - Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
  - Locations where drainage cannot run off safely. It can affect performance or function and etc.
- **Do not install the unit near the location where leakage of combustible gases can occur.**  
If leaked gases accumulate around the unit, it can cause fire.
- **Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.**  
Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.
- **Do not use the indoor unit at the place where water splashes may occur such as in laundries.**  
Since the indoor unit is not waterproof, it can cause electric shocks and fire.
- **Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.**  
Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
- **Do not place any variables which will be damaged by getting wet under the indoor unit.**  
When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.
- **Do not install the remote control at the direct sunlight.**  
It can cause malfunction or deformation of the remote control.
- **Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.**  
It can cause the damage of the items.
- **Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.**  
Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.
- **Do not touch any buttons with wet hands.**  
It can cause electric shocks.
- **Do not touch any refrigerant pipes with your hands when the system is in operation.**  
During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.

## BEFORE INSTALLATION

- Before installation check that the power source matches the air-conditioner.

Standard accessories (Installation kit) Accessories for indoor unit		Qty
①	Installation board (Attached to the rear of the indoor unit)	1
②	Wireless remote control	1
③	Remote control holder	1
④	Tapping screws (for installation board ø4 X 25mm)	5
⑤	Wood screws (for remote control holder ø3.5 X 16mm)	2
⑥	Battery [R03 (AAA, Micro) 1.5V]	2
⑦	Air-cleaning filters	2
⑧	Filter holders (Attached to the front panel of indoor unit)	2
⑨	Insulation (#486 50 x 100 t3)	1

Option parts		Q'ty
(a)	Sealing plate	1
(b)	Sleeve	1
(c)	Inclination plate	1
(d)	Putty	1
(e)	Drain hose (extension hose)	1
(f)	Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
1	Plus headed driver
2	Knife
3	Saw
4	Tape measure
5	Hammer
6	Spanner wrench
7	Torque wrench (14.0 ~ 61.0N·m (1.4 ~ 6.1kgf·m))
8	Hole core drill (65mm in diameter)
9	Wrench key (Hexagon) [4m/m]
10	Flaring tool set (Designed specifically for R410A)
11	Gas leak detector (Designed specifically for R410A)
12	Gauge for projection adjustment (Used when flare is made by using conventional flare tool)
13	Pipe bender

## SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

### Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.
- Install the indoor unit on the wall where the height from the floor is more than 1.8m.


### Wireless remote control

- A place where the air-conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.

## INSTALLATION OF INDOOR UNIT

### Installation of installation board


Look for the inside wall structures (Intermediates support or pillar and firmly install the unit after level surface has been checked.)



- Adjustment of the installation board in the horizontal direction is to be conducted with four screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.

### Drilling of holes and fixture of sleeve (Option parts)


When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.



- Drill a hole with whole core drill.
- In case of rear piping draw out, cut off the lower and right side portions of the sleeve collar.

### Installing the support of piping

#### In case of piping in the right rear direction




- Hold the bottom of the piping and fix direction before stretching it and shaping it.
- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.



Sufficient care must be taken not to damage the panel when connecting pipes.

#### Matters of special notice when piping from left or central/rear of the unit.

##### [Top view]




Piping is possible in the rear, left, left rear, left downward, right or downward direction.




### Relation between setting plate and indoor unit



#### INSTALLATION SPACE (INDOOR UNIT) (FRONT VIEW)



#### [Drain hose changing procedures]




## Fixing of indoor unit



### How to remove the indoor unit from the installation board

- 1 Push up at the marked portion of the indoor unit base lower latch, and slightly pull it toward you, (both right and left hand sides) (The indoor unit base lower latch can be removed from the installation board)
- 2 Push up the indoor unit upward. So the indoor unit will be removed from the installation board.




Since this air-conditioner has been designed to collect dew drops on the rear surface to the drain pan, do not attach the power cord above the gutter.



## Drainage

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.


**CAUTION** Go through all installation steps and check if the drainage is all right. Otherwise water leak may occur.




- Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- When the extended drain hose is indoor, securely insulate it with a heat insulator available in the market.

## CONNECTION OF REFRIGERANT PIPINGS

**Preparation** Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.




- Remove the flared nuts. (on both liquid and gas sides)



- Install the removed flared nuts to the pipes to be connected, then flared the pipes.

**CAUTION**  
Do not apply refrigerating machine oil to the flared surface.


### Flaring work



Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool	
		Clutch type	Wing nut type
ø6.35	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø9.52	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø12.7	0.0 - 0.5	1.0 - 1.5	2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool.  
Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.  
If a conventional flare tool is used, please use a copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.

## Connection




- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side (ø6.35) : 14.0 - 18.0 N·m (1.4 - 1.8 kgf·m)  
Gas side (ø9.52) : 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m)  
(ø12.7) : 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m)

### CAUTION


Do not apply excess torque to the flared nuts.  
Otherwise, the flared nuts may check depending.

## Insulation of the connection portion

Cover the coupling with insulator and then cover it with tapes.




Use an attached insulation pad for heat insulation.



- Cover the indoor unit's flare-connected joints, after they are checked for a gas leak, with an indoor unit heat insulating material and then wrap them with a tape with an attached insulation pad placed over the heat insulating material's slit area.


## Finishing work and fixing



Cover the exterior portion with outer tape and shape the piping so it will match the contours of the route that the piping to take.  
Also fix the wiring and pipings to the wall with clamps.


## Open/close and detachment/attachment of the air inlet panel

- To open, pull the panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.  
(The panel stops at approx. 60° open position)
- To close, hold the panel at both ends of lower part to lower downward and push it slightly until the latch works.
- To remove, pull up the panel to the position shown in right illustration and pull it toward you.
- To install, insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



## How to remove and fit the front panel

- Removing
  - 1 Remove the air inlet panel.
  - 2 Remove the 2 set screws.
  - 3 Remove the 3 latches in the upper section.
  - 4 Move the lower part of the panel forward and push upwards to remove.
- Fitting
  - 1 Do remove the air filter.
  - 2 Cover the body with the front panel.
  - 3 Fit the 3 latches in the upper section.
  - 4 Tighten the 2 set screws.
  - 5 Fit the air filter.
  - 6 Fit the air inlet panel.



## ELECTRICAL WIRING WORK

### Preparation of indoor unit

#### Mounting of connecting wires

- ① Remove the lid.
- ② Remove the terminal cover.
- ③ Remove the wiring clamp.
- ④ Connect the connecting wire securely to the terminal block.
  - 1) Connect the connection wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
  - 2) Take care not to confuse the terminal numbers for indoor and outdoor connections.
- ⑤ Fix the connecting wire by wiring clamp.
- ⑥ Attach the terminal cover.
- ⑦ Attach the lid.


#### CAUTION

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires. CENELEC code for cables Required field cables.

H05RN4G1.5 (example) or 245IEC57


H	Harmonized cable type
05	300/500 volts
R	Natural-and/or synth, rubber wire insulation
N	Polychloroprene rubber conductors insulation
R	Stranded core
4or5	Number of conductors
G	One conductor of the cable is the earth conductor (yellow/green)
1.5	Section of copper wire (mm <sup>2</sup> )



• Earth wire shall be Yellow/Green (Y/G) in color and longer than other AC wires for safety reason.

### Installing the air-cleaning filters

1. Open the air inlet panel and remove the air filters.
2. Install the air-cleaning filter in the filter holders, and then install the filter holders in the air-conditioner.
  - Each air-cleaning filter can be installed in the left or right filter holder.
3. Install the air filters and close the inlet panel.




## INSTALLATION OF WIRELESS REMOTE CONTROL

### Mounting method of battery

- Uncover the wireless remote control, and mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body regularly. (Fit the poles with the indication marks, ⊕ & ⊖ without fail)


#### CAUTION

Do not use new and old batteries together.



### Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.



## INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

When two air-conditioners are installed in the same room, use this setting when the two air-conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.

### Setting the wireless remote control


- ① Pull out the cover and take out batteries.
- ② Disconnect the switching line next to the battery with wire cutters.



- ③ Insert batteries. Close the cover.

### Setting an indoor unit

- ① Turn off the power source, and turn it on after 1 minute.
- ② Point the wireless remote control that was set according to the procedure described on the left side at the indoor unit and send a signal by pressing the ACL switch on the remote control. Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.
- ③ Check that the reception buzzer sound "pip" is emitted from the indoor unit. At completion of the setting, the indoor unit emits a buzzer sound "pip". (If no reception tone is emitted, start the setting from the beginning again.)



## HOW TO RELOCATE OR DISPOSE OF THE UNIT


- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

#### • Forced cooling operation

Turn on a power source again after a while after turn off a power source. Then press continually the ON/OFF button 5 seconds or more.

#### <How to pump down>


- ① Connect charge hose to check joint of outdoor unit.
- ② Liquid side : Close the liquid valve with hexagon wrench key.  
Gas side : Fully open the service valve (Gas side).  
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the service valve (Gas side).



## CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

- ① Remove the front panel and lid of control.
- ② Remove the control.
- ③ There is a terminal (respectively marked with CNS) for the indoor control board.

In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".



## INSTALLATION TEST CHECK POINTS

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

#### After installation

- |   |  |
|---|--|
| <input type="checkbox"/> The power source voltage is correct as the rating.                         | <input type="checkbox"/> Service valve is fully open.                                      |
| <input type="checkbox"/> No gas leaks from the joints of the service valve.                         | <input type="checkbox"/> The pipe joints for indoor and outdoor pipes have been insulated. |
| <input type="checkbox"/> Power cables and crossover wires are securely fixed to the terminal board. |  |
| <input type="checkbox"/> The screw of the lid and the terminal cover are tightened securely.        |  |

#### Test run

- |  |   |
|--|---|
| <input type="checkbox"/> Air-conditioning operation is normal. | <input type="checkbox"/> The wireless remote control is normal.   |
| <input type="checkbox"/> No abnormal noise.                    | <input type="checkbox"/> Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)   |
| <input type="checkbox"/> Water drains smoothly.                | When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction. |
| <input type="checkbox"/> Protective functions are not working. |   |

RLD012A001

## (c) Model SRK71ZR-S

- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, refer to page 30.
- A wired remote control unit is supplied separately as an option part.

- While installing the unit, be sure to check the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage etc.) and installation spaces.

## SAFETY PRECAUTIONS

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **[WARNING]** and **[CAUTION]**.  
**[WARNING]** : Wrong installation would cause serious consequences such as injuries or death.  
**[CAUTION]** : Wrong installation might cause serious consequences depending on circumstances.  
 Both mention the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- |   |                                      |   |   |  |
|---|--------------------------------------|---|---|--|
|  | Never do it under any circumstances. |  |  | Always do it according to the instruction. |
|---|--------------------------------------|---|---|--|

## WARNING

- |   |  |   |
|---|--|---|
|    | <ul style="list-style-type: none"> <li>• <b>Installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li> <li>• <b>Install the system in full accordance with the installation manual.</b><br/>Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>• <b>Be sure to use only for household and residence.</b><br/>If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>• <b>Use the original accessories and the specified components for installation.</b><br/>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>• <b>Install the unit in a location with good support.</b><br/>Unsuitable installation locations can cause the unit to fall resulting in material damage and personal injury.</li> <li>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b><br/>If the refrigerant comes into contact with naked flames, poisonous gas is produced.</li> <li>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b><br/>If the density of refrigerant exceeds the limit, consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</li> <li>• <b>After completing installation, check that no refrigerant leaks from the system.</b><br/>If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.</li> <li>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b><br/>Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>Tighten the flare nut by torque wrench with specified method.</b><br/>If the flare nuts were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li> <li>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b><br/>Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</li> <li>• <b>Be sure to shut off the power before starting electrical work.</b><br/>Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</li> <li>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b><br/>Unconformable cables can cause electric leak, anomalous heat production or fire.</li> <li>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch [fuse Model 63(21):16A, Model 71(24), 80(28), 92, 100:20A] with a contact separation of at least 3mm.</b></li> <li>• <b>When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.</b></li> <li>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b><br/>Loose connections or cable mountings can cause anomalous heat production or fire.</li> <li>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b><br/>Incorrect installation may result in overheating and fire.</li> <li>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b><br/>If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li> <li>• <b>Be sure to wear protective goggles and gloves while at work.</b></li> <li>• <b>Earth leakage breaker must be installed.</b><br/>If the earth leakage breaker is not installed, it can cause electric shocks.</li> </ul> |
|  | <ul style="list-style-type: none"> <li>• <b>Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.</b><br/>Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.</li> <li>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b><br/>If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li> <li>• <b>Do not process or splice the power cord, or share the socket with other power plugs.</b><br/>This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li> </ul>  | <ul style="list-style-type: none"> <li>• <b>Do not bundle or wind or process the power cord. Do not deform the power cord by treating it.</b><br/>This may cause fire or heating.</li> <li>• <b>Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.</b></li> <li>• <b>Do not run the unit with removed panels or protections.</b><br/>Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li> <li>• <b>Do not perform any change of protective device itself or its setup condition.</b><br/>The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</li> </ul>  |

## CAUTION

- |   |   |   |
|---|---|---|
|  | <ul style="list-style-type: none"> <li>• <b>Carry out the electrical work for ground lead with care.</b><br/>Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</li> </ul>   |   |
|  | <ul style="list-style-type: none"> <li>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be able to disconnect all poles under over current.</b><br/>Using the incorrect one could cause the system failure and fire.</li> <li>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b><br/>The isolator should be locked in OFF state in accordance with EN60204-1.</li> <li>• <b>Be sure to install indoor unit properly according to instruction manual so that drainage can run off smoothly.</b><br/>Improper installation of indoor unit can cause dropping water into the room and damaging personal property.</li> <li>• <b>Install the drainage pipe to run off drainage securely according to the installation manual.</b><br/>Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.</li> <li>• <b>Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings.</b><br/>Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.</li> <li>• <b>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></li> <li>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b><br/>Insufficient space can result in accident such as personal injury due to falling from the installation place.</li> <li>• <b>Take care when carrying the unit by hand.</b></li> </ul>   | <p>If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.</p> <ul style="list-style-type: none"> <li>• <b>Dispose of any packing materials correctly.</b><br/>Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.</li> <li>• <b>For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc.</b></li> <li>• <b>Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.</b><br/>Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.</li> <li>• <b>When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></li> <li>• <b>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.</b><br/>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.</li> </ul>  |
|  | <ul style="list-style-type: none"> <li>• <b>Do not install the unit in the locations listed below.</b> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> </ul> </li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blowing against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> <p>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</p> <li>• <b>Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).</b> <ul style="list-style-type: none"> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where vibration can be amplified due to insufficient strength of structure.</li> <li>• Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).</li> <li>• Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).</li> <li>• Locations where drainage cannot run off safely.</li> </ul> <p>It can affect performance or function and etc.</p> <li>• <b>Do not install the unit near the location where leakage of combustible gases can occur.</b></li> </li> | <p>If leaked gases accumulate around the unit, it can cause fire.</p> <ul style="list-style-type: none"> <li>• <b>Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.</b><br/>Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</li> <li>• <b>Do not use the indoor unit at the place where water splashes may occur such as in laundries.</b><br/>Since the indoor unit is not waterproof, it can cause electric shocks and fire.</li> <li>• <b>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</b><br/>Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.</li> <li>• <b>Do not place any variables which will be damaged by getting wet under the indoor unit.</b><br/>When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.</li> <li>• <b>Do not install the remote control at the direct sunlight.</b><br/>It can cause malfunction or deformation of the remote control.</li> <li>• <b>Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.</b><br/>It can cause the damage of the items.</li> <li>• <b>Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.</b><br/>Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.</li> <li>• <b>Do not touch any buttons with wet hands.</b><br/>It can cause electric shocks.</li> <li>• <b>Do not touch any refrigerant pipes with your hands when the system is in operation.</b><br/>During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.</li> <li>• <b>Do not wash the inside of the air-conditioner.</b><br/>Water leakage and permanent damage may result. Electrical hazard exists.</li> </ul> |

## BEFORE INSTALLATION

- Before installation check that the power source matches the air-conditioner.

Standard accessories (Installation kit)	
Accessories for indoor unit	
① Installation board (Attached to the rear of the indoor unit)	1
② Wireless remote control	1
③ Remote control holder	1
④ Tapping screws (for installation board $\phi 4 \times 25\text{mm}$ )	10
⑤ Wood screws (for remote control holder $\phi 3.5 \times 16\text{mm}$ )	2
⑥ Battery [R03 (AAA, Micro) 1.5V]	2
⑦ Air-cleaning filters	2
⑧ Filter holders	2
⑨ Insulation (#486 50 x 100 t3)	1

Locally procured parts	
a Sealing plate	1
b Sleeve	1
c Inclination plate	1
d Putty	1
e Drain hose (extension hose)	1
f Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
1 Plus headed driver	
2 Knife	
3 Saw	
4 Tape measure	
5 Hammer	
6 Spanner wrench	
7 Torque wrench (14.0 ~ 82.0N·m (1.4 ~ 8.2kgf·m))	
8 Hole core drill (65mm in diameter)	
9 Wrench key (Hexagon) [4m/m]	
10 Flaring tool set (Designed specifically for R410A)	
11 Gas leak detector (Designed specifically for R410A)	
12 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	
13 Pipe bender	

## SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

### Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.
- Install the indoor unit on the wall where the height from the floor to the bottom of the unit is more than 1.8m.




### Wireless remote control

- A place where the air-conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is not affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.


## INSTALLATION OF INDOOR UNIT

### Installation of Installation board

Look for the inside wall structures (Intermediate support or pillar and firmly install the unit after level surface has been checked.)






- Adjustment of the installation board in the horizontal direction is to be conducted with eight screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.



### Drilling of hole and fixture of sleeve (Locally procured parts)

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.




Installed state

- In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.

### Installing the support of piping

#### In case of piping in the right rear direction

##### Shaping of pipings



##### Taping of the exterior





- Hold the bottom of the piping and fix direction before stretching it and shaping it.


- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.

Sufficient care must be taken not to damage the panel when connecting pipes.


#### Matters of special notice when piping from left or central/rear of the unit. [Top view]





### Relation between setting plate and indoor unit



### [Drain hose changing procedures]




## Fixing of indoor unit



### How to remove the indoor unit from the installation board

- 1 Push up at the marked portion of the indoor unit base lower latch, and slightly pull it toward you, (both right and left hand sides) (The indoor unit base lower latch can be removed from the installation board)
- 2 Push up the indoor unit upward so that it can be removed from installation board.




Since this air-conditioner has been designed to collect dew drops on the rear surface to the drain pan, do not attach the power cord above the gutter.



## Drainage

- o Arrange the drain hose in a downward angle.
- o Avoid the following drain piping.


**CAUTION** Go through all installation steps and check if the drainage is all right. Otherwise water leak may occur.




- o Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- o When extended drain hose is present inside the room, insulate it securely with heat insulator available in the market.

## CONNECTION OF REFRIGERANT PIPINGS

**Preparation** Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.



- o Remove the flared nuts. (on both liquid and gas sides)




Dimension A  
Liquid side  $\phi 6.35 : 9.1$  (mm)  
 $\phi 9.52 : 13.2$  (mm)  
Gas side  $\phi 9.52 : 13.2$  (mm)  
 $\phi 12.7 : 16.6$  (mm)  
 $\phi 15.88 : 19.7$  (mm)

**CAUTION**  
Do not apply refrigerating machine oil to the flared surface.

- o Install the removed flared nuts to the pipes to be connected, then flared the pipes.


### Flaring work



Copper pipe diameter	Measurement B (mm)	
	Clutch type flare tool for R410A	Conventional (R22) flare tool
$\phi 6.35$	0.0 - 0.5	Clutch type 1.0 - 1.5 Wing nut type 1.5 - 2.0
$\phi 9.52$	0.0 - 0.5	Clutch type 1.0 - 1.5 Wing nut type 1.5 - 2.0
$\phi 12.7$	0.0 - 0.5	Clutch type 1.0 - 1.5 Wing nut type 2.0 - 2.5
$\phi 15.88$	0.0 - 0.5	Clutch type 1.0 - 1.5 Wing nut type 2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool.  
Note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.  
If a conventional flare tool is used, use a copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.

## Connection



- o Connect the pipes on both liquid and gas sides.
- o Tighten the nuts to the following torque.
  - Liquid side ( $\phi 6.35$ ) : 14.0 - 16.0 N·m (1.4 - 1.8 kgf·m)
  - ( $\phi 9.52$ ) : 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m)
  - ( $\phi 12.7$ ) : 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m)
  - ( $\phi 15.88$ ) : 68.0 - 82.0 N·m (6.8 - 8.2 kgf·m)


### CAUTION

Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack.


If FDC71VNP is connected, use reducer at gas side of indoor unit to change the pipe size from  $\phi 15.88$  to  $\phi 12.7$ . (Reducer is attached in the outdoor unit accessory)

## Insulation of the connection portion

Cover the coupling with insulator and then cover it with tapes.




Use an attached insulation pad for heat insulation.



- o Cover the indoor unit's flare-connected joints, after they are checked for a gas leak, with an indoor unit heat insulating material and then wrap them with a tape with an attached insulation pad placed over the heat insulating material's slit area.


## Finishing work and fixing



Cover the exterior portion with outer tape and shape the piping to match with the contours of the route that piping will take.  
Also fix the wiring and pipings to the wall with clamps.

## Open/close and detachment/attachment of the air inlet panel


- o To open, pull the panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.  
(The panel stops at approx. 60° open position)
- o To close, hold the panel at both ends of lower part to lower downward and push it slightly until the latch works.
- o To remove, pull up the panel to the position shown in right illustration and pull it toward you.
- o To install, insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



To remove / To install

## How to remove and install the front panel

- o Removing
  - 1 Remove the air inlet panel.
  - 2 Remove the 8 screws fixing to the front panel.
  - 3 Remove the 5 latches in the upper section of the front panel and then remove the front panel from the unit.
- o Installing
  - 1 Remove the air filter.
  - 2 Cover the unit with the front panel.
  - 3 Tighten the 8 screws to fix the front panel.
  - 4 Install the air filter.
  - 5 Install the air inlet panel.



## ELECTRICAL WIRING WORK

### Preparation of indoor unit


#### Mounting of connecting wires

- 1 Open the air inlet panel.
- 2 Remove the lid.
- 3 Remove the wiring clamp.
- 4 Connect the connecting wire securely to the terminal block.
- 5 Connect the connection wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
- 6 Take care not to confuse the terminal numbers for indoor and outdoor connections.
- 7 Fix the connecting wire by wiring clamp.
- 8 Attach the lid.
- 9 Close the air inlet panel.

○ In case of faulty wiring connection, indoor unit does not operate. Then, run lamp turns on and timer lamp blinks.


Use cables for interconnection wiring to avoid loosening of the wires.  
CENELEC code for cables Required field cables.

H05RN4G1.5 (example) or 245IEC57  
H Harmonized cable type  
05 300/500 volts  
R Natural-and/or synth. rubber wire insulation  
N Polychloroprene rubber conductors insulation  
R Stranded core  
4or5 Number of conductors  
G One conductor of the cable is the earth conductor (yellow/green)  
1.5 Section of copper wire (mm<sup>2</sup>)



### Installing the air-cleaning filters


- 1 Open the air inlet panel and remove the air filters.
- 2 Install the air-cleaning filter in the filter holders, and then install the filter holders in the air-conditioner.
- 3 Each air-cleaning filter can be installed in the left or right filter holder.
- 4 Install the air filters and close the inlet panel.



## INSTALLATION OF WIRELESS REMOTE CONTROL


### Mounting method of battery

- Uncover the wireless remote control, and mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body regularly.  
(Fit the poles with the indication marks ⊕ & ⊖ without fail)
- Do not use new and old batteries together.



### Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.




## INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

When two air-conditioners are installed in the same room, use this setting when the two air-conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.


### Setting the wireless remote control

- 1 Pull out the cover and take out batteries.
- 2 Disconnect the switching line next to the battery with wire cutters.
- 3 Insert batteries. Close the cover.



### Setting an indoor unit

- 1 Turn off the power source, and turn it on after 1 minute.
- 2 Point the wireless remote control that was set according to the procedure described on the left side at the indoor unit and send a signal by pressing the ACL switch on the wireless remote control. Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.
- 3 Check that the reception buzzer sound "pip" is emitted from the indoor unit.  
At completion of the setting, the indoor unit emits a buzzer sound "pip". (If no reception tone is emitted, start the setting from the beginning again.)



## HOW TO RELOCATE OR DISPOSE OF THE UNIT


- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

### <How to pump down>

- 1 Connect charge hose to check joint of outdoor unit.
- 2 Liquid side : Close the liquid valve with hexagon wrench key.  
Gas side : Fully open the service valve (Gas side).  
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- 3 After low pressure gauge become 0.01MPa, stop cooling operation and close the service valve (Gas side).


### • Forced cooling operation

Turn off power source. Turn on power source again after a while. Then, press the ON/OFF button continuously for at least 5 seconds. (The operation will start.)



## TERMINAL CONNECTION FOR AN INTERFACE

- 1 Remove the air inlet panel, lid and front panel.
- 2 Remove the control cover. (Remove the screw.)
- 3 There is a terminal (respectively marked with CNS) for the indoor control board.  
In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit.  
For more details, refer to the user's manual of your "Interface connection kit SC-BIKN-E".



## INSTALLATION TEST CHECK POINTS

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

### After installation

- ☐ The power source voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.

- ☐ The screw of the lid is tightened securely.
- ☐ Service valve is fully open.
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.

### Test run

- ☐ Air-conditioning operation is normal.
- ☐ No abnormal noise.
- ☐ Water drains smoothly.
- ☐ Protective functions are not working.
- ☐ The wireless remote control is normal.
- ☐ Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)

When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

RFB012A007

## (2) Floor standing type (SRF)

### Models SRF25ZMX-S, 35ZMX-S, 50ZMX-S

- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, please see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, please refer to page 30.




- A wired remote control unit is supplied separately as an option part.
- When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces.







## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
  - The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚡ CAUTION**.
    - ⚠ WARNING** : Wrong installation would cause serious consequences such as injuries or death.
    - ⚡ CAUTION** : Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, gloves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:

 Never do it under any circumstances.	  Always do it according to the instruction.
--	--

 <b>WARNING</b>	
 <ul style="list-style-type: none"><li>• <b>Installation must be carried out by the qualified installer.</b> If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li><li>• <b>Install the system in full accordance with the installation manual.</b> Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li><li>• <b>Be sure to use only for household and residence.</b> If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li><li>• <b>Use the original accessories and the specified components for installation.</b> If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li><li>• <b>Install the unit in a location with good support.</b> Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li><li>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b> If the refrigerant comes into contact with naked flames, poisonous gas is produced.</li><li>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b> If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</li><li>• <b>After completed installation, check that no refrigerant leaks from the system.</b> If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.</li><li>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b> Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li></ul>	<ul style="list-style-type: none"><li>• <b>Tighten the flare nut by torque wrench with specified method.</b> If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li><li>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b> Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</li><li>• <b>Be sure to shut off the power before starting electrical work.</b> Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</li><li>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b> Unconformable cables can cause electric leak, anomalous heat production or fire.</li><li>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm.</b></li><li>• <b>When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.</b></li><li>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b> Loose connections or cable mountings can cause anomalous heat production or fire.</li><li>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b> Incorrect installation may result in overheating and fire.</li><li>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b> If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li><li>• <b>Be sure to wear protective goggles and gloves while at work.</b></li><li>• <b>Earth leakage breaker must be installed.</b> If the earth leakage breaker is not installed, it can cause electric shocks.</li></ul>
 <ul style="list-style-type: none"><li>• <b>Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.</b> Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.</li><li>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b> If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li></ul>	<ul style="list-style-type: none"><li>• <b>Do not processing, splice the power cord, or share a socket with other power plugs.</b> This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li><li>• <b>Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to treat it.</b> This may cause fire or heating.</li></ul>

 <b>WARNING</b>	
 <ul style="list-style-type: none"><li>• <b>Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.</b></li><li>• <b>Do not run the unit with removed panels or protections.</b> Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li></ul>	<ul style="list-style-type: none"><li>• <b>Do not perform any change of protective device itself or its setup condition.</b> The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</li></ul>
 <b>CAUTION</b>	
 <ul style="list-style-type: none"><li>• <b>Carry out the electrical work for ground lead with care.</b> Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</li></ul>	
 <ul style="list-style-type: none"><li>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</b> Using the incorrect one could cause the system failure and fire.</li><li>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b> The isolator should be locked in OFF state in accordance with EN60204-1.</li><li>• <b>Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly.</b> Improper installation of indoor unit can cause dropping water into the room and damaging personal property.</li><li>• <b>Install the drainage pipe to run off drainage securely according to the installation manual.</b> Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.</li><li>• <b>Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings.</b> Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.</li><li>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b> Insufficient space can result in accident such as personal injury due to</li></ul>	<p>falling from the installation place.</p> <ul style="list-style-type: none"><li>• <b>For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc.</b></li><li>• <b>Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.</b> Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.</li><li>• <b>When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></li><li>• <b>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.</b> If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.</li></ul>
 <ul style="list-style-type: none"><li>• <b>Do not install the unit in the locations listed below.</b><ul style="list-style-type: none"><li>• Locations where carbon fiber, metal powder or any powder is floating.</li><li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li><li>• Vehicles and ships.</li><li>• Locations where cosmetic or special sprays are often used.</li><li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li><li>• Locations where any machines which generate high frequency harmonics are used.</li><li>• Locations with salty atmospheres such as coastlines.</li><li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li><li>• Locations where the unit is exposed to chimney smoke.</li><li>• Locations at high altitude (more than 1000m high).</li><li>• Locations with ammoniac atmospheres.</li><li>• Locations where heat radiation from other heat source can affect the unit.</li><li>• Locations without good air circulation.</li><li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li><li>• Locations where short circuit of air can occur (in case of multiple units installation).</li><li>• Locations where strong air blows against the air outlet of outdoor unit.</li><li>• Locations where something located above the unit could fall. It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</li></ul></li><li>• <b>Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).</b><ul style="list-style-type: none"><li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li><li>• Locations where vibration can be amplified due to insufficient strength of structure.</li><li>• Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).</li><li>• Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).</li><li>• Locations where drainage cannot run off safely. It can affect performance or function and etc.</li></ul></li><li>• <b>Do not install the unit near the location where leakage of combustible gases can occur.</b></li></ul>	<p>If leaked gases accumulate around the unit, it can cause fire.</p> <ul style="list-style-type: none"><li>• <b>Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.</b> Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</li><li>• <b>Do not use the indoor unit at the place where water splashes may occur such as in laundries.</b> Since the indoor unit is not waterproof, it can cause electric shocks and fire.</li><li>• <b>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</b> Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.</li><li>• <b>Do not place any variables which will be damaged by getting wet under the indoor unit.</b> When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.</li><li>• <b>Do not install the wireless remote control at the direct sunlight.</b> It can cause malfunction or deformation of the wireless remote control.</li><li>• <b>Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.</b> It can cause the damage of the items.</li><li>• <b>Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.</b> Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.</li><li>• <b>Do not touch any buttons with wet hands.</b> It can cause electric shocks.</li><li>• <b>Do not touch any refrigerant pipes with your hands when the system is in operation.</b> During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.</li></ul>

## BEFORE INSTALLATION

○ Before installation check that the power source matches the air-conditioner.

Standard accessories (Installation kit) Accessories for indoor unit		
①	Installation board (Attached to the rear of the indoor unit)	1
②	Wireless remote control	1
③	Remote control holder	1
④	Tapping screws (for installation board ø4 X 25mm)	9
⑤	Wood screws (for remote control switch holder ø3.5 X 16mm)	2
⑥	Battery [R03 (AAA, Micro) 1.5V]	2
⑦	Air-cleaning filters	2
⑧	Filter holders (Attached to the front panel of indoor unit)	2
⑨	Pipe cover (200mm)	1
⑩	Band	2

Option parts		Q'ty
a	Sealing plate	1
b	Sleeve	1
c	Inclination plate	1
d	Putty	1
e	Drain hose (extension hose)	1
f	Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
1	Plus headed driver
2	Knife
3	Saw
4	Tape measure
5	Hammer
6	Spanner wrench
7	Torque wrench (14.0 ~ 61.0N·m (1.4 ~ 6.1kgf·m))
8	Hole core drill (65mm in diameter)
9	Wrench key (Hexagon) [4m/m]
10	Flaring tool set (Designed specifically for R410A)
11	Gas leak detector (Designed specifically for R410A)
12	Gauge for projection adjustment (Used when flare is made by using conventional flare tool)
13	Pipe bender

## SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

### Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.
- Install the indoor unit on flat wall.

### Wireless remote control


- A place where the air-conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.

## INSTALLATION OF INDOOR UNIT

### Open and detachment of the air inlet panel


- To open, pull the panel at both ends of upper part and release latches, and undo the strings. Then remove the panel.

**CAUTION**  
When removing the air-inlet panel, be careful not to drop it on your feet.





### How to remove the front panel

- Remove the air inlet panel.
- Remove the 5 set screws.
- Remove the 3 latches in the upper section.  
If the latches are difficult to remove, push the latch portion out using a screw driver, for example.
- Move the lower part of the panel forward and remove the 6 latches in the under section.





### Drilling of holes and fixture of sleeve (Option parts)

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.




- Drill a hole with whole core drill.
- In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.

### Indoor unit piping direction




### Drainage

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.




**CAUTION** Go through all installation steps and check if the drainage is all right. Otherwise water leak may occur.

- Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- When the extended drain hose is indoor, securely insulate it with a heat insulator available in the market.




**CAUTION**  
Completely seal the hole on the wall with putty. Otherwise, furniture, or other, may be wetted by leaked water or dewing.



### Installing the support of piping

#### In case of piping in the right rear direction

##### Taping of the exterior



- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.

Sufficient care must be taken not to damage the panel when connecting pipes.

**CAUTION**  
Be careful not to stress the connecting refrigerant pipe. (Do not pull with a force of larger than 5 kgf.) If improperly installed, it may cause abnormal noise and vibration.


## Fixing of indoor unit

**CAUTION**

- During the installation, do not lean on the control box or the display, as they may be damaged.
- Install the indoor unit on flat wall. If improperly installed, it may cause abnormal noise and vibration. (Distortion on the wall shall be no larger than 3 mm.)

### Floor installation

Secure using upper 2 screws for floor installations. If possible, also attach two lower screws.




### Wall installation

At first secure the installation board using 5 screws and the indoor unit using 2 screws.

### Installation of Installation board



Look for the inside wall structures (Intersediats support or pillar and finally install the unit after level surface has been checked.)



- Adjustment of the installation board in the horizontal direction is to be conducted with five screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.

### Fixing on concrete wall

Use of nut anchor




- When practicing the half-console, make sure to fix the unit securely. Otherwise, it could fall.

## CONNECTION OF REFRIGERANT PIPINGS

**CAUTION** Be careful not to stress the connecting refrigerant pipes. (Do not pull with a force of larger than 5 kgf.)

### Preparation

Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.




- Remove the flared nuts. (on both liquid and gas sides)
- Install the removed flared nuts to the pipes to be connected, then flared the pipes.

**CAUTION** Do not apply refrigerating machine oil to the flared surface.

### Flaring work


Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional (R22) flare tool	Wing nut type
ø6.35	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø9.52	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø12.7	0.0 - 0.5	1.0 - 1.5	2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use. If a conventional flare tool is used, please use a copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.



### Connection


#### Indoor



- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.
  - Liquid side (ø6.35) : 14.0 - 18.0 N·m (1.4 - 1.8 kgf·m)
  - Liquid side (ø9.52) : 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m)
  - Gas side (ø12.7) : 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m)


**CAUTION** Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may check depending.

### Finishing work and fixing




### Insulation of the connection portion

Pass the refrigerant pipe through the piping hole to indoor side. Arrange the pipes according to the direction of piping.



Cover the coupling with insulator and then cover it with tapes. Use an attached pipe cover for heat insulation.



**CAUTION** If heat insulation is insufficient, water leakage may occur. In addition, the room temperature sensor may give a false alert due to heat radiation from the pipes.

- Cover the indoor unit's flare-connected joints, after they are checked for a gas leak, with an indoor unit heat insulating material and then wrap them with a tape with an attached pipe cover placed over the heat insulating material's slit area.

## ELECTRICAL WIRING WORK

### Preparation of indoor unit

#### Mounting of connecting wires

- Remove the fixing screw of clamp.
- Connect the connecting wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
- Take care not to confuse the terminal numbers for indoor and outdoor connections.
- Fix the connecting wire by wiring clamp.
- Pass the connecting wire through the wiring holder.



**CAUTION** In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires. CENELEC code for cables Required field cables.

H05RN4G1.5 (example) or 245IEC57	
H	Harmonized cable type
05	300/500 volts
R	Natural-and/or synth, rubber wire insulation
R	Polychloroprene rubber conductors insulation
R	Stranded core
4 or 5	Number of conductors
G	One conductor of the cable is the earth conductor (yellow/green)
1.5	Section of copper wire (mm²)


**CAUTION**

- During installation, do not lean on the control box or the display, as they may be damaged.
- Pass the connecting wire securely through the wiring holder. If it passes the sensor, it may not detect suction temperature and/or humidity.




### How to fit the front panel

- Fitting
- 1 Do remove the air filter.
  - 2 Cover the body with the front panel.
  - 3 Fit the 6 latches in the lower section, then 3 latches in the upper section.
  - 4 Tighten the 5 set screws.
  - 5 Fit the air filter.
  - 6 Fit the air inlet panel.



### Close and attachment of the air inlet panel


- To close, attach the panel after pulling the strings, hold the panel at both ends of upper part to lower downward and push it slightly until the latch works.



### Installing the air-cleaning filters

1. Open the air inlet panel and remove the air filters.
2. Install the air-cleaning filter in the filter holders, and then install the filter holders in the air-conditioner.
  - Each air-cleaning filter can be installed in the upper or lower filter holder.
3. Install the air filters and close the inlet panel.


**CAUTION**  
When installing an air-cleaning filter in the indoor unit, be careful not to injure your hand with the heat exchanger.



## INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

### Setting the wireless remote control

- 1 Pull out the cover and take out batteries.
- 2 Disconnect the switching line next to the battery with wire cutters.
- 3 Insert batteries. Close the cover.




### Setting an indoor unit

- 1 Turn off the power source, and turn it on after 1 minute.
- 2 Point the wireless remote control that was set according to the procedure described on the left side at the indoor unit and send a signal by pressing the ACL switch on the wireless remote control. Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.

- 3 Check that the reception buzzer sound "pip" is emitted from the indoor unit.  
At completion of the setting, the indoor unit emits a buzzer sound "pip". (If no reception tone is emitted, start the setting from the beginning again.)




When two air-conditioners are installed in the same room, use this setting when the two air-conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.



### Concealed installation

- Install the indoor unit according to the following instructions.
- 1 Secure the upper, right, and left spaces according to the right figure.
  - 2 Do not let the horizontal bar obstruct wind from blowing out upward/downward or reception from the wireless remote control.
  - 3 The lattice size should be 70 % or greater of the open rate.
  - 4 Cut the jumper cable (JP173) on the indoor circuit board to control the blow-out angle.

**CAUTION**  
Incorrect installation may cause problems such as non-cooling, non-warming, and condensation water leaking into the room.



## CONCERNING TERMINAL CONNECTION FOR AN INTERFACE


- 1 Remove the front panel and lid of control.
- 2 There is a terminal (respectively marked with CNS) for the indoor control board.  
In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit.  
For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".

## INSTALLATION OF WIRELESS REMOTE CONTROL

### Mounting method of battery


- Uncover the wireless remote control, and mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body regularly.  
(Fit the poles with the indication marks, ⊕ & ⊖ without fail)

**CAUTION**  
Do not use new and old batteries together.



### Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.  
○ Avoid installing it on a clay wall etc.




## HOW TO RELOCATE OR DISPOSE OF THE UNIT

- In order to protect the environment, be sure to pump down (recovery of refrigerant).  
○ Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

### <How to pump down>

- 1 Connect charge hose to service port of outdoor unit.
- 2 Liquid side : Close the service valve with hexagon wrench key.  
Gas side : Fully open the service valve  
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- 3 After low pressure gauge become 0.01MPa, stop cooling operation and close the service valve (gas side).

- Forced cooling operation  
Turn on a power source again after a while after turn off a power source. Then press continually the ON/OFF button 5 seconds or more.



## INSTALLATION TEST CHECK POINTS

### After installation

- ☐ The power source voltage is correct as the rating.  
☐ No gas leaks from the joints of the service valve.  
☐ Power cables and crossover wires are securely fixed to the terminal board.  
☐ The screw of the lid is tightened securely.

- ☐ Service valve is fully open.  
☐ The pipe joints for indoor and outdoor pipes have been insulated.

### Test run

- ☐ Air-conditioning operation is normal.  
☐ No abnormal noise.  
☐ Water drains smoothly.  
☐ Protective functions are not working.

- ☐ The wireless remote control is normal.  
☐ Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)  
When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

RJJ012A002

### (3) Ceiling concealed type (SRR)

#### Models SRR25ZM-S, 35ZM-S, 50ZM-S, 60ZM-S

- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, refer to page 30.
- A wired remote control unit is supplied separately as an option part.

- While installing the unit, be sure to check the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage etc.) and installation spaces.

### SAFETY PRECAUTIONS

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚡ CAUTION**.  
**⚠ WARNING** : Wrong installation would cause serious consequences such as injuries or death.  
**⚡ CAUTION** : Wrong installation might cause serious consequences depending on circumstances.
- Both mention the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- Before starting the installation work, proper precautions (using suitable protective clothing, gloves etc.) should be taken by qualified installer.
- Pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:



Never do it under any circumstances.



Always do it according to the instruction.



### WARNING

- |  |   |
|--|---|
| <p><b>⚠</b></p> <ul style="list-style-type: none"> <li>• <b>Installation must be carried out by the qualified installer.</b><br/>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li> <li>• <b>Install the system in full accordance with the installation manual.</b><br/>Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>• <b>Be sure to use only for household and residence.</b><br/>If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>• <b>Use the original accessories and the specified components for installation.</b><br/>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>• <b>Install the unit in a location with good support.</b><br/>Unsuitable installation locations can cause the unit to fall resulting in material damage and personal injury.</li> <li>• <b>Ventilate the working area well in the event of refrigerant leakage during installation.</b><br/>If the refrigerant comes into contact with naked flames, poisonous gas is produced.</li> <li>• <b>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</b><br/>If the density of refrigerant exceeds the limit, consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.</li> <li>• <b>After completing installation, check that no refrigerant leaks from the system.</b><br/>If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.</li> <li>• <b>Use the prescribed pipes, flare nuts and tools for R410A.</b><br/>Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>Tighten the flare nut by torque wrench with specified method.</b><br/>If the flare nuts were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li> <li>• <b>The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.</b><br/>Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.</li> <li>• <b>Be sure to shut off the power before starting electrical work.</b><br/>Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.</li> <li>• <b>Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.</b><br/>Unconformable cables can cause electric leak, anomalous heat production or fire.</li> <li>• <b>This appliance must be connected to main power source by means of a circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm.</b></li> <li>• <b>When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used.</b></li> <li>• <b>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.</b><br/>Loose connections or cable mountings can cause anomalous heat production or fire.</li> <li>• <b>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</b><br/>Incorrect installation may result in overheating and fire.</li> <li>• <b>Be sure to switch off the power source in the event of installation, inspection or servicing.</b><br/>If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li> <li>• <b>Be sure to wear protective goggles and gloves while at work.</b></li> <li>• <b>Earth leakage breaker must be installed.</b><br/>If the earth leakage breaker is not installed, it can cause electric shocks.</li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.</b><br/>Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.</li> <li>• <b>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</b><br/>If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li> <li>• <b>Do not process or splice the power cord, or share the socket with other power plugs.</b><br/>This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li> </ul>  | <ul style="list-style-type: none"> <li>• <b>Do not bundle or wind or process the power cord. Do not deform the power cord by treading it.</b><br/>This may cause fire or heating.</li> <li>• <b>Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.</b></li> <li>• <b>Do not run the unit with removed panels or protections.</b><br/>Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li> <li>• <b>Do not perform any change of protective device itself or its setup condition.</b><br/>The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.</li> </ul>  |



### CAUTION

- |  |   |   |
|--|---|---|
| <p><b>⚡</b></p> <ul style="list-style-type: none"> <li>• <b>Carry out the electrical work for ground lead with care.</b><br/>Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.</li> </ul>  | <p><b>⚠</b></p> <ul style="list-style-type: none"> <li>• <b>Use the circuit breaker of correct capacity. Circuit breaker should be able to disconnect all poles under over current.</b><br/>Using the incorrect one could cause the system failure and fire.</li> <li>• <b>Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.</b><br/>The isolator should be locked in OFF state in accordance with EN60204-1.</li> <li>• <b>Be sure to install indoor unit properly according to instruction manual so that drainage can run off smoothly.</b><br/>Improper installation of indoor unit can cause dropping water into the room and damaging personal property.</li> <li>• <b>Install the drainage pipe to run off drainage securely according to the installation manual.</b><br/>Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.</li> <li>• <b>Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bledings.</b><br/>Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.</li> <li>• <b>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</b></li> <li>• <b>Secure a space for installation, inspection and maintenance specified in the manual.</b><br/>Insufficient space can result in accident such as personal injury due to falling from the installation place.</li> <li>• <b>Take care when carrying the unit by hand.</b><br/>If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle</li> </ul>   | <p>when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.</p> <ul style="list-style-type: none"> <li>• <b>Dispose of any packing materials correctly.</b><br/>Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.</li> <li>• <b>For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc.</b></li> <li>• <b>Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.</b><br/>Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.</li> <li>• <b>When perform the air-conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air-conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.</b></li> <li>• <b>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.</b><br/>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.</li> </ul> |
| <p><b>⊘</b></p> <ul style="list-style-type: none"> <li>• <b>Do not install the unit in the locations listed below.</b> <ul style="list-style-type: none"> <li>• Locations where carbon fiber, metal powder or any powder is floating.</li> <li>• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>• Vehicles and ships.</li> <li>• Locations where cosmetic or special sprays are often used.</li> <li>• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> <li>• Locations where any machines which generate high frequency harmonics are used.</li> <li>• Locations with salty atmospheres such as coastlines.</li> <li>• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>• Locations where the unit is exposed to chimney smoke.</li> <li>• Locations at high altitude (more than 1000m high).</li> <li>• Locations with ammoniac atmospheres (e.g. organic fertilizer).</li> <li>• Locations with calcium chloride (e.g. snow melting agent).</li> <li>• Locations where heat radiation from other heat source can affect the unit.</li> <li>• Locations without good air circulation.</li> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>• Locations where strong air blows against the air outlet of outdoor unit.</li> <li>• Locations where something located above the unit could fall.</li> </ul> </li> <li>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</li> <li>• <b>Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).</b> <ul style="list-style-type: none"> <li>• Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>• Locations where vibration can be amplified due to insufficient strength of structure.</li> <li>• Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).</li> <li>• Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).</li> <li>• Locations where drainage cannot run off safely.</li> </ul> </li> <li>It can affect performance or function and etc.</li> <li>• <b>Do not install the unit near the location where leakage of combustible gases can occur.</b><br/>If leaked gases accumulate around the unit, it can cause fire.</li> </ul> | <ul style="list-style-type: none"> <li>• <b>Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.</b><br/>Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</li> <li>• <b>Do not use the indoor unit at the place where water splashes may occur such as in laundries.</b><br/>Since the indoor unit is not waterproof, it can cause electric shocks and fire.</li> <li>• <b>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</b><br/>Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.</li> <li>• <b>Do not place any variables which will be damaged by getting wet under the indoor unit.</b><br/>When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.</li> <li>• <b>Do not install the remote control at the direct sunlight.</b><br/>It can cause malfunction or deformation of the remote control.</li> <li>• <b>Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.</b><br/>It can cause the damage of the items.</li> <li>• <b>Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.</b><br/>Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.</li> <li>• <b>Do not touch any buttons with wet hands.</b><br/>It can cause electric shocks.</li> <li>• <b>Do not touch any refrigerant pipes with your hands when the system is in operation.</b><br/>During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.</li> <li>• <b>Do not wash the inside of the air-conditioner.</b><br/>Water leakage and permanent damage may result. Electrical hazard exists.</li> </ul> |   |

## Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts

Standard accessories (installation kit) Accessories for indoor unit	
① Wireless remote control	1
② Remote control holder	1
③ Remote control signal receiver	1
④ Installation frame (for remote control signal receiver)	1
⑤ Wood screws (for remote control holder ø3.5 X 16mm)	2
⑥ Battery [R03 (AAA, Micro) 1.5V]	2
⑦ Joint (for drain hose)	1
⑧ Clamp (for drain hose) (big:1, small:1)	2
⑨ Washer (for suspension bolt M10)	8
⑩ Flat head machine screw (for remote control signal receiver M3.5x10)	2
⑪ Plate (display)	1
⑫ Pipe cover (big:1, small:1)	2
⑬ Band	4

Locally procured parts	
Ⓐ Sealing plate	1
Ⓑ Sleeve	1
Ⓒ Inclination plate	1
Ⓓ Putty	1
Ⓔ Drain hose (VP25)	1
Ⓕ Suspension bolts (M10)	4
Ⓖ Nuts (M10)	8
Ⓗ Spring lock washers (M10)	4

Option parts (Separately sold parts)	
Bottom air inlet kit (25, 35 models : UT-BAT1EF) (50, 60 models : UT-BAT2EF)	1

Necessary tools for the installation work	
1 Plus headed driver	
2 Knife	
3 Saw	
4 Tape measure	
5 Hammer	
6 Spanner wrench	
7 Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)]	
8 Hole core drill (65mm in diameter)	
9 Wrench key (Hexagon) [4m/m]	
10 Flaring tool set (Designed specifically for R410A)	
11 Gas leak detector (Designed specifically for R410A)	
12 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	
13 Pipe bender	

## SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)




### Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
  - A firm location that may sustain the weight of the unit, and do not cause the unit or the ceiling to vibrate.
  - A place where there will be enough space for servicing. (Where space mentioned below can be secured)
  - Where wiring and the piping work will be easy to conduct.
  - The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
  - A place where it can be easily drained.
  - A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
  - Places where this unit is not affected by the high frequency equipment or electric equipment.
  - Avoid installing this unit in place where there is much oil mist.
  - Places where there is no electric equipment or household under the installing unit.
  - Where the suction inlet of the unit is located far from the air inlet on the ceiling, the entire inside of ceiling acts as an air suction duct so that the capacity is reduced at the startup.
  - Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
- This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above.
- If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.

### Wireless remote control

- A place where the air-conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.

### Space for installation and service




### Inspection opening for services

Service	Inspection opening (1)	Inspection opening (2)
Clamping of the flare of required and gas refrigerant pipe	Not Use	Use
Drain pipe connection	Not Use	Use
Installation and removal of blower	Use	Not Use
Control box		
Connecting wire (between indoor and outdoor)	Not Use	Use
Unit display section (Remote control signal receiver)	Not Use	Use
Replace drain pump	Not Use	Use
Replace heat exch sensor	Not Use	Use
Replace air filter	Use	Not Use


## INSTALLATION OF INDOOR UNIT

- Remove bracket from the unit after unpacking according to process as shown below.

- (1) Loosen 2 screws.
- (2) Remove bracket.
- (3) Tighten the screws.




### Suspension Bolt Location




### Drilling of hole and fixture of sleeve (Locally procured parts)



When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.



Drill a hole with whole core drill.




In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.



\* Sleeve is for use in refrigerant piping work. Please install another pipe separately for drain piping work.


### Pipe locations

All models




## INSTALLATION OF INDOOR UNIT

### Installing the main unit


- Attach the washers and nuts to the suspension bolts.
  - Attach the hanging tool to the above nuts, and tighten the nuts.
- 

### Securing the suspension bolts

#### If steel embedded ceiling




#### If wooden ceiling



### Adjustment for horizontality

- Either use a level vial, or adjust the level according to the method below.


- Adjust so the bottom side of the unit will be leveled with the water surface as illustrated below.



- If the unit is not leveled, it may cause malfunctions or inoperation of the float switch.

### Air inlet and outlet size


- Size of air inlet and outlet of the plate.




Model	A		B
	Inlet	Outlet	
25, 35	160	99	660
50, 60			860

## CONNECTION OF REFRIGERANT PIPINGS

### Preparation

- Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.
- 

#### Flaring work




Copper pipe diameter	Clutch type flare tool for R410A	Measurement B (mm)	
		Conventional (R22) flare tool	Wing nut type
ø6.35	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø9.52	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø12.7	0.0 - 0.5	1.0 - 1.5	2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool.  
Note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.  
If a conventional flare tool is used, use a copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.

#### CAUTION

Do not apply refrigerating machine oil to the flared surface.

### Connection




- Connect the pipes on both liquid and gas sides.
- Tighten the nuts to the following torque.  
Liquid side (ø6.35): 14.0 - 18.0 N·m (1.4 - 1.8 kgf·m)  
Gas side (ø9.52): 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m)  
(ø12.7): 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m)

#### CAUTION


Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack.

- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached bands.
- Make sure to insulate both gas pipes and liquid pipes completely.  
※Incomplete insulation may cause dew condensation or water dropping.
- Use heat-resistant (120 °C or more) insulations on the gas side pipes.
- In case of using at high humidity condition, reinforce insulation of refrigerant pipes.  
Surface of insulation may cause dew condition or water dropping, if insulations are not reinforced.

<The case of using thickness of insulation is 10mm>



<The case of using reinforced insulation>



## DRAIN PIPE

- Install the drain pipe according to the installation manual in order to drain properly.  
Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.

### Work procedure


- Insert the joint to the drain hose on the indoor unit and fix it securely with the clamp (small).

- Do not apply adhesives on this end.



- Connect the drain pipe (VP25) to the joint and fix it securely with the clamp (big).

- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.

- Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
- Do not set up air vent.



- When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP-30 or bigger size for main drain pipe.




- Insulate the drain pipe.

- Be sure to insulate the joint and the drain pipe installed indoor otherwise it may cause dew condensation and water leakage.

### Drain up

- The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



### Drain test


- Conduct a drainage test after completion of the electrical work and piping work.
- During the trial, make sure that drain flows properly through the piping and that no water leaks from connections.
- In case of a new building, conduct the test before it is furnished with the ceiling.
- Be sure to conduct this test even when the unit is installed in the heating season.

### Procedures of drain test

- Supply about 1000 cc of water to the unit through the air outlet by using a feed water pump.
- Check the drain while cooling operation.

### Outline of bottom drain piping work

- If the bottom drain piping can be done with a descending gradient (1/50-1/100), it is possible to connect the pipes as shown in the drawing below.




## ELECTRICAL WIRING WORK


**Preparation of indoor unit** ○ In case of faulty wiring connection, indoor unit does not operate. Then, run lamp turns on and timer lamp blinks.

### Mounting of connecting wires

- (1) Remove the control lid.
- (2) Remove the wiring clamp.
- (3) Connect the connecting wire to the terminal block.
  - 1) Connect the connection wire securely. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
  - 2) Take care not to confuse the terminal numbers for indoor and outdoor connections.
- (4) Fix the connecting wire by wiring clamp.
- (5) Connect the connector of the remote control signal receiver to the relay wiring.
- (6) Attach the control lid.




### Securing the remote control signal receiver



Use cables for interconnection wiring to avoid loosening of the wires.  
CENELEC code for cables Required field cables.

H05RN4G1.5 (example) or 245IEC57  
H Harmonized cable type  
05 300/500 volts  
N Natural-and/or synth. rubber wire insulation  
N Polychloroprene rubber conductors insulation  
R Stranded core  
4or5 Number of conductors  
G One conductor of the cable is the earth conductor (yellow/green)  
1.5 Section of copper wire (mm<sup>2</sup>)




- (1) Open a through-hole on the wall to install the reception face for the remote control signal receiver ③.
- (2) Insert the remote control signal receiver ③ in the installation frame ④, and fix the calking section.
- (3) Fix the installation frame ④ on the wall using the flat head machine screws ⑩.
- (4) Fix the plate (display) ⑪ on the installation frame ④ using the flat head machine screws packed together with the plate (display) ⑩.

## INSTALLATION OF WIRELESS REMOTE CONTROL


### Mounting method of battery

- Pull out the cover and mount the batteries [R03 (AAA, Micro), x2 pieces] in the body regularly.  
(Fit the poles with the indication marks, ⊕ & ⊖ without fail)
- Do not use new and old batteries together.



### Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.




## INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

When two air-conditioners are installed in the same room, use this setting when the two air-conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.

### Setting the wireless remote control

- (1) Pull out the cover and take out batteries.
- (2) Disconnect the switching line next to the battery with wire cutters.




Disconnect

- (3) Insert batteries. Close the cover.

### Setting an indoor unit

- (1) Turn off the power source, and turn it on after 1 minute.
- (2) Point the wireless remote control that was set according to the procedure described on the left side at the unit display section and send a signal by pressing the ACL switch on the wireless remote control.  
Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the unit display section for some time.
- (3) Check that the reception buzzer sound "pip" is emitted from the indoor unit.  
At completion of the setting, the indoor unit emits a buzzer sound "pip". (If no reception tone is emitted, start the setting from the beginning again.)




## HOW TO RELOCATE OR DISPOSE OF THE UNIT

- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.
- Forced cooling operation  
Turn off power source. Turn on power source again after a while. Then, press the ON/OFF button continuously for at least 5 seconds. (The operation will start.)

<How to pump down>

- (1) Connect charge hose to check joint of outdoor unit.
- (2) Liquid side : Close the liquid valve with hexagon wrench key.  
Gas side : Fully open the gas valve.  
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- (3) After low pressure gauge become 0.01MPa, stop cooling operation and close the gas valve.



## TERMINAL CONNECTION FOR AN INTERFACE

- (1) Remove the control lid. (Remove the screw.)
- (2) There is a terminal (respectively marked with CNS) for the indoor control board.  
In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit.  
For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".

## INSTALLATION TEST CHECK POINTS

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. Explain to the customer how to use the unit and how to take care of the unit following the installation manual.

### After installation

- |  |  |
|--|--|
| <input type="checkbox"/> Power cables and connecting wires are securely fixed to the terminal block. (Both indoor and outdoor) | <input type="checkbox"/> No gas leaks from the joints of the service valve.                |
| <input type="checkbox"/> The power source voltage is correct as the rating.  | <input type="checkbox"/> The pipe joints for indoor and outdoor pipes have been insulated. |
| <input type="checkbox"/> The drain hose is fixed securely.   | <input type="checkbox"/> The screw of the control lid is tightened securely.               |
| <input type="checkbox"/> Service valve is fully open.  |  |

### Test run

- |   |   |
|---|---|
| <input type="checkbox"/> Air-conditioning operation is normal.  | <input type="checkbox"/> Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)   |
| <input type="checkbox"/> No abnormal noise.                     | When the air-conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction. |
| <input type="checkbox"/> Water drains smoothly.                 |   |
| <input type="checkbox"/> Protective functions are not working.  |   |
| <input type="checkbox"/> The wireless remote control is normal. |   |

## (4) 4way ceiling cassette type (FDTC)

Models FDTC25VF, 35VF, 50VF, 60VF

This manual is for the installation of an indoor unit.

For remote control installation, refer to page 384. For wireless kit installation, refer to page 389. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 30.

This unit must always be used with the panel.

### SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, [WARNING] and [CAUTION].  
[WARNING]: Wrong installation would cause serious consequences such as injuries or death.  
[CAUTION]: Wrong installation might cause serious consequences depending on circumstances.  
Both mentions the important items to protect your health and safety so strictly follow them by any means.  
The meanings of "Marks" used here are as shown as follows:  
[S] Never do it under any circumstances. [O] Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.  
Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

### WARNING

- **Installation should be performed by the specialist.**  
If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**  
Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).**  
If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accidents.
- **Use the genuine accessories and the specified parts for installation.**  
If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**  
If the refrigerant contacts the fire, toxic gas is produced.
- **Install the unit in a location that can hold heavy weight.**  
Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**  
Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**  
If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**  
Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**  
Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel properly.**  
Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**  
If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R410A.**  
Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**  
If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**  
Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**  
If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**  
If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**  
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**  
Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**  
Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**  
If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**  
Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**  
It could cause electric shock, unit failure and improper running.


### CAUTION

- **Perform earth wiring surely.**  
Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short circuit.
- **Earth leakage breaker must be installed.**  
If the earth leakage breaker is not installed, it can cause electric shocks.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**  
Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**  
Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**  
If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfuric acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**  
It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**  
Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**  
Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**  
It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**  
Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**  
It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**  
Places where flammable gas could leak.  
Places where carbon fiber, metal powder or any powder is floated.  
Places where the substances which affect the air-conditioner are generated such as sulfide gas, chlorine gas, acid, alkali or ammoniac atmospheres.  
Places exposed to oil mist or steam directly.  
On vehicles and ships  
Places where machinery which generates high harmonics is used.  
Places where cosmetics or special sprays are frequently used.  
Highly salted area such as beach.  
Heavy snow area  
Places where the system is affected by smoke from a chimney.  
Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**  
Locations with any obstacles which can prevent inlet and outlet air of the unit  
Locations where vibration can be amplified due to insufficient strength of structure.  
Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)  
Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)  
Locations where drainage cannot run off safely.  
It can affect performance or function and etc..
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**  
Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**  
It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**  
If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**  
Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**  
Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**  
If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**  
Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**  
Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**  
Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**  
Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**  
Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**  
It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**  
It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**  
The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**  
It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**  
Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**  
It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.



#### ④ Installation of indoor unit (continued)

- Make sure to install the indoor unit horizontally. Confirm the levelness of the indoor unit with a level gauge or transparent hose filled with water. Keep the height difference at both ends of the indoor unit within 3mm.
- Tighten four upper nuts and fix the unit after height and levelness adjustment.




##### Caution

- Do not adjust the height by adjusting upper nuts. It will cause unexpected stress on the indoor unit and it will lead to deformation of the unit, failure of attaching a panel, and generating noise from the fan.
- Make sure to install the indoor unit horizontally and set the gap between the unit underside and the ceiling plane properly. Improper installation may cause air leakage, dew condensation, water leakage and noise.
- Even after decorative panel attached, still the unit height can be adjusted finely. Refer to the installation manual for decorative panel for details.
- Make sure there is no gap between decoration panel and ceiling surface, and between decoration panel and the indoor unit. The gap may cause air leakage, dew condensation and water leakage.
- In case decorative panel is not installed at the same time, or ceiling material is installed after the unit installed, put the cardboard template for installation attached on the package (packing material of cardboard box) on the bottom of the unit in order to avoid dust coming into the indoor unit.

#### ⑤ Refrigerant pipe

##### Caution

- Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product or a nut compatible with JIS B 8607, Class 2.  
Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
- In case of reuse: Do not use old flare nut, but use the one attached to the unit or compatible with JIS B 8607, Class 2.
- In case of reuse: Flare the end of pipe replaced partially for R410A.



Pipe dia. φ mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type) For R410A	Conventional tool		
6.35	0.8	0 ~ 0.5	0.7 ~ 1.3	8.9 ~ 9.1	14 ~ 18
9.52	0.8			12.8 ~ 13.2	34 ~ 42
12.7	0.8			16.2 ~ 16.6	49 ~ 61
15.88	1			19.3 ~ 19.7	68 ~ 82
19.05	1.2			23.6 ~ 24.0	100 ~ 120

- Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H 3300) for refrigeration pipe installation.  
In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
- Do not use any refrigerant other than R410A.  
Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.
- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
- Use special tools for R410A refrigerant.

##### Work procedure


- Remove the flare nut and blind flanges on the pipe of the indoor unit.  
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.  
(Gas may come out at this time, but it is not abnormal.)  
● Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
- Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.  
※ Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending.  
Do not twist a pipe or collapse to 2/3D or smaller.  
※ Do a flare connection as follows:  
● Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.  
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.  
● Make sure to insulate both gas pipes and liquid pipes completely.  
※ Incomplete insulation may cause dew condensation or water dropping.  
● Use heat-resistant (120 °C or more) insulations on the gas side pipes.  
● In case of using at high humidity condition, reinforce insulation of refrigerant pipes.  
Surface of insulation may cause dew condition or water dropping, if insulations are not reinforced.
- Refrigerant is charged in the outdoor unit.  
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

##### Caution:


Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.  
Refrigerating machine oil may be applied to the internal surface of flare only.

#### ⑤ Refrigerant pipe (continued)

<The case of using thickness of insulation is 10mm>



<The case of using reinforced insulation>




#### ⑥ Drain pipe

##### Caution


- Install the drain pipe according to the installation manual in order to drain properly.  
Imperfection in draining may cause flood indoors and wetting the household goods etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

##### Work procedure


- Make sure to insert the drain hose (the end mode of soft PVC) to the end of the step part of drain socket.  
Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw within 5mm left to the nut.  
● Do not apply adhesives on this end.




- Prepare a joint for connecting VP-20 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP-20 pipe (prepare on site).  
※ As for drain pipe, apply VP-20 made of rigid PVC which is on the market.  
● Make sure that the adhesive will not get into the supplied drain hose.  
It may cause the flexible part broken after the adhesive is dried up and gets rigid.  
● Do not bend or make an excess offset on the drain hose as shown in the picture.  
Bend or excess offset will cause drain leakage.



- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.  
● Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.  
● Do not set up air vent.



- When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP-30 or bigger size for main drain pipe.




## ⑥ Drain pipe (continued)

4. Insulate the drain pipe.
  - Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
  - ※ After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.


### Drain up

- The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



### Drain test

- After installation of drain pipe, make sure that drain system work in good condition and no water leakage from joint and drain pan. Check if the motor sound of drain pump is normal or not.
  - Do drain test even if installation of heating season.
  - For new building cases, make sure to complete the test before hanging the ceiling.
1. Pour water of about 1000cc into the drain pan in the indoor unit by pump so as not to get the electrical component wet.
  2. Make sure that water is drained out properly and there is no water leakage from any joints of the drain pipe at the test. Confirm that the water is properly drained out while the drain motor is operating. At the drain socket (transparent), it is possible to check if the water is drained out properly.
  3. Unplug the drain plug on the indoor unit to remove remaining water on the drain pan after the test, and re-plug it. And insulate the drain pipe properly finally.



### Drain pump operation


- Drain pump can be operated by remote control (wired).  
Drain pump can be operated by remote controller (wired).  
For the operation method, refer to [Operation for drain pump](#) in the installation manual for wiring work.
- In case electrical wiring work not finished  
Drain pump will run continuously when the dip switch "SW7-1" on the indoor unit PCB is turned ON, the Connector CNB is disconnected, and then the power source (220-240VAC on the terminal block [ ① and ② ] or [ ④ and ⑤ ] ) is turned ON.  
Make sure to turn OFF "SW7-1" and reconnect the Connector CNB after the test.

## ⑦ Wiring-out position and wiring connection


- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country. Be sure to use an exclusive circuit.
  - Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
  - Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
  - Be sure to do D type earth work.
  - For the details of electrical wiring work, see attached instruction manual for electrical wiring work.
1. Remove a lid of the control box (1 screws).
  2. Hold each wiring inside the unit and fasten them to terminal block securely.
  3. Fix the wiring with clamp.
  4. Install a lid of the control box back to original place.

## ⑦ Wiring-out position and wiring connection (continued)

### Single split (PAC) series



### VRF (KX) series



### Main fuse specification

Specification	Part No.
T3.15A L250V	SSA564A149F

## ⑧ Panel installation

- After wiring work finished, install the panel on the indoor unit.
- Refer to attached panel installation manual for details.

### Accessory items

1	Hook		1 piece	For fixing temporarily
2	Chain		2 pieces	
3	Bolt		4 pieces	For installing the panel
4	Screw		1 piece	For attaching a hook
5	Screw		2 pieces	For attaching a chain

- Attach the panel on the indoor unit after electrical wiring work.
- Refer to attached manual for panel installation for details.

## ⑨ Check list after installation

- Check the following items after all installation work completed.

Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Supply voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
There is mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	

# PANEL INSTALLATION MANUAL

PJA012D783


Please read this manual together with the indoor unit's installation manual.

## ⚠ WARNING

- **Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.**  
Loose connection or hold will cause abnormal heat generation or fire.
- **Make sure the power source is turned off when electric wiring work.**  
Otherwise, electric shock, malfunction and improper running may occur.

## ① Checking the indoor unit installation position

- Read this manual together with the air-conditioner installation manual carefully.
- Check if the gap between the ceiling plane and the indoor unit is correct by inserting the level gauge into the air outlet port of the indoor unit. (See below drawing)
- Adjust the installation elevation if necessary.
- Remove the level gauge before you attach the panel.




## ② Orientation of the panel and return air grille installation

- Take note that there is an orientation to install the panel.
  - Attach the panel with the orientation shown on the below.
  - Align the "PIPE SIDE" mark (on the panel) with the refrigerant pipes on the indoor unit.
- The intake grille can also be attached in a rotated position by 90 degrees.


### Caution

- In case the orientation of the panel is not correct, it will lead to air leakage and also it is not possible to connect the louver motor wiring.




## ③ Removing a corner panel

- Unscrew the screw from the corner area, pull the corner panel toward the direction indicated by the arrow mark.



## ④ Attaching a corner panel

- First insert the part "a" of a corner panel into the part "A" of the cover panel, engage two hooks and tighten the screw.




## ⑤ Panel installation

- Install the panel on the unit after completing the electrical wiring.

### Accessories


1	Hook		1 piece	For fixing temporarily
2	Chain		2 pieces	
3	Screw		4 pieces	For hoisting the panel
4	Screw		1 piece	For attaching a hook
5	Screw		2 pieces	For attaching a chain

- Screw in two bolts out of the four supplied with the panel by about slightly less than 5mm.  
(● mark (A) (B)) [Figure 1]



[Figure 1]

- Attach the hook supplied with the panel to the main body with the hook fixing screw (1 screw). [Figure 2]




[Figure 2]

- Open the intake grille.


- Please remove the screw of a corner panel and remove a corner panel. (four places)

- A panel is hooked on two bolts (● mark (A) (B)). [Figure 3]



[Figure 3]

6. Please rotate a hook, put in the slot on the panel, and carry out fixing the panel temporarily. [Figure 4]




[Figure 4]


7. Tighten the two bolts used for fixing the panel temporarily and the other two.

### Caution

- Improperly tightened hanging bolts can cause the problems listed below, so make sure that you have tightened them securely.




- If there is a gap remaining between the ceiling and the decorative panel even after the hanging bolts are tightened, adjust the installation level of the indoor unit again.



8. Please open the lid of a control box.


9. Like drain pump wiring, please band together by the clamp and put in louver motor wiring into a control box. [Figure 5]

10. Please connect a louver motor connector. [Figure 5]



[Figure 5]


11. Attach two chains to the intake grille with two screws. [Figure 6]



[Figure 6]

12. Replace the corner panels. Please also close a chain with a screw together then. [Figure 7]

13. Close the intake grill.



[Figure 7]

### Caution

Make sure there is no stress given on the panel when adjusting the height of the indoor unit to avoid unexpected distortion. It may cause the distortion of panel or failing to close the air return grille.

## ⑦ How to set the airflow direction

It is possible to change the movable range of the louver on the air outlet from the wired remote control. Once the top and bottom position is set, the louver will swing within the range between the top and the bottom when swing operation is chosen. It is also possible to apply different setting to each louver.

Note: This function is not able to be set with wireless remote controls or simple remote control (RCH-H3).

- 1 Stop the air-conditioner and press **SET** button and

**LOUVER** button simultaneously for three seconds or more.

The following is displayed if the number of the indoor units connected to the remote control are more than one. Go to step 4.

"DATA LOADING"

"No.1"

"1/0000"

"SELECT 1/0"

"1/0000"

- 2 Press **▲** or **▼** button. (selection of indoor unit)

Select the indoor unit of which the louver is set.

[EXAMPLE]

"1/0000"

"1/0003"

"1/0001"

"1/0002"

"1/0003"

- 3 Press **SET** button. (determination of indoor unit)

Selected indoor unit is fixed.

[EXAMPLE]

"1/0001"

"DATA LOADING"

"No.1"

"1/0000"

- 4 Press **▲** or **▼** button. (selection of louver No.)

Select the louver No. to be set according to the right figure.

[EXAMPLE]

"No.1"

"No.2"

"No.3"

"No.4"

- 5 Press **SET** button. (Determination of louver No.)

The louver No. to be set is confirmed and the display shows the upper limit of the movable range.

[EXAMPLE] If No. 1 louver is selected

"No.1 UPPER2"

"current upper limit position"

- 6 Press **▲** or **▼** button. (selection of upper limit position)

Select the upper limit of louver movable range. "position 1" is the most horizontal, and "position 6" is the most downward. "position --" is to return to the factory setting. If you need to change the setting to the default setting, use "position --".

"No.1 UPPER1"

"(the most horizontal)"

"No.1 UPPER2"

"No.1 UPPER3"

"No.1 UPPER4"

"No.1 UPPER5"

"No.1 UPPER6"

"(the most downwards)"

"No.1 UPPER--"

"(return to the default setting)"

- 7 Press **SET** button. (i in of the upper limit position)

The upper limit position is fixed and the setting position is displayed for two seconds. Then proceed to lower limit position selection display.

[EXAMPLE] "No.1 UPPER2"

"(displayed for two seconds)"

"No.1 LOWER5"

"(shows current setting)"

- 8 Press **▲** or **▼** button. (Selection of lower limit position)

Select the lower limit position of louver.

"position 1" is the most horizontal, and "position 6" is the most downwards.

"position --" is to return to the factory setting. If you need to change the setting to the default setting, use "position --".

"No.1 LOWER1"

"(the most horizontal)"

"No.1 LOWER2"

"No.1 LOWER3"

"No.1 LOWER4"

"No.1 LOWER5"

"No.1 LOWER6"

"(the most downwards)"

"No.1 LOWER--"

"(return to the default setting)"

- 9 Press **SET** button. (i in of the lower limit position)

Upper limit position and lower limit position are fixed, and the set positions are displayed for two seconds, then setting is completed.

After the setting is completed, the louver which was set moves from the original position to the lower limit position, and goes back to the original position again. (This operation is not performed if the indoor unit and/or indoor unit fan is in operation.)

[EXAMPLE] "No.1 LOWER1"

"(displayed for two seconds)"

"SET COMPLETE"

"No.1"

- 10 Press **ON/OFF** button.

Louver adjusting mode ends and returns to the original display.

For setting the swing range of other louvers, return to 1 and proceed same procedure respectively.

### Caution

If the upper limit position number and the lower limit position number are set to the same position, the louver is fixed at that position and auto swing does not function.

### ATTENTION


If you press **RESET** button during settings, the display will return to previous display.

If you press **ON/OFF** button during settings, the mode will be ended and return to original display, and the settings that have not been completed will become invalid.

When plural remote controls are connected, louver setting operation cannot be set by slave remote control.

If it is necessary to fix the louver position manually, follow the procedure mentioned below.

- Shut off the main power switch.
- Unplug the connector of the louver motor which you want to fix the position. Make sure to insulate unplugged connectors electrically with a vinyl tape.
- Adjust the louver position slowly by hand so as to be within the applicable range mentioned below table.



<Range of louver setting>

Vertical airflow direction	Horizontal 23°	Downwards 50°
Dimension L (mm)	40	24

※It can be set between 24-40mm freely.

### Caution

- Any automatic control or operation from the remote control will be disabled on the louver whose position is fixed in the above way.
- Do not set a louver beyond the specified range. Failure to observe this instruction may result in dripping, dew condensation, the fouling of the ceiling and the malfunctioning of the unit.

## (5) Ceiling suspended type (FDEN)

PFA012D621D<sub>△</sub>B

## Model FDEN50VF

This manual is for the installation of an indoor unit.

For remote control installation, refer to page 384. For wireless kit installation, refer to page 400. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 30.

## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **△WARNING** and **△CAUTION**.  
**△WARNING**: Wrong installation would cause serious consequences such as injuries or death.  
**△CAUTION**: Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.  
 The meanings of "Marks" used here are as shown as follows:  
 ⚠ Never do it under any circumstances. ⚡ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.  
 Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

## △WARNING

- **Installation should be performed by the specialist.**  
 If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**  
 Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).**  
 If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accidents.
- **Use the genuine accessories and the specified parts for installation.**  
 If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**  
 If the refrigerant contacts the fire, toxic gas is produced.
- **Install the unit in a location that can hold heavy weight.**  
 Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**  
 Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**  
 If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**  
 Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**  
 Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel properly.**  
 Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**  
 If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R410A.**  
 Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**  
 If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**  
 Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**  
 If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**  
 If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**  
 If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**  
 Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**  
 Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**  
 If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**  
 Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**  
 It could cause electric shock, unit failure and improper running.

## △ CAUTION


- **Perform earth wiring surely.**  
 Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure, electric shock and fire due to a short circuit.
- **Earth leakage breaker must be installed.**  
 If the earth leakage breaker is not installed, it can cause fire and electric shocks.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**  
 Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**  
 Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**  
 If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**  
 It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**  
 Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**  
 Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**  
 It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**  
 Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**  
 It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  - Places where flammable gas could leak.
  - Places where carbon fiber, metal powder or any powder is floated.
  - Place where the substances which affect the air-conditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammoniac atmospheres.
  - Places exposed to oil mist or steam directly.
  - On vehicles and ships
  - Places where machinery which generates high harmonics is used.
  - Places where cosmetics or special sprays are frequently used.
  - Highly salted area such as beach.
  - Heavy snow area
  - Places where the system is affected by smoke from a chimney.
  - Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  - Locations with any obstacles which can prevent inlet and outlet air of the unit
  - Locations where vibration can be amplified due to insufficient strength of structure.
  - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  - Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  - Locations where drainage cannot run off safely.
  - It can affect performance or function and etc..
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**  
 Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**  
 It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**  
 If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**  
 Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**  
 Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**  
 If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**  
 Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**  
 Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**  
 Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**  
 Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**  
 Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**  
 It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**  
 It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**  
 The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**  
 It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**  
 Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**  
 It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

## ① Before installation

- Install correctly according to the installation manual.
- Confirm the following points:
  - Unit type/Power source specification
  - Pipes/Wires/Small parts
  - Accessory items

### Accessory item


For unit hanging	For refrigerant pipe	For drain pipe	For air return grille
Flat washer (M10)	Pipe cover (large)	Drain hose (with clamp)	Drain hose (with clamp)
Paper pattern	Pipe cover (small)	Hose clamp	Fixing bracket
			Screw
			Heavy insulation
			Screw
8	1	1	4
For unit hanging	For heat insulation of gas pipe	For heat insulation of liquid pipe	For fixing of pipe connection
			For drain pipe mounting
			For fixing of drain hose
			For installing of fixing bracket
			For drain hose
			For fixing air return grille



## ② Selection of installation location for the indoor unit

- Select the suitable areas to install the unit under approval of the user.
  - Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
  - Areas where there is enough space to install and service.
  - Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
  - Areas where there is no obstruction of airflow on both air return grille and air supply port.
  - Areas where fire alarm will not be accidentally activated by the air-conditioner.
  - Areas where the supply air does not short-circuit.
  - Areas where it is not influenced by draft air.
  - Areas not exposed to direct sunlight.
  - Areas where dew point is lower than around 23°C and relative humidity is lower than 80%. This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above.
  - Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
  - Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
  - Areas where there is no influence by the heat which cookware generates.
  - Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
  - Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation. (A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air-conditioner might not work properly.)
- Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.
- If there are 2 units of wireless type, keep them away for more than 6m to avoid malfunction due to cross communication.
- When plural indoor units are installed nearby, keep them away for more than 4 to 5m.

### Space for installation and service




## ③ Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant.
  - For grid ceiling
    - When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
  - In case the unit is hung directly from the slab and is installed on the ceiling plane which has enough strength.
    - When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.
- Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.

## ③ Preparation before installation (continued)


### Pitch of suspension bolts and pipe position

#### Pitch of suspension bolts



Series	type	A (mm)	B (mm)
Single Split (PAC) series	40 to 50type	1070	1022
	60 to 71type	1320	1272
	100 to 140type	1620	1572
VRF (KX) series	36 to 56type	1070	1022
	71type	1320	1272
	112 to 140type	1620	1572

#### Pipe position




#### Haulage

- Move the box as close to the installation area as possible packed.
- If it must be unpacked, wrap the unit with a nylon sling, and be careful not to damage the unit.
- If you need to lay the unit on a floor after unpacking, always put it with the intake grille facing upward.

### Preparation before installation


#### 1. Remove the air return grille.

Slide stoppers (4 places) of the catches, then pull out the pins (4 or 6 places).




#### 3. Remove the hanging plate.

Remove the screw, and then loosen the fixing bolts.



### Location of pipe outlets



※The outlet through which the pipings are taken out is available in three directions.

※Pipes can be taken out in 3 directions (rear, right or top).

- Cut out holes using nippers, etc.
- Cut out holes to take out pipes along the cutoff line on the rear cover.
- Cut out the top face cover aligning to the piping position.
- When taking pipe out to right-hand side, cut out a hole along the groove at the inside of side panel.
- After installing pipes and wires, seal clearances around pipes and wires with putty, etc. to shut off dust.

Make sure to install the covers at rear and top in order to protect the inside of unit from intrusion of dust or protect wires from damages by sharp edges. When taking them out to the right-hand side, remove burrs or sharp edges from the cutout.



## ④ Remote control


### Installation of remote control

Up to two receiver or wired remote control can be installed in one indoor unit group.

- When both wired and wireless remote control are used
  - It is necessary to set wired or wireless remote control as slave. (For the method of changing the setting, refer to the installation manual attached to remote control or wireless kit.)
- When wired remote control are used only (wireless type)
  - It is necessary to remove the line that is connected to the receiver. Remove signal line connected to the receiver from primary side of terminal block (X, Y).

### ATTENTION

- ① Insulate with tape the removed line.
- ② The LED of that removed connector will not be able to make any indication.




## ⑤ Installation of indoor unit

### Work procedure

1. Select the suspension bolt locations and the pipe hole location.  
(1) Use enclosed paper pattern as a reference, and drill the holes for the suspension bolts and pipe.  
※Decide the locations based on direct measurements.  
(2) Once the locations are properly placed, the paper pattern can be removed.
2. Install the suspension bolts in place.
3. Fix with 4 suspension bolts, which can endure load of 500N.
4. Check the measurements given at the right figure for the length of the suspension bolts.

5. Fasten the hanging plate onto the suspension bolts.




6. Install the unit to the hanging plate.

- Slide the unit in from front side to get it hanged on the hanging plate with the bolts.
- Fasten the four fixing bolts (M8: 2 each on the left and right sides) firmly.
- Fasten the two screws (M4: 1 each on the left and right sides).

**⚠ WARNING :** Hang a side panel on from the panel side to the rear side and then fasten it securely onto the indoor unit with screws.

※To ensure smooth drain flow, install the unit with a descending slope toward the drain outlet.

**⚠ CAUTION :** Do not give the reversed slope, which may cause water leaks.




## ⑥ Refrigerant pipe

### Caution

- Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product or a nut compatible with JIS B 8607, Class 2.

Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.

- 1) In case of reuse: Do not use old flare nut, but use the one attached to the unit or compatible with JIS B 8607, Class 2.
- 2) In case of reuse: Flare the end of pipe replaced partially for R410A.



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		For R410A	Conventional tool		
6.35	0.8	0 ~ 0.5	0.7 ~ 1.3	8.9 ~ 9.1	14 ~ 18
9.52	0.8			12.8 ~ 13.2	34 ~ 42
12.7	0.8			16.2 ~ 16.6	49 ~ 61
15.88	1			19.3 ~ 19.7	68 ~ 82
19.05	1.2			23.6 ~ 24.0	100 ~ 120

- Use phosphorus deoxidized copper alloy seamless pipe (C12207 specified in JIS H 3300) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.

- Do not use any refrigerant other than R410A.

Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.

- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.

- Use special tools for R410A refrigerant.

### Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.  
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)  
● Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressurized.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.  
※ Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.  
※ Do a flare connection as follows:  
● Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.  
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.  
● Make sure to insulate both gas pipes and liquid pipes completely.  
※ Incomplete insulation may cause dew condensation or water dropping.  
● Use heat-resistant (120 °C or more) insulations on the gas side pipes.  
● In case of using at high humidity condition, reinforce insulation of refrigerant pipes.  
Surface of insulation may cause dew condition or water dropping, if insulations are not reinforced.

## ⑥ Refrigerant pipe (continued)


4. Refrigerant is charged in the outdoor unit.  
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

### Caution:


Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.

Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thickness of insulation is 10mm>



<The case of using reinforced insulation>




The pipe can be connected from three different directions. (back, right, top)

- When the pipe is routed through the back.


If the bracket is removed, piping work will become easy.

※After piping, reinstall the removed bracket.



- When the pipe is routed through the back.

Cut the removed top cover, and install to the rear panel instead of rear cover.



## ⑦ Drain pipe

The drain pipes may face out towards the back to the left, or to the right side.

### Caution

- Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

### Work procedure

1. Insert drain hose completely to the base, and tighten the drain hose clamp securely. (adhesive must not be used.)

※When plumbing on the left side, move the rubber plug and the cylindrical insulating materials by the pipe connecting hole on the left side of the unit to the right side.

2. Fix the drain hose at the lowest point with a hose clamp supplied as an accessory.

※Give a drain hose a gradient of 10mm as illustrated in the right drawing by laying it without leaving a slack.

- Take head of electrical cables so that they may not run beneath the drain hose. A drain hose must be clamped down with a hose clamp.

△ There is a possibility that drain water overflows.

3. Connect VP-20 (prepare on site) to drain hose. (adhesive must not be used.)

※ Use commercially available rigid PVC general pipe VP-20 for drain pipe.


4. Do not to make the up-down bending and trap in the mid-way while assuming that the drain pipes is downhill. (more than 1/100)

- Never set up air vent.

5. Insulate the drain pipe.

- Insulate the drain hose clamp with the heat insulation supplied as accessories.

- When the unit is installed in a humid place, consider precautions against dew condensation such as heat insulation for the drain pipe.



## ⑦ Drain pipe (continued)

### Drain test


- After installation of drain pipe, make sure that drain system work in good condition and no water leakage from joint and drain pan.
- Do drain test even if installation of heating season.

## ⑧ Wiring-out position and wiring connection


- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country. Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- Be sure to do D type earth work.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

- Remove a lid of the electrical box (2 screws).
- Hold each wiring inside the unit and connect to a terminal block surely.
- Fix the wiring by clamps.
- Install the removed parts back to original place.

### Single split (PAC) series



### VRF(KX) series





Main fuse specification

Specification	Port No.
T3.15A L250V	SSA564A116G

## ⑨ Attaching the air return grille

- The air return grille must be attached when electrical cabling work is completed.

- Fix the chains tied to the air return grille onto the indoor unit with screws supplied as accessories (4 pieces).
- Close the air return grille. This completes the unit installation work.



## ⑩ Check list after installation

- Check the following items after all installation work completed.

Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Supply voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
There is mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	

## ⑪ How to set the airflow direction

It is possible to change the movable range of the louver on the air outlet from the wired remote control. Once the top and bottom position is set, the louver will swing within the range between the top and the bottom when swing operation is chosen. It is also possible to apply different setting to each louver.

- Stop the air-conditioner and press **SET** button and **LOUVER** button simultaneously for three seconds or more.

- The following is displayed if the number of the indoor units connected to the remote control is one. Go to step 4.


"DATA LOADING"

"No.1"

- The following is displayed if the number of the indoor units connected to the remote control are more than one.

"SELECT 1/0"

"1/0000"



- Press **▲** or **▼** button.(selection of indoor unit) ●Select the indoor unit of which the louver is set.

[EXAMPLE]  
"1/0000" ▲ "1/0001" ▼ "1/0002" ▼  
"1/0003" ▼

- Press **SET** button.(determination of indoor unit) ●Selected indoor unit is fixed.

[EXAMPLE]  
"1/0001" (displayed for two seconds)

"DATA LOADING"

"No.1"

- Press **▲** or **▼** button.(selection of louver No.) ●Select the louver No. to be set according to the right figure.

[EXAMPLE]  
"No.1" ▲ "No.2" ▼ "No.3" ▼ "No.4" ▼

- Press **SET** button.(Determination of louver No.)


- The louver No. to be set is confirmed and the display shows the upper limit of the movable range.

[EXAMPLE] If No.1 louver is selected,  
"No.1 UPPER" (current upper limit position)

- Press **▲** or **▼** button.(selection of upper limit position)

- Select the upper limit of louver movable range.  
"position 1" is the most horizontal, and "position 6" is the most downward.  
"position --" is to return to the factory setting. If you need to change the setting to the default setting, use "position --".

"No.1 UPPER" (the most horizontal)  
"No.1 UPPER2" ▼  
"No.1 UPPER3" ▼  
"No.1 UPPER4" ▼  
"No.1 UPPER5" ▼  
"No.1 UPPER6" ▼ (the most downwards)  
"No.1 UPPER--" ▲ (return to the default setting)



- Press **SET** button.(Fixing of the upper limit position)

- The upper limit position is fixed and the setting position is displayed for two seconds. Then proceed to lower limit position selection display.

[EXAMPLE]  
"No.1 UPPER2" (displayed for two seconds)  
"No.1 LOUVER" (shows current setting)

- Press **▲** or **▼** button.(Selection of lower limit position)

- Select the lower limit position of louver.  
"position 1" is the most horizontal, and "position 6" is the most downwards.  
"position --" is to return to the factory setting. If you need to change the setting to the default setting, use "position --".


"No.1 LOUVER" (the most horizontal)  
"No.1 LOUVER2" ▼  
"No.1 LOUVER3" ▼  
"No.1 LOUVER4" ▼  
"No.1 LOUVER5" ▼  
"No.1 LOUVER6" ▼ (the most downwards)  
"No.1 LOUVER--" ▲ (return to the default setting)

- Press **SET** button.(Fixing of the lower limit position)

- Upper limit position and lower limit position are fixed, and the set positions are displayed for two seconds, then setting is completed.

- After the setting is completed, the louver which was set moves from the original position to the lower limit position, and goes back to the original position again. (This operation is not performed if the indoor unit and/or indoor unit fan is in operation.)

[EXAMPLE]  
"No.1 LOUVER" (displayed for two seconds)  
"SET COMPLETE"  
"No.1"



- Press **ON/OFF** button.

- Louver adjusting mode ends and returns to the original display.

### Caution

If the upper limit position number and the lower limit position number are set to the same position, the louver is fixed at that position auto swing does not function.

### ATTENTION

If you press **RESET** button during settings, the display will return to previous display. If you press **ON/OFF** button during settings, the mode will be ended and return to original display, and the settings that have not been completed will become invalid.

When plural remote controls are connected, louver setting operation cannot be set by slave remote control.

## (6) Duct connected Low / Middle static pressure type (FDUM)







## (a) Indoor unit

PJG012D008C 

















This manual is for the installation of an indoor unit.

For remote control installation, refer to page 384. For wireless kit installation, refer to page 404. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 30.































## SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels,  **WARNING** and  **CAUTION**.  
 **WARNING**: Wrong installation would cause serious consequences such as injuries or death.  
 **CAUTION**: Wrong installation might cause serious consequences depending on circumstances.  
 Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:  
 Never do it under any circumstances.  Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.  
 Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

 WARNING

- **Installation should be performed by the specialist.**   
 If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**   
 Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Check the density referred by the formula (accordance with ISO5149).**   
 If the density exceeds the limit density, please consult the dealer and install the ventilation system.
- **Use the genuine accessories and the specified parts for installation.**   
 If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**   
 If the refrigerant contacts the fire, toxic gas is produced.
- **Install the unit in a location that can hold heavy weight.**   
 Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**   
 Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**   
 If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**   
 Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**   
 Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel properly.**   
 Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**   
 If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R410A.**   
 Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**   
 If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**   
 Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**   
 If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**   
 If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**   
 If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**   
 Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**   
 Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**   
 If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**   
 Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**   
 It could cause electric shock, unit failure and improper running.

 CAUTION

- **Perform earth wiring surely.**   
 Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock or fire due to a short circuit.
- **Earth leakage breaker must be installed.**   
 If the earth leakage breaker is not installed, it could cause electric shocks or fire.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**   
 Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**   
 Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**   
 If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfuric acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**   
 It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**   
 Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**   
 Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**   
 It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**   
 Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**   
 It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**   
 - Places where flammable gas could leak.  
 - Places where carbon fiber, metal powder or any powder is floated.  
 - Place where the substances which affect the air-conditioner are generated such as sulfide gas, chlorine gas, acid, alkali or aromatic atmospheres.  
 - Places exposed to oil mist or steam directly.  
 - On vehicles and ships  
 - Places where machinery which generates high harmonics is used.  
 - Places where cosmetics or special sprays are frequently used.  
 - Highly salted area such as beach.  
 - Heavy snow area  
 - Places where the system is affected by smoke from a chimney.  
 - Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**   
 - Locations with any obstacles which can prevent inlet and outlet air of the unit  
 - Locations where vibration can be amplified due to insufficient strength of structure.  
 - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)  
 - Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)  
 - Locations where drainage cannot run off safely.  
 It can affect performance or function and etc..
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**   
 Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**   
 It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**   
 If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**   
 Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**   
 Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**   
 If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**   
 Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**   
 Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**   
 Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**   
 Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**   
 Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**   
 It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**   
 It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**   
 The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**   
 It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**   
 Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**   
 It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

○ This model is middle static ducted type air-conditioning unit. Therefore, do not use this model for direct blow type air-conditioning unit.

## ① Before installation


● Install correctly according to the installation manual.

● Confirm the following points:

○ Unit type/Power source specification    ○ Pipes/Wires/Small parts    ○ Accessory items

### Accessory item

For hanging	For refrigerant pipe			For drain pipe		
Flat washer (M10)	Pipe cover (big)	Pipe cover (small)	Strap	Pipe cover (big)	Pipe cover (small)	Drain hose
8	1	1	4	1	1	1
For unit hanging	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting
						For drain hose mounting



Accessory parts are stored inside this section side.

## ② Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- Areas where there is no obstruction of airflow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air-conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.  
(This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.)
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.  
(A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air-conditioner might not work properly.)


② Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

### Space for installation and service


● Make installation altitude over 2.5m.

(Indoor Unit)

Select either of two cases to keep space for installation and services.



Notes (a) There must not be obstacle to draw out fan motor. (hatched area)  
(b) Install refrigerant pipe, drain pipe, and wiring so as not to cross hatched area.



(Size of inspection hole)		UNIT: mm	
Single type	40-50	60-71	100-140
Multi type	22-56	71-90	112-160
A	1100	1300	1720
B	620	725	

## ③ Preparation before installation

● If suspension bolt becomes longer, do reinforcement of earthquake resistant.

○ For grid ceiling


When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.

○ In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.

When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.

● Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.

### Suspension Bolt Location



## ⑤ Duct Work

- ① A corrugated board (for preventing sputtering) is attached to the main body of the air-conditioner (on the outlet port). Do not remove it until connecting the duct.


● An air filter can be provided on the main body of the air-conditioner (on the inlet port). Remove it when connecting the duct on the inlet port.

### ② Blowout duct

- Use rectangular duct to connect with unit.

Duct size for each unit is as shown below.


	UNIT: mm		
Single type	40-50	60-71	100-140
Multi type	22-56	71-90	112-140
A	682	882	1202
B	172	172	172




- Duct should be at their minimum length.
- We recommend to use sound and heat insulated duct to prevent it from condensation.
- Connect duct to unit before ceiling attachment.

### ③ Inlet port


- When shipped the inlet port lies on the back.
- When connecting the duct to the inlet port, remove the air filter if it is fitted to the inlet port.
- When placing the inlet port to carry out suction from the bottom side, use the following procedure to replace the suction duct joint and the bottom plate.



- Remove the screws which fasten the bottom plate and the duct joint on the inlet port side of the unit.



- Replace the removed bottom plate and duct joint.




- Fit the duct joint with a screw; fit the bottom plate.


- Make sure to insulate the duct to prevent dewing on it.

### ④ Install the specific blowout duct in a location where the air will circulate to the entire room.

- Conduct the installation of the specific blowout hole and the connection of the duct before attaching them to the ceiling.
- Insulate the area where the duct is secured by a band for dew condensation prevention.




### ⑤ Make sure provide an inspection hole on the ceiling. It is indispensable to service electric equipment, motor, functional components and cleaning of heat exchanger.



### Bad example of duct work

- If a duct is not provided at the suction side but it is substituted with the space over the ceiling, humidity in the space will increase by the influence of capacity of ventilation fan, strength of wind blowing against the out door air louver, weather (rainy day) and others.
  - Moisture in air is likely to condense over the external plates of the unit and to drip on the ceiling. Unit should be operated under the conditions as listed in the above table and within the limitation of wind volume. When the building is a concrete structure, especially immediately after the construction, humidity tends to rise even if the space over the ceiling is not substituted in place of a duct. In such occasion, it is necessary to insulate the entire unit with glass wool (25mm). (Use a wire net or equivalent to hold the glass wool in place.)
  - It may run out the allowable limit of unit operation (Example: When outdoor air temperature is 35°C DB, suction air temperature is 27°C WB) and it could result in such troubles as compressor overload, etc..
  - There is a possibility that the blow air volume may exceed the allowable range of operation due to the capacity of ventilation fan or strength of wind blowing against external air louver so that drainage from be heat exchanger may fall to reach the drain pan but leak outside (Example: drip on to the ceiling) with consequential water leakage in the room.
- If vibration damping is not conducted between the unit and the duct, and between the unit and the slab, vibration will be transmitted to the duct and vibration noise may occur. Also, vibration may be transmitted from the unit to the slab. Vibration damping must be performed.




## ⑤ Duct Work (continued)

### Connecting the air intake/vent ducts

#### ① Fresh Air Intake


[for air intake duct only]

- Use the side fresh air intake hole, or supply through a part of the suction duct.



[for simultaneous air intake/vent]

- Intake air through the suction duct. (the side cannot be used)



#### ② Air Vent

- Use the side air vent hole. (always use together with the air intake)



- Insulate the duct to protect it from dew condensation.


## ⑥ Refrigerant pipe

### Caution

- Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product or a nut compatible with JIS B 8607, Class 2.

Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.

- In case of reuse: Do not use old flare nut, but use the one attached to the unit or compatible with JIS B 8607, Class 2.
- In case of reuse: Flare the end of pipe replaced partially for R410A.



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)	Conventional tool		
6.35	0.8	For R410A	0 ~ 0.5	8.9 ~ 9.1	14 ~ 18
9.52	0.8		0.7 ~ 1.3	12.8 ~ 13.2	34 ~ 42
12.7	0.8			16.2 ~ 16.6	49 ~ 61
15.88	1			19.3 ~ 19.7	68 ~ 82
19.05	1.2			23.6 ~ 24.0	100 ~ 120

- Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H 3300) for refrigeration pipe installation.

In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.


- Do not use any refrigerant other than R410A.

Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.

- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.

- Use special tools for R410A refrigerant.

### Piping work



When conducting piping work, make sure to allow the pipes to be aligned in a straight line for at least 250 mm, as shown in the left illustration. (This is necessary for the drain pump to function)

### Work procedure

- Remove the flare nut and blind flanges on the pipe of the indoor unit.
  - ※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
- Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
- Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
  - ※ Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending.
  - Do not twist a pipe or collapse to 2/3D or smaller.
  - ※ Do a flare connection as follows:
    - Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.
    - When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
  - Make sure to insulate both gas pipes and liquid pipes completely.
    - ※ Incomplete insulation may cause dew condensation or water dripping.
  - Use heat-resistant (120 °C or more) insulations on the gas side pipes.
  - In case of using at high humidity condition, reinforce insulation of refrigerant pipes. Surface of insulation may cause dew condition or water dripping, if insulations are not reinforced.


## ⑥ Refrigerant pipe (continued)

4. Refrigerant is charged in the outdoor unit.  
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.


### Caution:

Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.  
Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thickness of insulation is 10mm>



<The case of using reinforced insulation>



## ⑦ Drain pipe

### Caution


- Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

### Work procedure

1. Make sure to insert the drain hose (the end made of soft PVC) to the end of the step part of drain socket.

Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw within 5mm left to the nut.


- Do not apply adhesives on this end.
- Do not use acetone-based adhesives to connect to the drain socket.



2. Prepare a joint for connecting VP-25 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP-25 pipe (prepare on site).


※As for drain pipe, apply VP-25 made of rigid PVC which is on the market.

- Make sure that the adhesive will not get into the supplied drain hose. It may cause the flexible part broken after the adhesive is dried up and gets rigid.
- The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.



- As for drain pipe, apply VP25 (OD32).


If apply PVC25 (OD25), connect the expanded connector to the drain hose, with adhesive. (Multi unit only)




## ⑦ Drain pipe (continued)

3. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.

- Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
- Do not set up air vent.



- When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP-30 or bigger size for main drain pipe.




4. Insulate the drain pipe.

- Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.

※After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

### Drain up

- The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.




Otherwise, the construction point makes it same as drain pipe construction.

### Drain test

1. Conduct a drain test after completion of the electrical work.
2. During the trial, make sure that drain flows properly through the piping and that no water leaks from connections.
3. In case of a new building, conduct the test before it is furnished with the ceiling.
4. Be sure to conduct this test even when the unit is installed in the heating season.


### Procedures

1. Supply about 1000 cc of water to the unit through the air outlet by using a feed water pump.
2. Check the drain while cooling operation.



### Outline of bottom drain piping work


- If the bottom drain piping can be done with a descending gradient (1/50-1/100), it is possible to connect the pipes as shown in the drawing below.



### Uncoupling the drain motor connector

- Uncouple the connector CNR for the drain motor as illustrated in the drawing on the right.

Note: If the unit is run with the connector coupled, drain water will be discharged from the upper drain pipe joint, causing a water leak.




## (b) Replacement procedure of the fan unit


Notes (1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary to replace.

(2) For the maintenance space, refer to page 138.

(i) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.




(ii) Take out the fan unit in the arrow direction.




### 3. PIPING SYSTEMS

Models SCM40ZM-S, 45ZM-S




\*1 Humidity sensor  
SRK35ZM-S and SRF series only.



\*1 Gas line  
 Model 20, 25, 35 :  $\phi$  9.52  
 Model 50, 60 :  $\phi$  12.7

\*2 Humidity sensor  
 SRK50, 60ZMX-S, SRK35, 50ZM-S and SRF series only.

Models SCM50ZM-S, 60ZM-S



\*1 Gas line


Model 20, 25, 35 :  $\phi 9.52$

Model 50, 60 :  $\phi 12.7$

\*2 Humidity sensor

SRK50, 60ZMX-S, SRK35, 50ZM-S and SRF series only.


Models SCM71ZM-S, 80ZM-S



\*1 Gas line 20, 25, 35 type : φ 9.52  
50, 60 type : φ 12.7  
71 type : φ 15.88

\*2 Humidity sensor  
SRK50, 60ZMX-S, 35, 50ZM-S, 71ZR-S and SRF series only.

Model SCM100ZM-S




\*2 Humidity sensor  
SRK50, 60ZMX-S, 35, 50ZM-S, 71ZR-S and SRF series only.

## 4. RANGE OF USAGE & LIMITATIONS

### Models SCM40, 45, 50, 60

Model		SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S
Item					
Indoor intake air temperature (Upper, lower limits)	Cooling	Approximately 18 to 32℃			
	Heating	Approximately 15 to 30℃			
Outdoor air temperature (Upper, lower limits)	Cooling	Approximately -15 to 43℃			
	Heating	Approximately -15 to 24℃			
Indoor units that can be used in combination	Number of connected units	2 units		2 to 3 units	
	Total of indoor Units (class kW)	4.0–6.0kW	4.5–7.0kW	5.0–8.5kW	6.0–11.0kW
Total length for all rooms		Max. 30m		Max. 40m	
Length for one indoor unit		Max. 25m			
Difference in height between indoor and outdoor units	When indoor unit is above outdoor unit (A)	Max. 15m			
	When indoor unit is below outdoor unit (B)	Max. 15m			
Difference in height between indoor units (C)		Max. 25m			
Compressor stop/start frequency	1 cycle time	8 min or more (from stop to stop or from start to start)			
	Stop time	3 min or more			
Power source voltage	Voltage fluctuation	Within ±10% of rated voltage			
	Voltage drop during start	Within ±15% of rated voltage			
	Interval unbalance	Within ±3% of rated voltage			
Power cable length		32m <sup>(1)</sup>			

Note(1) The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.




**Models SCM71, 80, 100, 125**

Model		SCM71ZM-S	SCM80ZM-S	SCM100ZM-S	SCM125ZM-S
Item					
Indoor intake air temperature (Upper, lower limits)	Cooling	Approximately 18 to 32℃			
	Heating	Approximately 15 to 30℃			
Outdoor air temperature (Upper, lower limits)	Cooling	Approximately -15 to 43℃			
	Heating	Approximately -15 to 24℃			
Indoor units that can be used in combination	Number of connected units	2 to 4 units		4 <sup>(1)</sup> to 5 units	4 <sup>(1)</sup> to 6 units
	Total of indoor Units (class kW)	7.0–12.5kW	8.0–13.5kW	10.0–16.0kW	19.5kW
Total length for all rooms		Max. 70m		Max. 90m	
Length for one indoor unit		Max. 25m			
Difference in height between indoor and outdoor units	When indoor unit is above outdoor unit (A)	Max. 20m			
	When indoor unit is below outdoor unit (B)	Max. 20m			
Difference in height between indoor units (C)		Max. 25m			
Compressor stop/start frequency	1 cycle time	8 min or more (from stop to stop or from start to start)			
	Stop time	3 min or more			
Power source voltage	Voltage fluctuation	Within ±10% of rated voltage			
	Voltage drop during start	Within ±15% of rated voltage			
	Interval unbalance	Within ±3% of rated voltage			
Power cable length		32m <sup>(2)</sup>			

Notes(1) In case of combination with SRK-ZMX-S, SRK71ZR-S, FDEN50VF only, 3 Indoor units can be connectable.

In case of SRK71ZR-S+SRK71ZR-S, 2 Indoor units can be connectable.

- (2) The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.



## 5. TABLE OF INDOOR UNIT COMBINATIONS

- The combinations of the indoor units is indicated by numbers. They are read as follows.  
(Example) SRK20ZMX-S→20 SRK25ZMX-S→25
- The capacity of the indoor units is shown by rooms. If this exceeds the maximum capacity of the outdoor unit, the demand capacity will be proportionally distributed.
- If units are to be combined, use the table below to make the proper selection.

### • Number of connectable indoor units

	SCM40ZM-S,45ZM-S	SCM50ZM-S,60ZM-S	SCM71ZM-S,80ZM-S	SCM100ZM-S	SCM125ZM-S
MIN	2	2	2	4 <sup>(1)</sup>	4 <sup>(1)</sup>
MAX	2	3	4	5	6

Note(1) In case of combination with SRK-ZMX-S, SRK71ZR-S, FDEN50VF only, 3 Indoor units can be connectable.  
In case of SRK71ZR-S+SRK71ZR-S, 2 Indoor units can be connectable.

### (1) Model SCM40ZM-S

#### (a) Indoor unit SRK\*\*ZMX-S models only

<Cooling>

Indoor unit combination		Cooling capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	2.0	-	1.8	2.0	2.8	490	530	880	2.4	2.3	2.2
	25	2.5	-	1.8	2.5	3.4	490	670	1040	3.1	2.9	2.8
	35	3.5	-	1.8	3.5	3.9	490	970	1200	4.5	4.3	4.1
2 units	20 + 20	2.00	2.00	3.0	4.0	5.7	560	840	1750	3.9	3.7	3.5
	20 + 25	2.00	2.50	3.0	4.5	5.9	560	1040	1900	4.8	4.6	4.4
	20 + 35	1.89	3.31	3.0	5.2	5.9	560	1430	1900	6.6	6.3	6.0
	25 + 25	2.50	2.50	3.0	5.0	5.9	560	1280	1900	5.9	5.6	5.4
	25 + 35	2.17	3.03	3.0	5.2	5.9	560	1430	1900	6.6	6.3	6.0

<Heating>

Indoor unit combination		Heating capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	3.0	-	1.4	3.0	3.7	470	750	1070	3.4	3.3	3.2
	25	3.4	-	1.4	3.4	4.2	470	920	1210	4.2	4.0	3.9
	35	4.5	-	1.4	4.5	5.0	470	1210	1450	5.6	5.3	5.1
2 units	20 + 20	2.25	2.25	2.0	4.5	6.9	530	900	2300	4.1	4.0	3.8
	20 + 25	2.49	3.11	2.0	5.6	6.9	530	1200	2300	5.5	5.3	5.1
	20 + 35	2.11	3.69	2.0	5.8	6.9	530	1290	2300	5.9	5.7	5.4
	25 + 25	2.90	2.90	2.0	5.8	6.9	530	1290	2300	5.9	5.7	5.4
	25 + 35	2.42	3.38	2.0	5.8	6.9	530	1290	2300	5.9	5.7	5.4

#### (b) Indoor unit except SRK\*\*ZMX-S models

<Cooling>

Indoor unit combination		Cooling capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	2.0	-	1.8	2.0	2.7	490	560	880	2.6	2.5	2.4
	25	2.5	-	1.8	2.5	3.2	490	710	1040	3.3	3.1	3.0
	35	3.5	-	1.8	3.5	3.7	490	1030	1200	4.7	4.5	4.3
2 units	20 + 20	2.00	2.00	3.0	4.0	5.6	560	880	1750	4.0	3.9	3.7
	20 + 25	2.00	2.50	3.0	4.5	5.8	560	1090	1900	5.0	4.8	4.6
	20 + 35	1.89	3.31	3.0	5.2	5.8	560	1500	1900	6.9	6.6	6.3
	25 + 25	2.50	2.50	3.0	5.0	5.8	560	1340	1900	6.2	5.9	5.6
	25 + 35	2.17	3.03	3.0	5.2	5.8	560	1500	1900	6.9	6.6	6.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	3.0	-	1.4	3.0	3.5	470	900	1070	4.1	4.0	3.8
	25	3.4	-	1.4	3.4	4.0	470	1070	1210	4.9	4.7	4.5
	35	4.5	-	1.4	4.5	4.8	470	1340	1450	6.2	5.9	5.6
2 units	20 + 20	2.25	2.25	2.0	4.5	6.7	530	930	2300	4.3	4.1	3.9
	20 + 25	2.49	3.11	2.0	5.6	6.7	530	1240	2300	5.7	5.4	5.2
	20 + 35	2.11	3.69	2.0	5.8	6.7	530	1330	2300	6.1	5.8	5.6
	25 + 25	2.90	2.90	2.0	5.8	6.7	530	1330	2300	6.1	5.8	5.6
	25 + 35	2.42	3.38	2.0	5.8	6.7	530	1330	2300	6.1	5.8	5.6

ESP-PR-1107

## (2) Model SCM45ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	2.0	-	1.8	2.0	2.8	490	530	880	2.4	2.3	2.2
	25	2.5	-	1.8	2.5	3.4	490	670	1040	3.1	2.9	2.8
	35	3.5	-	1.8	3.5	3.9	490	970	1200	4.5	4.3	4.1
2 units	20 + 20	2.00	2.00	3.0	4.0	5.7	560	840	1750	3.9	3.7	3.5
	20 + 25	2.00	2.50	3.0	4.5	5.9	560	1040	1900	4.8	4.6	4.4
	20 + 35	2.00	3.50	3.0	5.5	6.3	560	1490	2110	6.8	6.5	6.3
	25 + 25	2.50	2.50	3.0	5.0	6.2	560	1280	2050	5.9	5.6	5.4
	25 + 35	2.42	3.38	3.0	5.8	6.4	560	1740	2140	8.0	7.6	7.3
	35 + 35	2.90	2.90	3.0	5.8	6.4	560	1740	2140	8.0	7.6	7.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	3.0	-	1.4	3.0	3.7	470	750	1070	3.4	3.3	3.2
	25	3.4	-	1.4	3.4	4.2	470	920	1210	4.2	4.0	3.9
	35	4.5	-	1.4	4.5	5.0	470	1210	1450	5.6	5.3	5.1
2 units	20 + 20	2.25	2.25	2.0	4.5	7.4	530	900	2570	4.1	4.0	3.8
	20 + 25	2.49	3.11	2.0	5.6	7.4	530	1200	2570	5.5	5.3	5.1
	20 + 35	2.36	4.14	2.0	6.5	7.4	530	1500	2570	6.9	6.6	6.3
	25 + 25	3.25	3.25	2.0	6.5	7.4	530	1500	2570	6.9	6.6	6.3
	25 + 35	2.71	3.79	2.0	6.5	7.4	530	1500	2570	6.9	6.6	6.3
	35 + 35	3.25	3.25	2.0	6.5	7.4	530	1500	2570	6.9	6.6	6.3

**(b) Indoor unit except SRK\*\*ZMX-S models**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	2.0	-	1.8	2.0	2.7	490	560	880	2.6	2.5	2.4
	25	2.5	-	1.8	2.5	3.2	490	710	1040	3.3	3.1	3.0
	35	3.5	-	1.8	3.5	3.7	490	1030	1200	4.7	4.5	4.3
2 units	20 + 20	2.00	2.00	3.0	4.0	5.6	560	880	1750	4.0	3.9	3.7
	20 + 25	2.00	2.50	3.0	4.5	5.8	560	1090	1900	5.0	4.8	4.6
	20 + 35	2.00	3.50	3.0	5.5	6.2	560	1560	2110	7.2	6.9	6.6
	25 + 25	2.50	2.50	3.0	5.0	6.1	560	1340	2050	6.2	5.9	5.6
	25 + 35	2.42	3.38	3.0	5.8	6.3	560	1820	2140	8.4	8.0	7.7
	35 + 35	2.90	2.90	3.0	5.8	6.3	560	1820	2140	8.4	8.0	7.7

&lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)					Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)		Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	Min.	Standard	Max.						
1 unit	20	3.0	-	1.4	3.0	3.5	470	900	1070	4.1	4.0	3.8
	25	3.4	-	1.4	3.4	4.0	470	1070	1210	4.9	4.7	4.5
	35	4.5	-	1.4	4.5	4.8	470	1340	1450	6.2	5.9	5.6
2 units	20 + 20	2.25	2.25	2.0	4.5	7.2	530	930	2570	4.3	4.1	3.9
	20 + 25	2.49	3.11	2.0	5.6	7.2	530	1240	2570	5.7	5.4	5.2
	20 + 35	2.36	4.14	2.0	6.5	7.2	530	1550	2570	7.1	6.8	6.5
	25 + 25	3.25	3.25	2.0	6.5	7.2	530	1550	2570	7.1	6.8	6.5
	25 + 35	2.71	3.79	2.0	6.5	7.2	530	1550	2570	7.1	6.8	6.5
	35 + 35	3.25	3.25	2.0	6.5	7.2	530	1550	2570	7.1	6.8	6.5

ESP-PR-1107

## (3) Model SCM50ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	2.0	-	-	1.8	2.0	2.8	500	550	900	2.5	2.4	2.3
	25	2.5	-	-	1.8	2.5	3.4	500	720	1070	3.3	3.2	3.0
	35	3.5	-	-	1.8	3.5	3.9	500	1080	1230	5.0	4.7	4.5
	50	5.0	-	-	1.8	5.0	5.5	500	1700	2000	7.8	7.5	7.2
2 units	20 + 20	2.00	2.00	-	3.0	4.0	5.7	570	910	1800	4.2	4.0	3.8
	20 + 25	1.91	2.39	-	3.0	4.3	5.9	570	1070	1980	4.9	4.7	4.5
	20 + 35	1.82	3.18	-	3.0	5.0	6.2	570	1430	2070	6.6	6.3	6.0
	20 + 50	1.71	4.29	-	3.0	6.0	6.5	570	1960	2150	9.0	8.6	8.2
	25 + 25	2.35	2.35	-	3.0	4.7	6.2	570	1270	2070	5.8	5.6	5.3
	25 + 35	2.21	3.09	-	3.0	5.3	6.5	570	1600	2150	7.3	7.0	6.7
	25 + 50	2.00	4.00	-	3.0	6.0	6.5	570	1960	2150	9.0	8.6	8.2
	35 + 35	3.00	3.00	-	3.0	6.0	6.5	570	1960	2150	9.0	8.6	8.2
3 units	35 + 50	2.47	3.53	-	3.0	6.0	6.5	570	1960	2150	9.0	8.6	8.2
	20 + 20 + 20	1.67	1.67	1.67	3.4	5.0	7.1	690	1080	2150	5.0	4.7	4.5
	20 + 20 + 25	1.60	1.60	2.00	3.4	5.2	7.1	690	1160	2150	5.3	5.1	4.9
	20 + 20 + 35	1.49	1.49	2.61	3.4	5.6	7.1	690	1330	2150	6.1	5.8	5.6
	20 + 25 + 25	1.54	1.93	1.93	3.4	5.4	7.1	690	1260	2150	5.8	5.5	5.3
	20 + 25 + 35	1.45	1.81	2.54	3.4	5.8	7.1	690	1430	2150	6.6	6.3	6.0
	25 + 25 + 25	1.87	1.87	1.87	3.4	5.6	7.1	690	1330	2150	6.1	5.8	5.6
3 units	25 + 25 + 35	1.76	1.76	2.47	3.4	6.0	7.1	690	1490	2150	6.8	6.5	6.3

&lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	3.0	-	-	1.4	3.0	3.7	480	820	1100	3.8	3.6	3.5
	25	3.4	-	-	1.4	3.4	4.2	480	980	1240	4.5	4.3	4.1
	35	4.5	-	-	1.4	4.5	5.0	480	1280	1490	5.9	5.6	5.4
	50	5.8	-	-	1.4	5.8	6.2	480	1740	2260	8.0	7.6	7.3
2 units	20 + 20	2.95	2.95	-	2.0	5.9	7.3	540	1480	2580	6.8	6.5	6.2
	20 + 25	2.67	3.33	-	2.0	6.0	7.3	540	1530	2580	7.0	6.7	6.4
	20 + 35	2.29	4.01	-	2.0	6.3	7.3	540	1620	2580	7.4	7.1	6.8
	20 + 50	1.89	4.71	-	2.0	6.6	7.3	540	1710	2580	7.9	7.5	7.2
	25 + 25	3.05	3.05	-	2.0	6.1	7.3	540	1560	2580	7.2	6.9	6.6
	25 + 35	2.67	3.73	-	2.0	6.4	7.3	540	1650	2580	7.6	7.2	6.9
	25 + 50	2.20	4.40	-	2.0	6.6	7.3	540	1710	2580	7.9	7.5	7.2
	35 + 35	3.30	3.30	-	2.0	6.6	7.3	540	1710	2580	7.9	7.5	7.2
3 units	35 + 50	2.72	3.88	-	2.0	6.6	7.3	540	1710	2580	7.9	7.5	7.2
	20 + 20 + 20	2.00	2.00	2.00	3.0	6.0	7.5	600	1310	2580	6.0	5.8	5.5
	20 + 20 + 25	1.91	1.91	2.38	3.0	6.2	7.5	600	1400	2580	6.4	6.1	5.9
	20 + 20 + 35	1.76	1.76	3.08	3.0	6.6	7.5	600	1560	2580	7.2	6.9	6.6
	20 + 25 + 25	1.83	2.29	2.29	3.0	6.4	7.5	600	1470	2580	6.7	6.5	6.2
	20 + 25 + 35	1.70	2.13	2.98	3.0	6.8	7.5	600	1620	2580	7.4	7.1	6.8
	25 + 25 + 25	2.20	2.20	2.20	3.0	6.6	7.5	600	1560	2580	7.2	6.9	6.6
3 units	25 + 25 + 35	2.06	2.06	2.88	3.0	7.0	7.5	600	1690	2580	7.8	7.4	7.1

ESP-PR-1106

**(b) Indoor unit except SRK\*\*ZMX-S models only**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	2.0	-	-	1.8	2.0	2.7	500	580	900	2.7	2.5	2.4
	25	2.5	-	-	1.8	2.5	3.2	500	760	1070	3.5	3.3	3.2
	35	3.5	-	-	1.8	3.5	3.7	500	1140	1230	5.2	5.0	4.8
	50	5.0	-	-	1.8	5.0	5.3	500	1790	2000	8.2	7.9	7.5
2 units	20 + 20	2.00	2.00	-	3.0	4.0	5.6	570	950	1800	4.4	4.2	4.0
	20 + 25	1.91	2.39	-	3.0	4.3	5.8	570	1110	1980	5.1	4.9	4.7
	20 + 35	1.82	3.18	-	3.0	5.0	6.1	570	1490	2070	6.8	6.5	6.3
	20 + 50	1.71	4.29	-	3.0	6.0	6.3	570	2040	2150	9.4	9.0	8.6
	25 + 25	2.35	2.35	-	3.0	4.7	6.1	570	1320	2070	6.1	5.8	5.6
	25 + 35	2.21	3.09	-	3.0	5.3	6.3	570	1660	2150	7.6	7.3	7.0
	25 + 50	2.00	4.00	-	3.0	6.0	6.3	570	2040	2150	9.4	9.0	8.6
	35 + 35	3.00	3.00	-	3.0	6.0	6.3	570	2040	2150	9.4	9.0	8.6
3 units	35 + 50	2.47	3.53	-	3.0	6.0	6.3	570	2040	2150	9.4	9.0	8.6
	20 + 20 + 20	1.67	1.67	1.67	3.4	5.0	6.9	690	1120	2150	5.3	5.1	4.9
	20 + 20 + 25	1.60	1.60	2.00	3.4	5.2	6.9	690	1200	2150	5.7	5.4	5.2
	20 + 20 + 35	1.49	1.49	2.61	3.4	5.6	6.9	690	1370	2150	6.5	6.2	5.9
	20 + 25 + 25	1.54	1.93	1.93	3.4	5.4	6.9	690	1300	2150	6.2	5.9	5.6
	20 + 25 + 35	1.45	1.81	2.54	3.4	5.8	6.9	690	1470	2150	7.0	6.7	6.4
	25 + 25 + 25	1.87	1.87	1.87	3.4	5.6	6.9	690	1370	2150	6.5	6.2	5.9
	25 + 25 + 35	1.76	1.76	2.47	3.4	6.0	6.9	690	1540	2150	7.3	7.0	6.7

&lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	3.0	-	-	1.4	3.0	3.5	480	1020	1100	4.7	4.5	4.3
	25	3.4	-	-	1.4	3.4	4.0	480	1180	1240	5.4	5.2	5.0
	35	4.5	-	-	1.4	4.5	4.8	480	1470	1490	6.7	6.5	6.2
	50	5.8	-	-	1.4	5.8	6.0	480	1910	2260	8.8	8.4	8.0
2 units	20 + 20	2.95	2.95	-	2.0	5.9	7.0	540	1510	2580	6.9	6.6	6.4
	20 + 25	2.67	3.33	-	2.0	6.0	7.0	540	1560	2580	7.2	6.9	6.6
	20 + 35	2.29	4.01	-	2.0	6.3	7.0	540	1650	2580	7.6	7.2	6.9
	20 + 50	1.89	4.71	-	2.0	6.6	7.0	540	1740	2580	8.0	7.6	7.3
	25 + 25	3.05	3.05	-	2.0	6.1	7.0	540	1590	2580	7.3	7.0	6.7
	25 + 35	2.67	3.73	-	2.0	6.4	7.0	540	1680	2580	7.7	7.4	7.1
	25 + 50	2.20	4.40	-	2.0	6.6	7.0	540	1740	2580	8.0	7.6	7.3
	35 + 35	3.30	3.30	-	2.0	6.6	7.0	540	1740	2580	8.0	7.6	7.3
3 units	35 + 50	2.72	3.88	-	2.0	6.6	7.0	540	1740	2580	8.0	7.6	7.3
	20 + 20 + 20	2.00	2.00	2.00	3.0	6.0	7.3	600	1340	2580	6.3	6.1	5.8
	20 + 20 + 25	1.91	1.91	2.38	3.0	6.2	7.3	600	1430	2580	6.8	6.5	6.2
	20 + 20 + 35	1.76	1.76	3.08	3.0	6.6	7.3	600	1600	2580	7.6	7.2	6.9
	20 + 25 + 25	1.83	2.29	2.29	3.0	6.4	7.3	600	1510	2580	7.1	6.8	6.6
	20 + 25 + 35	1.70	2.13	2.98	3.0	6.8	7.3	600	1660	2580	7.9	7.5	7.2
	25 + 25 + 25	2.20	2.20	2.20	3.0	6.6	7.3	600	1600	2580	7.6	7.2	6.9
	25 + 25 + 35	2.06	2.06	2.88	3.0	7.0	7.3	600	1730	2580	8.2	7.8	7.5

ESP-PR-1106

**(4) Model SCM60ZM-S****(a) Indoor unit SRK\*\*ZMX-S models only**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	Max.						
1 unit	20	2.0	-	-	1.8	2.0	2.8	500	540	950	2.5	2.4	2.3
	25	2.5	-	-	1.8	2.5	3.4	500	720	1080	3.3	3.2	3.0
	35	3.5	-	-	1.8	3.5	3.9	500	1090	1240	5.0	4.8	4.6
	50	5.0	-	-	1.8	5.0	5.8	500	1780	2100	8.2	7.8	7.5
	60	6.0	-	-	1.8	6.0	6.3	500	2260	2370	10.4	9.9	9.5
2 units	20 + 20	2.00	2.00	-	3.0	4.0	5.7	570	750	1750	3.4	3.3	3.2
	20 + 25	2.00	2.50	-	3.0	4.5	5.9	570	990	1910	4.5	4.3	4.2
	20 + 35	1.93	3.37	-	3.0	5.3	6.2	570	1550	2110	7.1	6.8	6.5
	20 + 50	1.89	4.71	-	3.0	6.6	6.9	570	2280	2390	10.5	10.0	9.6
	20 + 60	1.68	5.03	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	25 + 25	2.45	2.45	-	3.0	4.9	6.2	570	1270	2110	5.8	5.6	5.3
	25 + 35	2.42	3.38	-	3.0	5.8	6.5	570	1840	2270	8.4	8.1	7.7
	25 + 50	2.23	4.47	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	25 + 60	1.97	4.73	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	35 + 35	3.30	3.30	-	3.0	6.6	6.9	570	2280	2390	10.5	10.0	9.6
	35 + 50	2.76	3.94	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	35 + 60	2.47	4.23	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	50 + 50	3.35	3.35	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
	50 + 60	3.05	3.65	-	3.0	6.7	6.9	570	2320	2390	10.7	10.2	9.8
3 units	20 + 20 + 20	1.90	1.90	1.90	3.6	5.7	7.5	690	1390	2390	6.6	6.3	6.0
	20 + 20 + 25	1.82	1.82	2.27	3.6	5.9	7.5	690	1410	2390	6.7	6.4	6.1
	20 + 20 + 35	1.60	1.60	2.80	3.6	6.0	7.5	690	1430	2390	6.8	6.5	6.2
	20 + 20 + 50	1.40	1.40	3.50	3.6	6.3	7.5	690	1480	2390	7.0	6.7	6.4
	20 + 20 + 60	1.28	1.28	3.84	3.6	6.4	7.5	690	1500	2390	7.1	6.8	6.5
	20 + 25 + 25	1.69	2.11	2.11	3.6	5.9	7.5	690	1410	2390	6.7	6.4	6.1
	20 + 25 + 35	1.53	1.91	2.67	3.6	6.1	7.5	690	1460	2390	6.9	6.6	6.3
	20 + 25 + 50	1.35	1.68	3.37	3.6	6.4	7.5	690	1500	2390	7.1	6.8	6.5
	20 + 25 + 60	1.26	1.57	3.77	3.6	6.6	7.5	690	1520	2390	7.2	6.9	6.6
	20 + 35 + 35	1.40	2.45	2.45	3.6	6.3	7.5	690	1480	2390	7.0	6.7	6.4
	20 + 35 + 50	1.26	2.20	3.14	3.6	6.6	7.5	690	1520	2390	7.2	6.9	6.6
	25 + 25 + 25	2.00	2.00	2.00	3.6	6.0	7.5	690	1430	2390	6.8	6.5	6.2
	25 + 25 + 35	1.79	1.79	2.51	3.6	6.1	7.5	690	1460	2390	6.9	6.6	6.3
	25 + 25 + 50	1.60	1.60	3.20	3.6	6.4	7.5	690	1500	2390	7.1	6.8	6.5
	25 + 25 + 60	1.52	1.52	3.65	3.6	6.7	7.5	690	1540	2390	7.3	7.0	6.7
	25 + 35 + 35	1.68	2.36	2.36	3.6	6.4	7.5	690	1500	2390	7.1	6.8	6.5
	25 + 35 + 50	1.52	2.13	3.05	3.6	6.7	7.5	690	1540	2390	7.3	7.0	6.7
	35 + 35 + 35	2.20	2.20	2.20	3.6	6.6	7.5	690	1520	2390	7.2	6.9	6.6

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	Max.						
1 unit	20	3.0	-	-	1.5	3.0	3.7	600	780	1330	3.6	3.4	3.3
	25	3.4	-	-	1.5	3.4	4.2	600	950	1510	4.4	4.2	4.0
	35	4.5	-	-	1.5	4.5	5.0	600	1290	1790	5.9	5.7	5.4
	50	5.8	-	-	1.5	5.8	6.4	600	1780	2310	8.2	7.8	7.5
	60	6.8	-	-	1.5	6.8	7.3	600	2120	2660	9.7	9.3	8.9
2 units	20 + 20	3.00	3.00	-	2.1	6.0	7.3	630	1490	2100	6.8	6.5	6.3
	20 + 25	2.71	3.39	-	2.1	6.1	7.5	630	1570	2550	7.2	6.9	6.6
	20 + 35	2.36	4.14	-	2.1	6.5	7.6	630	1680	3000	7.7	7.4	7.1
	20 + 50	2.00	5.00	-	2.1	7.0	7.6	630	1900	3000	8.7	8.3	8.0
	20 + 60	1.78	5.33	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	25 + 25	3.15	3.15	-	2.1	6.3	7.6	630	1630	3000	7.5	7.2	6.9
	25 + 35	2.79	3.91	-	2.1	6.7	7.6	630	1760	3000	8.1	7.7	7.4
	25 + 50	2.37	4.73	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	25 + 60	2.09	5.01	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	35 + 35	3.50	3.50	-	2.1	7.0	7.6	630	1900	3000	8.7	8.3	8.0
	35 + 50	2.92	4.18	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	35 + 60	2.62	4.48	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	50 + 50	3.55	3.55	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
	50 + 60	3.23	3.87	-	2.1	7.1	7.6	630	1940	3000	8.9	8.5	8.2
3 units	20 + 20 + 20	2.20	2.20	2.20	3.2	6.6	7.8	660	1350	3000	6.4	6.1	5.9
	20 + 20 + 25	2.06	2.06	2.58	3.2	6.7	7.8	660	1390	3000	6.6	6.3	6.0
	20 + 20 + 35	1.81	1.81	3.17	3.2	6.8	7.8	660	1510	3000	7.1	6.8	6.6
	20 + 20 + 50	1.56	1.56	3.89	3.2	7.0	7.8	660	1690	3000	8.0	7.7	7.3
	20 + 20 + 60	1.44	1.44	4.32	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	20 + 25 + 25	1.94	2.43	2.43	3.2	6.8	7.8	660	1510	3000	7.1	6.8	6.6
	20 + 25 + 35	1.73	2.16	3.02	3.2	6.9	7.8	660	1560	3000	7.4	7.1	6.8
	20 + 25 + 50	1.49	1.87	3.74	3.2	7.1	7.8	660	1740	3000	8.2	7.9	7.6
	20 + 25 + 60	1.37	1.71	4.11	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	20 + 35 + 35	1.56	2.72	2.72	3.2	7.0	7.8	660	1690	3000	8.0	7.7	7.3
	20 + 35 + 50	1.37	2.40	3.43	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	25 + 25 + 25	2.27	2.27	2.27	3.2	6.8	7.8	660	1510	3000	7.1	6.8	6.6
	25 + 25 + 35	2.06	2.06	2.88	3.2	7.0	7.8	660	1690	3000	8.0	7.7	7.3
	25 + 25 + 50	1.80	1.80	3.60	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	25 + 25 + 60	1.64	1.64	3.93	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	25 + 35 + 35	1.87	2.62	2.62	3.2	7.1	7.8	660	1740	3000	8.2	7.9	7.6
	25 + 35 + 50	1.64	2.29	3.27	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1
	35 + 35 + 35	2.40	2.40	2.40	3.2	7.2	7.8	660	1860	3000	8.8	8.4	8.1

ESP-PR-1105

**(b) Indoor unit except SRK \*\*ZMX-S models only**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	2.0	-	-	1.8	2.0	2.7	500	570	950	2.6	2.5	2.4
	25	2.5	-	-	1.8	2.5	3.2	500	760	1080	3.5	3.3	3.2
	35	3.5	-	-	1.8	3.5	3.7	500	1150	1240	5.3	5.1	4.8
	50	5.0	-	-	1.8	5.0	5.6	500	1860	2100	8.5	8.2	7.8
	60	6.0	-	-	1.8	6.0	6.1	500	2350	2370	10.8	10.3	9.9
2 units	20 + 20	2.00	2.00	-	3.0	4.0	5.6	570	800	1750	3.7	3.5	3.4
	20 + 25	2.00	2.50	-	3.0	4.5	5.8	570	1050	1910	4.8	4.6	4.4
	20 + 35	1.93	3.37	-	3.0	5.3	6.1	570	1620	2110	7.4	7.1	6.8
	20 + 50	1.89	4.71	-	3.0	6.6	6.8	570	2330	2390	10.7	10.2	9.8
	20 + 60	1.68	5.03	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	25 + 25	2.45	2.45	-	3.0	4.9	6.1	570	1340	2110	6.2	5.9	5.6
	25 + 35	2.42	3.38	-	3.0	5.8	6.4	570	1920	2270	8.8	8.4	8.1
	25 + 50	2.23	4.47	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	25 + 60	1.97	4.73	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	35 + 35	3.30	3.30	-	3.0	6.6	6.8	570	2330	2390	10.7	10.2	9.8
	35 + 50	2.76	3.94	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	35 + 60	2.47	4.23	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	50 + 50	3.35	3.35	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
	50 + 60	3.05	3.65	-	3.0	6.7	6.8	570	2370	2390	10.9	10.4	10.0
3 units	20 + 20 + 20	1.90	1.90	1.90	3.6	5.7	7.3	690	1430	2390	6.8	6.5	6.2
	20 + 20 + 25	1.82	1.82	2.27	3.6	5.9	7.3	690	1450	2390	6.9	6.6	6.3
	20 + 20 + 35	1.60	1.60	2.80	3.6	6.0	7.3	690	1470	2390	7.0	6.7	6.4
	20 + 20 + 50	1.40	1.40	3.50	3.6	6.3	7.3	690	1520	2390	7.2	6.9	6.6
	20 + 20 + 60	1.28	1.28	3.84	3.6	6.4	7.3	690	1540	2390	7.3	7.0	6.7
	20 + 25 + 25	1.69	2.11	2.11	3.6	5.9	7.3	690	1450	2390	6.9	6.6	6.3
	20 + 25 + 35	1.53	1.91	2.67	3.6	6.1	7.3	690	1500	2390	7.1	6.8	6.5
	20 + 25 + 50	1.35	1.68	3.37	3.6	6.4	7.3	690	1540	2390	7.3	7.0	6.7
	20 + 25 + 60	1.26	1.57	3.77	3.6	6.6	7.3	690	1560	2390	7.4	7.1	6.8
	20 + 35 + 35	1.40	2.45	2.45	3.6	6.3	7.3	690	1520	2390	7.2	6.9	6.6
	20 + 35 + 50	1.26	2.20	3.14	3.6	6.6	7.3	690	1560	2390	7.4	7.1	6.8
	25 + 25 + 25	2.00	2.00	2.00	3.6	6.0	7.3	690	1470	2390	7.0	6.7	6.4
	25 + 25 + 35	1.79	1.79	2.51	3.6	6.1	7.3	690	1500	2390	7.1	6.8	6.5
	25 + 25 + 50	1.60	1.60	3.20	3.6	6.4	7.3	690	1540	2390	7.3	7.0	6.7
	25 + 25 + 60	1.52	1.52	3.65	3.6	6.7	7.3	690	1580	2390	7.5	7.2	6.9
	25 + 35 + 35	1.68	2.36	2.36	3.6	6.4	7.3	690	1540	2390	7.3	7.0	6.7
	25 + 35 + 50	1.52	2.13	3.05	3.6	6.7	7.3	690	1580	2390	7.5	7.2	6.9
	35 + 35 + 35	2.20	2.20	2.20	3.6	6.6	7.3	690	1560	2390	7.4	7.1	6.8

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)						Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)			Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	Min.	Standard	max.						
1 unit	20	3.0	-	-	1.5	3.0	3.5	600	970	1330	4.5	4.3	4.1
	25	3.4	-	-	1.5	3.4	4.0	600	1140	1510	5.2	5.0	4.8
	35	4.5	-	-	1.5	4.5	4.8	600	1480	1790	6.8	6.5	6.2
	50	5.8	-	-	1.5	5.8	6.1	600	1960	2310	9.0	8.6	8.2
	60	6.8	-	-	1.5	6.8	7.0	600	2250	2660	10.3	9.9	9.5
2 units	20 + 20	3.00	3.00	-	2.1	6.0	7.0	630	1520	2100	7.0	6.7	6.4
	20 + 25	2.71	3.39	-	2.1	6.1	7.2	630	1600	2550	7.3	7.0	6.7
	20 + 35	2.36	4.14	-	2.1	6.5	7.3	630	1710	3000	7.9	7.5	7.2
	20 + 50	2.00	5.00	-	2.1	7.0	7.3	630	1940	3000	8.9	8.5	8.2
	20 + 60	1.78	5.33	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	25 + 25	3.15	3.15	-	2.1	6.3	7.3	630	1660	3000	7.6	7.3	7.0
	25 + 35	2.79	3.91	-	2.1	6.7	7.3	630	1790	3000	8.2	7.9	7.5
	25 + 50	2.37	4.73	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	25 + 60	2.09	5.01	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	35 + 35	3.50	3.50	-	2.1	7.0	7.3	630	1940	3000	8.9	8.5	8.2
	35 + 50	2.92	4.18	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	35 + 60	2.62	4.48	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	50 + 50	3.55	3.55	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
	50 + 60	3.23	3.87	-	2.1	7.1	7.3	630	1980	3000	9.1	8.7	8.3
3 units	20 + 20 + 20	2.20	2.20	2.20	3.2	6.6	7.6	660	1380	3000	6.5	6.3	6.0
	20 + 20 + 25	2.06	2.06	2.58	3.2	6.7	7.6	660	1420	3000	6.7	6.4	6.2
	20 + 20 + 35	1.81	1.81	3.17	3.2	6.8	7.6	660	1540	3000	7.3	7.0	6.7
	20 + 20 + 50	1.56	1.56	3.89	3.2	7.0	7.6	660	1730	3000	8.2	7.8	7.5
	20 + 20 + 60	1.44	1.44	4.32	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	20 + 25 + 25	1.94	2.43	2.43	3.2	6.8	7.6	660	1540	3000	7.3	7.0	6.7
	20 + 25 + 35	1.73	2.16	3.02	3.2	6.9	7.6	660	1590	3000	7.5	7.2	6.9
	20 + 25 + 50	1.49	1.87	3.74	3.2	7.1	7.6	660	1780	3000	8.4	8.1	7.7
	20 + 25 + 60	1.37	1.71	4.11	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	20 + 35 + 35	1.56	2.72	2.72	3.2	7.0	7.6	660	1730	3000	8.2	7.8	7.5
	20 + 35 + 50	1.37	2.40	3.43	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	25 + 25 + 25	2.27	2.27	2.27	3.2	6.8	7.6	660	1540	3000	7.3	7.0	6.7
	25 + 25 + 35	2.06	2.06	2.88	3.2	7.0	7.6	660	1730	3000	8.2	7.8	7.5
	25 + 25 + 50	1.80	1.80	3.60	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	25 + 25 + 60	1.64	1.64	3.93	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	25 + 35 + 35	1.87	2.62	2.62	3.2	7.1	7.6	660	1780	3000	8.4	8.1	7.7
	25 + 35 + 50	1.64	2.29	3.27	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2
	35 + 35 + 35	2.40	2.40	2.40	3.2	7.2	7.6	660	1900	3000	9.0	8.6	8.2

ESP-PR-1105

## (5) Model SCM71ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	1.8	2.0	2.8	480	500	950	2.3	2.2	2.1
	25	2.5	-	-	-	1.8	2.5	3.4	480	680	1080	3.1	3.0	2.9
	35	3.5	-	-	-	1.8	3.5	3.9	480	1010	1240	4.6	4.4	4.3
	50	5.0	-	-	-	1.8	5.0	6.1	480	1530	2100	7.0	6.7	6.4
	60	6.0	-	-	-	1.8	6.0	7.0	480	1880	2700	8.6	8.3	7.9
2 units	20 + 20	2.00	2.00	-	-	3.0	4.0	6.1	550	850	1910	3.9	3.7	3.6
	20 + 25	2.00	2.50	-	-	3.0	4.5	6.4	550	1070	2060	4.9	4.7	4.5
	20 + 35	2.00	3.50	-	-	3.0	5.5	6.9	550	1470	2320	6.7	6.5	6.2
	20 + 50	1.94	4.86	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	20 + 60	1.70	5.10	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	25 + 25	2.50	2.50	-	-	3.0	5.0	6.8	550	1250	2270	5.7	5.5	5.3
	25 + 35	2.46	3.44	-	-	3.0	5.9	7.2	550	1660	2470	7.6	7.3	7.0
	25 + 50	2.27	4.53	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	25 + 60	2.00	4.80	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	35 + 35	3.40	3.40	-	-	3.0	6.8	7.6	550	2030	2680	9.3	8.9	8.5
	35 + 50	2.80	4.00	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	35 + 60	2.51	4.29	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	50 + 50	3.40	3.40	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	50 + 60	3.09	3.71	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
	60 + 60	3.40	3.40	-	-	3.0	6.8	7.7	550	2030	2750	9.3	8.9	8.5
3 units	20 + 20 + 20	2.00	2.00	2.00	-	3.7	6.0	8.2	670	1380	2750	6.3	6.1	5.8
	20 + 20 + 25	2.00	2.00	2.50	-	3.7	6.5	8.2	670	1560	2750	7.2	6.9	6.6
	20 + 20 + 35	1.84	1.84	3.22	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 20 + 50	1.53	1.53	3.83	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 20 + 60	1.38	1.38	4.14	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 25 + 25	1.94	2.43	2.43	-	3.7	6.8	8.2	670	1740	2750	8.0	7.6	7.3
	20 + 25 + 35	1.73	2.16	3.02	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 25 + 50	1.45	1.82	3.63	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 25 + 60	1.31	1.64	3.94	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 35 + 35	1.53	2.68	2.68	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 35 + 50	1.31	2.30	3.29	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 35 + 60	1.20	2.10	3.60	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	20 + 50 + 50	1.15	2.88	2.88	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 25 + 25	2.30	2.30	2.30	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 25 + 35	2.03	2.03	2.84	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 25 + 50	1.73	1.73	3.45	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 25 + 60	1.57	1.57	3.76	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 35 + 35	1.82	2.54	2.54	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 35 + 50	1.57	2.20	3.14	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 35 + 60	1.44	2.01	3.45	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	25 + 50 + 50	1.38	2.76	2.76	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	35 + 35 + 35	2.30	2.30	2.30	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7
	35 + 35 + 50	2.01	2.01	2.88	-	3.7	6.9	8.2	670	1830	2750	8.4	8.0	7.7

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	1.73	1.73	1.73	1.73	4.4	6.9	8.8	890	1700	2750	7.8	7.5	7.2
	20 + 20 + 20 + 25	1.62	1.62	1.62	2.03	4.4	6.9	8.8	890	1700	2750	7.8	7.5	7.2
	20 + 20 + 20 + 35	1.49	1.49	1.49	2.62	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 20 + 50	1.29	1.29	1.29	3.23	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 20 + 60	1.18	1.18	1.18	3.55	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 25 + 25	1.53	1.53	1.92	1.92	4.4	6.9	8.8	890	1700	2750	7.8	7.5	7.2
	20 + 20 + 25 + 35	1.42	1.42	1.78	2.49	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 25 + 50	1.23	1.23	1.54	3.09	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 25 + 60	1.14	1.14	1.42	3.41	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 35 + 35	1.29	1.29	2.26	2.26	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 20 + 35 + 50	1.14	1.14	1.99	2.84	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 25 + 25 + 25	1.49	1.87	1.87	1.87	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 25 + 25 + 35	1.35	1.69	1.69	2.37	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 25 + 25 + 50	1.18	1.48	1.48	2.96	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 25 + 35 + 35	1.23	1.54	2.16	2.16	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	20 + 35 + 35 + 35	1.14	1.99	1.99	1.99	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	25 + 25 + 25 + 25	1.78	1.78	1.78	1.78	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	25 + 25 + 25 + 35	1.61	1.61	1.61	2.26	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	25 + 25 + 25 + 50	1.42	1.42	1.42	2.84	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3
	25 + 25 + 35 + 35	1.48	1.48	2.07	2.07	4.4	7.1	8.8	890	1740	2750	8.0	7.6	7.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	1.5	3.0	3.7	600	840	1330	3.9	3.7	3.5
	25	3.4	-	-	-	1.5	3.4	4.2	600	1000	1510	4.6	4.4	4.2
	35	4.5	-	-	-	1.5	4.5	5.0	600	1330	1790	6.1	5.8	5.6
	50	5.8	-	-	-	1.5	5.8	6.5	600	1780	2310	8.2	7.8	7.5
	60	6.8	-	-	-	1.5	6.8	7.5	600	2100	2660	9.6	9.2	8.8
2 units	20 + 20	2.70	2.70	-	-	2.1	5.4	7.4	630	1340	1870	6.2	5.9	5.6
	20 + 25	2.62	3.28	-	-	2.1	5.9	7.7	630	1530	2130	7.0	6.7	6.4
	20 + 35	2.51	4.39	-	-	2.1	6.9	8.3	630	1910	2650	8.8	8.4	8.0
	20 + 50	2.34	5.86	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	20 + 60	2.05	6.15	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	25 + 25	3.20	3.20	-	-	2.1	6.4	8.1	630	1700	2480	7.8	7.5	7.2
	25 + 35	3.08	4.32	-	-	2.1	7.4	8.6	630	2090	2910	9.6	9.2	8.8
	25 + 50	2.73	5.47	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	25 + 60	2.41	5.79	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	35 + 35	4.10	4.10	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	35 + 50	3.38	4.82	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	35 + 60	3.02	5.18	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	50 + 50	4.10	4.10	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	50 + 60	3.73	4.47	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2
	60 + 60	4.10	4.10	-	-	2.1	8.2	8.7	630	2430	3350	11.2	10.7	10.2

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
3 units	20 + 20 + 20	2.57	2.57	2.57	-	3.2	7.7	9.1	660	1830	3350	8.4	8.0	7.7
	20 + 20 + 25	2.46	2.46	3.08	-	3.2	8.0	9.1	660	1930	3350	8.9	8.5	8.1
	20 + 20 + 35	2.24	2.24	3.92	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 20 + 50	1.87	1.87	4.67	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 20 + 60	1.68	1.68	5.04	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 25 + 25	2.34	2.93	2.93	-	3.2	8.2	9.1	660	1990	3350	9.1	8.7	8.4
	20 + 25 + 35	2.10	2.63	3.68	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 25 + 50	1.77	2.21	4.42	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 25 + 60	1.60	2.00	4.80	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 35 + 35	1.87	3.27	3.27	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 35 + 50	1.60	2.80	4.00	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 35 + 60	1.46	2.56	4.38	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	20 + 50 + 50	1.40	3.50	3.50	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 25 + 25	2.80	2.80	2.80	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 25 + 35	2.47	2.47	3.46	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 25 + 50	2.10	2.10	4.20	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 25 + 60	1.91	1.91	4.58	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 35 + 35	2.21	3.09	3.09	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 35 + 50	1.91	2.67	3.82	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 35 + 60	1.75	2.45	4.20	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	25 + 50 + 50	1.68	3.36	3.36	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	35 + 35 + 35	2.80	2.80	2.80	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
	35 + 35 + 50	2.45	2.45	3.50	-	3.2	8.4	9.1	660	2060	3350	9.5	9.0	8.7
4 units	20 + 20 + 20 + 20	2.10	2.10	2.10	2.10	3.6	8.4	9.4	800	1960	3350	9.0	8.6	8.2
	20 + 20 + 20 + 25	1.98	1.98	1.98	2.47	3.6	8.4	9.4	800	1960	3350	9.0	8.6	8.2
	20 + 20 + 20 + 35	1.79	1.79	1.79	3.13	3.6	8.5	9.4	800	1980	3350	9.1	8.7	8.3
	20 + 20 + 20 + 50	1.56	1.56	1.56	3.91	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 20 + 20 + 60	1.43	1.43	1.43	4.30	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 20 + 25 + 25	1.89	1.89	2.36	2.36	3.6	8.5	9.4	800	1980	3350	9.1	8.7	8.3
	20 + 20 + 25 + 35	1.70	1.70	2.13	2.98	3.6	8.5	9.4	800	1980	3350	9.1	8.7	8.3
	20 + 20 + 25 + 50	1.50	1.50	1.87	3.74	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 20 + 25 + 60	1.38	1.38	1.72	4.13	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 20 + 35 + 35	1.56	1.56	2.74	2.74	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 20 + 35 + 50	1.38	1.38	2.41	3.44	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 25 + 25 + 25	1.79	2.24	2.24	2.24	3.6	8.5	9.4	800	1980	3350	9.1	8.7	8.3
	20 + 25 + 25 + 35	1.64	2.05	2.05	2.87	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 25 + 25 + 50	1.43	1.79	1.79	3.58	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 25 + 35 + 35	1.50	1.87	2.62	2.62	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	20 + 35 + 35 + 35	1.38	2.41	2.41	2.41	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	25 + 25 + 25 + 25	2.13	2.13	2.13	2.13	3.6	8.5	9.4	800	1980	3350	9.1	8.7	8.3
	25 + 25 + 25 + 35	1.95	1.95	1.95	2.74	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	25 + 25 + 25 + 50	1.72	1.72	1.72	3.44	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4
	25 + 25 + 35 + 35	1.79	1.79	2.51	2.51	3.6	8.6	9.4	800	2000	3350	9.2	8.8	8.4

ESP-PR-1104

**(b) Indoor unit except SRK\*\*ZMX-S models only**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	1.8	2.0	2.7	480	530	950	2.4	2.3	2.2
	25	2.5	-	-	-	1.8	2.5	3.2	480	730	1080	3.4	3.2	3.1
	35	3.5	-	-	-	1.8	3.5	3.7	480	1120	1240	5.1	4.9	4.7
	50	5.0	-	-	-	1.8	5.0	5.8	480	1710	2100	7.9	7.5	7.2
	60	6.0	-	-	-	1.8	6.0	6.7	480	2140	2700	9.8	9.4	9.0
2 units	20 + 20	2.00	2.00	-	-	3.0	4.0	5.8	550	930	1910	4.3	4.1	3.9
	20 + 25	2.00	2.50	-	-	3.0	4.5	6.1	550	1170	2060	5.4	5.1	4.9
	20 + 35	2.00	3.50	-	-	3.0	5.5	6.6	550	1590	2320	7.3	7.0	6.7
	20 + 50	1.94	4.86	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	20 + 60	1.70	5.10	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	25 + 25	2.50	2.50	-	-	3.0	5.0	6.5	550	1360	2270	6.2	6.0	5.7
	25 + 35	2.46	3.44	-	-	3.0	5.9	6.8	550	1780	2470	8.2	7.8	7.5
	25 + 50	2.27	4.53	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	25 + 60	2.00	4.80	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	35 + 35	3.40	3.40	-	-	3.0	6.8	7.2	550	2150	2680	9.9	9.4	9.0
	35 + 50	2.80	4.00	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	35 + 60	2.51	4.29	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	50 + 50	3.40	3.40	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	50 + 60	3.09	3.71	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
	60 + 60	3.40	3.40	-	-	3.0	6.8	7.3	550	2150	2750	9.9	9.4	9.0
3 units	20 + 20 + 20	2.00	2.00	2.00	-	3.7	6.0	7.8	670	1450	2750	6.7	6.4	6.1
	20 + 20 + 25	2.00	2.00	2.50	-	3.7	6.5	7.8	670	1630	2750	7.5	7.2	6.9
	20 + 20 + 35	1.84	1.84	3.22	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 20 + 50	1.53	1.53	3.83	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 20 + 60	1.38	1.38	4.14	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 25 + 25	1.94	2.43	2.43	-	3.7	6.8	7.8	670	1820	2750	8.4	8.0	7.7
	20 + 25 + 35	1.73	2.16	3.02	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 25 + 50	1.45	1.82	3.63	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 25 + 60	1.31	1.64	3.94	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 35 + 35	1.53	2.68	2.68	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 35 + 50	1.31	2.30	3.29	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 35 + 60	1.20	2.10	3.60	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	20 + 50 + 50	1.15	2.88	2.88	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 25 + 25	2.30	2.30	2.30	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 25 + 35	2.03	2.03	2.84	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 25 + 50	1.73	1.73	3.45	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 25 + 60	1.57	1.57	3.76	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 35 + 35	1.82	2.54	2.54	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 35 + 50	1.57	2.20	3.14	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 35 + 60	1.44	2.01	3.45	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	25 + 50 + 50	1.38	2.76	2.76	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	35 + 35 + 35	2.30	2.30	2.30	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0
	35 + 35 + 50	2.01	2.01	2.88	-	3.7	6.9	7.8	670	1910	2750	8.8	8.4	8.0

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	1.73	1.73	1.73	1.73	4.4	6.9	8.3	890	1750	2750	8.0	7.7	7.4
	20 + 20 + 20 + 25	1.62	1.62	1.62	2.03	4.4	6.9	8.3	890	1750	2750	8.0	7.7	7.4
	20 + 20 + 20 + 35	1.49	1.49	1.49	2.62	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 20 + 50	1.29	1.29	1.29	3.23	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 20 + 60	1.18	1.18	1.18	3.55	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 25 + 25	1.53	1.53	1.92	1.92	4.4	6.9	8.3	890	1750	2750	8.0	7.7	7.4
	20 + 20 + 25 + 35	1.42	1.42	1.78	2.49	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 25 + 50	1.23	1.23	1.54	3.09	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 25 + 60	1.14	1.14	1.42	3.41	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 35 + 35	1.29	1.29	2.27	2.27	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 20 + 35 + 50	1.14	1.14	1.99	2.84	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 25 + 25 + 25	1.49	1.87	1.87	1.87	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 25 + 25 + 35	1.35	1.69	1.69	2.37	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 25 + 25 + 50	1.18	1.48	1.48	2.96	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 25 + 35 + 35	1.23	1.54	2.16	2.16	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	20 + 35 + 35 + 35	1.14	1.99	1.99	1.99	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	25 + 25 + 25 + 25	1.78	1.78	1.78	1.78	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	25 + 25 + 25 + 35	1.61	1.61	1.61	2.26	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	25 + 25 + 25 + 50	1.42	1.42	1.42	2.84	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5
	25 + 25 + 35 + 35	1.48	1.48	2.07	2.07	4.4	7.1	8.3	890	1790	2750	8.2	7.9	7.5

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	1.5	3.0	3.5	600	1060	1330	4.9	4.7	4.5
	25	3.4	-	-	-	1.5	3.4	4.0	600	1220	1510	5.6	5.4	5.1
	35	4.5	-	-	-	1.5	4.5	4.8	600	1510	1790	6.9	6.6	6.4
	50	5.8	-	-	-	1.5	5.8	6.2	600	1950	2310	9.0	8.6	8.2
	60	6.8	-	-	-	1.5	6.8	7.1	600	2240	2660	10.3	9.8	9.4
2 units	20 + 20	2.70	2.70	-	-	2.1	5.4	7.0	630	1370	1870	6.3	6.0	5.8
	20 + 25	2.62	3.28	-	-	2.1	5.9	7.3	630	1560	2130	7.2	6.9	6.6
	20 + 35	2.51	4.39	-	-	2.1	6.9	7.9	630	1950	2650	9.0	8.6	8.2
	20 + 50	2.34	5.86	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	20 + 60	2.05	6.15	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	25 + 25	3.20	3.20	-	-	2.1	6.4	7.7	630	1740	2480	8.0	7.6	7.3
	25 + 35	3.08	4.32	-	-	2.1	7.4	8.2	630	2130	2910	9.8	9.4	9.0
	25 + 50	2.73	5.47	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	25 + 60	2.41	5.79	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	35 + 35	4.10	4.10	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	35 + 50	3.38	4.82	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	35 + 60	3.02	5.18	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	50 + 50	4.10	4.10	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	50 + 60	3.73	4.47	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5
	60 + 60	4.10	4.10	-	-	2.1	8.2	8.3	630	2490	3350	11.4	10.9	10.5

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
3 units	20 + 20 + 20	2.57	2.57	2.57	-	3.2	7.7	8.9	660	1870	3350	8.6	8.2	7.9
	20 + 20 + 25	2.46	2.46	3.08	-	3.2	8.0	8.9	660	1970	3350	9.0	8.7	8.3
	20 + 20 + 35	2.24	2.24	3.92	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 20 + 50	1.87	1.87	4.67	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 20 + 60	1.68	1.68	5.04	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 25 + 25	2.34	2.93	2.93	-	3.2	8.2	8.9	660	2030	3350	9.3	8.9	8.5
	20 + 25 + 35	2.10	2.63	3.68	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 25 + 50	1.77	2.21	4.42	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 25 + 60	1.60	2.00	4.80	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 35 + 35	1.87	3.27	3.27	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 35 + 50	1.60	2.80	4.00	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 35 + 60	1.46	2.56	4.38	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	20 + 50 + 50	1.40	3.50	3.50	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 25 + 25	2.80	2.80	2.80	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 25 + 35	2.47	2.47	3.46	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 25 + 50	2.10	2.10	4.20	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 25 + 60	1.91	1.91	4.58	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 35 + 35	2.21	3.09	3.09	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 35 + 50	1.91	2.67	3.82	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
	25 + 35 + 60	1.75	2.45	4.20	-	3.2	8.4	8.9	660	2100	3350	9.6	9.2	8.8
4 units	20 + 20 + 20 + 20	2.10	2.10	2.10	2.10	3.6	8.4	9.1	800	2010	3350	9.2	8.8	8.5
	20 + 20 + 20 + 25	1.98	1.98	1.98	2.47	3.6	8.4	9.1	800	2010	3350	9.2	8.8	8.5
	20 + 20 + 20 + 35	1.79	1.79	1.79	3.13	3.6	8.5	9.1	800	2030	3350	9.3	8.9	8.5
	20 + 20 + 20 + 50	1.56	1.56	1.56	3.91	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 20 + 20 + 60	1.43	1.43	1.43	4.30	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 20 + 25 + 25	1.89	1.89	2.36	2.36	3.6	8.5	9.1	800	2030	3350	9.3	8.9	8.5
	20 + 20 + 25 + 35	1.70	1.70	2.13	2.98	3.6	8.5	9.1	800	2030	3350	9.3	8.9	8.5
	20 + 20 + 25 + 50	1.50	1.50	1.87	3.74	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 20 + 25 + 60	1.38	1.38	1.72	4.13	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 20 + 35 + 35	1.56	1.56	2.74	2.74	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 20 + 35 + 50	1.38	1.38	2.41	3.44	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 25 + 25 + 25	1.79	2.24	2.24	2.24	3.6	8.5	9.1	800	2030	3350	9.3	8.9	8.5
	20 + 25 + 25 + 35	1.64	2.05	2.05	2.87	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 25 + 25 + 50	1.43	1.79	1.79	3.58	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 25 + 35 + 35	1.50	1.87	2.62	2.62	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	20 + 35 + 35 + 35	1.38	2.41	2.41	2.41	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	25 + 25 + 25 + 25	2.13	2.13	2.13	2.13	3.6	8.5	9.1	800	2030	3350	9.3	8.9	8.5
	25 + 25 + 25 + 35	1.95	1.95	1.95	2.74	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	25 + 25 + 25 + 50	1.72	1.72	1.72	3.44	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6
	25 + 25 + 35 + 35	1.79	1.79	2.51	2.51	3.6	8.6	9.1	800	2050	3350	9.4	9.0	8.6

ESP-PR-1104

## (6) Model SCM80ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	1.8	2.0	2.8	480	500	950	2.3	2.2	2.1
	25	2.5	-	-	-	1.8	2.5	3.4	480	680	1080	3.1	3.0	2.9
	35	3.5	-	-	-	1.8	3.5	3.9	480	1010	1240	4.6	4.4	4.3
	50	5.0	-	-	-	1.8	5.0	6.1	480	1530	2100	7.0	6.7	6.4
	60	6.0	-	-	-	1.8	6.0	7.0	480	1880	2700	8.6	8.3	7.9
2 units	20 + 20	2.00	2.00	-	-	3.0	4.0	6.1	550	850	1910	3.9	3.7	3.6
	20 + 25	2.00	2.50	-	-	3.0	4.5	6.4	550	1070	2060	4.9	4.7	4.5
	20 + 35	2.00	3.50	-	-	3.0	5.5	6.9	550	1470	2320	6.7	6.5	6.2
	20 + 50	1.97	4.93	-	-	3.0	6.9	7.9	550	2070	2830	9.5	9.1	8.7
	20 + 60	1.85	5.55	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	25 + 25	2.50	2.50	-	-	3.0	5.0	6.8	550	1250	2270	5.7	5.5	5.3
	25 + 35	2.46	3.44	-	-	3.0	5.9	7.2	550	1660	2470	7.6	7.3	7.0
	25 + 50	2.47	4.93	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	25 + 60	2.18	5.22	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	35 + 35	3.45	3.45	-	-	3.0	6.9	7.6	550	2070	2680	9.5	9.1	8.7
	35 + 50	3.05	4.35	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	35 + 60	2.73	4.67	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	50 + 50	3.70	3.70	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	50 + 60	3.36	4.04	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
	60 + 60	3.70	3.70	-	-	3.0	7.4	7.9	550	2290	2830	10.5	10.1	9.6
3 units	20 + 20 + 20	2.00	2.00	2.00	-	3.7	6.0	8.5	670	1380	2830	6.3	6.1	5.8
	20 + 20 + 25	2.00	2.00	2.50	-	3.7	6.5	8.5	670	1560	2830	7.2	6.9	6.6
	20 + 20 + 35	1.89	1.89	3.31	-	3.7	7.1	8.5	670	1880	2830	8.6	8.3	7.9
	20 + 20 + 50	1.73	1.73	4.33	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 20 + 60	1.56	1.56	4.68	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 25 + 25	1.94	2.43	2.43	-	3.7	6.8	8.5	670	1740	2830	8.0	7.6	7.3
	20 + 25 + 35	1.88	2.34	3.28	-	3.7	7.5	8.5	670	2050	2830	9.4	9.0	8.6
	20 + 25 + 50	1.64	2.05	4.11	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 25 + 60	1.49	1.86	4.46	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 35 + 35	1.73	3.03	3.03	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 35 + 50	1.49	2.60	3.71	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 35 + 60	1.36	2.37	4.07	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 50 + 50	1.30	3.25	3.25	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	20 + 50 + 60	1.20	3.00	3.60	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 25 + 25	2.37	2.37	2.37	-	3.7	7.1	8.5	670	1880	2830	8.6	8.3	7.9
	25 + 25 + 35	2.29	2.29	3.21	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 25 + 50	1.95	1.95	3.90	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 25 + 60	1.77	1.77	4.25	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 35 + 35	2.05	2.87	2.87	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 35 + 50	1.77	2.48	3.55	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 35 + 60	1.63	2.28	3.90	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 50 + 50	1.56	3.12	3.12	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	25 + 50 + 60	1.44	2.89	3.47	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	35 + 35 + 35	2.60	2.60	2.60	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	35 + 35 + 50	2.28	2.28	3.25	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	35 + 35 + 60	2.10	2.10	3.60	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4
	35 + 50 + 50	2.02	2.89	2.89	-	3.7	7.8	8.5	670	2230	2830	10.2	9.8	9.4

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	1.95	1.95	1.95	1.95	4.4	7.8	9.2	890	2120	2830	9.6	9.2	8.8
	20 + 20 + 20 + 25	1.84	1.84	1.84	2.29	4.4	7.8	9.2	890	2120	2830	9.6	9.2	8.8
	20 + 20 + 20 + 35	1.66	1.66	1.66	2.91	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 20 + 50	1.44	1.44	1.44	3.59	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 20 + 60	1.33	1.33	1.33	4.00	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 20 + 25 + 25	1.76	1.76	2.19	2.19	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 25 + 35	1.58	1.58	1.98	2.77	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 25 + 50	1.37	1.37	1.72	3.43	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 25 + 60	1.28	1.28	1.60	3.84	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 20 + 35 + 35	1.44	1.44	2.51	2.51	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 20 + 35 + 50	1.28	1.28	2.24	3.20	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 20 + 35 + 60	1.19	1.19	2.07	3.56	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 25 + 25 + 25	1.66	2.08	2.08	2.08	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 25 + 25 + 35	1.50	1.88	1.88	2.63	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 25 + 25 + 50	1.33	1.67	1.67	3.33	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 25 + 25 + 60	1.23	1.54	1.54	3.69	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 25 + 35 + 35	1.37	1.72	2.40	2.40	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	20 + 25 + 35 + 50	1.23	1.54	2.15	3.08	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	20 + 35 + 35 + 35	1.28	2.24	2.24	2.24	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	25 + 25 + 25 + 25	1.98	1.98	1.98	1.98	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	25 + 25 + 25 + 35	1.80	1.80	1.80	2.51	4.4	7.9	9.2	890	2140	2830	9.7	9.3	8.9
	25 + 25 + 25 + 50	1.60	1.60	1.60	3.20	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	25 + 25 + 25 + 60	1.48	1.48	1.48	3.56	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	25 + 25 + 35 + 35	1.67	1.67	2.33	2.33	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	25 + 25 + 35 + 50	1.48	1.48	2.07	2.96	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0
	25 + 35 + 35 + 35	1.54	2.15	2.15	2.15	4.4	8.0	9.2	890	2160	2830	9.9	9.4	9.0

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	1.5	3.0	3.7	600	840	1330	3.9	3.7	3.5
	25	3.4	-	-	-	1.5	3.4	4.2	600	1000	1510	4.6	4.4	4.2
	35	4.5	-	-	-	1.5	4.5	5.0	600	1330	1790	6.1	5.8	5.6
	50	5.8	-	-	-	1.5	5.8	6.5	600	1780	2310	8.2	7.8	7.5
	60	6.8	-	-	-	1.5	6.8	7.5	600	2100	2660	9.6	9.2	8.8
2 units	20 + 20	2.70	2.70	-	-	2.1	5.4	7.4	630	1340	1870	6.2	5.9	5.6
	20 + 25	2.62	3.28	-	-	2.1	5.9	7.7	630	1530	2130	7.0	6.7	6.4
	20 + 35	2.51	4.39	-	-	2.1	6.9	8.3	630	1910	2650	8.8	8.4	8.0
	20 + 50	2.37	5.93	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	20 + 60	2.08	6.23	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	25 + 25	3.20	3.20	-	-	2.1	6.4	8.1	630	1700	2480	7.8	7.5	7.2
	25 + 35	3.08	4.32	-	-	2.1	7.4	8.6	630	2090	2910	9.6	9.2	8.8
	25 + 50	2.77	5.53	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	25 + 60	2.44	5.86	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	35 + 35	4.15	4.15	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	35 + 50	3.42	4.88	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	35 + 60	3.06	5.24	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	50 + 50	4.15	4.15	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	50 + 60	3.77	4.53	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
	60 + 60	4.15	4.15	-	-	2.1	8.3	8.8	630	2460	3430	11.3	10.8	10.4
3 units	20 + 20 + 20	2.57	2.57	2.57	-	3.2	7.7	9.3	660	1830	3430	8.4	8.0	7.7
	20 + 20 + 25	2.46	2.46	3.08	-	3.2	8.0	9.3	660	1930	3430	8.9	8.5	8.1
	20 + 20 + 35	2.27	2.27	3.97	-	3.2	8.5	9.3	660	2090	3430	9.6	9.2	8.8
	20 + 20 + 50	2.00	2.00	5.00	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 20 + 60	1.80	1.80	5.40	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 25 + 25	2.34	2.93	2.93	-	3.2	8.2	9.3	660	1990	3430	9.1	8.7	8.4
	20 + 25 + 35	2.20	2.75	3.85	-	3.2	8.8	9.3	660	2180	3430	10.0	9.6	9.2
	20 + 25 + 50	1.89	2.37	4.74	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 25 + 60	1.71	2.14	5.14	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 35 + 35	2.00	3.50	3.50	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 35 + 50	1.71	3.00	4.29	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 35 + 60	1.57	2.74	4.70	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 50 + 50	1.50	3.75	3.75	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	20 + 50 + 60	1.38	3.46	4.15	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 25 + 25	2.83	2.83	2.83	-	3.2	8.5	9.3	660	2090	3430	9.6	9.2	8.8
	25 + 25 + 35	2.65	2.65	3.71	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 25 + 50	2.25	2.25	4.50	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 25 + 60	2.05	2.05	4.91	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 35 + 35	2.37	3.32	3.32	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 35 + 50	2.05	2.86	4.09	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 35 + 60	1.88	2.63	4.50	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 50 + 50	1.80	3.60	3.60	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	25 + 50 + 60	1.67	3.33	4.00	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	35 + 35 + 35	3.00	3.00	3.00	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	35 + 35 + 50	2.63	2.63	3.75	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	35 + 35 + 60	2.42	2.42	4.15	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5
	35 + 50 + 50	2.33	3.33	3.33	-	3.2	9.0	9.3	660	2250	3430	10.3	9.9	9.5

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	max.						
4 units	20 + 20 + 20 + 20	2.28	2.28	2.28	2.28	3.6	9.1	9.8	800	2220	3430	10.2	9.7	9.3
	20 + 20 + 20 + 25	2.14	2.14	2.14	2.68	3.6	9.1	9.8	800	2220	3430	10.2	9.7	9.3
	20 + 20 + 20 + 35	1.94	1.94	1.94	3.39	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 20 + 20 + 50	1.67	1.67	1.67	4.18	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 20 + 20 + 60	1.55	1.55	1.55	4.65	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 20 + 25 + 25	2.04	2.04	2.56	2.56	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 20 + 25 + 35	1.84	1.84	2.30	3.22	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 20 + 25 + 50	1.62	1.62	2.02	4.04	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 20 + 25 + 60	1.49	1.49	1.86	4.46	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 20 + 35 + 35	1.67	1.67	2.93	2.93	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 20 + 35 + 50	1.49	1.49	2.60	3.72	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 20 + 35 + 60	1.38	1.38	2.41	4.13	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 25 + 25 + 25	1.94	2.42	2.42	2.42	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 25 + 25 + 35	1.75	2.19	2.19	3.07	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	20 + 25 + 25 + 50	1.55	1.94	1.94	3.88	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 25 + 25 + 60	1.43	1.79	1.79	4.29	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 25 + 35 + 35	1.62	2.02	2.83	2.83	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 25 + 35 + 50	1.43	1.79	2.50	3.58	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	20 + 35 + 35 + 35	1.49	2.60	2.60	2.60	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	25 + 25 + 25 + 25	2.30	2.30	2.30	2.30	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	25 + 25 + 25 + 35	2.09	2.09	2.09	2.93	3.6	9.2	9.8	800	2240	3430	10.3	9.8	9.4
	25 + 25 + 25 + 50	1.86	1.86	1.86	3.72	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	25 + 25 + 25 + 60	1.72	1.72	1.72	4.13	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	25 + 25 + 35 + 35	1.94	1.94	2.71	2.71	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	25 + 25 + 35 + 50	1.72	1.72	2.41	3.44	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5
	25 + 35 + 35 + 35	1.79	2.50	2.50	2.50	3.6	9.3	9.8	800	2260	3430	10.4	10.0	9.5

ESP-PR-1104

## (b) Indoor unit except SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	1.8	2.0	2.7	480	530	950	2.4	2.3	2.2
	25	2.5	-	-	-	1.8	2.5	3.2	480	730	1080	3.4	3.2	3.1
	35	3.5	-	-	-	1.8	3.5	3.7	480	1120	1240	5.1	4.9	4.7
	50	5.0	-	-	-	1.8	5.0	5.8	480	1710	2100	7.9	7.5	7.2
	60	6.0	-	-	-	1.8	6.0	6.7	480	2140	2700	9.8	9.4	9.0
2 units	20 + 20	2.00	2.00	-	-	3.0	4.0	5.8	550	930	1910	4.3	4.1	3.9
	20 + 25	2.00	2.50	-	-	3.0	4.5	6.1	550	1170	2060	5.4	5.1	4.9
	20 + 35	2.00	3.50	-	-	3.0	5.5	6.6	550	1590	2320	7.3	7.0	6.7
	20 + 50	1.97	4.93	-	-	3.0	6.9	7.5	550	2200	2830	10.1	9.7	9.3
	20 + 60	1.85	5.55	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	25 + 25	2.50	2.50	-	-	3.0	5.0	6.5	550	1360	2270	6.2	6.0	5.7
	25 + 35	2.46	3.44	-	-	3.0	5.9	6.8	550	1780	2470	8.2	7.8	7.5
	25 + 50	2.47	4.93	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	25 + 60	2.18	5.22	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	35 + 35	3.45	3.45	-	-	3.0	6.9	7.5	550	2200	2680	10.1	9.7	9.3
	35 + 50	3.05	4.35	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	35 + 60	2.73	4.67	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	50 + 50	3.70	3.70	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	50 + 60	3.36	4.04	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
	60 + 60	3.70	3.70	-	-	3.0	7.4	7.5	550	2430	2830	11.2	10.7	10.2
3 units	20 + 20 + 20	2.00	2.00	2.00	-	3.7	6.0	8.1	670	1450	2830	6.7	6.4	6.1
	20 + 20 + 25	2.00	2.00	2.50	-	3.7	6.5	8.1	670	1630	2830	7.5	7.2	6.9
	20 + 20 + 35	1.89	1.89	3.31	-	3.7	7.1	8.1	670	1950	2830	9.0	8.6	8.2
	20 + 20 + 50	1.73	1.73	4.33	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 20 + 60	1.56	1.56	4.68	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 25 + 25	1.94	2.43	2.43	-	3.7	6.8	8.1	670	1820	2830	8.4	8.0	7.7
	20 + 25 + 35	1.88	2.34	3.28	-	3.7	7.5	8.1	670	2130	2830	9.8	9.4	9.0
	20 + 25 + 50	1.64	2.05	4.11	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 25 + 60	1.49	1.86	4.46	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 35 + 35	1.73	3.03	3.03	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 35 + 50	1.49	2.60	3.71	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 35 + 60	1.36	2.37	4.07	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 50 + 50	1.30	3.25	3.25	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	20 + 50 + 60	1.20	3.00	3.60	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 25 + 25	2.37	2.37	2.37	-	3.7	7.1	8.1	670	1950	2830	9.0	8.6	8.2
	25 + 25 + 35	2.29	2.29	3.21	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 25 + 50	1.95	1.95	3.90	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 25 + 60	1.77	1.77	4.25	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 35 + 35	2.05	2.87	2.87	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 35 + 50	1.77	2.48	3.55	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 35 + 60	1.63	2.28	3.90	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 50 + 50	1.56	3.12	3.12	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	25 + 50 + 60	1.44	2.89	3.47	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	35 + 35 + 35	2.60	2.60	2.60	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	35 + 35 + 50	2.28	2.28	3.25	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	35 + 35 + 60	2.10	2.10	3.60	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8
	35 + 50 + 50	2.02	2.89	2.89	-	3.7	7.8	8.1	670	2320	2830	10.7	10.2	9.8

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	1.95	1.95	1.95	1.95	4.4	7.8	8.7	890	2180	2830	9.9	9.5	9.1
	20 + 20 + 20 + 25	1.84	1.84	1.84	2.29	4.4	7.8	8.7	890	2180	2830	9.9	9.5	9.1
	20 + 20 + 20 + 35	1.66	1.66	1.66	2.91	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 20 + 50	1.44	1.44	1.44	3.59	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 20 + 60	1.33	1.33	1.33	4.00	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 20 + 25 + 25	1.76	1.76	2.19	2.19	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 25 + 35	1.58	1.58	1.98	2.77	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 25 + 50	1.37	1.37	1.72	3.43	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 25 + 60	1.28	1.28	1.60	3.84	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 20 + 35 + 35	1.44	1.44	2.51	2.51	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 20 + 35 + 50	1.28	1.28	2.24	3.20	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 20 + 35 + 60	1.19	1.19	2.07	3.56	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 25 + 25 + 25	1.66	2.08	2.08	2.08	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 25 + 25 + 35	1.50	1.88	1.88	2.63	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 25 + 25 + 50	1.33	1.67	1.67	3.33	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 25 + 25 + 60	1.23	1.54	1.54	3.69	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 25 + 35 + 35	1.37	1.72	2.40	2.40	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	20 + 25 + 35 + 50	1.23	1.54	2.15	3.08	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	20 + 35 + 35 + 35	1.28	2.24	2.24	2.24	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	25 + 25 + 25 + 25	1.98	1.98	1.98	1.98	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	25 + 25 + 25 + 35	1.80	1.80	1.80	2.51	4.4	7.9	8.7	890	2200	2830	10.0	9.6	9.2
	25 + 25 + 25 + 50	1.60	1.60	1.60	3.20	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	25 + 25 + 25 + 60	1.48	1.48	1.48	3.56	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	25 + 25 + 35 + 35	1.67	1.67	2.33	2.33	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	25 + 25 + 35 + 50	1.48	1.48	2.07	2.96	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3
	25 + 35 + 35 + 35	1.54	2.15	2.15	2.15	4.4	8.0	8.7	890	2220	2830	10.1	9.7	9.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	1.5	3.0	3.5	600	1060	1330	4.9	4.7	4.5
	25	3.4	-	-	-	1.5	3.4	4.0	600	1220	1510	5.6	5.4	5.1
	35	4.5	-	-	-	1.5	4.5	4.8	600	1510	1790	6.9	6.6	6.4
	50	5.8	-	-	-	1.5	5.8	6.2	600	1950	2310	9.0	8.6	8.2
	60	6.8	-	-	-	1.5	6.8	7.1	600	2240	2660	10.3	9.8	9.4
2 units	20 + 20	2.70	2.70	-	-	2.1	5.4	7.0	630	1370	1870	6.3	6.0	5.8
	20 + 25	2.62	3.28	-	-	2.1	5.9	7.3	630	1560	2130	7.2	6.9	6.6
	20 + 35	2.51	4.39	-	-	2.1	6.9	7.9	630	1950	2650	9.0	8.6	8.2
	20 + 50	2.37	5.93	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	20 + 60	2.08	6.23	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	25 + 25	3.20	3.20	-	-	2.1	6.4	7.7	630	1740	2480	8.0	7.6	7.3
	25 + 35	3.08	4.32	-	-	2.1	7.4	8.2	630	2130	2910	9.8	9.4	9.0
	25 + 50	2.77	5.53	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	25 + 60	2.44	5.86	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	35 + 35	4.15	4.15	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	35 + 50	3.42	4.88	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	35 + 60	3.06	5.24	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	50 + 50	4.15	4.15	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	50 + 60	3.77	4.53	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
	60 + 60	4.15	4.15	-	-	2.1	8.3	8.4	630	2510	3430	11.5	11.0	10.6
3 units	20 + 20 + 20	2.57	2.57	2.57	-	3.2	7.7	9.1	660	1870	3430	8.6	8.2	7.9
	20 + 20 + 25	2.46	2.46	3.08	-	3.2	8.0	9.1	660	1970	3430	9.0	8.7	8.3
	20 + 20 + 35	2.27	2.27	3.97	-	3.2	8.5	9.1	660	2130	3430	9.8	9.4	9.0
	20 + 20 + 50	2.00	2.00	5.00	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 20 + 60	1.80	1.80	5.40	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 25 + 25	2.34	2.93	2.93	-	3.2	8.2	9.1	660	2030	3430	9.3	8.9	8.5
	20 + 25 + 35	2.20	2.75	3.85	-	3.2	8.8	9.1	660	2220	3430	10.2	9.7	9.3
	20 + 25 + 50	1.89	2.37	4.74	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 25 + 60	1.71	2.14	5.14	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 35 + 35	2.00	3.50	3.50	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 35 + 50	1.71	3.00	4.29	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 35 + 60	1.57	2.74	4.70	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 50 + 50	1.50	3.75	3.75	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	20 + 50 + 60	1.38	3.46	4.15	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 25 + 25	2.83	2.83	2.83	-	3.2	8.5	9.1	660	2130	3430	9.8	9.4	9.0
	25 + 25 + 35	2.65	2.65	3.71	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 25 + 50	2.25	2.25	4.50	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 25 + 60	2.05	2.05	4.91	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 35 + 35	2.37	3.32	3.32	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 35 + 50	2.05	2.86	4.09	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 35 + 60	1.88	2.63	4.50	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 50 + 50	1.80	3.60	3.60	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	25 + 50 + 60	1.67	3.33	4.00	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	35 + 35 + 35	3.00	3.00	3.00	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	35 + 35 + 50	2.63	2.63	3.75	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	35 + 35 + 60	2.42	2.42	4.15	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7
	35 + 50 + 50	2.33	3.33	3.33	-	3.2	9.0	9.1	660	2300	3430	10.6	10.1	9.7

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)							Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)				Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	2.28	2.28	2.28	2.28	3.6	9.1	9.5	800	2270	3430	10.4	10.0	9.6
	20 + 20 + 20 + 25	2.14	2.14	2.14	2.68	3.6	9.1	9.5	800	2270	3430	10.4	10.0	9.6
	20 + 20 + 20 + 35	1.94	1.94	1.94	3.39	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 20 + 20 + 50	1.67	1.67	1.67	4.18	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 20 + 20 + 60	1.55	1.55	1.55	4.65	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 20 + 25 + 25	2.04	2.04	2.56	2.56	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 20 + 25 + 35	1.84	1.84	2.30	3.22	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 20 + 25 + 50	1.62	1.62	2.02	4.04	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 20 + 25 + 60	1.49	1.49	1.86	4.46	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 20 + 35 + 35	1.67	1.67	2.93	2.93	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 20 + 35 + 50	1.49	1.49	2.60	3.72	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 20 + 35 + 60	1.38	1.38	2.41	4.13	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 25 + 25 + 25	1.94	2.42	2.42	2.42	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 25 + 25 + 35	1.75	2.19	2.19	3.07	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	20 + 25 + 25 + 50	1.55	1.94	1.94	3.88	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 25 + 25 + 60	1.43	1.79	1.79	4.29	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 25 + 35 + 35	1.62	2.02	2.83	2.83	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 25 + 35 + 50	1.43	1.79	2.50	3.58	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	20 + 35 + 35 + 35	1.49	2.60	2.60	2.60	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	25 + 25 + 25 + 25	2.30	2.30	2.30	2.30	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	25 + 25 + 25 + 35	2.09	2.09	2.09	2.93	3.6	9.2	9.5	800	2290	3430	10.5	10.1	9.6
	25 + 25 + 25 + 50	1.86	1.86	1.86	3.72	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	25 + 25 + 25 + 60	1.72	1.72	1.72	4.13	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	25 + 25 + 35 + 35	1.94	1.94	2.71	2.71	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	25 + 25 + 35 + 50	1.72	1.72	2.41	3.44	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8
	25 + 35 + 35 + 35	1.79	2.50	2.50	2.50	3.6	9.3	9.5	800	2310	3430	10.7	10.2	9.8

ESP-PR-1104

## (7) Model SCM100ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	-	-	1.8	2.0	2.8	650	750	1100	3.4	3.3	3.2
	25	2.5	-	-	-	-	-	1.8	2.5	3.4	650	950	1350	4.4	4.2	4.0
	35	3.5	-	-	-	-	-	1.8	3.5	3.9	650	1400	1600	6.4	6.1	5.9
	50	5.0	-	-	-	-	-	1.8	5.0	6.1	650	2000	2500	9.2	8.8	8.4
	60	6.0	-	-	-	-	-	1.8	6.0	7.0	650	2450	3000	11.2	10.8	10.3
2 units	20 + 20	2.00	2.00	-	-	-	-	3.0	4.0	5.6	740	910	1460	4.2	4.0	3.8
	20 + 25	2.00	2.50	-	-	-	-	3.0	4.5	6.2	740	1050	1820	4.8	4.6	4.4
	20 + 35	2.00	3.50	-	-	-	-	3.0	5.5	6.7	740	1430	2020	6.6	6.3	6.0
	20 + 50	2.00	5.00	-	-	-	-	3.0	7.0	8.9	740	2180	2820	10.0	9.6	9.2
	20 + 60	2.00	6.00	-	-	-	-	3.0	8.0	9.8	740	2530	3360	11.6	11.1	10.6
	25 + 25	2.50	2.50	-	-	-	-	3.0	5.0	6.8	740	1350	2200	6.2	5.9	5.7
	25 + 35	2.50	3.50	-	-	-	-	3.0	6.0	7.3	740	1720	2320	7.9	7.6	7.2
	25 + 50	2.50	5.00	-	-	-	-	3.0	7.5	9.5	740	2350	3220	10.8	10.3	9.9
	25 + 60	2.50	6.00	-	-	-	-	3.0	8.5	9.8	740	2680	3360	12.3	11.8	11.3
	35 + 35	3.50	3.50	-	-	-	-	3.0	7.0	7.8	740	2180	2820	10.0	9.6	9.2
	35 + 50	3.50	5.00	-	-	-	-	3.0	8.5	10.0	740	2680	3620	12.3	11.8	11.3
	35 + 60	3.50	6.00	-	-	-	-	3.0	9.5	10.9	740	3120	3990	14.3	13.7	13.1
	50 + 50	5.00	5.00	-	-	-	-	3.0	10.0	12.0	740	3350	4400	15.4	14.7	14.1
	50 + 60	4.55	5.45	-	-	-	-	3.0	10.0	12.0	740	3350	4400	15.4	14.7	14.1
	60 + 60	5.00	5.00	-	-	-	-	3.0	10.0	12.0	740	3340	4400	15.3	14.7	14.1
3 units	20 + 20 + 20	2.00	2.00	2.00	-	-	-	3.7	6.0	8.4	880	1460	2560	6.7	6.4	6.1
	20 + 20 + 25	2.00	2.00	2.50	-	-	-	3.7	6.5	9.0	880	1650	2700	7.6	7.2	6.9
	20 + 20 + 35	2.00	2.00	3.50	-	-	-	3.7	7.5	9.5	880	1980	3120	9.1	8.7	8.3
	20 + 20 + 50	2.00	2.00	5.00	-	-	-	3.7	9.0	11.7	880	2600	4120	11.9	11.4	10.9
	20 + 20 + 60	2.00	2.00	6.00	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	20 + 25 + 25	2.00	2.50	2.50	-	-	-	3.7	7.0	9.6	880	1850	3210	8.5	8.1	7.8
	20 + 25 + 35	2.00	2.50	3.50	-	-	-	3.7	8.0	10.1	880	2320	3630	10.7	10.2	9.8
	20 + 25 + 50	2.00	2.50	5.00	-	-	-	3.7	9.5	12.0	880	2980	4250	13.7	13.1	12.5
	20 + 25 + 60	1.90	2.38	5.71	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	20 + 35 + 35	2.00	3.50	3.50	-	-	-	3.7	9.0	10.6	880	2780	3750	12.8	12.2	11.7
	20 + 35 + 50	1.90	3.33	4.76	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	20 + 35 + 60	1.74	3.04	5.22	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	20 + 50 + 50	1.67	4.17	4.17	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	20 + 50 + 60	1.54	3.85	4.62	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	20 + 60 + 60	1.43	4.29	4.29	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	25 + 25 + 25	2.50	2.50	2.50	-	-	-	3.7	7.5	10.2	880	2030	3640	9.3	8.9	8.5
	25 + 25 + 35	2.50	2.50	3.50	-	-	-	3.7	8.5	10.7	880	2520	3900	11.6	11.1	10.6
	25 + 25 + 50	2.50	2.50	5.00	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	25 + 25 + 60	2.27	2.27	5.45	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	25 + 35 + 35	2.50	3.50	3.50	-	-	-	3.7	9.5	11.2	880	2980	3990	13.7	13.1	12.5
	25 + 35 + 50	2.27	3.18	4.55	-	-	-	3.7	10.0	12.0	880	3120	4250	14.3	13.7	13.1
	25 + 35 + 60	2.08	2.92	5.00	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	25 + 50 + 50	2.00	4.00	4.00	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	25 + 50 + 60	1.85	3.70	4.44	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	25 + 60 + 60	1.72	4.14	4.14	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	35 + 35 + 35	3.33	3.33	3.33	-	-	-	3.7	10.0	11.7	880	3120	4180	14.3	13.7	13.1
	35 + 35 + 50	2.92	2.92	4.17	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	35 + 35 + 60	2.69	2.69	4.62	-	-	-	3.7	10.0	12.0	880	3110	4250	14.3	13.7	13.1
	35 + 50 + 50	2.59	3.70	3.70	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	35 + 50 + 60	2.41	3.45	4.14	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	35 + 60 + 60	2.26	3.87	3.87	-	-	-	3.7	10.0	12.0	880	3090	4250	14.2	13.6	13.0
	50 + 50 + 50	3.33	3.33	3.33	-	-	-	3.7	10.0	12.0	880	3100	4250	14.2	13.6	13.0
	50 + 50 + 60	3.13	3.13	3.75	-	-	-	3.7	10.0	12.0	880	3090	4250	14.2	13.6	13.0

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	-	-	4.4	8.0	11.2	1100	2050	3680	9.3	8.9	8.6
	20 + 20 + 20 + 25	2.00	2.00	2.00	2.50	-	-	4.4	8.5	11.8	1100	2320	3890	10.6	10.1	9.7
	20 + 20 + 20 + 35	2.00	2.00	2.00	3.50	-	-	4.4	9.5	12.0	1100	2820	4050	12.8	12.3	11.8
	20 + 20 + 20 + 50	1.82	1.82	1.82	4.55	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 20 + 20 + 60	1.67	1.67	1.67	5.00	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 20 + 25 + 25	2.00	2.00	2.50	2.50	-	-	4.4	9.0	12.0	1100	2520	4050	11.5	11.0	10.5
	20 + 20 + 25 + 35	2.00	2.00	2.50	3.50	-	-	4.4	10.0	12.0	1100	3030	4050	13.8	13.2	12.6
	20 + 20 + 25 + 50	1.74	1.74	2.17	4.35	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 20 + 25 + 60	1.60	1.60	2.00	4.80	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 20 + 35 + 35	1.82	1.82	3.18	3.18	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 20 + 35 + 50	1.60	1.60	2.80	4.00	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 20 + 35 + 60	1.48	1.48	2.59	4.44	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 20 + 50 + 50	1.43	1.43	3.57	3.57	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 20 + 50 + 60	1.33	1.33	3.33	4.00	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	20 + 20 + 60 + 60	1.25	1.25	3.75	3.75	-	-	4.4	10.0	12.0	1100	2990	4050	13.6	13.0	12.5
	20 + 25 + 25 + 25	2.00	2.50	2.50	2.50	-	-	4.4	9.5	12.0	1100	2820	4050	12.8	12.3	11.8
	20 + 25 + 25 + 35	1.90	2.38	2.38	3.33	-	-	4.4	10.0	12.0	1100	3030	4050	13.8	13.2	12.6
	20 + 25 + 25 + 50	1.67	2.08	2.08	4.17	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 25 + 25 + 60	1.54	1.92	1.92	4.62	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 25 + 35 + 35	1.74	2.17	3.04	3.04	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	20 + 25 + 35 + 50	1.54	1.92	2.69	3.85	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 25 + 35 + 60	1.43	1.79	2.50	4.29	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 25 + 50 + 50	1.38	1.72	3.45	3.45	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	20 + 25 + 50 + 60	1.29	1.61	3.23	3.87	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	20 + 25 + 60 + 60	1.21	1.52	3.64	3.64	-	-	4.4	10.0	12.0	1100	2990	4050	13.6	13.0	12.5
	20 + 35 + 35 + 35	1.60	2.80	2.80	2.80	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 35 + 35 + 50	1.43	2.50	2.50	3.57	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	20 + 35 + 35 + 60	1.33	2.33	2.33	4.00	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	20 + 35 + 50 + 50	1.29	2.26	3.23	3.23	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	-	-	4.4	10.0	12.0	1100	3030	4050	13.8	13.2	12.6
	25 + 25 + 25 + 35	2.27	2.27	2.27	3.18	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	25 + 25 + 25 + 50	2.00	2.00	2.00	4.00	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	25 + 25 + 25 + 60	1.85	1.85	1.85	4.44	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	25 + 25 + 35 + 35	2.08	2.08	2.92	2.92	-	-	4.4	10.0	12.0	1100	3020	4050	13.7	13.1	12.6
	25 + 25 + 35 + 50	1.85	1.85	2.59	3.70	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	25 + 25 + 35 + 60	1.72	1.72	2.41	4.14	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	25 + 25 + 50 + 50	1.67	1.67	3.33	3.33	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	25 + 25 + 50 + 60	1.56	1.56	3.13	3.75	-	-	4.4	10.0	12.0	1100	2990	4050	13.6	13.0	12.5
	25 + 35 + 35 + 35	1.92	2.69	2.69	2.69	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	25 + 35 + 35 + 50	1.72	2.41	2.41	3.45	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	25 + 35 + 35 + 60	1.61	2.26	2.26	3.87	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5
	25 + 35 + 50 + 50	1.56	2.19	3.13	3.13	-	-	4.4	10.0	12.0	1100	2990	4050	13.6	13.0	12.5
	35 + 35 + 35 + 35	2.50	2.50	2.50	2.50	-	-	4.4	10.0	12.0	1100	3010	4050	13.7	13.1	12.6
	35 + 35 + 35 + 50	2.26	2.26	2.26	3.23	-	-	4.4	10.0	12.0	1100	3000	4050	13.7	13.1	12.5

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	12.0	1210	2860	4030	13.0	12.4	11.9
	20 + 20 + 20 + 20 + 25	1.90	1.90	1.90	1.90	2.38	-	5.1	10.0	12.0	1210	2860	4030	13.0	12.4	11.9
	20 + 20 + 20 + 20 + 35	1.74	1.74	1.74	1.74	3.04	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	20 + 20 + 20 + 20 + 50	1.54	1.54	1.54	1.54	3.85	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 20 + 60	1.43	1.43	1.43	1.43	4.29	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 25 + 25	1.82	1.82	1.82	2.27	2.27	-	5.1	10.0	12.0	1210	2860	4030	13.0	12.4	11.9
	20 + 20 + 20 + 25 + 35	1.67	1.67	1.67	2.08	2.92	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	20 + 20 + 20 + 25 + 50	1.48	1.48	1.48	1.85	3.70	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 25 + 60	1.38	1.38	1.38	1.72	4.14	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 35 + 35	1.54	1.54	1.54	2.69	2.69	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 35 + 50	1.38	1.38	1.38	2.41	3.45	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 20 + 35 + 60	1.29	1.29	1.29	2.26	3.87	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 20 + 20 + 50 + 50	1.25	1.25	1.25	3.13	3.13	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 20 + 25 + 25 + 25	1.74	1.74	2.17	2.17	2.17	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	20 + 20 + 25 + 25 + 35	1.60	1.60	2.00	2.00	2.80	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	20 + 20 + 25 + 25 + 50	1.43	1.43	1.79	1.79	3.57	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 25 + 25 + 60	1.33	1.33	1.67	1.67	4.00	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 25 + 35 + 35	1.48	1.48	1.85	2.59	2.59	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 25 + 35 + 50	1.33	1.33	1.67	2.33	3.33	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 25 + 35 + 60	1.25	1.25	1.56	2.19	3.75	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 20 + 35 + 35 + 35	1.38	1.38	2.41	2.41	2.41	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 20 + 35 + 35 + 50	1.25	1.25	2.19	2.19	3.13	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 25 + 25 + 25 + 25	1.67	2.08	2.08	2.08	2.08	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	20 + 25 + 25 + 25 + 35	1.54	1.92	1.92	1.92	2.69	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 25 + 25 + 25 + 50	1.38	1.72	1.72	1.72	3.45	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 25 + 25 + 25 + 60	1.29	1.61	1.61	1.61	3.87	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 25 + 25 + 35 + 35	1.43	1.79	1.79	2.50	2.50	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 25 + 25 + 35 + 50	1.29	1.61	1.61	2.26	3.23	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	20 + 25 + 35 + 35 + 35	1.33	1.67	2.33	2.33	2.33	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	20 + 35 + 35 + 35 + 35	1.25	2.19	2.19	2.19	2.19	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	25 + 25 + 25 + 25 + 25	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	12.0	1210	2850	4030	13.0	12.4	11.9
	25 + 25 + 25 + 25 + 35	1.85	1.85	1.85	1.85	2.59	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	25 + 25 + 25 + 25 + 50	1.67	1.67	1.67	1.67	3.33	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	25 + 25 + 25 + 25 + 60	1.56	1.56	1.56	1.56	3.75	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	25 + 25 + 25 + 35 + 35	1.72	1.72	1.72	2.41	2.41	-	5.1	10.0	12.0	1210	2840	4030	12.9	12.4	11.8
	25 + 25 + 25 + 35 + 50	1.56	1.56	1.56	2.19	3.13	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8
	25 + 25 + 35 + 35 + 35	1.61	1.61	2.26	2.26	2.26	-	5.1	10.0	12.0	1210	2830	4030	12.9	12.3	11.8

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	-	-	1.5	3.0	3.7	700	1010	1330	4.6	4.4	4.3
	25	3.4	-	-	-	-	-	1.5	3.4	4.2	700	1150	1540	5.3	5.1	4.8
	35	4.5	-	-	-	-	-	1.5	4.5	5.0	700	1540	1840	7.1	6.8	6.5
	50	5.8	-	-	-	-	-	1.5	5.8	6.5	700	2000	2410	9.2	8.8	8.4
	60	6.8	-	-	-	-	-	1.5	6.8	7.5	700	2360	2760	10.8	10.4	9.9
2 units	20 + 20	3.00	3.00	-	-	-	-	2.1	6.0	7.4	750	1510	1460	6.9	6.6	6.4
	20 + 25	2.84	3.56	-	-	-	-	2.1	6.4	7.9	750	1630	2210	7.5	7.2	6.9
	20 + 35	2.73	4.77	-	-	-	-	2.1	7.5	8.7	750	1950	2520	9.0	8.6	8.2
	20 + 50	2.51	6.29	-	-	-	-	2.1	8.8	10.2	750	2380	3220	10.9	10.5	10.0
	20 + 60	2.45	7.35	-	-	-	-	2.1	9.8	11.2	750	2780	3620	12.8	12.2	11.7
	25 + 25	3.40	3.40	-	-	-	-	2.1	6.8	8.4	750	1740	2420	8.0	7.6	7.3
	25 + 35	3.29	4.61	-	-	-	-	2.1	7.9	9.2	750	2100	2820	9.6	9.2	8.8
	25 + 50	3.07	6.13	-	-	-	-	2.1	9.2	10.7	750	2580	3610	11.8	11.3	10.9
	25 + 60	3.00	7.20	-	-	-	-	2.1	10.2	11.7	750	2980	3790	13.7	13.1	12.5
	35 + 35	4.50	4.50	-	-	-	-	2.1	9.0	10.0	750	2470	3210	11.3	10.8	10.4
	35 + 50	4.24	6.06	-	-	-	-	2.1	10.3	11.5	750	2980	3710	13.7	13.1	12.5
	35 + 60	4.16	7.14	-	-	-	-	2.1	11.3	12.5	750	3430	4100	15.7	15.1	14.4
	50 + 50	5.80	5.80	-	-	-	-	2.1	11.6	13.0	750	3580	4320	16.4	15.7	15.1
	50 + 60	5.45	6.55	-	-	-	-	2.1	12.0	13.5	750	3720	4520	17.1	16.3	15.7
	60 + 60	6.00	6.00	-	-	-	-	2.1	12.0	13.5	750	3720	4520	17.1	16.3	15.7
3 units	20 + 20 + 20	3.00	3.00	3.00	-	-	-	3.2	9.0	11.1	780	2230	3350	10.2	9.8	9.4
	20 + 20 + 25	2.89	2.89	3.62	-	-	-	3.2	9.4	11.6	780	2350	3550	10.8	10.3	9.9
	20 + 20 + 35	2.80	2.80	4.90	-	-	-	3.2	10.5	12.4	780	2710	3820	12.4	11.9	11.4
	20 + 20 + 50	2.62	2.62	6.56	-	-	-	3.2	11.8	13.5	780	3210	4190	14.7	14.1	13.5
	20 + 20 + 60	2.40	2.40	7.20	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	20 + 25 + 25	2.80	3.50	3.50	-	-	-	3.2	9.8	12.1	780	2510	3720	11.5	11.0	10.6
	20 + 25 + 35	2.73	3.41	4.77	-	-	-	3.2	10.9	12.9	780	2910	3990	13.4	12.8	12.2
	20 + 25 + 50	2.53	3.16	6.32	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	20 + 25 + 60	2.29	2.86	6.86	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	20 + 35 + 35	2.67	4.67	4.67	-	-	-	3.2	12.0	13.5	780	3360	4190	15.4	14.8	14.1
	20 + 35 + 50	2.29	4.00	5.71	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	20 + 35 + 60	2.09	3.65	6.26	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	20 + 50 + 50	2.00	5.00	5.00	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	20 + 50 + 60	1.85	4.62	5.54	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	20 + 60 + 60	1.71	5.14	5.14	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	25 + 25 + 25	3.40	3.40	3.40	-	-	-	3.2	10.2	12.6	780	2710	3880	12.4	11.9	11.4
	25 + 25 + 35	3.32	3.32	4.65	-	-	-	3.2	11.3	13.4	780	3110	4120	14.3	13.7	13.1
	25 + 25 + 50	3.00	3.00	6.00	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	25 + 25 + 60	2.73	2.73	6.55	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	25 + 35 + 35	3.16	4.42	4.42	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	25 + 35 + 50	2.73	3.82	5.45	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	25 + 35 + 60	2.50	3.50	6.00	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	25 + 50 + 50	2.40	4.80	4.80	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	25 + 50 + 60	2.22	4.44	5.33	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	25 + 60 + 60	2.07	4.97	4.97	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	35 + 35 + 35	4.00	4.00	4.00	-	-	-	3.2	12.0	13.5	780	3350	4190	15.4	14.7	14.1
	35 + 35 + 50	3.50	3.50	5.00	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	35 + 35 + 60	3.23	3.23	5.54	-	-	-	3.2	12.0	13.5	780	3340	4190	15.3	14.7	14.1
	35 + 50 + 50	3.11	4.44	4.44	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	35 + 50 + 60	2.90	4.14	4.97	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	35 + 60 + 60	2.71	4.65	4.65	-	-	-	3.2	12.0	13.5	780	3320	4190	15.2	14.6	14.0
	50 + 50 + 50	4.00	4.00	4.00	-	-	-	3.2	12.0	13.5	780	3330	4190	15.3	14.6	14.0
	50 + 50 + 60	3.75	3.75	4.50	-	-	-	3.2	12.0	13.5	780	3320	4190	15.2	14.6	14.0

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.5	950	3230	3840	14.7	14.1	13.5
	20 + 20 + 20 + 25	2.82	2.82	2.82	3.53	-	-	3.6	12.0	13.5	950	3230	3840	14.7	14.1	13.5
	20 + 20 + 20 + 35	2.53	2.53	2.53	4.42	-	-	3.6	12.0	13.5	950	3230	3840	14.7	14.1	13.5
	20 + 20 + 20 + 50	2.18	2.18	2.18	5.45	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 20 + 20 + 60	2.00	2.00	2.00	6.00	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 20 + 25 + 25	2.67	2.67	3.33	3.33	-	-	3.6	12.0	13.5	950	3230	3840	14.7	14.1	13.5
	20 + 20 + 25 + 35	2.40	2.40	3.00	4.20	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 20 + 25 + 50	2.09	2.09	2.61	5.22	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 20 + 25 + 60	1.92	1.92	2.40	5.76	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	20 + 20 + 35 + 35	2.18	2.18	3.82	3.82	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 20 + 35 + 50	1.92	1.92	3.36	4.80	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	20 + 20 + 35 + 60	1.78	1.78	3.11	5.33	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 20 + 50 + 50	1.71	1.71	4.29	4.29	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 20 + 50 + 60	1.60	1.60	4.00	4.80	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 20 + 60 + 60	1.50	1.50	4.50	4.50	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	20 + 25 + 25 + 25	2.53	3.16	3.16	3.16	-	-	3.6	12.0	13.5	950	3230	3840	14.7	14.1	13.5
	20 + 25 + 25 + 35	2.29	2.86	2.86	4.00	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 25 + 25 + 50	2.00	2.50	2.50	5.00	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 25 + 25 + 60	1.85	2.31	2.31	5.54	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	20 + 25 + 35 + 35	2.09	2.61	3.65	3.65	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	20 + 25 + 35 + 50	1.85	2.31	3.23	4.62	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	20 + 25 + 35 + 60	1.71	2.14	3.00	5.14	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 25 + 50 + 50	1.66	2.07	4.14	4.14	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 25 + 50 + 60	1.55	1.94	3.87	4.65	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	20 + 35 + 35 + 35	1.92	3.36	3.36	3.36	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	20 + 35 + 35 + 50	1.71	3.00	3.00	4.29	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 35 + 35 + 60	1.60	2.80	2.80	4.80	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	20 + 35 + 50 + 50	1.55	2.71	3.87	3.87	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	25 + 25 + 25 + 25	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	25 + 25 + 25 + 35	2.73	2.73	2.73	3.82	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	25 + 25 + 25 + 50	2.40	2.40	2.40	4.80	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	25 + 25 + 25 + 60	2.22	2.22	2.22	5.33	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	25 + 25 + 35 + 35	2.50	2.50	3.50	3.50	-	-	3.6	12.0	13.5	950	3220	3840	14.7	14.0	13.4
	25 + 25 + 35 + 50	2.22	2.22	3.11	4.44	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	25 + 25 + 35 + 60	2.07	2.07	2.90	4.97	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	25 + 25 + 50 + 50	2.00	2.00	4.00	4.00	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	25 + 25 + 50 + 60	1.88	1.88	3.75	4.50	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	25 + 35 + 35 + 35	2.31	3.23	3.23	3.23	-	-	3.6	12.0	13.5	950	3340	3840	15.2	14.5	13.9
	25 + 35 + 35 + 50	2.07	2.90	2.90	4.14	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	25 + 35 + 35 + 60	1.94	2.71	2.71	4.65	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	25 + 35 + 50 + 50	1.88	2.63	3.75	3.75	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3
	35 + 35 + 35 + 35	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.5	950	3210	3840	14.6	14.0	13.4
	35 + 35 + 35 + 50	2.71	2.71	2.71	3.87	-	-	3.6	12.0	13.5	950	3200	3840	14.6	13.9	13.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 20 + 20 + 20 + 20	2.40	2.40	2.40	2.40	2.40	-	4.0	12.0	13.5	1050	2930	3400	13.3	12.8	12.2
	20 + 20 + 20 + 20 + 25	2.29	2.29	2.29	2.29	2.86	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 20 + 20 + 20 + 35	2.09	2.09	2.09	2.09	3.65	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 20 + 20 + 20 + 50	1.85	1.85	1.85	1.85	4.62	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 20 + 60	1.71	1.71	1.71	1.71	5.14	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 25 + 25	2.18	2.18	2.18	2.73	2.73	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 20 + 20 + 25 + 35	2.00	2.00	2.00	2.50	3.50	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 20 + 20 + 25 + 50	1.78	1.78	1.78	2.22	4.44	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 25 + 60	1.66	1.66	1.66	2.07	4.97	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 35 + 35	1.85	1.85	1.85	3.23	3.23	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 35 + 50	1.66	1.66	1.66	2.90	4.14	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 20 + 35 + 60	1.55	1.55	1.55	2.71	4.65	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 20 + 20 + 50 + 50	1.50	1.50	1.50	3.75	3.75	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 20 + 25 + 25 + 25	2.09	2.09	2.61	2.61	2.61	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 20 + 25 + 25 + 35	1.92	1.92	2.40	2.40	3.36	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 25 + 25 + 50	1.71	1.71	2.14	2.14	4.29	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 25 + 25 + 60	1.60	1.60	2.00	2.00	4.80	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 25 + 35 + 35	1.78	1.78	2.22	3.11	3.11	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 25 + 35 + 50	1.60	1.60	2.00	2.80	4.00	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 25 + 35 + 60	1.50	1.50	1.88	2.63	4.50	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 20 + 35 + 35 + 35	1.66	1.66	2.90	2.90	2.90	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 20 + 35 + 35 + 50	1.50	1.50	2.63	2.63	3.75	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 25 + 25 + 25 + 25	2.00	2.50	2.50	2.50	2.50	-	4.0	12.0	13.5	1050	2920	3400	13.3	12.7	12.2
	20 + 25 + 25 + 25 + 35	1.85	2.31	2.31	2.31	3.23	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 25 + 25 + 25 + 50	1.66	2.07	2.07	2.07	4.14	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 25 + 25 + 25 + 60	1.55	1.94	1.94	1.94	4.65	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 25 + 25 + 35 + 35	1.71	2.14	2.14	3.00	3.00	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 25 + 25 + 35 + 50	1.55	1.94	1.94	2.71	3.87	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	20 + 25 + 35 + 35 + 35	1.60	2.00	2.80	2.80	2.80	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	20 + 35 + 35 + 35 + 35	1.50	2.63	2.63	2.63	2.63	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	25 + 25 + 25 + 25 + 25	2.40	2.40	2.40	2.40	2.40	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	25 + 25 + 25 + 25 + 35	2.22	2.22	2.22	2.22	3.11	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	25 + 25 + 25 + 25 + 50	2.00	2.00	2.00	2.00	4.00	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	25 + 25 + 25 + 25 + 60	1.88	1.88	1.88	1.88	4.50	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	25 + 25 + 25 + 35 + 35	2.07	2.07	2.07	2.90	2.90	-	4.0	12.0	13.5	1050	2910	3400	13.2	12.7	12.1
	25 + 25 + 25 + 35 + 50	1.88	1.88	1.88	2.63	3.75	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1
	25 + 25 + 35 + 35 + 35	1.94	1.94	2.71	2.71	2.71	-	4.0	12.0	13.5	1050	2900	3400	13.2	12.6	12.1

ESP-PR-1108

## (b) Indoor unit except SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	-	-	1.8	2.0	2.7	650	780	1100	3.6	3.4	3.3
	25	2.5	-	-	-	-	-	1.8	2.5	3.2	650	1000	1350	4.6	4.4	4.2
	35	3.5	-	-	-	-	-	1.8	3.5	3.7	650	1500	1600	6.9	6.6	6.3
	50	5.0	-	-	-	-	-	1.8	5.0	5.8	650	2150	2500	9.9	9.4	9.0
	60	6.0	-	-	-	-	-	1.8	6.0	6.7	650	2720	3000	12.5	11.9	11.4
	71	7.1	-	-	-	-	-	1.8	7.1	7.2	650	3250	3080	14.9	14.3	13.7
2 units	20 + 20	2.00	2.00	-	-	-	-	3.0	4.0	5.4	740	960	1460	4.4	4.2	4.0
	20 + 25	2.00	2.50	-	-	-	-	3.0	4.5	5.9	740	1100	1820	5.1	4.8	4.6
	20 + 35	2.00	3.50	-	-	-	-	3.0	5.5	6.4	740	1500	2020	6.9	6.6	6.3
	20 + 50	2.00	5.00	-	-	-	-	3.0	7.0	8.5	740	2290	2820	10.5	10.1	9.6
	20 + 60	2.00	6.00	-	-	-	-	3.0	8.0	9.4	740	2660	3360	12.2	11.7	11.2
	20 + 71	2.00	7.10	-	-	-	-	3.0	9.1	9.9	740	3100	3780	14.1	13.5	12.9
	25 + 25	2.50	2.50	-	-	-	-	3.0	5.0	6.8	740	1420	2200	6.5	6.2	6.0
	25 + 35	2.50	3.50	-	-	-	-	3.0	6.0	6.9	740	1810	2320	8.3	7.9	7.6
	25 + 50	2.50	5.00	-	-	-	-	3.0	7.5	9.0	740	2470	3220	11.3	10.8	10.4
	25 + 60	2.50	6.00	-	-	-	-	3.0	8.5	9.4	740	2810	3360	12.9	12.3	11.8
	25 + 71	2.53	7.17	-	-	-	-	3.0	9.7	10.4	740	3350	4020	15.4	14.7	14.1
	35 + 35	3.50	3.50	-	-	-	-	3.0	7.0	7.4	740	2290	2820	10.5	10.1	9.6
	35 + 50	3.50	5.00	-	-	-	-	3.0	8.5	9.5	740	2810	3620	12.9	12.3	11.8
	35 + 60	3.50	6.00	-	-	-	-	3.0	9.5	10.4	740	3280	3990	15.1	14.4	13.8
	35 + 71	3.30	6.70	-	-	-	-	3.0	10.0	10.9	740	3480	4250	15.8	15.1	14.5
	50 + 50	5.00	5.00	-	-	-	-	3.0	10.0	11.6	740	3480	4350	16.0	15.3	14.6
	50 + 60	4.55	5.45	-	-	-	-	3.0	10.0	11.8	740	3480	4410	16.0	15.3	14.6
	50 + 71	4.13	5.87	-	-	-	-	3.0	10.0	11.8	740	3470	4410	15.8	15.1	14.5
	60 + 60	5.00	5.00	-	-	-	-	3.0	10.0	11.8	740	3470	4410	15.9	15.2	14.6
	60 + 71	4.58	5.42	-	-	-	-	3.0	10.0	11.8	740	3470	4410	15.8	15.1	14.5
	71 + 71	5.00	5.00	-	-	-	-	3.0	10.0	11.8	740	3460	4410	15.6	14.9	14.3
3 units	20 + 20 + 20	2.00	2.00	2.00	-	-	-	3.7	6.0	8.1	880	1530	2490	7.0	6.7	6.4
	20 + 20 + 25	2.00	2.00	2.50	-	-	-	3.7	6.5	8.6	880	1730	2700	7.9	7.6	7.3
	20 + 20 + 35	2.00	2.00	3.50	-	-	-	3.7	7.5	9.1	880	2080	3120	9.6	9.1	8.8
	20 + 20 + 50	2.00	2.00	5.00	-	-	-	3.7	9.0	11.2	880	2730	4000	12.5	12.0	11.5
	20 + 20 + 60	2.00	2.00	6.00	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 20 + 71	1.80	1.80	6.40	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 25 + 25	2.00	2.50	2.50	-	-	-	3.7	7.0	9.1	880	1940	3210	8.9	8.5	8.2
	20 + 25 + 35	2.00	2.50	3.50	-	-	-	3.7	8.0	9.6	880	2440	3630	11.2	10.7	10.3
	20 + 25 + 50	2.00	2.50	5.00	-	-	-	3.7	9.5	11.5	880	3130	4120	14.4	13.7	13.2
	20 + 25 + 60	1.90	2.38	5.71	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 25 + 71	1.72	2.16	6.12	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 35 + 35	2.00	3.50	3.50	-	-	-	3.7	9.0	10.1	880	2920	3640	13.4	12.8	12.3
	20 + 35 + 50	1.90	3.33	4.76	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 35 + 60	1.74	3.04	5.22	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	20 + 35 + 71	1.59	2.78	5.63	-	-	-	4.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	20 + 50 + 50	1.67	4.17	4.17	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	20 + 50 + 60	1.54	3.85	4.62	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	20 + 50 + 71	1.42	3.55	5.04	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	20 + 60 + 60	1.43	4.29	4.29	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	20 + 60 + 71	1.32	3.97	4.70	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	25 + 25 + 25	2.50	2.50	2.50	-	-	-	3.7	7.5	9.4	880	2130	3340	9.8	9.4	9.0
	25 + 25 + 35	2.50	2.50	3.50	-	-	-	3.7	8.5	9.9	880	2650	3540	12.2	11.6	11.2
	25 + 25 + 50	2.50	2.50	5.00	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	25 + 25 + 60	2.27	2.27	5.45	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	25 + 25 + 71	2.07	2.07	5.87	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	25 + 35 + 35	2.50	3.50	3.50	-	-	-	3.7	9.5	10.4	880	3130	3950	14.4	13.7	13.2
	25 + 35 + 50	2.27	3.18	4.55	-	-	-	3.7	10.0	11.8	880	3280	4250	15.1	14.4	13.8
	25 + 35 + 60	2.08	2.92	5.00	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
3 units	25 + 35 + 71	1.91	2.67	5.42	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	25 + 50 + 50	2.00	4.00	4.00	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	25 + 50 + 60	1.85	3.70	4.44	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	25 + 50 + 71	1.71	3.42	4.86	-	-	-	3.7	10.0	11.8	880	3260	4250	21.4	20.5	19.7
	25 + 60 + 60	1.72	4.14	4.14	-	-	-	3.7	10.0	11.8	880	3260	4250	21.4	20.5	19.7
	25 + 60 + 71	1.60	3.85	4.55	-	-	-	3.7	10.0	11.8	880	3260	4250	21.4	20.5	19.7
	35 + 35 + 35	3.33	3.33	3.33	-	-	-	3.7	10.0	10.9	880	3280	4120	15.1	14.4	13.8
	35 + 35 + 50	2.92	2.92	4.17	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	35 + 35 + 60	2.69	2.69	4.62	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	35 + 35 + 71	2.48	2.48	5.04	-	-	-	3.7	10.0	11.8	880	3260	4250	14.8	14.2	13.6
	35 + 50 + 50	2.59	3.70	3.70	-	-	-	3.7	10.0	11.8	880	3270	4250	15.0	14.4	13.8
	35 + 50 + 60	2.41	3.45	4.14	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	35 + 50 + 71	2.24	3.21	4.55	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	35 + 60 + 60	2.26	3.87	3.87	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	50 + 50 + 50	3.33	3.33	3.33	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
	50 + 50 + 60	3.13	3.13	3.75	-	-	-	3.7	10.0	11.8	880	3260	4250	15.0	14.3	13.7
4 units	20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	-	-	4.4	8.0	10.8	1100	2110	3680	9.6	9.2	8.8
	20 + 20 + 20 + 25	2.00	2.00	2.00	2.50	-	-	4.4	8.5	11.1	1100	2390	3890	10.9	10.4	10.0
	20 + 20 + 20 + 35	2.00	2.00	2.00	3.50	-	-	4.4	9.5	11.6	1100	2900	3990	13.2	12.6	12.1
	20 + 20 + 20 + 50	1.82	1.82	1.82	4.55	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 20 + 60	1.67	1.67	1.67	5.00	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 20 + 71	1.53	1.53	1.53	5.42	-	-	4.4	10.0	11.8	1100	3200	4050	14.4	13.8	13.2
	20 + 20 + 25 + 25	2.00	2.00	2.50	2.50	-	-	4.4	9.0	11.6	1100	2600	3990	11.8	11.3	10.8
	20 + 20 + 25 + 35	2.00	2.00	2.50	3.50	-	-	4.4	10.0	11.8	1100	3220	4050	14.7	14.0	13.4
	20 + 20 + 25 + 50	1.74	1.74	2.17	4.35	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 25 + 60	1.60	1.60	2.00	4.80	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 25 + 71	1.47	1.47	1.84	5.22	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	20 + 20 + 35 + 35	1.82	1.82	3.18	3.18	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 35 + 50	1.60	1.60	2.80	4.00	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 20 + 35 + 60	1.48	1.48	2.59	4.44	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	20 + 20 + 35 + 71	1.37	1.37	2.40	4.86	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 20 + 50 + 50	1.43	1.43	3.57	3.57	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 20 + 50 + 60	1.33	1.33	3.33	4.00	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 20 + 60 + 60	1.25	1.25	3.75	3.75	-	-	4.4	10.0	11.8	1100	3180	4050	14.5	13.8	13.3
	20 + 25 + 25 + 25	2.00	2.50	2.50	2.50	-	-	4.4	9.5	11.8	1100	2900	4050	13.2	12.6	12.1
	20 + 25 + 25 + 35	1.90	2.38	2.38	3.33	-	-	4.4	10.0	11.8	1100	3220	4050	14.7	14.0	13.4
	20 + 25 + 25 + 50	1.67	2.08	2.08	4.17	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 25 + 25 + 60	1.54	1.92	1.92	4.62	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	20 + 25 + 25 + 71	1.46	1.81	1.81	4.93	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 25 + 35 + 35	1.74	2.17	3.04	3.04	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 25 + 35 + 50	1.54	1.92	2.69	3.85	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	20 + 25 + 35 + 60	1.43	1.79	2.50	4.29	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 25 + 35 + 71	1.32	1.66	2.32	4.70	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 25 + 50 + 50	1.38	1.72	3.45	3.45	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 25 + 50 + 60	1.29	1.61	3.23	3.87	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 35 + 35 + 35	1.60	2.80	2.80	2.80	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	20 + 35 + 35 + 50	1.43	2.50	2.50	3.57	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 35 + 35 + 60	1.33	2.33	2.33	4.00	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	20 + 35 + 50 + 50	1.29	2.26	3.23	3.23	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	-	-	4.4	10.0	11.8	1100	3220	4050	14.7	14.0	13.4
	25 + 25 + 25 + 35	2.27	2.27	2.27	3.18	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	25 + 25 + 25 + 50	2.00	2.00	2.00	4.00	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4
	25 + 25 + 25 + 60	1.85	1.85	1.85	4.44	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	25 + 25 + 25 + 71	1.71	1.71	1.71	4.86	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 25 + 35 + 35	2.08	2.08	2.92	2.92	-	-	4.4	10.0	11.8	1100	3210	4050	14.6	14.0	13.4

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	25 + 25 + 35 + 50	1.85	1.85	2.59	3.70	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	25 + 25 + 35 + 60	1.72	1.72	2.41	4.14	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 25 + 35 + 71	1.60	1.60	2.24	4.55	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 25 + 50 + 50	1.67	1.67	3.33	3.33	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 25 + 50 + 60	1.56	1.56	3.13	3.75	-	-	4.4	10.0	11.8	1100	3180	4050	14.5	13.8	13.3
	25 + 35 + 35 + 35	1.92	2.69	2.69	2.69	-	-	4.4	10.0	11.8	1100	3200	4050	14.6	13.9	13.3
	25 + 35 + 35 + 50	1.72	2.41	2.41	3.45	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 35 + 35 + 60	1.61	2.26	2.26	3.87	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	25 + 35 + 50 + 50	1.56	2.19	3.13	3.13	-	-	4.4	10.0	11.8	1100	3180	4050	14.5	13.8	13.3
	35 + 35 + 35 + 35	2.50	2.50	2.50	2.50	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
	35 + 35 + 35 + 50	2.26	2.26	2.26	3.23	-	-	4.4	10.0	11.8	1100	3190	4050	14.5	13.9	13.3
5 units	20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	11.8	1210	2950	4030	13.4	12.8	12.3
	20 + 20 + 20 + 20 + 25	1.90	1.90	1.90	1.90	2.38	-	5.1	10.0	11.8	1210	2950	4030	13.4	12.8	12.3
	20 + 20 + 20 + 20 + 35	1.74	1.74	1.74	1.74	3.04	-	5.1	10.0	11.8	1210	2950	4030	13.4	12.8	12.3
	20 + 20 + 20 + 20 + 50	1.54	1.54	1.54	1.54	3.85	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 20 + 20 + 60	1.43	1.43	1.43	1.43	4.29	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 20 + 71	1.32	1.32	1.32	1.32	4.70	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 25 + 25	1.82	1.82	1.82	2.27	2.27	-	5.1	10.0	11.8	1210	2950	4030	13.4	12.8	12.3
	20 + 20 + 20 + 25 + 35	1.67	1.67	1.67	2.08	2.92	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 20 + 25 + 50	1.48	1.48	1.48	1.85	3.70	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 20 + 25 + 60	1.38	1.38	1.38	1.72	4.14	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 25 + 71	1.28	1.28	1.28	1.60	4.55	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 35 + 35	1.54	1.54	1.54	2.69	2.69	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 20 + 35 + 50	1.38	1.38	1.38	2.41	3.45	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 35 + 60	1.29	1.29	1.29	2.26	3.87	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 20 + 50 + 50	1.25	1.25	1.25	3.13	3.13	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 25 + 25 + 25	1.74	1.74	2.17	2.17	2.17	-	5.1	10.0	11.8	1210	2950	4030	13.4	12.8	12.3
	20 + 20 + 25 + 25 + 35	1.60	1.60	2.00	2.00	2.80	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 25 + 25 + 50	1.43	1.43	1.79	1.79	3.57	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 25 + 25 + 60	1.33	1.33	1.67	1.67	4.00	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 25 + 35 + 35	1.48	1.48	1.85	2.59	2.59	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 20 + 25 + 35 + 50	1.33	1.33	1.67	2.33	3.33	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 25 + 35 + 60	1.25	1.25	1.56	2.19	3.75	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 35 + 35 + 35	1.38	1.38	2.41	2.41	2.41	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 20 + 35 + 35 + 50	1.25	1.25	2.19	2.19	3.13	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 25 + 25 + 25 + 25	1.67	2.08	2.08	2.08	2.08	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 25 + 25 + 25 + 35	1.54	1.92	1.92	1.92	2.69	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	20 + 25 + 25 + 25 + 50	1.38	1.72	1.72	1.72	3.45	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 25 + 25 + 25 + 60	1.29	1.61	1.61	1.61	3.87	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 25 + 25 + 35 + 35	1.43	1.79	1.79	2.50	2.50	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 25 + 25 + 35 + 50	1.29	1.61	1.61	2.26	3.23	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 25 + 35 + 35 + 35	1.33	1.67	2.33	2.33	2.33	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	20 + 35 + 35 + 35 + 35	1.25	2.19	2.19	2.19	2.19	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	25 + 25 + 25 + 25 + 25	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	25 + 25 + 25 + 25 + 35	1.85	1.85	1.85	1.85	2.59	-	5.1	10.0	11.8	1210	2940	4030	13.4	12.8	12.3
	25 + 25 + 25 + 25 + 50	1.67	1.67	1.67	1.67	3.33	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	25 + 25 + 25 + 25 + 60	1.56	1.56	1.56	1.56	3.75	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	25 + 25 + 25 + 35 + 35	1.72	1.72	1.72	2.41	2.41	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	25 + 25 + 25 + 35 + 50	1.56	1.56	1.56	2.19	3.13	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2
	25 + 25 + 35 + 35 + 35	1.61	1.61	2.26	2.26	2.26	-	5.1	10.0	11.8	1210	2930	4030	13.3	12.8	12.2

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	-	-	1.5	3.0	3.6	700	1220	1330	5.6	5.4	5.1
	25	3.4	-	-	-	-	-	1.5	3.4	4.1	700	1265	1540	5.8	5.6	5.3
	35	4.5	-	-	-	-	-	1.5	4.5	4.9	700	1650	1840	7.6	7.2	6.9
	50	5.8	-	-	-	-	-	1.5	5.8	6.4	700	2120	2410	9.7	9.3	8.9
	60	6.8	-	-	-	-	-	1.5	6.8	7.4	700	2500	2760	11.5	11.0	10.5
	71	8.0	-	-	-	-	-	1.5	8.0	8.1	700	3020	3090	13.9	13.3	12.7
2 units	20 + 20	3.00	3.00	-	-	-	-	2.1	6.0	7.2	750	1540	1860	7.1	6.8	6.5
	20 + 25	2.84	3.56	-	-	-	-	2.1	6.4	7.7	750	1660	2210	7.6	7.3	7.0
	20 + 35	2.73	4.77	-	-	-	-	2.1	7.5	8.5	750	1990	2520	9.1	8.7	8.4
	20 + 50	2.51	6.29	-	-	-	-	2.1	8.8	10.0	750	2430	3220	11.2	10.7	10.2
	20 + 60	2.45	7.35	-	-	-	-	2.1	9.8	11.0	750	2840	3620	13.0	12.5	12.0
	20 + 71	2.42	8.58	-	-	-	-	2.1	11.0	11.6	750	2840	3620	13.0	12.5	12.0
	25 + 25	3.40	3.40	-	-	-	-	2.1	6.8	8.2	750	1770	2420	8.1	7.8	7.4
	25 + 35	3.29	4.61	-	-	-	-	2.1	7.9	9.0	750	2140	2820	9.8	9.4	9.0
	25 + 50	3.07	6.13	-	-	-	-	2.1	9.2	10.5	750	2630	3610	12.1	11.6	11.1
	25 + 60	3.00	7.20	-	-	-	-	2.1	10.2	11.5	750	3040	3790	14.0	13.4	12.8
	25 + 71	2.97	8.43	-	-	-	-	2.1	11.4	12.1	750	3440	4250	15.8	15.1	14.5
	35 + 35	4.50	4.50	-	-	-	-	2.1	9.0	9.8	750	2520	3210	11.6	11.1	10.6
	35 + 50	4.24	6.06	-	-	-	-	2.1	10.3	11.3	750	3040	3710	14.0	13.4	12.8
	35 + 60	4.16	7.14	-	-	-	-	2.1	11.3	12.3	750	3420	4320	15.7	15.0	14.4
	35 + 71	3.96	8.04	-	-	-	-	2.1	12.0	12.9	750	4030	4690	18.5	17.7	17.0
	50 + 50	5.80	5.80	-	-	-	-	2.1	11.6	12.8	750	3660	4620	16.8	16.1	15.4
	50 + 60	5.45	6.55	-	-	-	-	2.1	12.0	13.3	750	4030	4920	18.5	17.7	17.0
	50 + 71	4.96	7.04	-	-	-	-	2.1	12.0	13.3	750	4030	4920	18.5	17.7	17.0
	60 + 60	6.00	6.00	-	-	-	-	2.1	12.0	13.3	750	4030	4920	18.5	17.7	17.0
	60 + 71	5.50	6.50	-	-	-	-	2.1	12.0	13.3	750	4030	4920	18.5	17.7	17.0
	71 + 71	6.00	6.00	-	-	-	-	2.1	12.0	13.3	750	4030	4920	18.5	17.7	17.0
3 units	20 + 20 + 20	3.00	3.00	3.00	-	-	-	3.2	9.0	10.9	780	2270	3350	10.4	10.0	9.6
	20 + 20 + 25	2.89	2.89	3.62	-	-	-	3.2	9.4	11.4	780	2400	3550	11.0	10.5	10.1
	20 + 20 + 35	2.80	2.80	4.90	-	-	-	3.2	10.5	12.2	780	2760	3820	12.7	12.1	11.6
	20 + 20 + 50	2.62	2.62	6.56	-	-	-	3.2	11.8	13.3	780	3270	4290	15.0	14.4	13.8
	20 + 20 + 60	2.40	2.40	7.20	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	20 + 20 + 71	2.16	2.16	7.68	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	20 + 25 + 25	2.80	3.50	3.50	-	-	-	3.2	9.8	11.9	780	2560	3720	11.8	11.2	10.8
	20 + 25 + 35	2.73	3.41	4.77	-	-	-	3.2	10.9	12.7	780	2970	3990	13.6	13.0	12.5
	20 + 25 + 50	2.53	3.16	6.32	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	20 + 25 + 60	2.29	2.86	6.86	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	20 + 25 + 71	2.07	2.59	7.34	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	20 + 35 + 35	2.67	4.67	4.67	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	20 + 35 + 50	2.29	4.00	5.71	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	20 + 35 + 60	2.09	3.65	6.26	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	20 + 35 + 71	1.90	3.33	6.76	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	20 + 50 + 50	2.00	5.00	5.00	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	20 + 50 + 60	1.85	4.62	5.54	-	-	-	3.2	12.0	13.3	780	3400	4290	15.6	14.9	14.3
	20 + 50 + 71	1.70	4.26	6.04	-	-	-	4.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	20 + 60 + 60	1.71	5.14	5.14	-	-	-	5.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	20 + 60 + 71	1.59	4.77	5.64	-	-	-	6.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	25 + 25 + 25	3.40	3.40	3.40	-	-	-	3.2	10.2	12.4	780	2760	3880	12.7	12.1	11.6
	25 + 25 + 35	3.32	3.32	4.65	-	-	-	3.2	11.3	13.2	780	3170	4120	14.6	13.9	13.3
	25 + 25 + 50	3.00	3.00	6.00	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	25 + 25 + 60	2.73	2.73	6.55	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	25 + 25 + 71	2.48	2.48	7.04	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	25 + 35 + 35	3.16	4.42	4.42	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	25 + 35 + 50	2.73	3.82	5.45	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
3 units	25 + 35 + 60	2.50	3.50	6.00	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	25 + 35 + 71	2.29	3.21	6.50	-	-	-	4.2	12.0	13.3	780	3400	4290	15.6	14.9	14.3
	25 + 50 + 50	2.40	4.80	4.80	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	25 + 50 + 60	2.22	4.44	5.33	-	-	-	3.2	12.0	13.3	780	3400	4290	15.6	14.9	14.3
	25 + 50 + 71	2.05	4.11	5.84	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	25 + 60 + 60	2.07	4.97	4.97	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	25 + 60 + 71	1.92	4.62	5.46	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	35 + 35 + 35	4.00	4.00	4.00	-	-	-	3.2	12.0	13.3	780	3420	4290	15.7	15.0	14.4
	35 + 35 + 50	3.50	3.50	5.00	-	-	-	3.2	12.0	13.3	780	3410	4290	15.7	15.0	14.4
	35 + 35 + 60	3.23	3.23	5.54	-	-	-	3.2	12.0	13.3	780	3400	4290	15.6	14.9	14.3
	35 + 35 + 71	2.98	2.98	6.04	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	35 + 50 + 50	3.11	4.44	4.44	-	-	-	3.2	12.0	13.3	780	3400	4290	15.6	14.9	14.3
	35 + 50 + 60	2.90	4.14	4.97	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	35 + 50 + 71	2.69	3.85	5.46	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	35 + 60 + 60	2.71	4.65	4.65	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	50 + 50 + 50	4.00	4.00	4.00	-	-	-	3.2	12.0	13.3	780	3390	4290	15.6	14.9	14.3
	50 + 50 + 60	3.75	3.75	4.50	-	-	-	3.2	12.0	13.3	780	3380	4290	15.5	14.8	14.2
4 units	20 + 20 + 20 + 20	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.3	950	3270	3920	14.9	14.2	13.6
	20 + 20 + 20 + 25	2.82	2.82	2.82	3.53	-	-	3.6	12.0	13.3	950	3270	3920	14.9	14.2	13.6
	20 + 20 + 20 + 35	2.53	2.53	2.53	4.42	-	-	3.6	12.0	13.3	950	3270	3920	14.9	14.2	13.6
	20 + 20 + 20 + 50	2.18	2.18	2.18	5.45	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 20 + 20 + 60	2.00	2.00	2.00	6.00	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 20 + 20 + 71	1.83	1.83	1.83	6.50	-	-	3.6	12.0	13.3	950	3250	3920	14.6	14.0	13.4
	20 + 20 + 25 + 25	2.67	2.67	3.33	3.33	-	-	3.6	12.0	13.3	950	3270	3920	14.9	14.2	13.6
	20 + 20 + 25 + 35	2.40	2.40	3.00	4.20	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 20 + 25 + 50	2.09	2.09	2.61	5.22	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 20 + 25 + 60	1.92	1.92	2.40	5.76	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 20 + 25 + 71	1.76	1.76	2.21	6.26	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 20 + 35 + 35	2.18	2.18	3.82	3.82	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 20 + 35 + 50	1.92	1.92	3.36	4.80	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 20 + 35 + 60	1.78	1.78	3.11	5.33	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 20 + 35 + 71	1.64	1.64	2.88	5.84	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 20 + 50 + 50	1.71	1.71	4.29	4.29	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 20 + 50 + 60	1.60	1.60	4.00	4.80	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 20 + 60 + 60	1.50	1.50	4.50	4.50	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 25 + 25 + 25	2.53	3.16	3.16	3.16	-	-	3.6	12.0	13.3	950	3270	3920	14.9	14.2	13.6
	20 + 25 + 25 + 35	2.29	2.86	2.86	4.00	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 25 + 25 + 50	2.00	2.50	2.50	5.00	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 25 + 25 + 60	1.85	2.31	2.31	5.54	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 25 + 25 + 71	1.70	2.13	2.13	6.04	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 25 + 35 + 35	2.09	2.61	3.65	3.65	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	20 + 25 + 35 + 50	1.85	2.31	3.23	4.62	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 25 + 35 + 60	1.71	2.14	3.00	5.14	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 25 + 35 + 71	1.59	1.99	2.78	5.64	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 25 + 50 + 50	1.66	2.07	4.14	4.14	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 25 + 50 + 60	1.55	1.94	3.87	4.65	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 35 + 35 + 35	1.92	3.36	3.36	3.36	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	20 + 35 + 35 + 50	1.71	3.00	3.00	4.29	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 35 + 35 + 60	1.60	2.80	2.80	4.80	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	20 + 35 + 50 + 50	1.55	2.71	3.87	3.87	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 25 + 25 + 25	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	25 + 25 + 25 + 35	2.73	2.73	2.73	3.82	-	-	3.6	12.0	13.3	950	3260	3920	14.8	14.2	13.6
	25 + 25 + 25 + 50	2.40	2.40	2.40	4.80	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	25 + 25 + 25 + 60	2.22	2.22	2.22	5.33	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	25 + 25 + 25 + 71	2.05	2.05	2.05	5.84	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	25 + 25 + 35 + 35	2.50	2.50	3.50	3.50	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	25 + 25 + 35 + 50	2.22	2.22	3.11	4.44	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	25 + 25 + 35 + 60	2.07	2.07	2.90	4.97	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 25 + 35 + 71	1.92	1.92	2.69	5.46	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 25 + 50 + 50	2.00	2.00	4.00	4.00	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 25 + 50 + 60	1.88	1.88	3.75	4.50	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 35 + 35 + 35	2.31	3.23	3.23	3.23	-	-	3.6	12.0	13.3	950	3250	3920	14.8	14.1	13.6
	25 + 35 + 35 + 50	2.07	2.90	2.90	4.14	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 35 + 35 + 60	1.94	2.71	2.71	4.65	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	25 + 35 + 50 + 50	1.88	2.63	3.75	3.75	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	35 + 35 + 35 + 35	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
	35 + 35 + 35 + 50	2.71	2.71	2.71	3.87	-	-	3.6	12.0	13.3	950	3240	3920	14.7	14.1	13.5
5 units	20 + 20 + 20 + 20 + 20	2.40	2.40	2.40	2.40	2.40	-	4.0	12.0	13.3	1050	3220	3620	14.7	14.0	13.4
	20 + 20 + 20 + 20 + 25	2.29	2.29	2.29	2.29	2.86	-	4.0	12.0	13.3	1050	3220	3620	14.7	14.0	13.4
	20 + 20 + 20 + 20 + 35	2.09	2.09	2.09	2.09	3.65	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 20 + 20 + 20 + 50	1.85	1.85	1.85	1.85	4.62	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 20 + 60	1.71	1.71	1.71	1.71	5.14	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 20 + 71	1.59	1.59	1.59	1.59	5.64	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 20 + 25 + 25	2.18	2.18	2.18	2.73	2.73	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 20 + 20 + 25 + 35	2.00	2.00	2.00	2.50	3.50	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 20 + 20 + 25 + 50	1.78	1.78	1.78	2.22	4.44	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 25 + 60	1.66	1.66	1.66	2.07	4.97	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 25 + 71	1.54	1.54	1.54	1.92	5.46	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 20 + 35 + 35	1.85	1.85	1.85	3.23	3.23	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 35 + 50	1.66	1.66	1.66	2.90	4.14	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 20 + 35 + 60	1.55	1.55	1.55	2.71	4.65	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 20 + 50 + 50	1.50	1.50	1.50	3.75	3.75	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 25 + 25 + 25	2.09	2.09	2.61	2.61	2.61	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 20 + 25 + 25 + 35	1.92	1.92	2.40	2.40	3.36	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 20 + 25 + 25 + 50	1.71	1.71	2.14	2.14	4.29	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 25 + 25 + 60	1.60	1.60	2.00	2.00	4.80	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 25 + 35 + 35	1.78	1.78	2.22	3.11	3.11	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 25 + 35 + 50	1.60	1.60	2.00	2.80	4.00	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 25 + 35 + 60	1.50	1.50	1.88	2.63	4.50	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 20 + 35 + 35 + 35	1.66	1.66	2.90	2.90	2.90	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 20 + 35 + 35 + 50	1.50	1.50	2.63	2.63	3.75	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 25 + 25 + 25 + 25	2.00	2.50	2.50	2.50	2.50	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	20 + 25 + 25 + 25 + 35	1.85	2.31	2.31	2.31	3.23	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 25 + 25 + 25 + 50	1.66	2.07	2.07	2.07	4.14	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 25 + 25 + 25 + 60	1.55	1.94	1.94	1.94	4.65	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 25 + 25 + 35 + 35	1.71	2.14	2.14	3.00	3.00	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	20 + 25 + 25 + 35 + 50	1.55	1.94	1.94	2.71	3.87	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 25 + 35 + 35 + 35	1.60	2.00	2.80	2.80	2.80	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	20 + 35 + 35 + 35 + 35	1.50	2.63	2.63	2.63	2.63	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	25 + 25 + 25 + 25 + 25	2.40	2.40	2.40	2.40	2.40	-	4.0	12.0	13.3	1050	3210	3620	14.6	14.0	13.4
	25 + 25 + 25 + 25 + 35	2.22	2.22	2.22	2.22	3.11	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	25 + 25 + 25 + 25 + 50	2.00	2.00	2.00	2.00	4.00	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	25 + 25 + 25 + 25 + 60	1.88	1.88	1.88	1.88	4.50	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	25 + 25 + 25 + 35 + 35	2.07	2.07	2.07	2.90	2.90	-	4.0	12.0	13.3	1050	3200	3620	14.6	13.9	13.3
	25 + 25 + 25 + 35 + 50	1.88	1.88	1.88	2.63	3.75	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3
	25 + 25 + 35 + 35 + 35	1.94	1.94	2.71	2.71	2.71	-	4.0	12.0	13.3	1050	3190	3620	14.5	13.9	13.3

ESP-PR-1108

## (8) Model SCM125ZM-S

## (a) Indoor unit SRK\*\*ZMX-S models only

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	-	-	1.8	2.0	2.8	650	750	1100	3.4	3.3	3.2
	25	2.5	-	-	-	-	-	1.8	2.5	3.4	650	950	1350	4.4	4.2	4.0
	35	3.5	-	-	-	-	-	1.8	3.5	3.9	650	1400	1600	6.4	6.1	5.9
	50	5.0	-	-	-	-	-	1.8	5.0	6.1	650	2000	2500	9.2	8.8	8.4
	60	6.0	-	-	-	-	-	1.8	6.0	7.0	650	2450	3000	11.2	10.8	10.3
2 units	20 + 20	2.00	2.00	-	-	-	-	3.0	4.0	5.6	740	910	1460	4.2	4.0	3.8
	20 + 25	2.00	2.50	-	-	-	-	3.0	4.5	6.2	740	1050	1820	4.8	4.6	4.4
	20 + 35	2.00	3.50	-	-	-	-	3.0	5.5	6.7	740	1430	2020	6.6	6.3	6.0
	20 + 50	2.00	5.00	-	-	-	-	3.0	7.0	8.9	740	2180	2820	10.0	9.6	9.2
	20 + 60	2.00	6.00	-	-	-	-	3.0	8.0	9.8	740	2530	3360	11.6	11.1	10.6
	25 + 25	2.50	2.50	-	-	-	-	3.0	5.0	6.8	740	1350	2200	6.2	5.9	5.7
	25 + 35	2.50	3.50	-	-	-	-	3.0	6.0	7.3	740	1720	2320	7.9	7.6	7.2
	25 + 50	2.50	5.00	-	-	-	-	3.0	7.5	9.5	740	2350	3220	10.8	10.3	9.9
	25 + 60	2.50	6.00	-	-	-	-	3.0	8.5	9.8	740	2680	3360	12.3	11.8	11.3
	35 + 35	3.50	3.50	-	-	-	-	3.0	7.0	7.8	740	2180	2820	10.0	9.6	9.2
	35 + 50	3.50	5.00	-	-	-	-	3.0	8.5	10.0	740	2680	3620	12.3	11.8	11.3
	35 + 60	3.50	6.00	-	-	-	-	3.0	9.5	10.9	740	3120	3990	14.3	13.7	13.1
	50 + 50	5.00	5.00	-	-	-	-	3.0	10.0	12.2	740	3350	4450	15.4	14.7	14.1
	50 + 60	5.00	6.00	-	-	-	-	3.0	11.0	12.5	740	3685	4520	16.9	16.2	15.5
	60 + 60	6.00	6.00	-	-	-	-	3.0	12.0	12.5	740	4200	4520	19.3	18.4	17.7
3 units	20 + 20 + 20	2.00	2.00	2.00	-	-	-	3.7	6.0	8.4	880	1460	2560	6.7	6.4	6.1
	20 + 20 + 25	2.00	2.00	2.50	-	-	-	3.7	6.5	9.0	880	1650	2700	7.6	7.2	6.9
	20 + 20 + 35	2.00	2.00	3.50	-	-	-	3.7	7.5	9.5	880	1980	3120	9.1	8.7	8.3
	20 + 20 + 50	2.00	2.00	5.00	-	-	-	3.7	9.0	11.7	880	2600	4120	11.9	11.4	10.9
	20 + 20 + 60	2.00	2.00	6.00	-	-	-	3.7	10.0	12.6	880	3120	4680	14.3	13.7	13.1
	20 + 25 + 25	2.00	2.50	2.50	-	-	-	3.7	7.0	9.6	880	1850	3210	8.5	8.1	7.8
	20 + 25 + 35	2.00	2.50	3.50	-	-	-	3.7	8.0	10.1	880	2320	3630	10.7	10.2	9.8
	20 + 25 + 50	2.00	2.50	5.00	-	-	-	3.7	9.5	12.3	880	2980	4510	13.7	13.1	12.5
	20 + 25 + 60	2.00	2.50	6.00	-	-	-	3.7	10.5	12.8	880	3590	4800	16.5	15.8	15.1
	20 + 35 + 35	2.00	3.50	3.50	-	-	-	3.7	9.0	10.6	880	2780	4120	12.8	12.2	11.7
	20 + 35 + 50	2.00	3.50	5.00	-	-	-	3.7	10.5	12.8	880	3590	4800	16.5	15.8	15.1
	20 + 35 + 60	2.00	3.50	6.00	-	-	-	3.7	11.5	12.8	880	3950	4800	18.1	17.3	16.6
	20 + 50 + 50	2.00	5.00	5.00	-	-	-	3.7	12.0	12.8	880	4230	4800	19.4	18.6	17.8
	20 + 50 + 60	1.92	4.81	5.77	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	20 + 60 + 60	1.79	5.36	5.36	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	25 + 25 + 25	2.50	2.50	2.50	-	-	-	3.7	7.5	10.2	880	2030	3640	9.3	8.9	8.5
	25 + 25 + 35	2.50	2.50	3.50	-	-	-	3.7	8.5	10.7	880	2520	3900	11.6	11.1	10.6
	25 + 25 + 50	2.50	2.50	5.00	-	-	-	3.7	10.0	12.8	880	3260	4800	15.0	14.3	13.7
	25 + 25 + 60	2.50	2.50	6.00	-	-	-	3.7	11.0	12.8	880	3720	4800	17.1	16.3	15.7
	25 + 35 + 35	2.50	3.50	3.50	-	-	-	3.7	9.5	11.2	880	2980	4510	13.7	13.1	12.5
	25 + 35 + 50	2.50	3.50	5.00	-	-	-	3.7	11.0	12.8	880	3720	4800	17.1	16.3	15.7
	25 + 35 + 60	2.50	3.50	6.00	-	-	-	3.7	12.0	12.8	880	4230	4800	19.4	18.6	17.8
	25 + 50 + 50	2.50	5.00	5.00	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	25 + 50 + 60	2.31	4.63	5.56	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	25 + 60 + 60	2.16	5.17	5.17	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	35 + 35 + 35	3.50	3.50	3.50	-	-	-	3.7	10.5	11.7	880	3590	4180	16.5	15.8	15.1
	35 + 35 + 50	3.50	3.50	5.00	-	-	-	3.7	12.0	12.8	880	4230	4800	19.4	18.6	17.8
	35 + 35 + 60	3.37	3.37	5.77	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	35 + 50 + 50	3.24	4.63	4.63	-	-	-	3.7	12.5	12.8	880	4450	4800	20.4	19.5	18.7
	35 + 50 + 60	3.02	4.31	5.17	-	-	-	3.7	12.5	12.8	880	4450	4800	20.2	19.3	18.5
	35 + 60 + 60	2.82	4.84	4.84	-	-	-	3.7	12.5	12.8	880	4450	4800	20.2	19.3	18.5
	50 + 50 + 50	4.17	4.17	4.17	-	-	-	3.7	12.5	12.8	880	4440	4800	20.4	19.5	18.7
	50 + 50 + 60	3.91	3.91	4.69	-	-	-	3.7	12.5	12.8	880	4440	4800	20.4	19.5	18.7
	50 + 60 + 60	3.68	4.41	4.41	-	-	-	3.7	12.5	12.8	880	4430	4800	20.3	19.5	18.6
	60 + 60 + 60	4.17	4.17	4.17	-	-	-	3.7	12.5	12.8	880	4430	4800	20.3	19.5	18.6

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	-	-	4.4	8.0	11.2	1100	2050	3680	9.3	8.9	8.6
	20 + 20 + 20 + 25	2.00	2.00	2.00	2.50	-	-	4.4	8.5	11.8	1100	2320	3890	10.6	10.1	9.7
	20 + 20 + 20 + 35	2.00	2.00	2.00	3.50	-	-	4.4	9.5	12.3	1100	2820	4530	12.8	12.3	11.8
	20 + 20 + 20 + 50	2.00	2.00	2.00	5.00	-	-	4.4	11.0	13.0	1100	3480	4800	15.8	15.1	14.5
	20 + 20 + 20 + 60	2.00	2.00	2.00	6.00	-	-	4.4	12.0	13.0	1100	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25	2.00	2.00	2.50	2.50	-	-	4.4	9.0	12.4	1100	2520	4590	11.5	11.0	10.5
	20 + 20 + 25 + 35	2.00	2.00	2.50	3.50	-	-	4.4	10.0	12.9	1100	3120	4780	14.2	13.6	13.0
	20 + 20 + 25 + 50	2.00	2.00	2.50	5.00	-	-	4.4	11.5	13.0	1100	3720	4800	16.9	16.2	15.5
	20 + 20 + 25 + 60	2.00	2.00	2.50	6.00	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	20 + 20 + 35 + 35	2.00	2.00	3.50	3.50	-	-	4.4	11.0	13.0	1100	3480	4800	15.8	15.1	14.5
	20 + 20 + 35 + 50	2.00	2.00	3.50	5.00	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	20 + 20 + 35 + 60	1.85	1.85	3.24	5.56	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 20 + 50 + 50	1.79	1.79	4.46	4.46	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 20 + 50 + 60	1.67	1.67	4.17	5.00	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 20 + 60 + 60	1.56	1.56	4.69	4.69	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 25 + 25 + 25	2.00	2.50	2.50	2.50	-	-	4.4	9.5	13.0	1100	2820	4800	12.8	12.3	11.8
	20 + 25 + 25 + 35	2.00	2.50	2.50	3.50	-	-	4.4	10.5	13.0	1100	3340	4800	15.2	14.5	13.9
	20 + 25 + 25 + 50	2.00	2.50	2.50	5.00	-	-	4.4	12.0	13.0	1100	3980	4800	18.1	17.3	16.6
	20 + 25 + 25 + 60	1.92	2.40	2.40	5.77	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	20 + 25 + 35 + 35	2.00	2.50	3.50	3.50	-	-	4.4	11.5	13.0	1100	3720	4800	16.9	16.2	15.5
	20 + 25 + 35 + 50	1.92	2.40	3.37	4.81	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	20 + 25 + 35 + 60	1.79	2.23	3.13	5.36	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 25 + 50 + 50	1.72	2.16	4.31	4.31	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 25 + 50 + 60	1.61	2.02	4.03	4.84	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 25 + 60 + 60	1.52	1.89	4.55	4.55	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 35 + 35 + 35	2.00	3.50	3.50	3.50	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	20 + 35 + 35 + 50	1.79	3.13	3.13	4.46	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 35 + 35 + 60	1.67	2.92	2.92	5.00	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	20 + 35 + 50 + 50	1.61	2.82	4.03	4.03	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 35 + 50 + 60	1.52	2.65	3.79	4.55	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 35 + 60 + 60	1.43	2.50	4.29	4.29	-	-	5.4	12.5	13.0	1100	4570	4801	20.6	19.7	18.9
	20 + 50 + 50 + 50	1.47	3.68	3.68	3.68	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	20 + 50 + 50 + 60	1.39	3.47	3.47	4.17	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	20 + 50 + 60 + 60	1.32	3.29	3.95	3.95	-	-	4.4	12.5	13.0	1100	4560	4800	20.7	19.8	19.0
	25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	-	-	4.4	10.0	13.0	1100	3120	4800	14.2	13.6	13.0
	25 + 25 + 25 + 35	2.50	2.50	2.50	3.50	-	-	4.4	11.0	13.0	1100	3480	4800	15.8	15.1	14.5
	25 + 25 + 25 + 50	2.50	2.50	2.50	5.00	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	25 + 25 + 25 + 60	2.31	2.31	2.31	5.56	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	25 + 25 + 35 + 35	2.50	2.50	3.50	3.50	-	-	4.4	12.0	13.0	1100	3980	4800	18.1	17.3	16.6
	25 + 25 + 35 + 50	2.31	2.31	3.24	4.63	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	25 + 25 + 35 + 60	2.16	2.16	3.02	5.17	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	25 + 25 + 50 + 50	2.08	2.08	4.17	4.17	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	25 + 25 + 50 + 60	1.95	1.95	3.91	4.69	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	25 + 25 + 60 + 60	1.84	1.84	4.41	4.41	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	25 + 35 + 35 + 35	2.40	3.37	3.37	3.37	-	-	4.4	12.5	13.0	1100	4600	4800	20.9	20.0	19.2
	25 + 35 + 35 + 50	2.16	3.02	3.02	4.31	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	25 + 35 + 35 + 60	2.02	2.82	2.82	4.84	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	25 + 35 + 50 + 50	1.95	2.73	3.91	3.91	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	25 + 35 + 50 + 60	1.84	2.57	3.68	4.41	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	25 + 35 + 60 + 60	1.74	2.43	4.17	4.17	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	25 + 50 + 50 + 50	1.79	3.57	3.57	3.57	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	25 + 50 + 50 + 60	1.69	3.38	3.38	4.05	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	25 + 50 + 60 + 60	1.60	3.21	3.85	3.85	-	-	4.4	12.5	13.0	1100	4560	4800	20.7	19.8	19.0
	35 + 35 + 35 + 35	3.13	3.13	3.13	3.13	-	-	4.4	12.5	13.0	1100	4590	4800	20.9	20.0	19.1
	35 + 35 + 35 + 50	2.82	2.82	2.82	4.03	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	35 + 35 + 35 + 60	2.65	2.65	2.65	4.55	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	35 + 35 + 50 + 50	2.57	2.57	3.68	3.68	-	-	4.4	12.5	13.0	1100	4580	4800	20.8	19.9	19.1
	35 + 35 + 50 + 60	2.43	2.43	3.47	4.17	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	35 + 35 + 60 + 60	2.30	2.30	3.95	3.95	-	-	4.4	12.5	13.0	1100	4560	4800	20.7	19.8	19.0
	35 + 50 + 50 + 50	2.36	3.38	3.38	3.38	-	-	4.4	12.5	13.0	1100	4570	4800	20.8	19.9	19.1
	35 + 50 + 50 + 60	2.24	3.21	3.21	3.85	-	-	4.4	12.5	13.0	1100	4560	4800	20.7	19.8	19.0
5 units	20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	13.5	1210	2880	4800	13.1	12.5	12.0
	20 + 20 + 20 + 20 + 25	2.00	2.00	2.00	2.00	2.50	-	5.1	10.5	13.5	1210	3120	4800	14.2	13.6	13.0
	20 + 20 + 20 + 20 + 35	2.00	2.00	2.00	2.00	3.50	-	5.1	11.5	13.5	1210	3620	4800	16.5	15.8	15.1
	20 + 20 + 20 + 20 + 50	1.92	1.92	1.92	1.92	4.81	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	20 + 20 + 20 + 20 + 60	1.79	1.79	1.79	1.79	5.36	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 20 + 20 + 25 + 25	2.00	2.00	2.00	2.50	2.50	-	5.1	11.0	13.5	1210	3320	4800	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 35	2.00	2.00	2.00	2.50	3.50	-	5.1	12.0	13.5	1210	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 25 + 50	1.85	1.85	1.85	2.31	4.63	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	20 + 20 + 20 + 25 + 60	1.72	1.72	1.72	2.16	5.17	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 20 + 20 + 35 + 35	1.92	1.92	1.92	3.37	3.37	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	20 + 20 + 20 + 35 + 50	1.72	1.72	1.72	3.02	4.31	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 20 + 20 + 35 + 60	1.61	1.61	1.61	2.82	4.84	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 20 + 50 + 50	1.56	1.56	1.56	3.91	3.91	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 20 + 50 + 60	1.47	1.47	1.47	3.68	4.41	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 20 + 20 + 60 + 60	1.39	1.39	1.39	4.17	4.17	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 20 + 25 + 25 + 25	2.00	2.00	2.50	2.50	2.50	-	5.1	11.5	13.5	1210	3620	4800	16.5	15.8	15.1
	20 + 20 + 25 + 25 + 35	2.00	2.00	2.50	2.50	3.50	-	5.1	12.5	13.5	1210	4330	4800	19.7	18.8	18.1
	20 + 20 + 25 + 25 + 50	1.79	1.79	2.23	2.23	4.46	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 20 + 25 + 25 + 60	1.67	1.67	2.08	2.08	5.00	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 25 + 35 + 35	1.85	1.85	2.31	3.24	3.24	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	20 + 20 + 25 + 35 + 50	1.67	1.67	2.08	2.92	4.17	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 25 + 35 + 60	1.56	1.56	1.95	2.73	4.69	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 25 + 50 + 50	1.52	1.52	1.89	3.79	3.79	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 20 + 25 + 50 + 60	1.43	1.43	1.79	3.57	4.29	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 20 + 25 + 60 + 60	1.35	1.35	1.69	4.05	4.05	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 20 + 35 + 35 + 35	1.72	1.72	3.02	3.02	3.02	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 20 + 35 + 35 + 50	1.56	1.56	2.73	2.73	3.91	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 20 + 35 + 35 + 60	1.47	1.47	2.57	2.57	4.41	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 20 + 35 + 50 + 50	1.43	1.43	2.50	3.57	3.57	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 20 + 35 + 50 + 60	1.35	1.35	2.36	3.38	4.05	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 20 + 35 + 60 + 60	1.28	1.28	2.24	3.85	3.85	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	20 + 20 + 50 + 50 + 50	1.32	1.32	3.29	3.29	3.29	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	20 + 25 + 25 + 25 + 25	2.00	2.50	2.50	2.50	2.50	-	5.1	12.0	13.5	1210	3990	4800	18.2	17.4	16.6
	20 + 25 + 25 + 25 + 35	1.92	2.40	2.40	2.40	3.37	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	20 + 25 + 25 + 25 + 50	1.72	2.16	2.16	2.16	4.31	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 25 + 25 + 25 + 60	1.61	2.02	2.02	2.02	4.84	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 25 + 25 + 35 + 35	1.79	2.23	2.23	3.13	3.13	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	20 + 25 + 25 + 35 + 50	1.61	2.02	2.02	2.82	4.03	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 25 + 25 + 35 + 60	1.52	1.89	1.89	2.65	4.55	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 25 + 25 + 50 + 50	1.47	1.84	1.84	3.68	3.68	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 25 + 25 + 50 + 60	1.39	1.74	1.74	3.47	4.17	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 25 + 25 + 60 + 60	1.32	1.64	1.64	3.95	3.95	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	20 + 25 + 35 + 35 + 35	1.67	2.08	2.92	2.92	2.92	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 25 + 35 + 35 + 50	1.52	1.89	2.65	2.65	3.79	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	20 + 25 + 35 + 35 + 60	1.43	1.79	2.50	2.50	4.29	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 25 + 35 + 50 + 50	1.39	1.74	2.43	3.47	3.47	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 25 + 35 + 50 + 60	1.32	1.64	2.30	3.29	3.95	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 25 + 50 + 50 + 50	1.28	1.60	3.21	3.21	3.21	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	20 + 35 + 35 + 35 + 35	1.56	2.73	2.73	2.73	2.73	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	20 + 35 + 35 + 35 + 50	1.43	2.50	2.50	2.50	3.57	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 35 + 35 + 35 + 60	1.35	2.36	2.36	2.36	4.05	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	20 + 35 + 35 + 50 + 50	1.32	2.30	2.30	3.29	3.29	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	25 + 25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	2.50	-	5.1	12.5	13.5	1210	4330	4800	19.7	18.8	18.1
	25 + 25 + 25 + 25 + 35	2.31	2.31	2.31	2.31	3.24	-	5.1	12.5	13.5	1210	4320	4800	19.7	18.8	18.0
	25 + 25 + 25 + 25 + 50	2.08	2.08	2.08	2.08	4.17	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	25 + 25 + 25 + 25 + 60	1.95	1.95	1.95	1.95	4.69	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	25 + 25 + 25 + 35 + 35	2.16	2.16	2.16	3.02	3.02	-	5.1	12.5	13.5	1210	4310	4800	19.6	18.8	18.0
	25 + 25 + 25 + 35 + 50	1.95	1.95	1.95	2.73	3.91	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	25 + 25 + 25 + 35 + 60	1.84	1.84	1.84	2.57	4.41	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	25 + 25 + 25 + 50 + 50	1.79	1.79	1.79	3.57	3.57	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	25 + 25 + 25 + 50 + 60	1.69	1.69	1.69	3.38	4.05	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	25 + 25 + 25 + 60 + 60	1.60	1.60	1.60	3.85	3.85	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	25 + 25 + 35 + 35 + 35	2.02	2.02	2.82	2.82	2.82	-	5.1	12.5	13.5	1210	4300	4800	19.6	18.7	17.9
	25 + 25 + 35 + 35 + 50	1.84	1.84	2.57	2.57	3.68	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	25 + 25 + 35 + 35 + 60	1.74	1.74	2.43	2.43	4.17	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	25 + 25 + 35 + 50 + 50	1.69	1.69	2.36	3.38	3.38	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	25 + 25 + 35 + 50 + 60	1.60	1.60	2.24	3.21	3.85	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	25 + 35 + 35 + 35 + 35	1.89	2.65	2.65	2.65	2.65	-	5.1	12.5	13.5	1210	4290	4800	19.5	18.7	17.9
	25 + 35 + 35 + 35 + 50	1.74	2.43	2.43	2.43	3.47	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	25 + 35 + 35 + 35 + 60	1.64	2.30	2.30	2.30	3.95	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	25 + 35 + 35 + 50 + 50	1.60	2.24	2.24	3.21	3.21	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
	35 + 35 + 35 + 35 + 35	2.50	2.50	2.50	2.50	2.50	-	5.1	12.5	13.5	1210	4280	4800	19.5	18.6	17.9
	35 + 35 + 35 + 35 + 50	2.30	2.30	2.30	2.30	3.29	-	5.1	12.5	13.5	1210	4270	4800	19.4	18.6	17.8
6 units	20 + 20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	2.00	5.5	12.0	13.8	1280	3660	4620	16.7	15.9	15.3
	20 + 20 + 20 + 20 + 20 + 25	2.00	2.00	2.00	2.00	2.00	2.50	5.5	12.5	14.0	1280	3900	4800	17.7	17.0	16.3
	20 + 20 + 20 + 20 + 20 + 35	1.85	1.85	1.85	1.85	1.85	3.24	5.5	12.5	14.0	1280	3890	4800	17.7	16.9	16.2
	20 + 20 + 20 + 20 + 20 + 50	1.67	1.67	1.67	1.67	1.67	4.17	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 20 + 20 + 60	1.56	1.56	1.56	1.56	1.56	4.69	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 20 + 25 + 25	1.92	1.92	1.92	1.92	2.40	2.40	5.5	12.5	14.0	1280	3900	4800	17.7	17.0	16.3
	20 + 20 + 20 + 20 + 25 + 35	1.79	1.79	1.79	1.79	2.23	3.13	5.5	12.5	14.0	1280	3880	4800	17.7	16.9	16.2
	20 + 20 + 20 + 20 + 25 + 50	1.61	1.61	1.61	1.61	2.02	4.03	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 20 + 25 + 60	1.52	1.52	1.52	1.52	1.89	4.55	5.5	12.5	14.0	1280	3850	4800	17.5	16.8	16.1
	20 + 20 + 20 + 20 + 35 + 35	1.67	1.67	1.67	1.67	2.92	2.92	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 20 + 35 + 50	1.52	1.52	1.52	1.52	2.65	3.79	5.5	12.5	14.0	1280	3850	4800	17.5	16.8	16.1
	20 + 20 + 20 + 20 + 35 + 60	1.43	1.43	1.43	1.43	2.50	4.29	5.5	12.5	14.0	1280	3830	4800	17.4	16.7	16.0
	20 + 20 + 20 + 20 + 50 + 50	1.39	1.39	1.39	1.39	3.47	3.47	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 20 + 20 + 20 + 50 + 60	1.32	1.32	1.32	1.32	3.29	3.95	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 20 + 25 + 25 + 25	1.85	1.85	1.85	2.31	2.31	2.31	5.5	12.5	14.0	1280	3890	4800	17.7	16.9	16.2
	20 + 20 + 20 + 25 + 25 + 35	1.72	1.72	1.72	2.16	2.16	3.02	5.5	12.5	14.0	1280	3870	4800	17.6	16.8	16.1
	20 + 20 + 20 + 25 + 25 + 50	1.56	1.56	1.56	1.95	1.95	3.91	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 25 + 25 + 60	1.47	1.47	1.47	1.84	1.84	4.41	5.5	12.5	14.0	1280	3840	4800	17.5	16.7	16.0
	20 + 20 + 20 + 25 + 35 + 35	1.61	1.61	1.61	2.02	2.82	2.82	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 20 + 25 + 35 + 50	1.47	1.47	1.47	1.84	2.57	3.68	5.5	12.5	14.0	1280	3840	4800	17.5	16.7	16.0
	20 + 20 + 20 + 25 + 35 + 60	1.39	1.39	1.39	1.74	2.43	4.17	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 20 + 20 + 25 + 50 + 50	1.35	1.35	1.35	1.69	3.38	3.38	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	20 + 20 + 20 + 25 + 50 + 60	1.28	1.28	1.28	1.60	3.21	3.85	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 20 + 35 + 35 + 35	1.52	1.52	1.52	2.65	2.65	2.65	5.5	12.5	14.0	1280	3850	4800	17.5	16.8	16.1
	20 + 20 + 20 + 35 + 35 + 50	1.39	1.39	1.39	2.43	2.43	3.47	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 20 + 20 + 35 + 35 + 60	1.32	1.32	1.32	2.30	2.30	3.95	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 20 + 35 + 50 + 50	1.28	1.28	1.28	2.24	3.21	3.21	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 25 + 25 + 25 + 25	1.79	1.79	2.23	2.23	2.23	2.23	5.5	12.5	14.0	1280	3880	4800	17.7	16.9	16.2
	20 + 20 + 25 + 25 + 25 + 35	1.67	1.67	2.08	2.08	2.08	2.92	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
6 units	20 + 20 + 25 + 25 + 25 + 50	1.52	1.52	1.89	1.89	1.89	3.79	5.5	12.5	14.0	1280	3850	4800	17.5	16.8	16.1
	20 + 20 + 25 + 25 + 25 + 60	1.43	1.43	1.79	1.79	1.79	4.29	5.5	12.5	14.0	1280	3830	4800	17.4	16.7	16.0
	20 + 20 + 25 + 25 + 35 + 35	1.56	1.56	1.95	1.95	2.73	2.73	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 20 + 25 + 25 + 35 + 50	1.43	1.43	1.79	1.79	2.50	3.57	5.5	12.5	14.0	1280	3830	4800	17.4	16.7	16.0
	20 + 20 + 25 + 25 + 35 + 60	1.35	1.35	1.69	1.69	2.36	4.05	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	20 + 20 + 25 + 25 + 50 + 50	1.32	1.32	1.64	1.64	3.29	3.29	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 25 + 35 + 35 + 35	1.47	1.47	1.84	2.57	2.57	2.57	5.5	12.5	14.0	1280	3840	4800	17.5	16.7	16.0
	20 + 20 + 25 + 35 + 35 + 50	1.35	1.35	1.69	2.36	2.36	3.38	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	20 + 20 + 25 + 35 + 35 + 60	1.28	1.28	1.60	2.24	2.24	3.85	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 20 + 35 + 35 + 35 + 35	1.39	1.39	2.43	2.43	2.43	2.43	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 20 + 35 + 35 + 35 + 50	1.28	1.28	2.24	2.24	2.24	3.21	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 25 + 25 + 25 + 25 + 25	1.72	2.16	2.16	2.16	2.16	2.16	5.5	12.5	14.0	1280	3870	4800	17.6	16.8	16.1
	20 + 25 + 25 + 25 + 25 + 35	1.61	2.02	2.02	2.02	2.02	2.82	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	20 + 25 + 25 + 25 + 25 + 50	1.47	1.84	1.84	1.84	1.84	3.68	5.5	12.5	14.0	1280	3840	4800	17.5	16.7	16.0
	20 + 25 + 25 + 25 + 25 + 60	1.39	1.74	1.74	1.74	1.74	4.17	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 25 + 25 + 25 + 35 + 35	1.52	1.89	1.89	1.89	2.65	2.65	5.5	12.5	14.0	1280	3850	4800	17.5	16.8	16.1
	20 + 25 + 25 + 25 + 35 + 50	1.39	1.74	1.74	1.74	2.43	3.47	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	20 + 25 + 25 + 25 + 35 + 60	1.32	1.64	1.64	1.64	2.30	3.95	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 25 + 25 + 25 + 50 + 50	1.28	1.60	1.60	1.60	3.21	3.21	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 25 + 25 + 35 + 35 + 35	1.43	1.79	1.79	2.50	2.50	2.50	5.5	12.5	14.0	1280	3830	4800	17.4	16.7	16.0
	20 + 25 + 25 + 35 + 35 + 50	1.32	1.64	1.64	2.30	2.30	3.29	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	20 + 25 + 35 + 35 + 35 + 35	1.35	1.69	2.36	2.36	2.36	2.36	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	20 + 35 + 35 + 35 + 35 + 35	1.28	2.24	2.24	2.24	2.24	2.24	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	25 + 25 + 25 + 25 + 25 + 25	2.08	2.08	2.08	2.08	2.08	2.08	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	25 + 25 + 25 + 25 + 25 + 35	1.95	1.95	1.95	1.95	1.95	2.73	5.5	12.5	14.0	1280	3860	4800	17.6	16.8	16.1
	25 + 25 + 25 + 25 + 25 + 50	1.79	1.79	1.79	1.79	1.79	3.57	5.5	12.5	14.0	1280	3830	4800	17.4	16.7	16.0
	25 + 25 + 25 + 25 + 25 + 60	1.69	1.69	1.69	1.69	1.69	4.05	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	25 + 25 + 25 + 25 + 35 + 35	1.84	1.84	1.84	1.84	2.57	2.57	5.5	12.5	14.0	1280	3840	4800	17.5	16.7	16.0
	25 + 25 + 25 + 25 + 35 + 50	1.69	1.69	1.69	1.69	2.36	3.38	5.5	12.5	14.0	1280	3810	4800	17.3	16.6	15.9
	25 + 25 + 25 + 25 + 35 + 60	1.60	1.60	1.60	1.60	2.24	3.85	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	25 + 25 + 25 + 35 + 35 + 35	1.74	1.74	1.74	2.43	2.43	2.43	5.5	12.5	14.0	1280	3820	4800	17.4	16.6	15.9
	25 + 25 + 25 + 35 + 35 + 50	1.60	1.60	1.60	2.24	2.24	3.21	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8
	25 + 25 + 35 + 35 + 35 + 35	1.64	1.64	2.30	2.30	2.30	2.30	5.5	12.5	14.0	1280	3800	4800	17.3	16.5	15.8

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	-	-	1.5	3.0	3.7	700	1010	1330	4.6	4.4	4.3
	25	3.4	-	-	-	-	-	1.5	3.4	4.2	700	1150	1540	5.3	5.1	4.8
	35	4.5	-	-	-	-	-	1.5	4.5	5.0	700	1540	1840	7.1	6.8	6.5
	50	5.8	-	-	-	-	-	1.5	5.8	6.5	700	2000	2410	9.2	8.8	8.4
	60	6.8	-	-	-	-	-	1.5	6.8	7.5	700	2360	2760	10.8	10.4	9.9
2 units	20 + 20	3.00	3.00	-	-	-	-	2.1	6.0	7.4	750	1510	1460	6.9	6.6	6.4
	20 + 25	2.84	3.56	-	-	-	-	2.1	6.4	7.9	750	1630	2210	7.5	7.2	6.9
	20 + 35	2.73	4.77	-	-	-	-	2.1	7.5	8.7	750	1950	2520	9.0	8.6	8.2
	20 + 50	2.51	6.29	-	-	-	-	2.1	8.8	10.2	750	2380	3220	10.9	10.5	10.0
	20 + 60	2.45	7.35	-	-	-	-	2.1	9.8	11.2	750	2780	3620	12.8	12.2	11.7
	25 + 25	3.40	3.40	-	-	-	-	2.1	6.8	8.4	750	1740	2420	8.0	7.6	7.3
	25 + 35	3.29	4.61	-	-	-	-	2.1	7.9	9.2	750	2100	2820	9.6	9.2	8.8
	25 + 50	3.07	6.13	-	-	-	-	2.1	9.2	10.7	750	2580	3610	11.8	11.3	10.9
	25 + 60	3.00	7.20	-	-	-	-	2.1	10.2	11.7	750	2980	3790	13.7	13.1	12.5
	35 + 35	4.50	4.50	-	-	-	-	2.1	9.0	10.0	750	2470	3210	11.3	10.8	10.4
	35 + 50	4.24	6.06	-	-	-	-	2.1	10.3	11.5	750	2980	3710	13.7	13.1	12.5
	35 + 60	4.16	7.14	-	-	-	-	2.1	11.3	12.5	750	3350	4320	15.4	14.7	14.1
	50 + 50	5.80	5.80	-	-	-	-	2.1	11.6	13.0	750	3590	4620	16.5	15.8	15.1
	50 + 60	5.73	6.87	-	-	-	-	2.1	12.6	14.0	750	4010	5230	18.4	17.6	16.9
	60 + 60	6.75	6.75	-	-	-	-	2.1	13.5	14.0	750	4450	5230	20.4	19.5	18.7
3 units	20 + 20 + 20	3.00	3.00	3.00	-	-	-	3.2	9.0	11.1	780	2230	3350	10.2	9.8	9.4
	20 + 20 + 25	2.89	2.89	3.62	-	-	-	3.2	9.4	11.6	780	2350	3550	10.8	10.3	9.9
	20 + 20 + 35	2.80	2.80	4.90	-	-	-	3.2	10.5	12.4	780	2710	3820	12.4	11.9	11.4
	20 + 20 + 50	2.62	2.62	6.56	-	-	-	3.2	11.8	13.9	780	3210	4290	14.7	14.1	13.5
	20 + 20 + 60	2.56	2.56	7.68	-	-	-	3.2	12.8	14.0	780	3620	4350	16.6	15.9	15.2
	20 + 25 + 25	2.80	3.50	3.50	-	-	-	3.2	9.8	12.1	780	2510	3720	11.5	11.0	10.6
	20 + 25 + 35	2.73	3.41	4.77	-	-	-	3.2	10.9	12.9	780	2910	3990	13.4	12.8	12.2
	20 + 25 + 50	2.57	3.21	6.42	-	-	-	3.2	12.2	14.0	780	3410	4350	15.7	15.0	14.4
	20 + 25 + 60	2.51	3.14	7.54	-	-	-	3.2	13.2	14.0	780	3910	4350	18.0	17.2	16.5
	20 + 35 + 35	2.67	4.67	4.67	-	-	-	3.2	12.0	13.7	780	3390	4220	15.6	14.9	14.3
	20 + 35 + 50	2.53	4.43	6.33	-	-	-	3.2	13.3	14.0	780	3900	4350	17.9	17.1	16.4
	20 + 35 + 60	2.35	4.11	7.04	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	20 + 50 + 50	2.25	5.63	5.63	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	20 + 50 + 60	2.08	5.19	6.23	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	20 + 60 + 60	1.93	5.79	5.79	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	25 + 25 + 25	3.40	3.40	3.40	-	-	-	3.2	10.2	12.6	780	2710	3880	12.4	11.9	11.4
	25 + 25 + 35	3.32	3.32	4.65	-	-	-	3.2	11.3	13.4	780	3110	4120	14.3	13.7	13.1
	25 + 25 + 50	3.15	3.15	6.30	-	-	-	3.2	12.6	14.0	780	3620	4350	16.6	15.9	15.2
	25 + 25 + 60	3.07	3.07	7.36	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	25 + 35 + 35	3.26	4.57	4.57	-	-	-	3.2	12.4	14.0	780	3710	4350	17.0	16.3	15.6
	25 + 35 + 50	3.07	4.30	6.14	-	-	-	3.2	13.5	14.0	780	4060	4350	18.6	17.8	17.1
	25 + 35 + 60	2.81	3.94	6.75	-	-	-	3.2	13.5	14.0	780	4060	4350	18.6	17.8	17.1
	25 + 50 + 50	2.70	5.40	5.40	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	25 + 50 + 60	2.50	5.00	6.00	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	25 + 60 + 60	2.33	5.59	5.59	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	35 + 35 + 35	4.50	4.50	4.50	-	-	-	3.2	13.5	14.0	780	4060	4350	18.6	17.8	17.1
	35 + 35 + 50	3.94	3.94	5.63	-	-	-	3.2	13.5	14.0	780	4060	4350	18.6	17.8	17.1
	35 + 35 + 60	3.63	3.63	6.23	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	35 + 50 + 50	3.50	5.00	5.00	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	35 + 50 + 60	3.26	4.66	5.59	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	35 + 60 + 60	3.05	5.23	5.23	-	-	-	3.2	13.5	14.0	780	4050	4350	18.6	17.8	17.0
	50 + 50 + 50	4.50	4.50	4.50	-	-	-	3.2	13.5	14.0	780	4040	4350	18.5	17.7	17.0
	50 + 50 + 60	4.22	4.22	5.06	-	-	-	3.2	13.5	14.0	780	4040	4350	18.5	17.7	17.0
	50 + 60 + 60	3.97	4.76	4.76	-	-	-	3.2	13.5	14.0	780	4040	4350	18.5	17.7	17.0
	60 + 60 + 60	4.50	4.50	4.50	-	-	-	3.2	13.5	14.0	780	4030	4350	18.5	17.7	17.0

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 20 + 20 + 20	3.00	3.00	3.00	3.00	-	-	3.6	12.0	14.0	950	3210	3920	14.6	14.0	13.4
	20 + 20 + 20 + 25	2.92	2.92	2.92	3.65	-	-	3.6	12.4	14.0	950	3390	3920	15.4	14.8	14.1
	20 + 20 + 20 + 35	2.84	2.84	2.84	4.97	-	-	3.6	13.5	14.0	950	3700	3920	16.8	16.1	15.4
	20 + 20 + 20 + 50	2.45	2.45	2.45	6.14	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 20 + 20 + 60	2.25	2.25	2.25	6.75	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 20 + 25 + 25	2.84	2.84	3.56	3.56	-	-	3.6	12.8	14.0	950	3440	3920	15.7	15.0	14.3
	20 + 20 + 25 + 35	2.70	2.70	3.38	4.73	-	-	3.6	13.5	14.0	950	3700	3920	16.8	16.1	15.4
	20 + 20 + 25 + 50	2.35	2.35	2.93	5.87	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 20 + 25 + 60	2.16	2.16	2.70	6.48	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 20 + 35 + 35	2.45	2.45	4.30	4.30	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 20 + 35 + 50	2.16	2.16	3.78	5.40	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 20 + 35 + 60	2.00	2.00	3.50	6.00	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 20 + 50 + 50	1.93	1.93	4.82	4.82	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 20 + 50 + 60	1.80	1.80	4.50	5.40	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 20 + 60 + 60	1.69	1.69	5.06	5.06	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 25 + 25 + 25	2.78	3.47	3.47	3.47	-	-	3.6	13.2	14.0	950	3550	3920	16.2	15.5	14.8
	20 + 25 + 25 + 35	2.57	3.21	3.21	4.50	-	-	3.6	13.5	14.0	950	3700	3920	16.8	16.1	15.4
	20 + 25 + 25 + 50	2.25	2.81	2.81	5.63	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 25 + 25 + 60	2.08	2.60	2.60	6.23	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 25 + 35 + 35	2.35	2.93	4.11	4.11	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	20 + 25 + 35 + 50	2.08	2.60	3.63	5.19	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 25 + 35 + 60	1.93	2.41	3.38	5.79	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 25 + 50 + 50	1.86	2.33	4.66	4.66	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 25 + 50 + 60	1.74	2.18	4.35	5.23	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 25 + 60 + 60	1.64	2.05	4.91	4.91	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	20 + 35 + 35 + 35	2.16	3.78	3.78	3.78	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	20 + 35 + 35 + 50	1.93	3.38	3.38	4.82	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 35 + 35 + 60	1.80	3.15	3.15	5.40	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 35 + 50 + 50	1.74	3.05	4.35	4.35	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	20 + 35 + 50 + 60	1.64	2.86	4.09	4.91	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	20 + 35 + 60 + 60	1.54	2.70	4.63	4.63	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	20 + 50 + 50 + 50	1.59	3.97	3.97	3.97	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	20 + 50 + 50 + 60	1.50	3.75	3.75	4.50	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	20 + 50 + 60 + 60	1.42	3.55	4.26	4.26	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
	25 + 25 + 25 + 25	3.38	3.38	3.38	3.38	-	-	3.6	13.5	14.0	950	3700	3920	16.8	16.1	15.4
	25 + 25 + 25 + 35	3.07	3.07	3.07	4.30	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	25 + 25 + 25 + 50	2.70	2.70	2.70	5.40	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	25 + 25 + 25 + 60	2.50	2.50	2.50	6.00	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	25 + 25 + 35 + 35	2.81	2.81	3.94	3.94	-	-	3.6	13.5	14.0	950	3690	3920	16.8	16.1	15.4
	25 + 25 + 35 + 50	2.50	2.50	3.50	5.00	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	25 + 25 + 35 + 60	2.33	2.33	3.26	5.59	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 25 + 50 + 50	2.25	2.25	4.50	4.50	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 25 + 50 + 60	2.11	2.11	4.22	5.06	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 25 + 60 + 60	1.99	1.99	4.76	4.76	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	25 + 35 + 35 + 35	2.60	3.63	3.63	3.63	-	-	3.6	13.5	14.0	950	3680	3920	16.7	16.0	15.3
	25 + 35 + 35 + 50	2.33	3.26	3.26	4.66	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 35 + 35 + 60	2.18	3.05	3.05	5.23	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 35 + 50 + 50	2.11	2.95	4.22	4.22	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	25 + 35 + 50 + 60	1.99	2.78	3.97	4.76	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	25 + 35 + 60 + 60	1.88	2.63	4.50	4.50	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	25 + 50 + 50 + 50	1.93	3.86	3.86	3.86	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	25 + 50 + 50 + 60	1.82	3.65	3.65	4.38	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
	25 + 50 + 60 + 60	1.73	3.46	4.15	4.15	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
	35 + 35 + 35 + 35	3.38	3.38	3.38	3.38	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3
	35 + 35 + 35 + 50	3.05	3.05	3.05	4.35	-	-	3.6	13.5	14.0	950	3670	3920	16.7	16.0	15.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	35 + 35 + 35 + 60	2.86	2.86	2.86	4.91	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	35 + 35 + 50 + 50	2.78	2.78	3.97	3.97	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	35 + 35 + 50 + 60	2.63	2.63	3.75	4.50	-	-	3.6	13.5	14.0	950	3660	3920	16.7	15.9	15.3
	35 + 35 + 60 + 60	2.49	2.49	4.26	4.26	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
	35 + 50 + 50 + 50	2.55	3.65	3.65	3.65	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
	35 + 50 + 50 + 60	2.42	3.46	3.46	4.15	-	-	3.6	13.5	14.0	950	3650	3920	16.6	15.9	15.2
5 units	20 + 20 + 20 + 20 + 20	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	14.0	1050	3380	3470	15.4	14.7	14.1
	20 + 20 + 20 + 20 + 25	2.57	2.57	2.57	2.57	3.21	-	4.0	13.5	14.0	1050	3380	3470	15.4	14.7	14.1
	20 + 20 + 20 + 20 + 35	2.35	2.35	2.35	2.35	4.11	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	20 + 20 + 20 + 20 + 50	2.08	2.08	2.08	2.08	5.19	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 20 + 20 + 60	1.93	1.93	1.93	1.93	5.79	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 20 + 25 + 25	2.45	2.45	2.45	3.07	3.07	-	4.0	13.5	14.0	1050	3380	3470	15.4	14.7	14.1
	20 + 20 + 20 + 25 + 35	2.25	2.25	2.25	2.81	3.94	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	20 + 20 + 20 + 25 + 50	2.00	2.00	2.00	2.50	5.00	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 20 + 25 + 60	1.86	1.86	1.86	2.33	5.59	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 20 + 35 + 35	2.08	2.08	2.08	3.63	3.63	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 20 + 35 + 50	1.86	1.86	1.86	3.26	4.66	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 20 + 35 + 60	1.74	1.74	1.74	3.05	5.23	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 20 + 50 + 50	1.69	1.69	1.69	4.22	4.22	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 20 + 50 + 60	1.59	1.59	1.59	3.97	4.76	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 20 + 60 + 60	1.50	1.50	1.50	4.50	4.50	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 20 + 25 + 25 + 25	2.35	2.35	2.93	2.93	2.93	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	20 + 20 + 25 + 25 + 35	2.16	2.16	2.70	2.70	3.78	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	20 + 20 + 25 + 25 + 50	1.93	1.93	2.41	2.41	4.82	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 25 + 25 + 60	1.80	1.80	2.25	2.25	5.40	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 25 + 35 + 35	2.00	2.00	2.50	3.50	3.50	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 20 + 25 + 35 + 50	1.80	1.80	2.25	3.15	4.50	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 25 + 35 + 60	1.69	1.69	2.11	2.95	5.06	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 25 + 50 + 50	1.64	1.64	2.05	4.09	4.09	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 25 + 50 + 60	1.54	1.54	1.93	3.86	4.63	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 25 + 60 + 60	1.46	1.46	1.82	4.38	4.38	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 20 + 35 + 35 + 35	1.86	1.86	3.26	3.26	3.26	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 20 + 35 + 35 + 50	1.69	1.69	2.95	2.95	4.22	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 35 + 35 + 60	1.59	1.59	2.78	2.78	4.76	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 35 + 50 + 50	1.54	1.54	2.70	3.86	3.86	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 20 + 35 + 50 + 60	1.46	1.46	2.55	3.65	4.38	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 20 + 35 + 60 + 60	1.38	1.38	2.42	4.15	4.15	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	20 + 20 + 50 + 50 + 50	1.42	1.42	3.55	3.55	3.55	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25	2.25	2.81	2.81	2.81	2.81	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	20 + 25 + 25 + 25 + 35	2.08	2.60	2.60	2.60	3.63	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 25 + 25 + 25 + 50	1.86	2.33	2.33	2.33	4.66	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 25 + 25 + 25 + 60	1.74	2.18	2.18	2.18	5.23	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 25 + 25 + 35 + 35	1.93	2.41	2.41	3.38	3.38	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	20 + 25 + 25 + 35 + 50	1.74	2.18	2.18	3.05	4.35	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 25 + 25 + 35 + 60	1.64	2.05	2.05	2.86	4.91	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 25 + 25 + 50 + 50	1.59	1.99	1.99	3.97	3.97	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 25 + 25 + 50 + 60	1.50	1.88	1.88	3.75	4.50	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 25 + 25 + 60 + 60	1.42	1.78	1.78	4.26	4.26	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	20 + 25 + 35 + 35 + 35	1.80	2.25	3.15	3.15	3.15	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	20 + 25 + 35 + 35 + 50	1.64	2.05	2.86	2.86	4.09	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 25 + 35 + 35 + 60	1.54	1.93	2.70	2.70	4.63	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 25 + 35 + 50 + 50	1.50	1.88	2.63	3.75	3.75	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 25 + 35 + 50 + 60	1.42	1.78	2.49	3.55	4.26	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	20 + 25 + 50 + 50 + 50	1.38	1.73	3.46	3.46	3.46	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	20 + 35 + 35 + 35 + 35	1.69	2.95	2.95	2.95	2.95	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 35 + 35 + 35 + 50	1.54	2.70	2.70	2.70	3.86	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	20 + 35 + 35 + 35 + 60	1.46	2.55	2.55	2.55	4.38	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	20 + 35 + 35 + 50 + 50	1.42	2.49	2.49	3.55	3.55	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 25	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	14.0	1050	3370	3470	15.3	14.7	14.1
	25 + 25 + 25 + 25 + 35	2.50	2.50	2.50	2.50	3.50	-	4.0	13.5	14.0	1050	3360	3470	15.3	14.6	14.0
	25 + 25 + 25 + 25 + 50	2.25	2.25	2.25	2.25	4.50	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	25 + 25 + 25 + 25 + 60	2.11	2.11	2.11	2.11	5.06	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 25 + 25 + 35 + 35	2.33	2.33	2.33	3.26	3.26	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	25 + 25 + 25 + 35 + 50	2.11	2.11	2.11	2.95	4.22	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 25 + 25 + 35 + 60	1.99	1.99	1.99	2.78	4.76	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 25 + 25 + 50 + 50	1.93	1.93	1.93	3.86	3.86	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 25 + 25 + 50 + 60	1.82	1.82	1.82	3.65	4.38	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	25 + 25 + 25 + 60 + 60	1.73	1.73	1.73	4.15	4.15	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	25 + 25 + 35 + 35 + 35	2.18	2.18	3.05	3.05	3.05	-	4.0	13.5	14.0	1050	3350	3470	15.2	14.6	14.0
	25 + 25 + 35 + 35 + 50	1.99	1.99	2.78	2.78	3.97	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 25 + 35 + 35 + 60	1.88	1.88	2.63	2.63	4.50	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	25 + 25 + 35 + 50 + 50	1.82	1.82	2.55	3.65	3.65	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	25 + 25 + 35 + 50 + 60	1.73	1.73	2.42	3.46	4.15	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	25 + 35 + 35 + 35 + 35	2.05	2.86	2.86	2.86	2.86	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	25 + 35 + 35 + 35 + 50	1.88	2.63	2.63	2.63	3.75	-	4.0	13.5	14.0	1050	3330	3470	15.2	14.5	13.9
	25 + 35 + 35 + 35 + 60	1.78	2.49	2.49	2.49	4.26	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	25 + 35 + 35 + 50 + 50	1.73	2.42	2.42	3.46	3.46	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
	35 + 35 + 35 + 35 + 35	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	14.0	1050	3340	3470	15.2	14.5	13.9
	35 + 35 + 35 + 35 + 50	2.49	2.49	2.49	2.49	3.55	-	4.0	13.5	14.0	1050	3320	3470	15.1	14.4	13.8
6 units	20 + 20 + 20 + 20 + 20 + 20	2.25	2.25	2.25	2.25	2.25	2.25	4.5	13.5	14.0	1150	3260	3420	14.8	14.2	13.6
	20 + 20 + 20 + 20 + 20 + 25	2.16	2.16	2.16	2.16	2.16	2.70	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 20 + 35	2.00	2.00	2.00	2.00	2.00	3.50	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 20 + 50	1.80	1.80	1.80	1.80	1.80	4.50	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 20 + 60	1.69	1.69	1.69	1.69	1.69	5.06	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 25 + 25	2.08	2.08	2.08	2.08	2.60	2.60	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 25 + 35	1.93	1.93	1.93	1.93	2.41	3.38	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 25 + 50	1.74	1.74	1.74	1.74	2.18	4.35	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 25 + 60	1.64	1.64	1.64	1.64	2.05	4.91	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 35 + 35	1.80	1.80	1.80	1.80	3.15	3.15	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 20 + 35 + 50	1.64	1.64	1.64	1.64	2.86	4.09	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 35 + 60	1.54	1.54	1.54	1.54	2.70	4.63	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 50 + 50	1.50	1.50	1.50	1.50	3.75	3.75	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 20 + 50 + 60	1.42	1.42	1.42	1.42	3.55	4.26	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 25 + 25	2.00	2.00	2.00	2.50	2.50	2.50	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 25 + 25 + 35	1.86	1.86	1.86	2.33	2.33	3.26	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 20 + 25 + 25 + 50	1.69	1.69	1.69	2.11	2.11	4.22	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 25 + 60	1.59	1.59	1.59	1.99	1.99	4.76	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 35 + 35	1.74	1.74	1.74	2.18	3.05	3.05	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 35 + 50	1.59	1.59	1.59	1.99	2.78	3.97	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 35 + 60	1.50	1.50	1.50	1.88	2.63	4.50	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 50 + 50	1.46	1.46	1.46	1.82	3.65	3.65	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 25 + 50 + 60	1.38	1.38	1.38	1.73	3.46	4.15	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	20 + 20 + 20 + 35 + 35 + 35	1.64	1.64	1.64	2.86	2.86	2.86	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 20 + 35 + 35 + 50	1.50	1.50	1.50	2.63	2.63	3.75	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 35 + 35 + 60	1.42	1.42	1.42	2.49	2.49	4.26	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 20 + 35 + 50 + 50	1.38	1.38	1.38	2.42	3.46	3.46	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	20 + 20 + 25 + 25 + 25 + 25	1.93	1.93	2.41	2.41	2.41	2.41	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 25 + 25 + 25 + 35	1.80	1.80	2.25	2.25	2.25	3.15	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 20 + 25 + 25 + 25 + 50	1.64	1.64	2.05	2.05	2.05	4.09	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 25 + 25 + 25 + 60	1.54	1.54	1.93	1.93	1.93	4.63	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5

&lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
6 units	20 + 20 + 25 + 25 + 35 + 35	1.69	1.69	2.11	2.11	2.95	2.95	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 25 + 25 + 35 + 50	1.54	1.54	1.93	1.93	2.70	3.86	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 25 + 25 + 35 + 60	1.46	1.46	1.82	1.82	2.55	4.38	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 25 + 25 + 50 + 50	1.42	1.42	1.78	1.78	3.55	3.55	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 25 + 35 + 35 + 35	1.59	1.59	1.99	2.78	2.78	2.78	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 20 + 25 + 35 + 35 + 50	1.46	1.46	1.82	2.55	2.55	3.65	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 25 + 35 + 35 + 60	1.38	1.38	1.73	2.42	2.42	4.15	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	20 + 20 + 35 + 35 + 35 + 35	1.50	1.50	2.63	2.63	2.63	2.63	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 20 + 35 + 35 + 35 + 50	1.38	1.38	2.42	2.42	2.42	3.46	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	20 + 25 + 25 + 25 + 25 + 25	1.86	2.33	2.33	2.33	2.33	2.33	4.5	13.5	14.0	1150	3250	3420	14.8	14.1	13.6
	20 + 25 + 25 + 25 + 25 + 35	1.74	2.18	2.18	2.18	2.18	3.05	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 25 + 50	1.59	1.99	1.99	1.99	1.99	3.97	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 25 + 60	1.50	1.88	1.88	1.88	1.88	4.50	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 35 + 35	1.64	2.05	2.05	2.05	2.86	2.86	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 35 + 50	1.50	1.88	1.88	1.88	2.63	3.75	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 35 + 60	1.42	1.78	1.78	1.78	2.49	4.26	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 25 + 25 + 25 + 50 + 50	1.38	1.73	1.73	1.73	3.46	3.46	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	20 + 25 + 25 + 35 + 35 + 35	1.54	1.93	1.93	2.70	2.70	2.70	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 25 + 25 + 35 + 35 + 50	1.42	1.78	1.78	2.49	2.49	3.55	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 25 + 35 + 35 + 35 + 35	1.46	1.82	2.55	2.55	2.55	2.55	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	20 + 35 + 35 + 35 + 35 + 35	1.38	2.42	2.42	2.42	2.42	2.42	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	25 + 25 + 25 + 25 + 25 + 25	2.25	2.25	2.25	2.25	2.25	2.25	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 25 + 35	2.11	2.11	2.11	2.11	2.11	2.95	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 25 + 50	1.93	1.93	1.93	1.93	1.93	3.86	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 25 + 60	1.82	1.82	1.82	1.82	1.82	4.38	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 35 + 35	1.99	1.99	1.99	1.99	2.78	2.78	4.5	13.5	14.0	1150	3240	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 35 + 50	1.82	1.82	1.82	1.82	2.55	3.65	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	25 + 25 + 25 + 25 + 35 + 60	1.73	1.73	1.73	1.73	2.42	4.15	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	25 + 25 + 25 + 35 + 35 + 35	1.88	1.88	1.88	2.63	2.63	2.63	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5
	25 + 25 + 25 + 35 + 35 + 50	1.73	1.73	1.73	2.42	2.42	3.46	4.5	13.5	14.0	1150	3220	3420	14.7	14.0	13.4
	25 + 25 + 35 + 35 + 35 + 35	1.78	1.78	2.49	2.49	2.49	2.49	4.5	13.5	14.0	1150	3230	3420	14.7	14.1	13.5

ESP-PR-1108

**(b) Indoor unit except SRK\*\*ZMX-S models only**

&lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	2.0	-	-	-	-	-	1.8	2.0	2.7	650	780	1100	3.6	3.4	3.3
	25	2.5	-	-	-	-	-	1.8	2.5	3.2	650	1000	1350	4.6	4.4	4.2
	35	3.5	-	-	-	-	-	1.8	3.5	3.7	650	1500	1600	6.9	6.6	6.3
	50	5.0	-	-	-	-	-	1.8	5.0	5.8	650	2150	2500	9.9	9.4	9.0
	60	6.0	-	-	-	-	-	1.8	6.0	6.7	650	2720	3000	12.5	11.9	11.4
	71	7.1	-	-	-	-	-	1.8	7.1	7.2	650	3250	3080	14.9	14.3	13.7
2 units	20 + 20	2.00	2.00	-	-	-	-	3.0	4.0	5.4	740	960	1460	4.4	4.2	4.0
	20 + 25	2.00	2.50	-	-	-	-	3.0	4.5	5.9	740	1100	1820	5.1	4.8	4.6
	20 + 35	2.00	3.50	-	-	-	-	3.0	5.5	6.4	740	1500	2020	6.9	6.6	6.3
	20 + 50	2.00	5.00	-	-	-	-	3.0	7.0	8.5	740	2290	2820	10.5	10.1	9.6
	20 + 60	2.00	6.00	-	-	-	-	3.0	8.0	9.4	740	2660	3360	12.2	11.7	11.2
	20 + 71	2.00	7.10	-	-	-	-	3.0	9.1	9.9	740	3100	3780	14.1	13.5	12.9
	25 + 25	2.50	2.50	-	-	-	-	3.0	5.0	6.8	740	1420	2200	6.5	6.2	6.0
	25 + 35	2.50	3.50	-	-	-	-	3.0	6.0	6.9	740	1810	2320	8.3	7.9	7.6
	25 + 50	2.50	5.00	-	-	-	-	3.0	7.5	9.0	740	2470	3220	11.3	10.8	10.4
	25 + 60	2.50	6.00	-	-	-	-	3.0	8.5	9.4	740	2810	3360	12.9	12.3	11.8
	25 + 71	2.53	7.17	-	-	-	-	3.0	9.7	10.4	740	3350	4020	15.4	14.7	14.1
	35 + 35	3.50	3.50	-	-	-	-	3.0	7.0	7.4	740	2290	2820	10.5	10.1	9.6
	35 + 50	3.50	5.00	-	-	-	-	3.0	8.5	9.5	740	2810	3620	12.9	12.3	11.8
	35 + 60	3.50	6.00	-	-	-	-	3.0	9.5	10.4	740	3280	3990	15.1	14.4	13.8
	35 + 71	3.50	7.10	-	-	-	-	3.0	10.6	10.9	740	3760	4250	17.1	16.3	15.7
	50 + 50	5.00	5.00	-	-	-	-	3.0	10.0	10.8	740	3520	4050	16.2	15.5	14.8
	50 + 60	5.00	6.00	-	-	-	-	3.0	11.0	12.0	740	3870	4410	17.8	17.0	16.3
	50 + 71	4.96	7.04	-	-	-	-	3.0	12.0	12.0	740	4410	4410	20.0	19.2	18.4
	60 + 60	6.00	6.00	-	-	-	-	3.0	12.0	12.0	740	4410	4410	20.2	19.4	18.6
	60 + 71	5.73	6.77	-	-	-	-	3.0	12.5	12.5	740	4710	4710	21.4	20.5	19.6
	71 + 71	6.25	6.25	-	-	-	-	3.0	12.5	12.5	740	4710	4710	21.2	20.3	19.4
3 units	20 + 20 + 20	2.00	2.00	2.00	-	-	-	3.7	6.0	8.1	880	1530	2560	7.0	6.7	6.4
	20 + 20 + 25	2.00	2.00	2.50	-	-	-	3.7	6.5	8.6	880	1730	2700	7.9	7.6	7.3
	20 + 20 + 35	2.00	2.00	3.50	-	-	-	3.7	7.5	9.1	880	2080	3120	9.6	9.1	8.8
	20 + 20 + 50	2.00	2.00	5.00	-	-	-	3.7	9.0	11.2	880	2730	4120	12.5	12.0	11.5
	20 + 20 + 60	2.00	2.00	6.00	-	-	-	3.7	10.0	12.1	880	3280	4680	15.1	14.4	13.8
	20 + 20 + 71	2.00	2.00	7.10	-	-	-	3.7	11.1	12.6	880	3930	4710	18.0	17.3	16.5
	20 + 25 + 25	2.00	2.50	2.50	-	-	-	3.7	7.0	9.1	880	1940	3210	8.9	8.5	8.2
	20 + 25 + 35	2.00	2.50	3.50	-	-	-	3.7	8.0	9.6	880	2440	3450	11.2	10.7	10.3
	20 + 25 + 50	2.00	2.50	5.00	-	-	-	3.7	9.5	11.7	880	3130	4480	14.4	13.7	13.2
	20 + 25 + 60	2.00	2.50	6.00	-	-	-	3.7	10.5	12.6	880	3770	4800	17.3	16.6	15.9
	20 + 25 + 71	2.00	2.50	7.10	-	-	-	3.7	11.6	12.6	880	4210	4800	19.1	18.3	17.5
	20 + 35 + 35	2.00	3.50	3.50	-	-	-	3.7	9.0	10.1	880	2920	3850	13.4	12.8	12.3
	20 + 35 + 50	2.00	3.50	5.00	-	-	-	3.7	10.5	12.0	880	3770	4450	17.3	16.6	15.9
	20 + 35 + 60	2.00	3.50	6.00	-	-	-	3.7	11.5	12.6	880	4150	4800	19.1	18.2	17.5
	20 + 35 + 71	1.98	3.47	7.04	-	-	-	4.7	12.5	12.6	880	4670	4800	21.2	20.3	19.5
	20 + 50 + 50	2.00	5.00	5.00	-	-	-	3.7	12.0	12.6	880	4440	4800	20.4	19.5	18.7
	20 + 50 + 60	1.92	4.81	5.77	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	20 + 50 + 71	1.77	4.43	6.29	-	-	-	3.7	12.5	12.6	881	4670	4800	21.4	20.5	19.7
	20 + 60 + 60	1.79	5.36	5.36	-	-	-	3.7	12.5	12.6	881	4670	4800	21.4	20.5	19.7
	20 + 60 + 71	1.66	4.97	5.88	-	-	-	3.7	12.5	12.6	881	4670	4800	21.4	20.5	19.7
	20 + 71 + 71	1.54	5.48	5.48	-	-	-	3.7	12.5	12.6	881	4660	4800	21.4	20.5	19.6
	25 + 25 + 25	2.50	2.50	2.50	-	-	-	3.7	7.5	9.6	880	2130	3640	9.8	9.4	9.0
	25 + 25 + 35	2.50	2.50	3.50	-	-	-	3.7	8.5	10.1	880	2650	3900	12.2	11.6	11.2
	25 + 25 + 50	2.50	2.50	5.00	-	-	-	3.7	10.0	12.6	880	3420	4800	15.7	15.0	14.4
	25 + 25 + 60	2.50	2.50	6.00	-	-	-	3.7	11.0	12.6	880	3910	4800	18.0	17.2	16.5
	25 + 25 + 71	2.58	2.58	7.33	-	-	-	3.7	12.5	12.6	880	4670	4800	21.2	20.3	19.5
	25 + 35 + 35	2.50	3.50	3.50	-	-	-	3.7	9.5	10.4	880	3130	3910	14.4	13.7	13.2
	25 + 35 + 50	2.50	3.50	5.00	-	-	-	3.7	11.0	12.6	880	3910	4800	18.0	17.2	16.5

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
3 units	25 + 35 + 60	2.50	3.50	6.00	-	-	-	3.7	12.0	12.6	880	4440	4800	20.4	19.5	18.7
	25 + 35 + 71	2.39	3.34	6.77	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 50 + 50	2.50	5.00	5.00	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 50 + 60	2.31	4.63	5.56	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 50 + 71	2.14	4.28	6.08	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 60 + 60	2.16	5.17	5.17	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 60 + 71	2.00	4.81	5.69	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	25 + 71 + 71	1.87	5.31	5.31	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	35 + 35 + 35	3.50	3.50	3.50	-	-	-	3.7	10.5	10.9	880	3770	4180	17.3	16.6	15.9
	35 + 35 + 50	3.50	3.50	5.00	-	-	-	3.7	12.0	12.6	880	4440	4800	20.4	19.5	18.7
	35 + 35 + 60	3.37	3.37	5.77	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	35 + 35 + 71	3.10	3.10	6.29	-	-	-	3.7	12.5	12.6	880	4660	4800	21.2	20.3	19.4
	35 + 50 + 50	3.24	4.63	4.63	-	-	-	3.7	12.5	12.6	880	4670	4800	21.4	20.5	19.7
	35 + 50 + 60	3.02	4.31	5.17	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	35 + 50 + 71	2.80	4.01	5.69	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	35 + 60 + 60	2.82	4.84	4.84	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	35 + 60 + 71	2.64	4.52	5.35	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	35 + 71 + 71	2.47	5.01	5.01	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
	50 + 50 + 50	4.17	4.17	4.17	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	50 + 50 + 60	3.91	3.91	4.69	-	-	-	3.7	12.5	12.6	880	4660	4800	21.4	20.5	19.6
	50 + 50 + 71	3.65	3.65	5.19	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
	50 + 60 + 60	3.68	4.41	4.41	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
	50 + 60 + 71	3.45	4.14	4.90	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
	60 + 60 + 60	4.17	4.17	4.17	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
	60 + 60 + 71	3.93	3.93	4.65	-	-	-	3.7	12.5	12.6	880	4650	4800	21.3	20.4	19.6
4 units	20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	-	-	4.4	8.0	10.8	1100	2110	3680	9.6	9.2	8.8
	20 + 20 + 20 + 25	2.00	2.00	2.00	2.50	-	-	4.4	8.5	11.3	1100	2390	3890	10.9	10.4	10.0
	20 + 20 + 20 + 35	2.00	2.00	2.00	3.50	-	-	4.4	9.5	11.8	1100	2900	4350	13.2	12.6	12.1
	20 + 20 + 20 + 50	2.00	2.00	2.00	5.00	-	-	4.4	11.0	12.8	1100	3580	4800	16.3	15.6	14.9
	20 + 20 + 20 + 60	2.00	2.00	2.00	6.00	-	-	4.4	12.0	12.8	1100	4100	4800	18.7	17.8	17.1
	20 + 20 + 20 + 71	1.91	1.91	1.91	6.77	-	-	4.4	12.5	12.8	1100	4730	4800	21.3	20.4	19.5
	20 + 20 + 25 + 25	2.00	2.00	2.50	2.50	-	-	4.4	9.0	11.8	1100	2600	4410	11.8	11.3	10.8
	20 + 20 + 25 + 35	2.00	2.00	2.50	3.50	-	-	4.4	10.0	12.3	1100	3210	4780	14.6	14.0	13.4
	20 + 20 + 25 + 50	2.00	2.00	2.50	5.00	-	-	4.4	11.5	12.8	1100	3830	4800	17.4	16.7	16.0
	20 + 20 + 25 + 60	2.00	2.00	2.50	6.00	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	20 + 20 + 25 + 71	1.84	1.84	2.30	6.53	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 20 + 35 + 35	2.00	2.00	3.50	3.50	-	-	4.4	11.0	12.8	1100	3580	4800	16.3	15.6	14.9
	20 + 20 + 35 + 50	2.00	2.00	3.50	5.00	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	20 + 20 + 35 + 60	1.85	1.85	3.24	5.56	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 20 + 35 + 71	1.71	1.71	3.00	6.08	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 20 + 50 + 50	1.79	1.79	4.46	4.46	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 20 + 50 + 60	1.67	1.67	4.17	5.00	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 20 + 50 + 71	1.55	1.55	3.88	5.51	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 20 + 60 + 60	1.56	1.56	4.69	4.69	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 20 + 60 + 71	1.46	1.46	4.39	5.19	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 20 + 71 + 71	1.37	1.37	4.88	4.88	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	20 + 25 + 25 + 25	2.00	2.50	2.50	2.50	-	-	4.4	9.5	12.8	1100	2900	4800	13.2	12.6	12.1
	20 + 25 + 25 + 35	2.00	2.50	2.50	3.50	-	-	4.4	10.5	12.8	1100	3440	4800	15.7	15.0	14.3
	20 + 25 + 25 + 50	2.00	2.50	2.50	5.00	-	-	4.4	12.0	12.8	1100	4100	4800	18.7	17.8	17.1
	20 + 25 + 25 + 60	1.92	2.40	2.40	5.77	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	21 + 26 + 26 + 71	1.82	2.26	2.26	6.16	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 25 + 35 + 35	2.00	2.50	3.50	3.50	-	-	4.4	11.5	12.8	1100	3830	4800	17.4	16.7	16.0
	20 + 25 + 35 + 50	1.92	2.40	3.37	4.81	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	20 + 25 + 35 + 60	1.79	2.23	3.13	5.36	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 25 + 35 + 71	1.66	2.07	2.90	5.88	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 25 + 50 + 50	1.72	2.16	4.31	4.31	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 25 + 50 + 60	1.61	2.02	4.03	4.84	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 25 + 50 + 71	1.51	1.88	3.77	5.35	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 25 + 60 + 60	1.52	1.89	4.55	4.55	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 25 + 60 + 71	1.42	1.78	4.26	5.04	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 25 + 71 + 71	1.34	1.67	4.75	4.75	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	20 + 35 + 35 + 35	2.00	3.50	3.50	3.50	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	20 + 35 + 35 + 50	1.79	3.13	3.13	4.46	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 35 + 35 + 60	1.67	2.92	2.92	5.00	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	20 + 35 + 35 + 71	1.55	2.72	2.72	5.51	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 35 + 50 + 50	1.61	2.82	4.03	4.03	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 35 + 50 + 60	1.52	2.65	3.79	4.55	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 35 + 50 + 71	1.42	2.49	3.55	5.04	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 35 + 60 + 60	1.43	2.50	4.29	4.29	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	20 + 35 + 60 + 71	1.34	2.35	4.03	4.77	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	20 + 50 + 50 + 50	1.47	3.68	3.68	3.68	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	20 + 50 + 50 + 60	1.39	3.47	3.47	4.17	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	20 + 50 + 50 + 71	1.31	3.27	3.27	4.65	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	20 + 50 + 60 + 60	1.32	3.29	3.95	3.95	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	-	-	4.4	10.0	12.8	1100	3210	4800	14.6	14.0	13.4
	25 + 25 + 25 + 35	2.50	2.50	2.50	3.50	-	-	4.4	11.0	12.8	1100	3580	4800	16.3	15.6	14.9
	25 + 25 + 25 + 50	2.50	2.50	2.50	5.00	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	25 + 25 + 25 + 60	2.31	2.31	2.31	5.56	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 25 + 25 + 71	2.14	2.14	2.14	6.08	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 25 + 35 + 35	2.50	2.50	3.50	3.50	-	-	4.4	12.0	12.8	1100	4100	4800	18.7	17.8	17.1
	25 + 25 + 35 + 50	2.31	2.31	3.24	4.63	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 25 + 35 + 60	2.16	2.16	3.02	5.17	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 25 + 35 + 71	2.00	2.00	2.80	5.69	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 25 + 50 + 50	2.08	2.08	4.17	4.17	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 25 + 50 + 60	1.95	1.95	3.91	4.69	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 25 + 50 + 71	1.83	1.83	3.65	5.19	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 25 + 60 + 60	1.84	1.84	4.41	4.41	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 25 + 60 + 71	1.73	1.73	4.14	4.90	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	25 + 25 + 71 + 71	1.63	1.63	4.62	4.62	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	25 + 35 + 35 + 35	2.40	3.37	3.37	3.37	-	-	4.4	12.5	12.8	1100	4740	4800	21.6	20.6	19.8
	25 + 35 + 35 + 50	2.16	3.02	3.02	4.31	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	25 + 35 + 35 + 60	2.02	2.82	2.82	4.84	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 35 + 35 + 71	1.88	2.64	2.64	5.35	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 35 + 50 + 50	1.95	2.73	3.91	3.91	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 35 + 50 + 60	1.84	2.57	3.68	4.41	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	25 + 35 + 50 + 71	1.73	2.42	3.45	4.90	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	25 + 35 + 60 + 60	1.74	2.43	4.17	4.17	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	25 + 35 + 60 + 71	1.64	2.29	3.93	4.65	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	25 + 50 + 50 + 50	1.79	3.57	3.57	3.57	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	25 + 50 + 50 + 60	1.69	3.38	3.38	4.05	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	25 + 50 + 60 + 60	1.60	3.21	3.85	3.85	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	35 + 35 + 35 + 35	3.13	3.13	3.13	3.13	-	-	4.4	12.5	12.8	1100	4730	4800	21.5	20.6	19.7
	35 + 35 + 35 + 50	2.82	2.82	2.82	4.03	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	35 + 35 + 35 + 60	2.65	2.65	2.65	4.55	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	35 + 35 + 35 + 71	2.49	2.49	2.49	5.04	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	35 + 35 + 50 + 50	2.57	2.57	3.68	3.68	-	-	4.4	12.5	12.8	1100	4720	4800	21.5	20.5	19.7
	35 + 35 + 50 + 60	2.43	2.43	3.47	4.17	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	35 + 35 + 50 + 71	2.29	2.29	3.27	4.65	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	35 + 35 + 60 + 60	2.30	2.30	3.95	3.95	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6
	35 + 50 + 50 + 50	2.36	3.38	3.38	3.38	-	-	4.4	12.5	12.8	1100	4710	4800	21.4	20.5	19.6
	35 + 50 + 50 + 60	2.24	3.21	3.21	3.85	-	-	4.4	12.5	12.8	1100	4700	4800	21.4	20.5	19.6

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	-	5.1	10.0	13.3	1210	2950	4800	13.4	12.8	12.3
	20 + 20 + 20 + 20 + 25	2.00	2.00	2.00	2.00	2.50	-	5.1	10.5	13.3	1210	3200	4800	14.6	13.9	13.3
	20 + 20 + 20 + 20 + 35	2.00	2.00	2.00	2.00	3.50	-	5.1	11.5	13.3	1210	3710	4800	16.9	16.1	15.5
	20 + 20 + 20 + 20 + 50	1.92	1.92	1.92	1.92	4.81	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	20 + 20 + 20 + 20 + 60	1.79	1.79	1.79	1.79	5.36	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 20 + 20 + 20 + 71	1.66	1.66	1.66	1.66	5.88	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 20 + 25 + 25	2.00	2.00	2.00	2.50	2.50	-	5.1	11.0	13.3	1210	3400	4800	15.5	14.8	14.2
	20 + 20 + 20 + 25 + 35	2.00	2.00	2.00	2.50	3.50	-	5.1	12.0	13.3	1210	4090	4800	18.6	17.8	17.1
	20 + 20 + 20 + 25 + 50	1.85	1.85	1.85	2.31	4.63	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	20 + 20 + 20 + 25 + 60	1.72	1.72	1.72	2.16	5.17	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 20 + 20 + 25 + 71	1.60	1.60	1.60	2.00	5.69	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 20 + 35 + 35	1.92	1.92	1.92	3.37	3.37	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	20 + 20 + 20 + 35 + 50	1.72	1.72	1.72	3.02	4.31	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 20 + 20 + 35 + 60	1.61	1.61	1.61	2.82	4.84	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 20 + 35 + 71	1.51	1.51	1.51	2.64	5.35	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 20 + 20 + 50 + 50	1.56	1.56	1.56	3.91	3.91	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 20 + 50 + 60	1.47	1.47	1.47	3.68	4.41	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 20 + 20 + 50 + 71	1.38	1.38	1.38	3.45	4.90	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 20 + 60 + 60	1.39	1.39	1.39	4.17	4.17	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 20 + 60 + 71	1.31	1.31	1.31	3.93	4.65	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 20 + 25 + 25 + 25	2.00	2.00	2.50	2.50	2.50	-	5.1	11.5	13.3	1210	3710	4800	16.9	16.1	15.5
	20 + 20 + 25 + 25 + 35	2.00	2.00	2.50	2.50	3.50	-	5.1	12.5	13.3	1210	4440	4800	20.2	19.3	18.5
	20 + 20 + 25 + 25 + 50	1.79	1.79	2.23	2.23	4.46	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 20 + 25 + 25 + 60	1.67	1.67	2.08	2.08	5.00	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 25 + 25 + 71	1.55	1.55	1.94	1.94	5.51	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 25 + 35 + 35	1.85	1.85	2.31	3.24	3.24	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	20 + 20 + 25 + 35 + 50	1.67	1.67	2.08	2.92	4.17	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 25 + 35 + 60	1.56	1.56	1.95	2.73	4.69	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 25 + 35 + 71	1.46	1.46	1.83	2.56	5.19	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 20 + 25 + 50 + 50	1.52	1.52	1.89	3.79	3.79	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 20 + 25 + 50 + 60	1.43	1.43	1.79	3.57	4.29	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 25 + 50 + 71	1.34	1.34	1.68	3.36	4.77	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 25 + 60 + 60	1.35	1.35	1.69	4.05	4.05	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 35 + 35 + 35	1.72	1.72	3.02	3.02	3.02	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 20 + 35 + 35 + 50	1.56	1.56	2.73	2.73	3.91	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 20 + 35 + 35 + 60	1.47	1.47	2.57	2.57	4.41	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 20 + 35 + 35 + 71	1.38	1.38	2.42	2.42	4.90	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 35 + 50 + 50	1.43	1.43	2.50	3.57	3.57	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 35 + 50 + 60	1.35	1.35	2.36	3.38	4.05	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 20 + 35 + 60 + 60	1.28	1.28	2.24	3.85	3.85	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 20 + 50 + 50 + 50	1.32	1.32	3.29	3.29	3.29	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 25 + 25 + 25 + 25	2.00	2.50	2.50	2.50	2.50	-	5.1	12.0	13.3	1210	4090	4800	18.6	17.8	17.1
	20 + 25 + 25 + 25 + 35	1.92	2.40	2.40	2.40	3.37	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	20 + 25 + 25 + 25 + 50	1.72	2.16	2.16	2.16	4.31	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 25 + 25 + 25 + 60	1.61	2.02	2.02	2.02	4.84	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 25 + 25 + 25 + 71	1.51	1.88	1.88	1.88	5.35	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 25 + 25 + 35 + 35	1.79	2.23	2.23	3.13	3.13	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	20 + 25 + 25 + 35 + 50	1.61	2.02	2.02	2.82	4.03	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 25 + 25 + 35 + 60	1.52	1.89	1.89	2.65	4.55	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 25 + 25 + 35 + 71	1.42	1.78	1.78	2.49	5.04	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 25 + 25 + 50 + 50	1.47	1.84	1.84	3.68	3.68	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 25 + 25 + 50 + 60	1.39	1.74	1.74	3.47	4.17	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 25 + 25 + 50 + 71	1.31	1.64	1.64	3.27	4.65	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 25 + 25 + 60 + 60	1.32	1.64	1.64	3.95	3.95	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 25 + 35 + 35 + 35	1.67	2.08	2.92	2.92	2.92	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 25 + 35 + 35 + 50	1.52	1.89	2.65	2.65	3.79	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	20 + 25 + 35 + 35 + 60	1.43	1.79	2.50	2.50	4.29	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 25 + 35 + 35 + 71	1.34	1.68	2.35	2.35	4.77	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 25 + 35 + 50 + 50	1.39	1.74	2.43	3.47	3.47	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 25 + 35 + 50 + 60	1.32	1.64	2.30	3.29	3.95	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 25 + 50 + 50 + 50	1.28	1.60	3.21	3.21	3.21	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	20 + 35 + 35 + 35 + 35	1.56	2.73	2.73	2.73	2.73	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	20 + 35 + 35 + 35 + 50	1.43	2.50	2.50	2.50	3.57	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 35 + 35 + 35 + 60	1.35	2.36	2.36	2.36	4.05	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	20 + 35 + 35 + 50 + 50	1.32	2.30	2.30	3.29	3.29	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	25 + 25 + 25 + 25 + 25	2.50	2.50	2.50	2.50	2.50	-	5.1	12.5	13.3	1210	4440	4800	20.2	19.3	18.5
	25 + 25 + 25 + 25 + 35	2.31	2.31	2.31	2.31	3.24	-	5.1	12.5	13.3	1210	4430	4800	20.2	19.3	18.5
	25 + 25 + 25 + 25 + 50	2.08	2.08	2.08	2.08	4.17	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	25 + 25 + 25 + 25 + 60	1.95	1.95	1.95	1.95	4.69	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	25 + 25 + 25 + 35 + 35	2.16	2.16	2.16	3.02	3.02	-	5.1	12.5	13.3	1210	4420	4800	20.1	19.2	18.4
	25 + 25 + 25 + 35 + 50	1.95	1.95	1.95	2.73	3.91	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	25 + 25 + 25 + 35 + 60	1.84	1.84	1.84	2.57	4.41	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	25 + 25 + 25 + 35 + 71	1.73	1.73	1.73	2.42	4.90	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 25 + 25 + 50 + 50	1.79	1.79	1.79	3.57	3.57	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 25 + 25 + 50 + 60	1.69	1.69	1.69	3.38	4.05	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 25 + 25 + 60 + 60	1.60	1.60	1.60	3.85	3.85	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	25 + 25 + 35 + 35 + 35	2.02	2.02	2.82	2.82	2.82	-	5.1	12.5	13.3	1210	4410	4800	20.1	19.2	18.4
	25 + 25 + 35 + 35 + 50	1.84	1.84	2.57	2.57	3.68	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	25 + 25 + 35 + 35 + 60	1.74	1.74	2.43	2.43	4.17	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 25 + 35 + 35 + 71	1.64	1.64	2.29	2.29	4.65	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	25 + 25 + 35 + 50 + 50	1.69	1.69	2.36	3.38	3.38	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 25 + 35 + 50 + 60	1.60	1.60	2.24	3.21	3.85	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	25 + 35 + 35 + 35 + 35	1.89	2.65	2.65	2.65	2.65	-	5.1	12.5	13.3	1210	4400	4800	20.0	19.1	18.4
	25 + 35 + 35 + 35 + 50	1.74	2.43	2.43	2.43	3.47	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	25 + 35 + 35 + 35 + 60	1.64	2.30	2.30	2.30	3.95	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	25 + 35 + 35 + 50 + 50	1.60	2.24	2.24	3.21	3.21	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
	35 + 35 + 35 + 35 + 35	2.50	2.50	2.50	2.50	2.50	-	5.1	12.5	13.3	1210	4390	4800	20.0	19.1	18.3
	35 + 35 + 35 + 35 + 50	2.30	2.30	2.30	2.30	3.29	-	5.1	12.5	13.3	1210	4380	4800	19.9	19.1	18.3
6 units	20 + 20 + 20 + 20 + 20 + 20	2.00	2.00	2.00	2.00	2.00	2.00	5.5	12.0	13.6	1280	3750	4620	17.1	16.3	15.6
	20 + 20 + 20 + 20 + 20 + 25	2.00	2.00	2.00	2.00	2.00	2.50	5.5	12.5	13.3	1280	4010	4800	18.2	17.5	16.7
	20 + 20 + 20 + 20 + 20 + 35	1.85	1.85	1.85	1.85	1.85	3.24	5.5	12.5	13.3	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 20 + 20 + 20 + 50	1.67	1.67	1.67	1.67	1.67	4.17	5.5	12.5	13.3	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 20 + 60	1.56	1.56	1.56	1.56	1.56	4.69	5.5	12.5	13.3	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 20 + 71	1.46	1.46	1.46	1.46	1.46	5.19	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 20 + 25 + 25	1.92	1.92	1.92	1.92	2.40	2.40	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 20 + 20 + 25 + 35	1.79	1.79	1.79	1.79	2.23	3.13	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 20 + 20 + 25 + 50	1.61	1.61	1.61	1.61	2.02	4.03	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 25 + 60	1.52	1.52	1.52	1.52	1.89	4.55	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 35 + 35	1.67	1.67	1.67	1.67	2.92	2.92	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 35 + 50	1.52	1.52	1.52	1.52	2.65	3.79	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 20 + 35 + 60	1.43	1.43	1.43	1.43	2.50	4.29	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 20 + 35 + 71	1.34	1.34	1.34	1.34	2.35	4.77	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 20 + 50 + 50	1.39	1.39	1.39	1.39	3.47	3.47	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 20 + 50 + 60	1.32	1.32	1.32	1.32	3.29	3.95	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 25 + 25	1.85	1.85	1.85	2.31	2.31	2.31	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 20 + 25 + 25 + 35	1.72	1.72	1.72	2.16	2.16	3.02	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 20 + 25 + 25 + 50	1.56	1.56	1.56	1.95	1.95	3.91	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 25 + 25 + 60	1.47	1.47	1.47	1.84	1.84	4.41	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6

## &lt;Cooling&gt;

Indoor unit combination		Cooling capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
6 units	20 + 20 + 20 + 25 + 25 + 71	1.38	1.38	1.38	1.73	1.73	4.90	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 35 + 35	1.61	1.61	1.61	2.02	2.82	2.82	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 25 + 35 + 50	1.47	1.47	1.47	1.84	2.57	3.68	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 35 + 60	1.39	1.39	1.39	1.74	2.43	4.17	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 35 + 71	1.31	1.31	1.31	1.64	2.29	4.65	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 50 + 50	1.35	1.35	1.35	1.69	3.38	3.38	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 25 + 50 + 60	1.28	1.28	1.28	1.60	3.21	3.85	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 20 + 35 + 35 + 35	1.52	1.52	1.52	2.65	2.65	2.65	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 20 + 35 + 35 + 50	1.39	1.39	1.39	2.43	2.43	3.47	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 20 + 35 + 35 + 60	1.32	1.32	1.32	2.30	2.30	3.95	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 20 + 35 + 50 + 50	1.28	1.28	1.28	2.24	3.21	3.21	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25 + 25 + 25	1.79	1.79	2.23	2.23	2.23	2.23	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 20 + 25 + 25 + 25 + 35	1.67	1.67	2.08	2.08	2.08	2.92	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 25 + 25 + 25 + 50	1.52	1.52	1.89	1.89	1.89	3.79	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 25 + 25 + 25 + 60	1.43	1.43	1.79	1.79	1.79	4.29	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25 + 25 + 71	1.34	1.34	1.68	1.68	1.68	4.77	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25 + 35 + 35	1.56	1.56	1.95	1.95	2.73	2.73	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 20 + 25 + 25 + 35 + 50	1.43	1.43	1.79	1.79	2.50	3.57	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25 + 35 + 60	1.35	1.35	1.69	1.69	2.36	4.05	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 25 + 50 + 50	1.32	1.32	1.64	1.64	3.29	3.29	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 25 + 35 + 35 + 35	1.47	1.47	1.84	2.57	2.57	2.57	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 35 + 35 + 50	1.35	1.35	1.69	2.36	2.36	3.38	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 25 + 35 + 35 + 60	1.28	1.28	1.60	2.24	2.24	3.85	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 20 + 35 + 35 + 35 + 35	1.39	1.39	2.43	2.43	2.43	2.43	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 20 + 35 + 35 + 35 + 50	1.28	1.28	2.24	2.24	2.24	3.21	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 25 + 25	1.72	2.16	2.16	2.16	2.16	2.16	5.5	12.5	13.8	1280	4000	4800	18.2	17.4	16.7
	20 + 25 + 25 + 25 + 25 + 35	1.61	2.02	2.02	2.02	2.02	2.82	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 25 + 25 + 25 + 25 + 50	1.47	1.84	1.84	1.84	1.84	3.68	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 25 + 60	1.39	1.74	1.74	1.74	1.74	4.17	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 25 + 71	1.31	1.64	1.64	1.64	1.64	4.65	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 35 + 35	1.52	1.89	1.89	1.89	2.65	2.65	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	20 + 25 + 25 + 25 + 35 + 50	1.39	1.74	1.74	1.74	2.43	3.47	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 35 + 60	1.32	1.64	1.64	1.64	2.30	3.95	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 25 + 25 + 25 + 50 + 50	1.28	1.60	1.60	1.60	3.21	3.21	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 25 + 25 + 35 + 35 + 35	1.43	1.79	1.79	2.50	2.50	2.50	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 25 + 25 + 35 + 35 + 50	1.32	1.64	1.64	2.30	2.30	3.29	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	20 + 25 + 35 + 35 + 35 + 35	1.35	1.69	2.36	2.36	2.36	2.36	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	20 + 35 + 35 + 35 + 35 + 35	1.28	2.24	2.24	2.24	2.24	2.24	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	25 + 25 + 25 + 25 + 25 + 25	2.08	2.08	2.08	2.08	2.08	2.08	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	25 + 25 + 25 + 25 + 25 + 35	1.95	1.95	1.95	1.95	1.95	2.73	5.5	12.5	13.8	1280	3990	4800	18.2	17.4	16.6
	25 + 25 + 25 + 25 + 25 + 50	1.79	1.79	1.79	1.79	1.79	3.57	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	25 + 25 + 25 + 25 + 25 + 60	1.69	1.69	1.69	1.69	1.69	4.05	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	25 + 25 + 25 + 25 + 35 + 35	1.84	1.84	1.84	1.84	2.57	2.57	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	25 + 25 + 25 + 25 + 35 + 50	1.69	1.69	1.69	1.69	2.36	3.38	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	25 + 25 + 25 + 25 + 35 + 60	1.60	1.60	1.60	1.60	2.24	3.85	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	25 + 25 + 25 + 35 + 35 + 35	1.74	1.74	1.74	2.43	2.43	2.43	5.5	12.5	13.8	1280	3980	4800	18.1	17.3	16.6
	25 + 25 + 25 + 35 + 35 + 50	1.60	1.60	1.60	2.24	2.24	3.21	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6
	25 + 25 + 35 + 35 + 35 + 35	1.64	1.64	2.30	2.30	2.30	2.30	5.5	12.5	13.8	1280	3970	4800	18.1	17.3	16.6

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
1 unit	20	3.0	-	-	-	-	-	1.5	3.0	3.6	700	1220	1330	5.6	5.4	5.1
	25	3.4	-	-	-	-	-	1.5	3.4	4.1	700	1265	1540	5.8	5.6	5.3
	35	4.5	-	-	-	-	-	1.5	4.5	4.9	700	1650	1840	7.6	7.2	6.9
	50	5.8	-	-	-	-	-	1.5	5.8	6.4	700	2120	2410	9.7	9.3	8.9
	60	6.8	-	-	-	-	-	1.5	6.8	7.4	700	2500	2760	11.5	11.0	10.5
	71	8.0	-	-	-	-	-	1.5	8.0	8.1	700	3020	3090	13.9	13.3	12.7
2 units	20 + 20	3.00	3.00	-	-	-	-	2.1	6.0	7.2	750	1540	1860	7.1	6.8	6.5
	20 + 25	2.84	3.56	-	-	-	-	2.1	6.4	7.7	750	1660	2210	7.6	7.3	7.0
	20 + 35	2.73	4.77	-	-	-	-	2.1	7.5	8.5	750	1990	2520	9.1	8.7	8.4
	20 + 50	2.51	6.29	-	-	-	-	2.1	8.8	10.0	750	2430	3220	11.2	10.7	10.2
	20 + 60	2.45	7.35	-	-	-	-	2.1	9.8	11.0	750	2840	3620	13.0	12.5	12.0
	20 + 71	2.42	8.58	-	-	-	-	2.1	11.0	11.6	750	2840	3620	13.0	12.5	12.0
	25 + 25	3.40	3.40	-	-	-	-	2.1	6.8	8.2	750	1770	2420	8.1	7.8	7.4
	25 + 35	3.29	4.61	-	-	-	-	2.1	7.9	9.0	750	2140	2820	9.8	9.4	9.0
	25 + 50	3.07	6.13	-	-	-	-	2.1	9.2	10.5	750	2630	3610	12.1	11.6	11.1
	25 + 60	3.00	7.20	-	-	-	-	2.1	10.2	11.5	750	3040	3790	14.0	13.4	12.8
	25 + 71	2.97	8.43	-	-	-	-	2.1	11.4	12.1	750	3440	4250	15.8	15.1	14.5
	35 + 35	4.50	4.50	-	-	-	-	2.1	9.0	9.8	750	2520	3210	11.6	11.1	10.6
	35 + 50	4.24	6.06	-	-	-	-	2.1	10.3	11.3	750	3040	3710	14.0	13.4	12.8
	35 + 60	4.16	7.14	-	-	-	-	2.1	11.3	12.3	750	3420	4320	15.7	15.0	14.4
	35 + 71	4.13	8.37	-	-	-	-	2.1	12.5	12.9	750	4030	4690	18.5	17.7	17.0
	50 + 50	5.80	5.80	-	-	-	-	2.1	11.6	12.8	750	3660	4620	16.8	16.1	15.4
	50 + 60	5.73	6.87	-	-	-	-	2.1	12.6	13.8	750	4090	5230	18.8	18.0	17.2
	50 + 71	5.58	7.92	-	-	-	-	2.1	13.5	13.8	750	4540	5230	20.8	19.9	19.1
	60 + 60	6.75	6.75	-	-	-	-	2.1	13.5	13.8	750	4540	5230	20.8	19.9	19.1
	60 + 71	6.18	7.32	-	-	-	-	2.1	13.5	13.8	750	4540	5230	20.8	19.9	19.1
	71 + 71	6.75	6.75	-	-	-	-	2.1	13.5	13.8	750	4530	5230	20.8	19.9	19.1
3 units	20 + 20 + 20	3.00	3.00	3.00	-	-	-	3.2	9.0	10.9	780	2270	3350	10.4	10.0	9.6
	20 + 20 + 25	2.89	2.89	3.62	-	-	-	3.2	9.4	11.4	780	2400	3550	11.0	10.5	10.1
	20 + 20 + 35	2.80	2.80	4.90	-	-	-	3.2	10.5	12.2	780	2760	3820	12.7	12.1	11.6
	20 + 20 + 50	2.62	2.62	6.56	-	-	-	3.2	11.8	13.7	780	3270	4290	15.0	14.4	13.8
	20 + 20 + 60	2.56	2.56	7.68	-	-	-	3.2	12.8	13.8	780	3690	4350	16.9	16.2	15.5
	20 + 20 + 71	2.43	2.43	8.64	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	20 + 25 + 25	2.80	3.50	3.50	-	-	-	3.2	9.8	11.9	780	2560	3720	11.8	11.2	10.8
	20 + 25 + 35	2.73	3.41	4.77	-	-	-	3.2	10.9	12.7	780	2970	3990	13.6	13.0	12.5
	20 + 25 + 50	2.57	3.21	6.42	-	-	-	3.2	12.2	13.8	780	3480	4350	16.0	15.3	14.6
	20 + 25 + 60	2.51	3.14	7.54	-	-	-	3.2	13.2	13.8	780	3990	4350	18.3	17.5	16.8
	20 + 25 + 71	2.33	2.91	8.26	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	20 + 35 + 35	2.67	4.67	4.67	-	-	-	3.2	12.0	13.5	780	3460	4220	15.9	15.2	14.6
	20 + 35 + 50	2.53	4.43	6.33	-	-	-	3.2	13.3	13.8	780	3980	4350	18.3	17.5	16.8
	20 + 35 + 60	2.35	4.11	7.04	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	20 + 35 + 71	2.14	3.75	7.61	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	20 + 50 + 50	2.25	5.63	5.63	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	20 + 50 + 60	2.08	5.19	6.23	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	20 + 50 + 71	1.91	4.79	6.80	-	-	-	4.2	13.5	13.8	780	4130	4350	18.8	18.0	17.2
	20 + 60 + 60	1.93	5.79	5.79	-	-	-	5.2	13.5	13.8	780	4130	4350	18.6	17.8	17.0
	20 + 60 + 71	1.79	5.36	6.35	-	-	-	6.2	13.5	13.8	780	4120	4350	18.4	17.6	16.8
	20 + 71 + 71	1.67	5.92	5.92	-	-	-	7.2	13.5	13.8	780	4120	4350	18.2	17.4	16.7
	25 + 25 + 25	3.40	3.40	3.40	-	-	-	3.2	10.2	12.4	780	2760	3880	12.7	12.1	11.6
	25 + 25 + 35	3.32	3.32	4.65	-	-	-	3.2	11.3	13.2	780	3170	4120	14.6	13.9	13.3
	25 + 25 + 50	3.15	3.15	6.30	-	-	-	3.2	12.6	13.8	780	3690	4350	16.9	16.2	15.5
	25 + 25 + 60	3.07	3.07	7.36	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 25 + 71	2.79	2.79	7.92	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 35 + 35	3.26	4.57	4.57	-	-	-	3.2	12.4	13.8	780	3780	4350	17.4	16.6	15.9

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
3 units	25 + 35 + 50	3.07	4.30	6.14	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	25 + 35 + 60	2.81	3.94	6.75	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	25 + 35 + 71	2.58	3.61	7.32	-	-	-	4.2	13.5	13.8	780	4130	4350	18.8	18.0	17.2
	25 + 50 + 50	2.70	5.40	5.40	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 50 + 60	2.50	5.00	6.00	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 50 + 71	2.31	4.62	6.57	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 60 + 60	2.33	5.59	5.59	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	25 + 60 + 71	2.16	5.19	6.14	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	25 + 71 + 71	2.02	5.74	5.74	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	35 + 35 + 35	4.50	4.50	4.50	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	35 + 35 + 50	3.94	3.94	5.63	-	-	-	3.2	13.5	13.8	780	4140	4350	19.0	18.2	17.4
	35 + 35 + 60	3.63	3.63	6.23	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	35 + 35 + 71	3.35	3.35	6.80	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	35 + 50 + 50	3.50	5.00	5.00	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	35 + 50 + 60	3.26	4.66	5.59	-	-	-	3.2	13.5	13.8	780	4130	4350	19.0	18.1	17.4
	35 + 50 + 71	3.03	4.33	6.14	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	35 + 60 + 60	3.05	5.23	5.23	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	35 + 60 + 71	2.85	4.88	5.77	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	35 + 71 + 71	2.67	5.42	5.42	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	50 + 50 + 50	4.50	4.50	4.50	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	50 + 50 + 60	4.22	4.22	5.06	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	50 + 50 + 71	3.95	3.95	5.61	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	50 + 60 + 60	3.97	4.76	4.76	-	-	-	3.2	13.5	13.8	780	4120	4350	18.9	18.1	17.3
	50 + 60 + 71	3.73	4.48	5.30	-	-	-	3.2	13.5	13.8	780	4110	4350	18.9	18.1	17.3
	60 + 60 + 60	4.50	4.50	4.50	-	-	-	3.2	13.5	13.8	780	4110	4350	18.9	18.1	17.3
	60 + 60 + 71	4.24	4.24	5.02	-	-	-	3.2	13.5	13.8	780	4110	4350	18.9	18.1	17.3
4 units	20 + 20 + 20 + 20	3.00	3.00	3.00	3.00	-	-	3.6	12.0	13.8	950	3270	3920	14.9	14.2	13.6
	20 + 20 + 20 + 25	2.92	2.92	2.92	3.65	-	-	3.6	12.4	13.8	950	3460	3920	15.7	15.1	14.4
	20 + 20 + 20 + 35	2.84	2.84	2.84	4.97	-	-	3.6	13.5	13.8	950	3770	3920	17.2	16.4	15.7
	20 + 20 + 20 + 50	2.45	2.45	2.45	6.14	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 20 + 20 + 60	2.25	2.25	2.25	6.75	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 20 + 20 + 71	2.06	2.06	2.06	7.32	-	-	3.6	13.5	13.8	950	3750	3920	16.9	16.2	15.5
	20 + 20 + 25 + 25	2.84	2.84	3.56	3.56	-	-	3.6	12.8	13.8	950	3510	3920	16.0	15.3	14.6
	20 + 20 + 25 + 35	2.70	2.70	3.38	4.73	-	-	3.6	13.5	13.8	950	3770	3920	17.2	16.4	15.7
	20 + 20 + 25 + 50	2.35	2.35	2.93	5.87	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 20 + 25 + 60	2.16	2.16	2.70	6.48	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 20 + 25 + 71	1.99	1.99	2.48	7.05	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 20 + 35 + 35	2.45	2.45	4.30	4.30	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 20 + 35 + 50	2.16	2.16	3.78	5.40	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 20 + 35 + 60	2.00	2.00	3.50	6.00	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 20 + 35 + 71	1.85	1.85	3.24	6.57	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 20 + 50 + 50	1.93	1.93	4.82	4.82	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 20 + 50 + 60	1.80	1.80	4.50	5.40	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 20 + 50 + 71	1.68	1.68	4.19	5.95	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 20 + 60 + 60	1.69	1.69	5.06	5.06	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 20 + 60 + 71	1.58	1.58	4.74	5.61	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 20 + 71 + 71	1.48	1.48	5.27	5.27	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 25 + 25 + 25	2.78	3.47	3.47	3.47	-	-	3.6	13.2	13.8	950	3620	3920	16.5	15.8	15.1
	20 + 25 + 25 + 35	2.57	3.21	3.21	4.50	-	-	3.6	13.5	13.8	950	3770	3920	17.2	16.4	15.7
	20 + 25 + 25 + 50	2.25	2.81	2.81	5.63	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 25 + 25 + 60	2.08	2.60	2.60	6.23	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 25 + 25 + 71	1.91	2.39	2.39	6.80	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 25 + 35 + 35	2.35	2.93	4.11	4.11	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	20 + 25 + 35 + 50	2.08	2.60	3.63	5.19	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 25 + 35 + 60	1.93	2.41	3.38	5.79	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
4 units	20 + 25 + 35 + 71	1.79	2.24	3.13	6.35	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 25 + 50 + 50	1.86	2.33	4.66	4.66	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 25 + 50 + 60	1.74	2.18	4.35	5.23	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 25 + 50 + 71	1.63	2.03	4.07	5.77	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 25 + 60 + 60	1.64	2.05	4.91	4.91	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 25 + 60 + 71	1.53	1.92	4.60	5.45	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 25 + 71 + 71	1.44	1.80	5.13	5.13	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	20 + 35 + 35 + 35	2.16	3.78	3.78	3.78	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	20 + 35 + 35 + 50	1.93	3.38	3.38	4.82	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 35 + 35 + 60	1.80	3.15	3.15	5.40	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 35 + 35 + 71	1.68	2.93	2.93	5.95	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 35 + 50 + 50	1.74	3.05	4.35	4.35	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	20 + 35 + 50 + 60	1.64	2.86	4.09	4.91	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 35 + 50 + 71	1.53	2.68	3.84	5.45	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 35 + 60 + 60	1.54	2.70	4.63	4.63	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 35 + 60 + 71	1.45	2.54	4.35	5.15	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	20 + 50 + 50 + 50	1.59	3.97	3.97	3.97	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 50 + 50 + 60	1.50	3.75	3.75	4.50	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	20 + 50 + 50 + 71	1.41	3.53	3.53	5.02	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	20 + 50 + 60 + 60	1.42	3.55	4.26	4.26	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	25 + 25 + 25 + 25	3.38	3.38	3.38	3.38	-	-	3.6	13.5	13.8	950	3770	3920	17.2	16.4	15.7
	25 + 25 + 25 + 35	3.07	3.07	3.07	4.30	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	25 + 25 + 25 + 50	2.70	2.70	2.70	5.40	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	25 + 25 + 25 + 60	2.50	2.50	2.50	6.00	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	25 + 25 + 25 + 71	2.31	2.31	2.31	6.57	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 25 + 35 + 35	2.81	2.81	3.94	3.94	-	-	3.6	13.5	13.8	950	3760	3920	17.1	16.4	15.7
	25 + 25 + 35 + 50	2.50	2.50	3.50	5.00	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	25 + 25 + 35 + 60	2.33	2.33	3.26	5.59	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 25 + 35 + 71	2.16	2.16	3.03	6.14	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 25 + 50 + 50	2.25	2.25	4.50	4.50	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 25 + 50 + 60	2.11	2.11	4.22	5.06	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 25 + 50 + 71	1.97	1.97	3.95	5.61	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 25 + 60 + 60	1.99	1.99	4.76	4.76	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 25 + 60 + 71	1.86	1.86	4.48	5.30	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 25 + 71 + 71	1.76	1.76	4.99	4.99	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	25 + 35 + 35 + 35	2.60	3.63	3.63	3.63	-	-	3.6	13.5	13.8	950	3750	3920	17.1	16.3	15.6
	25 + 35 + 35 + 50	2.33	3.26	3.26	4.66	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 35 + 35 + 60	2.18	3.05	3.05	5.23	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 35 + 35 + 71	2.03	2.85	2.85	5.77	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 35 + 50 + 50	2.11	2.95	4.22	4.22	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	25 + 35 + 50 + 60	1.99	2.78	3.97	4.76	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 35 + 50 + 71	1.86	2.61	3.73	5.30	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 35 + 60 + 60	1.88	2.63	4.50	4.50	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 35 + 60 + 71	1.77	2.47	4.24	5.02	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	25 + 50 + 50 + 50	1.93	3.86	3.86	3.86	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	25 + 50 + 50 + 60	1.82	3.65	3.65	4.38	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	25 + 50 + 60 + 60	1.73	3.46	4.15	4.15	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	35 + 35 + 35 + 35	3.38	3.38	3.38	3.38	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	35 + 35 + 35 + 50	3.05	3.05	3.05	4.35	-	-	3.6	13.5	13.8	950	3740	3920	17.0	16.3	15.6
	35 + 35 + 35 + 60	2.86	2.86	2.86	4.91	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	35 + 35 + 35 + 71	2.68	2.68	2.68	5.45	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	35 + 35 + 50 + 50	2.78	2.78	3.97	3.97	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	35 + 35 + 50 + 60	2.63	2.63	3.75	4.50	-	-	3.6	13.5	13.8	950	3730	3920	17.0	16.2	15.6
	35 + 35 + 50 + 71	2.47	2.47	3.53	5.02	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	35 + 35 + 60 + 60	2.49	2.49	4.26	4.26	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	35 + 50 + 50 + 50	2.55	3.65	3.65	3.65	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5
	35 + 50 + 50 + 60	2.42	3.46	3.46	4.15	-	-	3.6	13.5	13.8	950	3720	3920	16.9	16.2	15.5

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 20 + 20 + 20 + 20	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	13.8	1050	3450	3470	15.7	15.0	14.4
	20 + 20 + 20 + 20 + 25	2.57	2.57	2.57	2.57	3.21	-	4.0	13.5	13.8	1050	3450	3470	15.7	15.0	14.4
	20 + 20 + 20 + 20 + 35	2.35	2.35	2.35	2.35	4.11	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	20 + 20 + 20 + 20 + 50	2.08	2.08	2.08	2.08	5.19	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 20 + 20 + 60	1.93	1.93	1.93	1.93	5.79	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 20 + 20 + 71	1.79	1.79	1.79	1.79	6.35	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 20 + 25 + 25	2.45	2.45	2.45	3.07	3.07	-	4.0	13.5	13.8	1050	3450	3470	15.7	15.0	14.4
	20 + 20 + 20 + 25 + 35	2.25	2.25	2.25	2.81	3.94	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	20 + 20 + 20 + 25 + 50	2.00	2.00	2.00	2.50	5.00	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 20 + 25 + 60	1.86	1.86	1.86	2.33	5.59	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 20 + 25 + 71	1.73	1.73	1.73	2.16	6.14	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 20 + 35 + 35	2.08	2.08	2.08	3.63	3.63	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 20 + 35 + 50	1.86	1.86	1.86	3.26	4.66	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 20 + 35 + 60	1.74	1.74	1.74	3.05	5.23	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 20 + 35 + 71	1.63	1.63	1.63	2.85	5.77	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 20 + 50 + 50	1.69	1.69	1.69	4.22	4.22	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 20 + 50 + 60	1.59	1.59	1.59	3.97	4.76	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 20 + 60 + 60	1.50	1.50	1.50	4.50	4.50	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 20 + 20 + 60 + 71	1.41	1.41	1.41	4.24	5.02	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 20 + 25 + 25 + 25	2.35	2.35	2.93	2.93	2.93	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	20 + 20 + 25 + 25 + 35	2.16	2.16	2.70	2.70	3.78	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	20 + 20 + 25 + 25 + 50	1.93	1.93	2.41	2.41	4.82	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 25 + 25 + 60	1.80	1.80	2.25	2.25	5.40	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 25 + 25 + 71	1.68	1.68	2.10	2.10	5.95	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 25 + 35 + 35	2.00	2.00	2.50	3.50	3.50	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 20 + 25 + 35 + 50	1.80	1.80	2.25	3.15	4.50	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 25 + 35 + 60	1.69	1.69	2.11	2.95	5.06	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 25 + 35 + 71	1.58	1.58	1.97	2.76	5.61	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 25 + 50 + 50	1.64	1.64	2.05	4.09	4.09	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 25 + 50 + 60	1.54	1.54	1.93	3.86	4.63	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 25 + 50 + 71	1.45	1.45	1.81	3.63	5.15	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 20 + 25 + 60 + 60	1.46	1.46	1.82	4.38	4.38	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 20 + 35 + 35 + 35	1.86	1.86	3.26	3.26	3.26	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 20 + 35 + 35 + 50	1.69	1.69	2.95	2.95	4.22	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 35 + 35 + 60	1.59	1.59	2.78	2.78	4.76	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 35 + 35 + 71	1.49	1.49	2.61	2.61	5.30	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 20 + 35 + 50 + 50	1.54	1.54	2.70	3.86	3.86	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 20 + 35 + 50 + 60	1.46	1.46	2.55	3.65	4.38	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 20 + 35 + 60 + 60	1.38	1.38	2.42	4.15	4.15	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 20 + 50 + 50 + 50	1.42	1.42	3.55	3.55	3.55	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 25 + 25 + 25 + 25	2.25	2.81	2.81	2.81	2.81	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	20 + 25 + 25 + 25 + 35	2.08	2.60	2.60	2.60	3.63	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 25 + 25 + 25 + 50	1.86	2.33	2.33	2.33	4.66	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 25 + 25 + 25 + 60	1.74	2.18	2.18	2.18	5.23	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 25 + 25 + 25 + 71	1.63	2.03	2.03	2.03	5.77	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 25 + 35 + 35	1.93	2.41	2.41	3.38	3.38	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	20 + 25 + 25 + 35 + 50	1.74	2.18	2.18	3.05	4.35	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	20 + 25 + 25 + 35 + 60	1.64	2.05	2.05	2.86	4.91	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 25 + 35 + 71	1.53	1.92	1.92	2.68	5.45	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 25 + 50 + 50	1.59	1.99	1.99	3.97	3.97	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 25 + 50 + 60	1.50	1.88	1.88	3.75	4.50	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 25 + 25 + 50 + 71	1.41	1.77	1.77	3.53	5.02	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 25 + 25 + 60 + 60	1.42	1.78	1.78	4.26	4.26	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 25 + 35 + 35 + 35	1.80	2.25	3.15	3.15	3.15	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
5 units	20 + 25 + 35 + 35 + 50	1.64	2.05	2.86	2.86	4.09	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 35 + 35 + 60	1.54	1.93	2.70	2.70	4.63	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 25 + 35 + 35 + 71	1.45	1.81	2.54	2.54	5.15	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 25 + 35 + 50 + 50	1.50	1.88	2.63	3.75	3.75	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 25 + 35 + 50 + 60	1.42	1.78	2.49	3.55	4.26	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 25 + 50 + 50 + 50	1.38	1.73	3.46	3.46	3.46	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	20 + 35 + 35 + 35 + 35	1.69	2.95	2.95	2.95	2.95	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 35 + 35 + 35 + 50	1.54	2.70	2.70	2.70	3.86	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	20 + 35 + 35 + 35 + 60	1.46	2.55	2.55	2.55	4.38	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	20 + 35 + 35 + 50 + 50	1.42	2.49	2.49	3.55	3.55	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	25 + 25 + 25 + 25 + 25	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	13.8	1050	3440	3470	15.7	15.0	14.3
	25 + 25 + 25 + 25 + 35	2.50	2.50	2.50	2.50	3.50	-	4.0	13.5	13.8	1050	3430	3470	15.6	14.9	14.3
	25 + 25 + 25 + 25 + 50	2.25	2.25	2.25	2.25	4.50	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	25 + 25 + 25 + 25 + 60	2.11	2.11	2.11	2.11	5.06	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 25 + 25 + 71	1.97	1.97	1.97	1.97	5.61	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 25 + 35 + 35	2.33	2.33	2.33	3.26	3.26	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	25 + 25 + 25 + 35 + 50	2.11	2.11	2.11	2.95	4.22	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 25 + 35 + 60	1.99	1.99	1.99	2.78	4.76	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 25 + 35 + 71	1.86	1.86	1.86	2.61	5.30	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	25 + 25 + 25 + 50 + 50	1.93	1.93	1.93	3.86	3.86	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 25 + 50 + 60	1.82	1.82	1.82	3.65	4.38	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	25 + 25 + 25 + 60 + 60	1.73	1.73	1.73	4.15	4.15	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	25 + 25 + 35 + 35 + 35	2.18	2.18	3.05	3.05	3.05	-	4.0	13.5	13.8	1050	3420	3470	15.6	14.9	14.3
	25 + 25 + 35 + 35 + 50	1.99	1.99	2.78	2.78	3.97	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 25 + 35 + 35 + 60	1.88	1.88	2.63	2.63	4.50	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	25 + 25 + 35 + 35 + 71	1.77	1.77	2.47	2.47	5.02	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	25 + 25 + 35 + 50 + 50	1.82	1.82	2.55	3.65	3.65	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	25 + 25 + 35 + 50 + 60	1.73	1.73	2.42	3.46	4.15	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	25 + 35 + 35 + 35 + 35	2.05	2.86	2.86	2.86	2.86	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	25 + 35 + 35 + 35 + 50	1.88	2.63	2.63	2.63	3.75	-	4.0	13.5	13.8	1050	3400	3470	15.5	14.8	14.2
	25 + 35 + 35 + 35 + 60	1.78	2.49	2.49	2.49	4.26	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	25 + 35 + 35 + 50 + 50	1.73	2.42	2.42	3.46	3.46	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
	35 + 35 + 35 + 35 + 35	2.70	2.70	2.70	2.70	2.70	-	4.0	13.5	13.8	1050	3410	3470	15.5	14.8	14.2
	35 + 35 + 35 + 35 + 50	2.49	2.49	2.49	2.49	3.55	-	4.0	13.5	13.8	1050	3390	3470	15.4	14.8	14.1
6 units	20 + 20 + 20 + 20 + 20 + 20	2.25	2.25	2.25	2.25	2.25	2.25	4.5	13.5	13.8	1150	3330	3420	15.2	14.5	13.9
	20 + 20 + 20 + 20 + 20 + 25	2.16	2.16	2.16	2.16	2.16	2.70	4.5	13.5	13.8	1150	3330	3420	15.2	14.5	13.9
	20 + 20 + 20 + 20 + 20 + 35	2.00	2.00	2.00	2.00	2.00	3.50	4.5	13.5	13.8	1150	3330	3420	15.2	14.5	13.9
	20 + 20 + 20 + 20 + 20 + 50	1.80	1.80	1.80	1.80	1.80	4.50	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 20 + 60	1.69	1.69	1.69	1.69	1.69	5.06	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 20 + 71	1.58	1.58	1.58	1.58	1.58	5.61	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 25 + 25	2.08	2.08	2.08	2.08	2.60	2.60	4.5	13.5	13.8	1150	3330	3420	15.2	14.5	13.9
	20 + 20 + 20 + 20 + 25 + 35	1.93	1.93	1.93	1.93	2.41	3.38	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 25 + 50	1.74	1.74	1.74	1.74	2.18	4.35	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 25 + 60	1.64	1.64	1.64	1.64	2.05	4.91	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 25 + 71	1.53	1.53	1.53	1.53	1.92	5.45	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 35 + 35	1.80	1.80	1.80	1.80	3.15	3.15	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 35 + 50	1.64	1.64	1.64	1.64	2.86	4.09	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 35 + 60	1.54	1.54	1.54	1.54	2.70	4.63	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 35 + 71	1.45	1.45	1.45	1.45	2.54	5.15	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 50 + 50	1.50	1.50	1.50	1.50	3.75	3.75	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 20 + 50 + 60	1.42	1.42	1.42	1.42	3.55	4.26	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 25 + 25	2.00	2.00	2.00	2.50	2.50	2.50	4.5	13.5	13.8	1150	3330	3420	15.2	14.5	13.9
	20 + 20 + 20 + 25 + 25 + 35	1.86	1.86	1.86	2.33	2.33	3.26	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 25 + 50	1.69	1.69	1.69	2.11	2.11	4.22	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 25 + 60	1.59	1.59	1.59	1.99	1.99	4.76	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8

## &lt;Heating&gt;

Indoor unit combination		Heating capacity (kW)									Power consumption (W)			Standard current (A)		
		Indoor unit capacity (kW)						Total capacity (kW)			Min.	Standard	Max.	220V	230V	240V
		A	B	C	D	E	F	Min.	Standard	Max.						
6 units	20 + 20 + 20 + 25 + 25 + 71	1.49	1.49	1.49	1.86	1.86	5.30	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 35 + 35	1.74	1.74	1.74	2.18	3.05	3.05	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 35 + 50	1.59	1.59	1.59	1.99	2.78	3.97	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 35 + 60	1.50	1.50	1.50	1.88	2.63	4.50	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 50 + 50	1.46	1.46	1.46	1.82	3.65	3.65	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 25 + 50 + 60	1.38	1.38	1.38	1.73	3.46	4.15	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 35 + 35 + 35	1.64	1.64	1.64	2.86	2.86	2.86	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 20 + 35 + 35 + 50	1.50	1.50	1.50	2.63	2.63	3.75	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 35 + 35 + 60	1.42	1.42	1.42	2.49	2.49	4.26	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 20 + 35 + 50 + 50	1.38	1.38	1.38	2.42	3.46	3.46	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 25 + 25	1.93	1.93	2.41	2.41	2.41	2.41	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 25 + 35	1.80	1.80	2.25	2.25	2.25	3.15	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 25 + 50	1.64	1.64	2.05	2.05	2.05	4.09	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 25 + 60	1.54	1.54	1.93	1.93	1.93	4.63	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 25 + 71	1.45	1.45	1.81	1.81	1.81	5.15	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 35 + 35	1.69	1.69	2.11	2.11	2.95	2.95	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 35 + 50	1.54	1.54	1.93	1.93	2.70	3.86	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 35 + 60	1.46	1.46	1.82	1.82	2.55	4.38	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 25 + 50 + 50	1.42	1.42	1.78	1.78	3.55	3.55	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 35 + 35 + 35	1.59	1.59	1.99	2.78	2.78	2.78	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 35 + 35 + 50	1.46	1.46	1.82	2.55	2.55	3.65	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 25 + 35 + 35 + 60	1.38	1.38	1.73	2.42	2.42	4.15	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 35 + 35 + 35 + 35	1.50	1.50	2.63	2.63	2.63	2.63	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 20 + 35 + 35 + 35 + 50	1.38	1.38	2.42	2.42	2.42	3.46	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25 + 25	1.86	2.33	2.33	2.33	2.33	2.33	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25 + 35	1.74	2.18	2.18	2.18	2.18	3.05	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25 + 50	1.59	1.99	1.99	1.99	1.99	3.97	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25 + 60	1.50	1.88	1.88	1.88	1.88	4.50	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 25 + 71	1.41	1.77	1.77	1.77	1.77	5.02	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 35 + 35	1.64	2.05	2.05	2.05	2.86	2.86	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 35 + 50	1.50	1.88	1.88	1.88	2.63	3.75	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 35 + 60	1.42	1.78	1.78	1.78	2.49	4.26	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 25 + 50 + 50	1.38	1.73	1.73	1.73	3.46	3.46	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 35 + 35 + 35	1.54	1.93	1.93	2.70	2.70	2.70	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 25 + 35 + 35 + 50	1.42	1.78	1.78	2.49	2.49	3.55	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 25 + 35 + 35 + 35 + 35	1.46	1.82	2.55	2.55	2.55	2.55	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	20 + 35 + 35 + 35 + 35 + 35	1.38	2.42	2.42	2.42	2.42	2.42	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 25 + 25	2.25	2.25	2.25	2.25	2.25	2.25	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 25 + 35	2.11	2.11	2.11	2.11	2.11	2.95	4.5	13.5	13.8	1150	3320	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 25 + 50	1.93	1.93	1.93	1.93	1.93	3.86	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 25 + 60	1.82	1.82	1.82	1.82	1.82	4.38	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 35 + 35	1.99	1.99	1.99	1.99	2.78	2.78	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 35 + 50	1.82	1.82	1.82	1.82	2.55	3.65	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 25 + 35 + 60	1.73	1.73	1.73	1.73	2.42	4.15	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 35 + 35 + 35	1.88	1.88	1.88	2.63	2.63	2.63	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 25 + 35 + 35 + 50	1.73	1.73	1.73	2.42	2.42	3.46	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8
	25 + 25 + 35 + 35 + 35 + 35	1.78	1.78	2.49	2.49	2.49	2.49	4.5	13.5	13.8	1150	3310	3420	15.1	14.4	13.8


ESP-PR-1108

## 6. SELECTION CHARTS

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

**Net capacity = Capacity shown on specification × Correction factors as follows.**

### (1) Coefficient of cooling and heating capacity in relation to temperatures



### (2) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way piping length between the indoor and outdoor units.

Piping length [m]	7	10	15	20	25
Cooling	1.0	0.99	0.975	0.965	0.95
Heating	1.0	1.0	1.0	1.0	1.0

### (3) Correction relative to frosting on outdoor heat exchanger during heating

In additions to the foregoing corrections (1), (2) the heating capacity needs to be adjusted also with respect to the frosting on the outdoor heat exchanger.

Air inlet temperature of outdoor unit in °CWB	-15	-10	-9	-7	-5	-3	-1	1	3	5 or more
Adjustment coefficient	0.95	0.95	0.94	0.93	0.91	0.88	0.86	0.87	0.92	1.00

#### How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model SCM80ZM-S (SRK25ZMX-S : 4 units) with the piping length of 10m, indoor wet-bulb temperature at 19.0°C and outdoor dry-bulb temperature 35°C is

$$\text{Net cooling capacity} = \frac{(1.98 \times 4)}{\text{Table of indoor unit combination (Refer to page 165)}} \times \frac{0.99}{\text{Length 10m}} \times \frac{1.0}{\text{Factor by air temperatures}} \div 7.84\text{kW}$$


Outdoor unit SCM80ZM-S  
Indoor unit SRK25ZMX-S × 4 units

## 7. OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER

### 7.1 SRK, SRF and SRR series


#### 7.1.1 Operation control function by wireless remote control



##### (1) SRK series



#### Unit display section

Models SRK20, 25, 35, 50, 60ZMX-S



**Models SRK20, 25, 35, 50ZM-S****Model SRK71ZR-S**

## (2) SRF, SRR series

**Operation section****OPERATION MODE select button**

Each time the button is pressed, the mode changes.

**TEMPERATURE button**

This button sets the room temperature.

**HI/ECO button**

This button changes the HIGH POWER/ECONOMY operation. (This function is invalid)

**SILENT button**

This button changes the SILENT operation.

**ON TIMER button**

This button selects ON TIMER operation.

**OFF TIMER button**

This button selects OFF TIMER operation.

**WEEKLY button**

This button switches the WEEKLY TIMER to ON/OFF.

**CLEAN switch**

This switch selects the CLEAN operation.

**SLEEP button**

This button selects SLEEP operation.

**Transmission section****ON/OFF (luminous) button**

Press to start operation, press again to stop.

**FAN SPEED button**

Each time the button is pressed, the fan speed changes.

**AIR FLOW (UP/DOWN) button**

This button changes the air flow (up/down) direction.

**NIGHT SETBACK button**

This button sets NIGHT SETBACK operation.

**SET/Child Lock button**

Use this button to set the timer and Child Lock.

**CANCEL button**

This button cancels the ON timer, OFF timer, and SLEEP operation.

**TIMER button**

This buttons is used for setting the current time and timer function.

**PROGRAM button**

This button sets WEEKLY TIMER.

**ACL switch**

Switch for resetting microcomputer.

**TIME SET UP switch**

This switch is for setting the time.


•The above illustration shows all controls, but in practice only the relevant parts are shown.

**Unit display section****Models SRF25, 35, 50ZMX-S****Unit ON/OFF button**

This button can be used for turning on/off the unit when remote control is not available.

**HI POWER light (green)**

Illuminates during HIGH POWER operation. Blinks during heating preparation.

**AIR SELECTION button**

Use this button to switch between the combination of upper and lower air outlets and upper air outlet.

**AIR OUTLET SELECTION light (green)**

Illuminates during upper air outlet operation.

**Wireless remote control signal receiver****ECONO light (green)**

Illuminates during ECONOMY operation.

**TIMER light (yellow)**




Illuminates during TIMER operation.

**RUN**


①

**RUN (HOT KEEP) light (green)**

- Illuminates during operation.
- Blinks when airflow stops due to the 'HOT KEEP', 'CLEAN operation' and 'operation mode invalid'.



## (3) SRR series

**Unit display section****7.1.2 Operation control function by indoor control****(1) Unit ON/OFF button**

When the wireless remote control batteries become weak, or if the wireless remote control is lost or malfunctioning, this button may be used to turn the unit on and off.

**(a) Operation**

Push the button once to place the unit in the automatic mode. Push it once more to turn the unit off.


**(b) Details of operation**

The unit will go into the automatic mode in which it automatically determines, from indoor temperature (as detected by sensor), whether to go into COOL, DRY or HEAT modes.


Function Operation mode	Indoor temperature setting	Fan speed	Flap/Louver	Timer Switch
COOL	About 24°C	Auto	Auto	Continuous
DRY	About 25°C <sup>(1)</sup>			
HEAT	About 26°C <sup>(1)</sup>			

Notes (1) Model SRK71ZR-S only.

DRY, HEAT: About 24°C

• **Models SRK20, 25, 35, 50, 60ZMX-S**

Unit ON/OFF button




• **Models SRK20, 25, 35, 50ZM-S**

Unit ON/OFF button



**(b) Setting an indoor unit**

- (i) Turn off the power source, and turn it on after 1 minute.
- (ii) Point the wireless remote control that was set according to the procedure described on the underside at the indoor unit and send a signal by pressing the ACL switch on the wireless remote control. Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.
- (iii) Check that the reception buzzer sound "pip" is emitted from the indoor unit. At completion of the setting, the indoor unit emits a buzzer sound "pip".(If no reception tone is emitted, start the setting from the beginning again.)


**• SRK series****• SRF series****• SRR series****(4) Selection of the annual cooling function**

- (a) The annual cooling control is valid from factory default setting.


It is possible to disable by cutting jumper wire (J172 or JA3), or changing the setting of dip switch (SW2-4) on the interface kit (option) PCB if it is connected.

Jumper wire (J172 or JA3)	Interface kit (SC-BIKN-E) SW2-4	Function
Shorted	ON	Enabled factory default setting
Shorted	OFF	Disabled
Open	ON	Disabled
Open	OFF	Disabled

**• Model SRK20, 25, 35, 50, 60ZMX-S**  
**SRF25, 35, 50ZMX-S**




**• Model SRK20, 25, 35, 50ZM-S, 71ZR-S**  
**SRR25, 35, 50, 60ZM-S**



**(b) Content of control**

- (i) If the outdoor air temperature sensor (Tho-A) detects below 5°C, the indoor unit speed is switched to 9th step. (It is not possible to change.)
- (ii) If the outdoor air temperature sensor (Tho-A) detects higher than A°C, the indoor unit speed is changed to the normal control speed.



Model	A
SRR25, 35, 50, 60ZM-S	17
SRK71ZR-S SRF25, 35, 50ZMX-S	7
SRK20, 25, 35, 50, 60ZMX-S SRK20, 25, 35, 50ZM-S	10

**(5) High power operation**

Pressing the HI POWER/ECONO button intensifies the operating power and initiates powerful cooling and heating operation for 15 minutes continuously. The wireless remote control displays and the FAN SPEED display disappears.

- (a) During the HIGH POWER operation, the room temperature is not controlled. When it causes an excessive cooling and heating, press the HI POWER/ECONO button again to cancel the HIGH POWER operation.
- (b) HIGH POWER operation is not available during dehumidifying and the program timer operations.
- (c) When HIGH POWER operation is set after ON TIMER operation, HIGH POWER operation will start from the set time.
- (d) When the following operation are set, HIGH POWER operation will be canceled.
- ① When the HI POWER/ECONO button is pressed again.
  - ② When the operation mode is changed.
  - ③ When it has been 15 minutes since HIGH POWER operation has started.
  - ④ When the 3D AUTO button is pressed. (SRK only)
  - ⑤ When the SILENT button is pressed.
  - ⑥ When the NIGHT SETBACK button is pressed.
- (e) Not operable while the air-conditioner is OFF.
- (f) After HIGH POWER operation, the sound of refrigerant flowing may be heard.

**(6) Economy operation**


Pressing the HI POWER/ECONO button initiate a soft operation with the power suppressed in order to avoid an excessive cooling or heating. The unit operate 1.5°C higher than the setting temperature during cooling or 2.5°C lower than that during heating. The wireless remote control displays ECONO mark and the FAN SPEED display disappears.

- (a) It will go into ECONOMY operation at the next time the air-conditioner runs in the following cases.
- ① When the air-conditioner is stopped by ON/OFF button during ECONOMY operation.
  - ② When the air-conditioner is stopped in SLEEP or OFF TIMER operation during ECONOMY operation.
  - ③ When the operation is retrieved from CLEAN or ALLERGEN CLEAR operation.
- (b) When the following operation are set, ECONOMY operation will be canceled.
- ① When the HI POWER/ECONO button is pressed again.
  - ② When the operation mode is changed DRY to FAN.
- (c) Not operable while the air-conditioner is OFF.
- (d) The setting temperature is adjusted according to the following table.


Mode	Cooling	Heating
Item		
Temperature adjustment	① +0.5	① -1.0
	② +1.0	② -2.0
	③ +1.5 <sup>(1)</sup>	③ -2.5 <sup>(1)</sup>

- ① at the start of operation.
- ② one hour after the start of operation.
- ③ two hours after the start of operation.

Note (1) The figure below shows the SRK71ZR-S only.




**(7) Flap and louver control (SRK and SRF series only)****◆ SRK series**

Control the flap and louver by AIRFLOW  (UP/DOWN) and  (LEFT/RIGHT) button on the wireless remote control.






**(a) Flap**

Each time when you press the AIRFLOW  (UP/DOWN) button the mode changes as follows.








• Angle of flap from horizontal






**Models SRK20, 25, 35, 50, 60ZMX-S**

Remote control display					
COOL , DRY, FAN	Approx. 5°	Approx. 20°	Approx. 35°	Approx. 45°	Approx. 60°
HEAT	Approx. 20°	Approx. 35°	Approx. 45°	Approx. 60°	Approx. 75°

**Models SRK20, 25, 35, 50ZM-S**


Remote control display					
COOL , DRY, FAN	Approx. 10°	Approx. 25°	Approx. 40°	Approx. 50°	Approx. 60°
HEAT	Approx. 25°	Approx. 40°	Approx. 50°	Approx. 60°	Approx. 70°

**Model SRK71ZR-S**






Remote control display					
COOL , DRY, FAN	Approx. 5°	Approx. 20°	Approx. 35°	Approx. 50°	Approx. 70°
HEAT	Approx. 20°	Approx. 35°	Approx. 45°	Approx. 60°	Approx. 70°

**(b) Louver****Models SRK20, 25, 35, 50, 60ZMX-S, 20, 25, 35, 50ZM-S**

Each time when you press the AIRFLOW  (LEFT/RIGHT) button the mode changes as follows.




• Angle of louver

Remote control display					
Center installation	Left Approx. 50°	Left Approx. 20°	Center	Right Approx. 20°	Right Approx. 50°
Right end installation	Left Approx. 50°	Left Approx. 45°	Left Approx. 30°	Center	Right Approx. 20°
Left end installation	Left Approx. 20°	Center	Right Approx. 30°	Right Approx. 45°	Right Approx. 50°

**Model SRK71ZR-S**

Each time when you press the AIR FLOW L/R (LEFT/RIGHT) button the mode changes as follows.



• Angle of louver


Remote control display					
Center installation	Left Approx. 50°	Left Approx. 20°	Center	Right Approx. 20°	Right Approx. 50°

**(c) Swing****(i) Swing flap**

Flap moves in upward and downward directions continuously.

◆ In HEAT operation

◆ In COOL, DRY, FAN operation



Notes (1) Values in ( ) are for the models SRK20, 25, 35, 50ZM-S.

(2) Values in [ ] are for the model SRK71ZR-S.

**(ii) Swing louver**

Louver moves in left and right directions continuously.

**(d) Memory flap (Flap or louver stopped)**

When you press the AIRFLOW (UP/DOWN or LEFT/RIGHT) button once while the flap or louver is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap or louver will automatically be set at this angle when the next operation is started.

**(e) When not operating**


The flap returns to the position of air flow directly below, when operation has stopped.

**◆ SRF series**

Control the flap by AIRFLOW ◆ (UP/DOWN) button on the wireless remote control.

**(a) Flap**

Each time when you press the AIRFLOW ◆ (UP/DOWN) button the mode changes as follows.



• Angle of flap from horizontal


Remote control display					
COOL, DRY, FAN	Approx. 60°	Approx. 50°	Approx. 38°	Approx. 21.5°	Approx. 12°
HEAT	Approx. 44°	Approx. 32°	Approx. 21.5°	Approx. 12°	Approx. 5°

**(b) Swing****(i) Swing flap**

Flap moves in upward and downward directions continuously.

◆ In HEAT operation

◆ In COOL, DRY, FAN operation

**(c) Memory flap (Flap stopped)**


When you press the AIRFLOW button once while the flap is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap will automatically be set at this angle when the next operation is started.

**(d) When not operating**

The flap returns to the position of air flow directly below, when operation has stopped.

**(8) Air outlet selection (SRF series only)****(a) AIR SELECTION button can switch between the combination of upper and lower air outlets and upper air outlet. Not operable while the air conditioner is OFF.**


- (i) Each time the AIR SELECTION button is pressed. The combination of the upper and lower air outlets and the upper air outlet can be switched.
- (ii) When the upper air outlet is selected, AIR OUTLET SELECTION light on the unit display area will light green.

**(b) Auto air outlet selection****(i) COOL, DRY operation**

- 1) In case both lower and upper outlets operation is selected in COOL or DRY operation, both outlets will be kept for sixty minutes after the start or until indoor temperature is below the setting point. And then the air outlet will change to the upper outlet. That state will be maintained until switch is turned off.
- 2) In case both outlets operation with auto fan speed mode is selected, the upper outlet will be kept for ten minutes after the start or until indoor temperature is close to reaching the setting point. And then the air outlet will change to both outlets in order to spread comfort air to every corner.

**(ii) HEAT operation**

- 1) In case both lower and upper outlets operation with auto fan speed mode is selected, the lower outlet will be kept for twenty minutes after the start or until indoor temperature is close to reaching the setting point. And then the air outlet will change to both outlets. That state will be maintained until the switch is turned off.
- 2) Automatic adjustment of lower air outlet direction prevents stirring up of warm air and keeps optimum comfort at floor level.



**(9) 3D auto operation (SRK series only)**

Control the flap and louver by 3D AUTO button on the wireless remote control.

Air flow selection and air flow direction are automatically controlled, allowing the entire indoor to efficiently conditioned.

**(a) During cooling and heating (Including auto cooling and heating)****(i) Air flow selection is determined according to room temperature and setting temperature.**

Operation mode	Air flow selection					
	AUTO		HI	MED	LO	ULO
Cooling	Room temp. – Setting temp. >5°C		HI	MED	LO	ULO
	HIGH POWER					
Heating	Setting temp. – Room temp. >5°C					
	HIGH POWER					

**(ii) Air flow direction is controlled according to the indoor temperature and setting temperature.****1) When 3D auto operation starts**

	Cooling	Heating
Flap	Up/down swing	
Louver	Wide (fixed)	Center (fixed)

**2) When Room temp. – Setting temp. is  $\leq 5^{\circ}\text{C}$  during cooling and when Setting temp. – Room temp. is  $\leq 5^{\circ}\text{C}$  during heating, the system switches to the following air flow direction control. After the louver swings left and right symmetrically for 3 cycles, control is switched to the control in 3).**

	Cooling	Heating
Flap	Horizontal blowing (Fixed)	Slant forwardl blowing (Fixed)
Louver	Left/right swing	

**3) After the flap swings for 5 cycles, control is switched to the control in 4).**

	Cooling	Heating
Flap	Up/down swing	
Louver	Center (Fixed)	

**4) For 5 minutes, the following air flow direction control is carried out.**

	Cooling	Heating
Flap	Horizontal blowing (Fixed)	Slant forwardl blowing (Fixed)
Louver	Wide (Fixed)	

**5) After 5 minutes have passed, the air flow direction is determined according to the indoor temperature and setting temperature.**

Operation mode	Air flow direction control		
Cooling	Room temp. – Setting temp. $\leq 2^{\circ}\text{C}$	$2^{\circ}\text{C} < \text{Room temp. – Setting temp.} \leq 5^{\circ}\text{C}$	Room temp. – Setting temp. $> 5^{\circ}\text{C}$
	The control in 4) continues.	Control returns to the control in 2).	Control returns to the control in 1).
Heating	Setting temp. – Room temp. $\leq 2^{\circ}\text{C}$	$2^{\circ}\text{C} < \text{Setting temp. – Room temp.} \leq 5^{\circ}\text{C}$	Setting temp. – Room temp. $> 5^{\circ}\text{C}$
	The control in 4) continues.	Control returns to the control in 2).	Control returns to the control in 1).

**(b) During dehumidifying operation (including auto dehumidifying operation)**

Flap	Horizontal blowing (Fixed)
Louver	Wide (Fixed)

## (10) Timer operation

### (a) Comfortable timer setting (ON timer)

If the timer is set at ON when the operation select switch is set at the cooling or heating, or the cooling or heating in auto mode operation is selected, the comfortable timer starts and determines the starting time of next operation based on the initial value of 15 minutes and the relationship between the room temperature at the setting time and the setting temperature.

### (b) Sleep timer operation

Pressing the SLEEP button causes the temperature to be controlled with respect to the set temperature.

### (c) OFF timer operation

The OFF timer can be set at a specific time (in 10-minute units) within a 24-hour period.

### (d) Weekly timer operation

Timer operation (ON timer, OFF timer) can be set up to 4 times a day for each weekday.

## (11) Night setback

As “Night setback” signal is received from the wireless remote control, the heating operation starts with the setting temperature at 10°C.

## (12) Installation location setting (SRK series only)

When the indoor unit is installed at the end of a room, control the air flow direction so that it is not toward the side walls. If you set the wireless remote control installation position, keep it so that the air flow is within the range shown in the following figure.

### (a) Setting

#### (i) If the air-conditioning unit is running, press the ON/OFF button to stop.

The installation location setting cannot be made while the unit is running.


#### (ii) Press the AIR FLOW (UP/DOWN) button and the AIRFLOW (LEFT/RIGHT) button together for 5 seconds or more.

The installation location display illuminates.

#### (iii) Setting the air-conditioning installation location.

Press the AIR FLOW (LEFT/RIGHT) button and adjust to the desired location.


Each time the AIR FLOW (LEFT/RIGHT) button is pressed, the indicator is switched in the order of:



#### (iv) Press the ON/OFF button.

The air-conditioner's installation location is set.

Press within 60 seconds of setting the installation location (while the installation location setting display illuminates).




**(13) Determining the operating mode**

The cooling and heating operating modes are the wireless remote control mode that have been previously determined.

If a mode differing from these is selected after this, the selected mode will appear in the display of the wireless remote control, but only the fan will operate.

Example	First operation			Second operation			Notes
	Selected mode	Remote control display	Operation	Selected mode	Remote control display	Operation	
1	Cooling	COOL	COOL	Heating	HEAT	FAN <sup>(1)</sup>	• Different mode is only fan operation.
2	Heating	HEAT	HEAT	Cooling	COOL	FAN	

Note (1) If the display shows heating and the operation is fan, Hot keep will operate.

**Example of operating pattern****(14) Drain pump abnormalities detection (SRR series only)**

- (a) Drain motor (DM) is operated during the cooling or dehumidifying mode operations and simultaneously with the compressor ON. The DM continues to operate for 5 minutes after the operation stop, anomalous stop, thermostat stop or when it was switched from the COOL and DRY operations to the fan or HEAT operation.

	Indoor unit operation mode				
	Stop <sup>(1)</sup>	COOL	DRY	FAN <sup>(2)</sup>	HEAT
Compressor ON	Control A				
Compressor OFF					

Note (1) Including the stop from the cooling, dehumidifying, fan and heating, and the anomalous stop  
 (2) Including the "FAN" operation according to the mismatch of operation modes

**(i) Control A**

- 1) If the float switch detects any anomalous draining condition, the unit stops with the anomalous stop and the drain pump starts. After detecting the anomalous condition, the drain motor continues to be ON.
- 2) It keeps operating while the float switch is detecting the anomalous condition.

**(ii) Control B**

If the float switch detects any anomalous drain condition, the drain motor is turned ON for 5 minutes, and at 10 seconds after the drain motor OFF it checks the float switch. If it is normal, the unit is stopped under the normal mode or, if there is any anomalous condition, displayed by the flashing of display lights and the drain motor is turned ON. (The ON condition is maintained during the drain detection.)


**(15) Outline of dry (dehumidifying) operation****(a) Purpose of DRY mode**

The purpose is "Dehumidifying", and not to control the humidity to the target condition.

Indoor/outdoor unit control the operation condition to reduce the humidity, and also prevent over cooling.

**(b) Outline of control**

- (i) Indoor unit fan speed and compressor are controlled by the area which is selected by the temperature difference.




- (ii) The indoor unit check the current area by every 5 minutes, and operate by the next checking.

**(c) Other**

When the outdoor air temperature and room temperature is low for cooling operation, indoor unit can not operate in cooling, and dehumidifying. In this case, the units operate in heating to rise the room temperature, and after that start dehumidifying operation.

**(16) Outline of automatic operation****(a) Determination of operation mode**

The unit checks the indoor air temperature and the outdoor air temperature, determines the operation mode, and then begins in the automatic operation.



- (b) The unit checks the temperature every hour after the start of operation and, if the result of check is not same as the previous operation mode, changes the operation mode.
- (i) If the setting temperature is changed with the wireless remote control, the operation mode is judged immediately.
- (ii) When both the indoor and the outdoor air temperatures are in the range "A", cooling or heating is switched depending on the difference between the setting temperature and the indoor air temperature.
- (iii) When the operation mode has been judged following the change of setting temperature with the wireless remote control, the hourly judgment of operation mode is cancelled.
- (c) When the unit is started again within one hour after the stop of automatic operation or when the automatic operation is selected during heating, cooling or dehumidifying operation, the unit is operated in the previous operation mode.
- (d) Setting temperature can be adjusted within the following range. There is the relationship as shown below between the signals of the wireless remote control and the setting temperature.

**Models SRK-ZMX-S, ZM-S, SRF, SRR**

Unit : °C

		Signals of wireless remote control (Display)												
		-6	-5	-4	-3	-2	-1	±0	+1	+2	+3	+4	+5	+6
Setting temperature	Cooling	18	19	20	21	22	23	24	25	26	27	28	29	30
	Dehumidifying	19	20	21	22	23	24	25	26	27	28	29	30	31
	Heating	20	21	22	23	24	25	26	27	28	29	30	31	32

## Model SRK71ZR-S

Unit : °C

		Signals of wireless remote control (Display)												
		-6	-5	-4	-3	-2	-1	±0	+1	+2	+3	+4	+5	+6
Setting temperature	Cooling													
	Dehumidifying	18	19	20	21	22	23	24	25	26	27	28	29	30
	Heating													

- (e) When the unit is operated automatically with the wired remote control connected, the cooling operation is controlled according to the display temperatures while the setting temperature is compensated by +1°C during dehumidifying or by +2°C during heating. (Models SRK-ZMX-S, ZM-S, SRF, SRR only)

**(17) Operation permission/prohibition control**

The air-conditioner operation is controlled by releasing the jumper wire (J3) on the indoor PCB and inputting the external signal into the CnT.

Note (1) Please install the separately-sold Interface kit (SC-BIK-E). Remove the jumper wire (J1 or J3) from the Interface kit circuit board.

- (a) The operation mode is switched over between permission and prohibition by releasing the jumper wire (J3) on the indoor PCB.**

When the jumper wire (J3) is short circuited	When the jumper wire (J3) is released
Normal operation is enable (when shipping) When CnT input is set to ON, the operation starts and if the input is set to OFF, the operation stops. For the CnT and remote control inputs, the input which is activated later has priority and can start and stop the operation.	Permission / Prohibition mode When CnT input is set to ON, the operation mode is changed to permission and if input is set to OFF the operation is prohibited.

- (b) In the case of CnT input ON (Operation permission)**

- (i) The air-conditioner can be operated or stopped by the wired remote control signal.  
(When the "CENTER" mode is set, the operation can be controlled only by the center input.)
- (ii) When the CnT input is changed from OFF to ON, the air-conditioner operation mode is changed depending on the status of the jumper wire (J1) on the indoor control board.

When the jumper wire (J1) is short circuited	When the jumper wire (J1) is released
The signal (a) above starts the air-conditioner. (Shipping status)	When the CnT input is set to ON, the air-conditioner starts operation. After that, the operation of the air-conditioner depends on (a) above. (Local status)

- (c) In the case of CnT input OFF (Operation prohibition)**

- (i) Air-conditioner is unable to control the operation/stop, ect. in accordance with signals from the wired remote control signal wire.
- (ii) Air-conditioner stops as it changes CnT input ON → OFF.

**(18) External control (remote display) /control of input signal**

- (a) External control (remote display) output**

Following output connectors (CnT) are provided on the printed circuit board of indoor unit.

Note (1) Please install the separately-sold Interface kit (SC-BIK-E). The output connector (CnT) is located on the circuit board of the Interface kit.

- **Operation output:** Power to engage DC 12V relay (provided by the customer) is outputted during operation.
- **Heating output:** Power to engage DC 12V relay (provided by the customer) is outputted during the heating operation.
- **Compressor OPERATION output:** Power to engage DC 12V relay (provided by the customer) is outputted while the compressor is operating.
- **MALFUNCTION output:** When any error occurs, the power to engage DC 12V relay (provided by the customer) is outputted.


**(b) Control of input signal**

Control of input signal (switch input, timer input) connectors (CnT) are provided on the printed circuit board of indoor unit. However, when the operation of air-conditioner is under the “CENTER” mode, the wired remote control by CnT is invalid.

**(i) Level input**

If the factory settings (Jumper wire J1 EXTERNAL INPUT on the PCB of indoor unit) are set, or “LEVEL INPUT” is selected in the wired remote control’s indoor unit settings.

- 1) Input signal to CnT OFF → ON - - - - - Air-conditioner ON
- 2) Input signal to CnT ON → OFF - - - - - Air-conditioner OFF




Note (1) The ON with the \* mark indicates an ON operation using the wired remote control, etc.

**(ii) Pulse input**

When Jumper wire J1 on the PCB of indoor unit is cut at the field or “PULSE INPUT” is selected in the wired remote control’s indoor unit settings.

Input signal to CnT becomes valid at OFF → ON only and the motion of air-conditioner [ON/OFF] is inverted.

**(19) Hot keep operation**

If the hot keep operation is selected during the heating operation, the indoor fan is controlled based on the temperature of the indoor heat exchanger (Th2) to prevent blowing of cool wind.


However, if the fan speed setting is HI and room temperature is 19°C or higher, this control is not executed.

**(20) Frost prevention control (During cooling or dehumidifying)****(a) Operating conditions**

- (i) Indoor heat exchanger temperature (Th2) is lower than 2.5°C.
- (ii) 8 minutes after reaching the compressor command speed except 0 rps.

**(b) Detail of anti-frost operation**

Operation mode	Protective control	Reset
Item		
Compressor operation	Forced outage	Operation instruction
Indoor fan	Depends on operation mode	Depends on operation mode



- (c) **Reset condition:** The indoor heat exchanger temperature (Th2) is 8°C or higher.

**(21) Heating high pressure control**

(a) **Start condition:** When the indoor heat exchanger temperature (Th2) has become higher than the start temperature for 1 minute continuously.

(b) **Contents of control:** Compressor stop

Room temperature (Th1) \ Item	Release temperature	Start temperature
$Th1 \leq 24^{\circ}\text{C}$	48.5°C	62°C
$24^{\circ}\text{C} < Th1 \leq 27^{\circ}\text{C}$	47.5°C (48.5°C)	61°C
$27^{\circ}\text{C} < Th1$	46.5°C (48.5°C)	60°C

Note (1) Values in ( ) are for the model SRK71ZR-S.

(c) **Release condition:** When the indoor heat exchanger temperature (Th2) has become lower than the release temperature.

**(22) Heating overload protective control**

(a) **Operating conditions :** When the outdoor air temperature (Tho-A) is 17°C or higher continues for 30 seconds while the compressor command speed other than 0 rps.

(b) **Detail of operation :** The indoor fan is stepped up by 1 speed step.

Model	Fan speed	Upper limit
SRK20-35ZMX-S		8th
SRK50, 60ZMX-S		9th
SRK20-50ZM-S		
SRF25-50ZMX-S		
SRR25-60ZM-S		10th
SRK71ZR-S		

(c) **Reset condition :** The outdoor air temperature (Tho-A) is lower than 16°C.

**(23) Indoor fan motor protection**

When the air-conditioner is operating and the indoor fan motor is turned ON, if the indoor fan motor has operated at 300 (SRF:150)  $\text{min}^{-1}$  or under for more than 30 seconds, the unit enters first in the stop mode and then stops the entire system.

## 7.2 FDTC, FDEN and FDUM series

### 7.2.1 Remote control (Option parts)


#### (1) Wired remote control

##### Model RC-E5

The figure below shows the remote control with the cover opened. Note that all the items that may be displayed in the liquid crystal display area are shown in the figure for the sake of explanation

Characters displayed with dots in the liquid crystal display area are abbreviated.


The figure below shows the remote control with the cover opened.




\* All displays are described in the liquid crystal display for explanation.

## Model RC-EX1A

All icons are shown for the sake of explanation.




Touch panel system, which is operated by tapping the LCD screen with a finger, is employed for any operations other than the ① Run/Stop, ② High power and ③ Energy-saving switches.




## (2) Wireless remote control

### Indication section



### Operation section



\* All displays are described in the liquid crystal display for explanation

## 7.2.2 Operation control function by the wired remote control

### • Model RC-E5

#### (1) Switching sequence of the operation mode switches of remote control



#### (2) [CPU reset]

This functions when “CHECK” and “GRILL” buttons on the remote control are pressed simultaneously. Operation is same as that of the power source reset.

#### (3) [Power failure compensation function]...Electric power source failure

- This becomes effective if “Power failure compensation effective” is selected with the setting of remote control function.
- Since it memorizes always the condition of remote control, it starts operation according to the contents of memory no sooner than normal state is recovered after the power failure. Although the auto swing stop position and the timer mode are cancelled, the weekly timer setting is restored with the holiday setting for all weekdays.

After recovering from the power failure, it readjusts the clock and resets the holiday setting for each weekday so that the setting of weekly timer becomes effective.

- Content memorized with the power failure compensation are as follows.

Note (1) Items⑥, ⑦ and ⑧ are memorized regardless whether the power failure compensation is effective or not while the setting of silent mode is cancelled regardless whether the power failure compensation is effective or not.

##### ① At power failure – Operating/stopped

If it had been operating under the off timer mode, sleep timer mode, the state of stop is memorized. (Although the timer mode is cancelled at the recovery from power failure, the setting of weekly timer is changed to the holiday setting for all weekdays.)

##### ② Operation mode

##### ③ Airflow volume mode

##### ④ Room temperature setting

##### ⑤ Louver auto swing/stop


However, the stop position (4-position) is cancelled so that it returns to Position (1).

##### ⑥ “Remote control function items” which have been set with the remote control function setting (“Indoor function items” are saved in the memory of indoor unit.)

##### ⑦ Upper limit value and lower limit value which have been set with the temperature setting control


##### ⑧ Sleep timer and weekly timer settings (Other timer settings are not memorized.)

#### [Parts layout on remote control PCB]



#### Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Set SW1 to “Slave” for the slave remote control. It was factory set to “Master” for shipment.

Note: The setting “Remote control thermistor enabled” is only selectable with the master remote control in the position where you want to check room temperature.

The air-conditioner operation follows the last operation of the remote control regardless of the master / slave setting of it.

#### Caution

When using multiple remote controls, the following displays or settings cannot be done with the slave remote control. It is available only with the master remote control.


- ① Lower position setting (set upper or lower limit of swinging range)
- ② Setting indoor unit functions
- ③ Setting temperature range
- ④ Operation data display
- ⑤ Error data display
- ⑥ Silent mode setting
- ⑦ Test operation of drain pump
- ⑧ Remote control sensor setting

• Model RC-EX1A

(1) Switching sequence of the operation mode switches of remote control


- Tap the change operation mode button on the TOP screen.
- When the change operation mode screen is displayed, tap the button of desired mode.
- When the operation mode is selected, the display returns to the TOP screen.

Icons displayed have the following meanings.



Notes(1) Operation modes which cannot be selected depending on combinations of IU and OU are not displayed.

- When the Auto is selected, the cooling and heating switching operation is performed automatically according to indoor and outdoor temperatures.



(2) CPU reset

Reset CPU from the remote control as follows.

- Tap the **Menu** button on the TOP screen.
- Main menu screen is displayed.**  
Tap the "Service & Maintenance" on the menu screen.
- Service & maintenance menus are displayed.**
- Display the service password input screen.**  
Enter the service password (4-digit number).
- Service & maintenance menu 1**
- Service & maintenance menu 2**
- Special settings**  
CPU reset : Microcomputers of IU and OU connected are reset (State of restoration after power failure).
- CPU reset**  
All microcomputers on the R/C operated, other R/Cs, IUs and OUs are reset (State of restoration after power failure). Tap [Yes] to reset CPU

(3) Power failure compensation function (Electric power source failure)

Enable the Auto-restart function from the remote control as follows.

- Tap the **Menu** button on the TOP screen.
- Main menu screen is displayed.**  
Tap the "Service & Maintenance" on the menu screen.
- Service & maintenance menus are displayed.**
- Display the service password input screen.**  
Enter the service password (4-digit number).
- R/C setting menu 1**
- R/C setting menu 2**
- R/C setting menu 3**
- Auto-restart**  
Set the state of operation to be started when the power source is restored after a power failure.  
  
Enable : It returns to the state before the power source failure as soon as the power is restored (After the end of the primary control at the power on).  
Disable : It stops after the restoration of power source, regardless of the state of operation before the power failure.

- Since it memorizes always the condition of remote control, it starts operation according to the contents of memory no sooner than normal state is recovered after the power failure. Although the auto swing stop position and the timer mode are cancelled, the weekly timer setting is restored with the holiday setting for all weekdays.

After recovering from the power failure, it readjusts the clock and resets the holiday setting for each weekday so that the setting of weekly timer becomes effective.

- Content memorized with the power failure compensation are as follows.

Note (1) Items (f), (g) and (h) are memorized regardless whether the power failure compensation is effective or not while the setting of silent mode is cancelled regardless whether the power failure compensation is effective or not.

- (a) At power failure – Operating/stopped

If it had been operating under the off timer mode, sleep timer mode, the state of stop is memorized. (Although the timer mode is cancelled at the recovery from power failure, the setting of weekly timer is changed to the holiday setting for all weekdays.)

- (b) Operation mode

- (c) Airflow volume mode

- (d) Room temperature setting

- (e) Louver auto swing/stop

However, the stop position (4-position) is cancelled so that it returns to Position (1).

- (f) “Remote control function items” which have been set with the remote control function setting (“Indoor function items” are saved in the memory of indoor unit.)


- (g) Upper limit value and lower limit value which have been set with the temperature setting control

- (h) Sleep timer and weekly timer settings (Other timer settings are not memorized.)

## 7.2.3 Operation control function by the indoor control

### (1) Auto operation


- (a) If "Auto" mode is selected by the remote control, the heating and the cooling are automatically switched according to the difference between outdoor air temperature and setting temperature and the difference between setting temperature and return air temperature. (When the switching of cooling mode ↔ heating mode takes place within 3 minutes, the compressor does not operate for 3 minutes by the control of 3-minute timer.) This will facilitate the cooling/heating switching operation in intermediate seasons and the adaptation to unmanned operation at stores, etc (ATM corner of bank).



Notes (1) Temperature range of switching cooling/heating mode can be changed by RC-EX1A from  $\pm 1.0 \sim \pm 4.0$ .

- (2) Room temperature control during auto cooling/auto heating is performed according to the room temperature setting temperature. (DIFF:  $\pm 1$  deg)


- (3) If the indoor heat exchanger temperature rises to 59°C or higher during heating operation, it is switched automatically to cooling operation. In addition, for 1 hour after this switching, the heating operation is not performed, regardless of the temperature shown at right.



- (b) The following automatic controls are performed other than (a) above.


- (i) Cooling or heating operation mode is judged according to the conditions of the "Judgment based on Setting temperature + Cooling select temperature and Indoor return air temperature" and the "Judgment based on Outdoor temperature".

- 1) In "Setting temperature - Cooling select temperature < Indoor return air temperature" and "Outdoor temperature/Cooling < Outdoor return air temperature" ⇒ Operation mode: Cooling
- 2) "Setting temperature + Heating select temperature > Indoor return air temperature" and "Outdoor temperature/Heating > Outdoor air temperature" ⇒ Operation mode: Heating
- 3) The outdoor air temperature of the above judgment conditions is sampled at every 10 minutes.
- 4) In the range where the above cooling and heating zones are overlapped ⇒ Forced thermostat OFF



(ii) Regardless of the setting temperature, the cooling or heating operation mode is judged according to the "Judgment based on Room temperature/Cooling or Heating and Outdoor temperature/Cooling or Heating".

- 1) In case of "Room temperature/Cooling < Indoor return air temperature" and "Outdoor temperature/Cooling < Outdoor air temperature" ⇒ Operation mode: Cooling
- 2) In case of "Room temperature/Heating > Indoor return air temperature" and "Outdoor temperature /Heating > Outdoor air temperature" ⇒ Operation mode: Heating
- 3) The outdoor air temperature of the above judgment conditions is sampled at every 10 minutes.
- 4) In the range where the above cooling and heating zones are overlapped ⇒ Forced thermostat OFF



## (2) Operations of functional items during cooling/heating

Operation Functional item	Cooling		Fan	Heating			Dehumidifying
	Thermostat ON	Thermostat OFF		Thermostat ON	Thermostat OFF	Hot start (Defrost)	
Compressor	○	×	×	○	×	○	○/×
4-way valve	×	×	×	○	○	○(×)	×
Outdoor unit fan	○	×	×	○	×	○(×)	○/×
Indoor unit fan	○	○	○	○/×	○/×	○/×	○/×
Drain pump <sup>(3)</sup>	○	× <sup>(2)</sup>	× <sup>(2)</sup>	○/× <sup>(2)</sup>			Thermostat ON: ○ Thermostat OFF: × <sup>(2)</sup>

Note (1) ○: Operation ×: Stop ○/×: Turned ON/OFF by the control other than the room temperature control.

(2) ON during the drain motor delay control.

(3) Drain pump ON setting may be selected with the indoor unit function setting of the wired remote control.

## (3) Dehumidifying operation

Return air temperature thermistor [ThI-A (by the remote control when the remote control thermistor is enabled)] controls the indoor temperature environment simultaneously.

- (a) Operation is started in the cooling mode. When the difference between the return air temperature and the setting temperature is 2°C or less, the indoor unit fan tap is brought down by one tap. That tap is retained for 3 minutes after changing the indoor unit fan tap.
- (b) If the return air temperature exceeds the setting temperature by 3°C during dehumidifying operation, the indoor unit fan tap is raised. That tap is retained for 3 minutes after changing the indoor unit fan tap.
- (c) If the thermostat OFF is established during the above control, the indoor unit fan tap at the thermostat ON is retained so far as the thermostat is turned OFF.

**(4) Timer operation****(a) RC-EX1A****(i) Sleep timer**

Set the time from the start to stop of operation. The time can be selected in the range from 30 to 240 minutes (in the unit of 10-minute).

Note (1) Enable the "Sleep timer" setting from the remote control. If the setting is enabled, the timer operates at every time.

**(ii) Set OFF timer by hour**

Set the time to stop the unit after operation, in the range from 1 to 12 hours (in the unit of hour).

**(iii) Set ON timer by hour**

Set the time to start the unit after the stop of operation, in the range from 1 to 12 hours (in the unit of hour). It is allowed also to set simultaneously the indoor temperature, operation mode, air flow rate and warm-up enabled/disabled.

**(iv) Set ON timer by clock**

Set the time to start operation. The time can be set in the unit of 5-minute. This setting can be activated only once or at every time. It is allowed also to set simultaneously the indoor temperature, operation mode, air flow rate and warm-up enabled/disabled.

Note (1) It is necessary to set the clock to use this timer.

**(v) Set OFF timer by clock**

Set the time to stop operation. The time can be set in the unit of 5-minute. This setting can be activated only once or at every time.

Note (1) It is necessary to set the clock to use this timer.

**(vi) Weekly timer**

Set the ON or OFF timer for a week. Up to 8 patterns can be set for a day. The day-off setting is provided for holidays and non-business days.

Note (1) It is necessary to set the clock to use the weekly timer.

**(vii) Combination of patterns which can be set for the timer operations**

	Sleep time	Set OFF timer by hour	Set ON timer by hour	Set OFF timer by clock	Set ON timer by clock	Weekly timer
Sleep time		×	×	○	○	○
Set OFF timer by hour	×		×	×	×	×
Set ON timer by hour	×	×		×	×	×
Set OFF timer by clock	○	×	×		○	×
Set ON timer by clock	○	×	×	○		×
Weekly timer	○	×	×	×	×	

Note (1) ○: Allowed ×: Not

**(b) RC-E5****(i) Sleep timer**

Set the duration of time from the present to the time to turn off the air-conditioner.

It can be selected from 10 steps in the range from "OFF 1 hour later" to "OFF 10 hours later". After the sleep timer setting, the remaining time is displayed with progress of time in the unit of hour.

**(ii) OFF timer**

Time to turn OFF the air-conditioner can be set in the unit of 10 minutes.

**(iii) ON timer**

Time to turn ON the air-conditioner can be set. Indoor temperature can be set simultaneously.

**(iv) Weekly timer**

Timer operation (ON timer, OFF timer) can be set up to 4 times a day for each weekday.

**(v) Timer operations which can be set in combination**

Item	Item	Timer	OFF timer	ON timer	Weekly timer
Timer			×	○	×
OFF timer	×			○	×
ON timer	○		○		×
Weekly timer	×	×	×	×	

Note (1) ○: Allowed ×: Not

(2) Since the ON timer, sleep timer and OFF timer are set in parallel, when the times to turn ON and OFF the air-conditioner are duplicated, the setting of the OFF timer has priority.

**(5) Remote control display during the operation stop**

When the operation is stopped (the power source is turned ON), it displays preferentially the “Room temperature”, “Center/Remote”, “Filter sign”, “Inspection” and “Timer operation”.

**(6) Hot start (Cold draft prevention at heating)****(a) Operating conditions**

When either one of following conditions is satisfied, the hot start control is performed.

- (i) From stop to heating operation
- (ii) From cooling to heating operation
- (iii) From heating thermostat OFF to ON
- (iv) After completing the defrost control (only on units with thermostat ON)

**(b) Contents of operation****(i) Indoor fan motor control at hot start**

- 1) Within 7 minutes after starting heating operation, the fan mode is determined depending on the condition of thermostat (fan control with heating thermostat OFF).

**a) Thermostat OFF**

- i) Operates according to the fan control setting at heating thermostat OFF.
- ii) Even if it changes from thermostat OFF to ON, the fan continues to operate with the fan control at thermostat OFF till the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher.
- iii) When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher, the fan operates with the set airflow volume.

**b) Thermostat ON**

- i) When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 25°C or lower, the fan is turned OFF and does not operate.
- ii) When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 25°C or higher, the fan operates with the fan control at heating thermostat OFF.
- iii) When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher, the fan operates with the set airflow volume.
- c) If the fan control at heating thermostat OFF is set at the “Set airflow volume” (from the remote control), the fan operates with the set airflow volume regardless of the thermostat ON/OFF.
- 2) Once the fan motor is changed from OFF to ON during the thermostat ON, the indoor fan motor is not turned OFF even if the heat exchanger thermistor detects lower than 25°C.

Note (1) When the defrost control signal is received, it complies with the fan control during defrost operation.

- 3) Once the hot start is completed, it will not restart even if the temperature on the heat exchanger thermistor drops.

(ii) During the hot start, the louver is kept at the horizontal position.

(iii) When the fan motor is turned OFF for 7 minutes continuously after defrosting, the fan motor is turned ON regardless of the temperatures detected with the indoor heat exchanger thermistors (ThI-R1, R2).

**(c) Ending conditions**

- (i) If one of following conditions is satisfied during the hot start control, this control is terminated, and the fan is operated with the set airflow volume.
  - 1) Heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher.
  - 2) It has elapsed 7 minutes after starting the hot start control.

**(7) Hot keep**

Hot keep control is performed at the start of the defrost control.

**(a) Control**

- (i) When the indoor heat exchanger temperature (detected with ThI-R1 or R2) drops to 35°C or lower, the speed of indoor fan is changed to the lower tap at each setting.
- (ii) During the hot keep, the louver is kept at the horizontal position.

**(b) Ending condition**

When the indoor fan is at the lower tap at each setting, it returns to the set airflow volume as the indoor heat exchanger temperature rises to 45°C or higher.

## (8) Auto swing control

### (a) RC-EX1A

#### (i) Louver control

- 1) To operate the swing louver when the air-conditioner is operating, press the “Direction” button on the TOP screen of remote control. The wind direction select screen will be displayed.
- 2) To swing the louver, touch the “Auto swing” button. The lover will move up and down. To fix the swing louver at a position, touch one of [1] - [4] buttons. The swing lover will stop at the selected position.
- 3) Louver operation at the power on with a unit having the louver 4-position control function  
The louver swings one time automatically (without operating the remote control) at the power on.  
This allows the microcomputer recognizing and inputting the louver motor (LM) position.

#### (ii) Automatic louver level setting during heating

At the hot start and the heating thermostat OFF, regardless whether the auto swing switch is operated or not (auto swing or louver stop), the louver takes the level position (in order to prevent blowing of cool wind). The louver position display LCD continues to show the display which has been shown before entering this control.

#### (iii) Louver free stop control

If you touch the “Menu” → “Next” → “R/C settings” buttons one after another on the TOP screen of remote control, the “Flap control” screen is displayed. If the free stop is selected on this screen, the louver motor stops upon receipt of the stop signal from the remote control. If the auto swing signal is received from the remote control, the auto swing will start from the position before the stop.

### (b) RC-E5

#### (i) Louver control

- 1) Press the “LOUVER” button to operate the swing louver when the air-conditioner is operating.  
“SWING ㄣ” is displayed for 3 seconds and then the swing louver moves up and down continuously.
- 2) To fix the swing louver at a position, press one time the “LOUVER” button while the swing louver is moving so that four stop positions are displayed one after another per second.  
When a desired stop position is displayed, press the “LOUVER” button again. The display stops, changes to show the “STOP 1 ㄣ” for 5 seconds and then the swing louver stops.
- 3) Louver operation at the power on with a unit having the louver 4-position control function  
The louver swings one time automatically (without operating the remote control) at the power on.  
This allows inputting the louver motor (LM) position, which is necessary for the microcomputer to recognize the louver position.

Note (1) If you press the “LOUVER” button, the swing motion is displayed on the louver position LCD for 10 second. The display changes to the “SWING ㄣ” display 3 seconds later.

#### (ii) Automatic louver level setting during heating

At the hot start with the heating thermostat OFF, regardless whether the auto swing switch is operated or not (auto swing or louver stop), the louver takes the level position (In order to prevent the cold start). The louver position display LCD continues to show the display which has been shown before entering this control.


#### (iii) Louver-free stop control

When the louver-free stop has been selected with the indoor function of wired remote control “ㄣ POSITION”, the louver motor stops when it receives the stop signal from the remote control. If the auto swing signal is received from the remote control, the auto swing will start from the position where it was before the stop.

Note (1) When the indoor function of wired remote control “ㄣ POSITION” has been switched, switch also the remote control function “ㄣ POSITION” in the same way.

**(9) Thermostat operation****(a) Cooling**


- (i) Thermostat is operated with the room temperature control.
- (ii) Thermostat is turned ON or OFF relative to the setting room temperature as shown below.



- (iii) Thermostat is turned ON when the room temperature is in the range of  $-1 < \text{Setting temperature} < +1$  at the start of cooling operation (including from heating to cooling).

**(b) Heating**

- (i) Thermostat is operated with the room temperature control.
- (ii) Thermostat is turned ON or OFF relative to the setting room temperature as shown below.



- (iii) Thermostat is turned ON when the room temperature is in the range of  $-1 < \text{Setting point} < +1$  at the start of cooling operation (including from cooling to heating).

**(c) Fan control during heating thermostat OFF**

- (i) Following fan controls during the heating thermostat OFF can be selected with the indoor function setting of the wired remote control.
  - ① Low fan speed (Factory default), ② Set fan speed, ③ Intermittence, ④ Fan OFF
- (ii) When the "Low fan speed (Factory default)" is selected, the following taps are used for the indoor fans.
  - For AC motor : Lo tap
  - For DC motor : ULo tap
- (iii) When the "Set fan speed" is selected, it is operated with the set fan speed also in the thermostat OFF condition.
- (iv) If the "Intermittence" is selected, following controls are performed:
  - 1) If the thermostat is turned OFF during the heating operation, the indoor unit fan motor stops.
  - 2) Indoor fan OFF is fixed for 5 minutes. After the 5 minutes, the indoor fan is operated at Lo or ULo for 2 minutes. In the meantime the louver is controlled at level.
  - 3) After operating at Lo or ULo for 2 minutes, the indoor fan moves to the state of 1) above.
  - 4) If the thermostat is turned ON, it moves to the hot start control.
  - 5) When the heating thermostat is turned OFF, the remote control displays the temperature detected at the fan stop and revises the temperature later when the indoor fan changes from Lo or ULo to stop. The remote control uses the operation data display function to display temperatures and updates values of temperature even when the indoor fan is turned OFF.
  - 6) When the defrosting starts while the heating thermostat is turned OFF or the thermostat is turned OFF during defrosting, the indoor fan is turned OFF. (Hot keep or hot start control takes priority.) However, the suction temperature is updated at every 7-minute.
  - 7) When the heating thermostat is turned ON or the operation is changed to another mode (including stop), this control is stopped immediately, and the operating condition is restored.
- (v) When the "Fan OFF" is selected, the fan on the indoor unit of which the thermostat has been turned OFF, is turned OFF. The same occurs also when the remote control sensor is effective.

**(d) Fan control during cooling thermostat OFF**

- (i) Following fan controls during the cooling thermostat OFF can be selected with the indoor function setting of the wired remote control.
  - ① Low fan speed, ② Set fan speed (Factory default), ③ Intermittence, ④ Fan OFF
- (ii) When the “Low fan speed” is selected, the following taps are used for the indoor fans.
  - For AC motor : Lo tap
  - For DC motor : ULo tap
- (iii) When the “Set fan speed” is selected, it is operated with the set fan speed also in the thermostat OFF condition.
- (iv) If the “Intermittence” is selected, following controls are performed:
  - 1) If the thermostat is turned OFF during the cooling operation, the indoor unit fan motor stops.
  - 2) Indoor fan OFF is fixed for 5 minutes. After the 5 minutes, the indoor fan is operated at Lo or ULo for 2 minutes.
  - 3) After operating at Lo or ULo for 2 minutes, the indoor fan moves to the state of 1) above.
  - 4) If the thermostat is turned ON, the fan starts operation at set fan speed.
  - 5) When the cooling thermostat is turned OFF, the remote control displays the temperature detected at the fan stop and revises the temperature later when the indoor fan changes from Lo or ULo to stop.  
By using operation data display function at remote control, the temperature as displayed and the value is updated including the fan stops.
  - 6) When the cooling thermostat is turned ON or the operation is changed to another mode (including stop), this control is stopped immediately, and the operating condition is restored.
- (v) When the “Fan OFF” is selected, the fan on the indoor unit of which the thermostat has been turned OFF, is turned OFF. The same occurs also when the remote control sensor is effective.

**(10) Filter sign**

As the operation time (Total ON time of ON/OFF switch) accumulates to 180 hours (1), “FILTER CLEANING” is displayed on the remote control. (This is displayed when the unit is in trouble and under the central control, regardless of ON/OFF)

Note (1) Time setting for the filter sign can be made as shown below using the indoor function of wired remote control “FILTER SIGN SET”. (It is set at TYPE 1 at the shipping from factory.)

Filter sign setting	Function
<b>TYPE 1</b>	Setting time: 180 hrs (Factory default)
<b>TYPE 2</b>	Setting time: 600 hrs
<b>TYPE 3</b>	Setting time: 1,000 hrs
<b>TYPE 4</b>	Setting time: 1,000 hrs (Unit stop) <sup>(2)</sup>

(2) After the setting time has elapsed, the “FILTER CLEANING” is displayed and, after operating for 24 hours further (counted also during the stop), the unit stops.

**(11) Compressor inching prevention control**

- (a) 3-minute timer  
When the compressor has been stopped by the thermostat, remote control operation switch or anomalous condition, its restart will be inhibited for 3 minutes. However, the 3-minute timer is invalidated at the power on the electric power source for the unit.
- (b) 3-minute forced operation timer
  - (i) Compressor will not stop for 3 minutes after the compressor ON. However, it stops immediately when the unit is stopped by means of the ON/OFF switch or by when the thermister turned OFF the change of operation mode.
  - (ii) If the thermostat is turned OFF during the forced operation control of heating compressor, the louver position (with the auto swing) is returned to the level position.

Note (1) The compressor stops when it has entered the protective control.


**(12) Drain pump control**

- (a) This control is operated when the inverter frequency is other than 0 Hz during the cooling operation and automatic cooling and dehumidifying operations.
- (b) Drain pump ON condition continues for 5 minutes even when it enters the OFF range according to (i) above after turning the drain pump ON, and then stops. The 5-minute delay continues also in the event of anomalous stop.
- (c) The drain pump is operated with the 5-minute delay operation when the compressor is changed from ON to OFF.
- (d) Even in conditions other than the above (such as heating, fan, stop, cooling thermostat OFF), the drain pump control is performed by the drain detection.
- (e) Following settings can be made using the indoor function setting of the wired remote control.
  - (i) 标准 [Standard (in cooling & dehumidifying)] : Drain pump is run during cooling and dehumidifying.
  - (ii) 标准 AND 制热 [Operate in standard & heating] : Drain pump is run during cooling, dehumidifying and heating.
  - (iii) 标准 AND 制热 AND 送风 [Operate in heating & fan] : Drain pump is run during cooling, dehumidifying, heating and fan.
  - (iv) 标准 AND 送风 [Operate in standard & fan] : Drain pump is run during cooling, dehumidifying and fan.

Note (1) Values in [ ] are for the RC-EX1A model.

**(13) Drain pump abnormalities detection**

- (a) Drain detection switch is turned ON or OFF with the float switch (FS) and the timer.



[\*1] Drain detection switch is turned “ON” when the float switch “Open” is detected for 3 seconds continuously in the drain detectable space.

[\*2] Drain detection switch is turned “OFF” when the float switch “Close” is detected for 10 seconds continuously. It detects always from 30 seconds after turning the power ON.

- 1) There is no detection of anomalous draining for 10 seconds after turning the drain pump OFF.
- 2) Turning the drain detection switch “ON” causes to turn ON the drain pump forcibly.
- 3) Turning the drain detection switch “OFF” releases the forced drain pump ON condition.

- (b) Indoor unit performs the control A or B depending on each operating condition.

	Indoor unit operation mode				
	Stop <sup>(1)</sup>	COOL	DRY	FAN <sup>(2)</sup>	HEAT
Compressor ON	Control A				
Compressor OFF					
	Control B				

Note (1) Including the stop from the cooling, dehumidifying, fan and heating, and the anomalous stop  
 (2) Including the “Fan” operation according to the mismatch of operation modes

- (i) Control A
  - 1) If the float switch detects any anomalous draining condition, the unit stops with the anomalous stop (displays E9) and the drain pump starts. After detecting the anomalous condition, the drain motor continues to be ON.
  - 2) It keeps operating while the float switch is detecting the anomalous condition.
- (ii) Control B
 

If the float switch detects any anomalous drain condition, the drain motor is turned ON for 5 minutes, and at 10 seconds after the drain motor OFF it checks the float switch. If it is normal, the unit is stopped under the normal mode or, if there is any anomalous condition, E9 is displayed and the drain motor is turned ON. (The ON condition is maintained during the drain detection.)

**(14) Operation check/drain pump test run operation mode**

- (a) If the power is turned on by the dip switch (SW7-1) on the indoor PCB when electric power source is supplied, it enters the mode of operation check/drain pump test run. It is ineffective (prohibited) to change the switch after turning power on.
- (b) When the communication with the remote control has been established within 60 seconds after turning power on by the dip switch (SW7-1) ON, it enters the operation check mode. Unless the remote control communication is established, it enters the drain pump test run mode.

Note (1) To select the drain pump test run mode, disconnect the remote control connector (CNB) on the indoor PCB to shut down the remote control communication.

## (c) Operation check mode


There is no communication with the outdoor unit but it allows performing operation in respective modes by operating the remote control.

## (d) Drain pump test run mode

As the drain pump test run is established, the drain pump only operates and during the operation protective functions by the microcomputer of indoor unit become ineffective.

**(15) Cooling, dehumidifying frost protection**

- (a) To prevent frosting during cooling mode or dehumidifying mode operation, the of compressor speed is reduced if the indoor heat exchanger temperature (detected with ThI-R) drops to 1.0 °C or lower at 4 minutes after the start of compressor operation. If the indoor unit heat exchanger temperature is 1.0 °C or lower after 1 minutes, the compressor speed is reduced further. If it becomes 2.5 °C or higher, the control terminates. When the indoor heat exchanger temperature has become as show below after reducing the compressor speed, it is switched to the fan operation. For the selection of indoor fan speed, refer to item 2).



## (b) Selection of indoor fan speed

If it enters the frost prevention control during cooling operation (excluding dehumidifying), the indoor unit fan speed is switched.

- (i) When the indoor return air detection temperature (detected with ThI-A) is 23°C or higher and the indoor heat exchanger temperature (detected with ThI-R) detects the compressor frequency drop start temperature A°C+1°C, of indoor unit fan speed is increased by 20min<sup>-1</sup>.
- (ii) If the phenomenon of 1) above is detected again after the acceleration of indoor unit fan, indoor unit fan speed is increased further by 20min<sup>-1</sup>.

Note (1) Indoor unit fan speed can be increased by up to 2 taps.


## • Compressor frequency drop start temperature

Item	Symbol	A
Temperature - Low (Factory default)		1.0
Temperature - High		2.5

Note (1) Frost prevention temperature setting can be selected with the indoor unit function setting of the wired remote control.

**(16) Heating overload protection**

- (a) If the indoor heat exchanger temperature (detected with ThI-R) at 63°C or higher is detected for 2 seconds continuously, the compressor stops. When the compressor is restarted after a 3-minute delay, if a temperature at 63°C or higher is detected for 2 seconds continuously within 60 minutes after initial detection and if this is detected 5 times consecutively, the compressor stops with the anomalous stop (E8). Anomalous stop occurs also when the indoor heat exchanger temperature at 63°C or higher is detected for 6 minutes continuously.



## (b) Indoor unit fan speed selection

If, after second detection of heating overload protection up to fourth, the indoor fan is set at Me and Lo taps when the compressor is turned ON, the indoor fan speed is increased by 1 tap.

**(17) Anomalous fan motor**


- (a) After starting the fan motor, if the fan motor speed is  $200\text{min}^{-1}$  or less is detected for 30 seconds continuously and 4 times within 60 minutes, then fan motor stops with the anomalous stop (E16).
- (b) If the fan motor fails to reach at  $-50\text{min}^{-1}$  less than the required speed, it stops with the anomalous stop (E20).

**(18) Plural unit control – Control of 16 units group by one remote control****(a) Function**

One remote control switch can control a group of multiple number of unit (Max. 16 indoor units). “Operation mode” which is set by the remote control switch can operate or stop all units in the group one after another in the order of unit No.<sup>(1)</sup>. Thermostat and protective function of each unit function independently.

Note (1) Unit No. is set by SW2 on the indoor unit control PCB. Unit No. setting by SW2 is necessary for the indoor unit only.

SW2: For setting of 0 – 9, A – F



(2) Unit No. may be set at random unless duplicated, it should be better to set orderly like 0, 1, 2..., F to avoid mistake.

**(b) Display to the remote control**

- (i) Center or each remote control basis, heating preparation: the youngest unit No. among the operating units in the remote mode (or the center mode unless the remote mode is available) is displayed.
- (ii) Inspection display, filter sign: Any of unit that starts initially is displayed.
- (iii) Confirmation of connected units
  - 1) In case of RC-EX1A remote control  
If you touch the buttons in the order of “Menu” → “Next” → “Service & Maintenance” → “IU address” on the TOP screen of remote control, the indoor units which are connected are displayed.
  - 2) In case of RC-E5 remote control  
Pressing “AIR CON No.” button on the remote control displays the indoor unit address. If “▲” “▼” button is pressed at the next, it is displayed orderly starting from the unit of youngest No.
- (iv) In case of anomaly
  - 1) If any anomaly occurs on a unit in a group (a protective function operates), that unit stops with the anomalous stop but any other normal units continue to run as they are.
  - 2) Signal wiring procedure  
Signal wiring between indoor and outdoor units should be made on each unit same as the normal wiring. For the group control, lay connect with sires wiring between rooms using terminal blocks (X, Y) of remote control. Connect the remote control communication wire separately from the power source wire or wires of other electric devices (AC220V or higher).

**(19) High ceiling control**

When sufficient air flow rate cannot be obtained from the indoor unit which is installed at a room with high ceiling, the air flow rate can be increased by changing the fan tap. To change the fan tap, use the indoor unit function “FAN SPEED SET” on the wired remote control.

Fan tap		Indoor unit airflow setting				
FAN SPEED SET	STANDARD	PHi1 - Hi - Me - Lo	Hi - Me - Lo	Hi - Lo	Hi - Me	
	HIGH SPEED1, 2	PHi1 - PHi1 - Hi - Me	PHi1 - Hi - Me	PHi1 - Me	PHi1 - Hi	

Notes (1) Factory default is STANDARD.

(2) At the hot-start and heating thermostat OFF, or other, the indoor unit fan is operated at the low speed tap of each setting.

(3) This function is not able to be set with wireless remote controls or simple remote control (RCH-E3)

**(20) Abnormal temperature thermistor (return air/indoor heat exchanger) wire/short-circuit detection****(a) Broken wire detection**

When the return air temperature thermistor detects -50°C or lower or the heat exchanger temperature thermistor detect -50°C or lower for 5 seconds continuously, the compressor stops. After a 3-minute delay, the compressor restarts but, if it is detected again within 60 minutes after the initial detection for 6 minutes continuously, stops again (the return air temperature thermistor: E7, the heat exchanger temperature thermistor: E6).


**(b) Short-circuit detection**

If the heat exchanger temperature thermistor detects 70°C or higher for 5 seconds continuously at 2 minutes and 20 seconds after the compressor ON during cooling operation, the compressor stops (E6).

**(21) External input/output control (CnT or CnTA)**

Be sure to connect the wired remote control to the indoor unit. Without wired remote control remote operation by CnT is not possible to perform.

• CnT



- |                          |                            |
|--------------------------|----------------------------|
| ① Operation output       | (CnT-2: XR1)               |
| ② Heating output         | (CnT-3: XR2)               |
| ③ Thermostat ON output   | (CnT-4: XR3)               |
| ④ Error output           | (CnT-5: XR4)               |
| ⑤ Remote operation input | (CnT-6: Volt-free contact) |

• CnTA



Note (1) CnTA function can be changed by RC-EX1A.

**■ Priority order for combinations of CnT and CnTA input.**

		CnTA					
		① Operation stop level	② Operation stop pulse	③ Operation permission/prohibition	④ Operation permission/prohibition pulse	⑤ Cooling/heating selection level	⑥ Cooling/heating selection pulse
CnT	① Operation stop level	CnT ①	CnT ①	CnT ① + CnTA ②	CnT ①	CnT ① / CnTA ⑤	CnT ① / CnTA ⑥
	② Operation stop pulse	CnT ②	CnT ②	CnT ② + CnTA ③	CnT ②	CnT ② / CnTA ⑤	CnT ② / CnTA ⑥
	③ Operation permission/prohibition level	CnT ③ > CnTA ①	CnT ③ > CnTA ②	CnT ③ + CnTA ③	CnT ③	CnT ③ / CnTA ⑤	CnT ③ / CnTA ⑥
	④ Operation permission/prohibition pulse	CnT ④	CnT ④	CnT ④ + CnTA ③※	CnT ④	CnT ④ / CnTA ⑤	CnT ④ / CnTA ⑥
	⑤ Cooling/heating selection level	CnT ⑤ / CnTA ①	CnT ⑤ / CnTA ②	CnT ⑤ / CnTA ③※	CnT ⑤ / CnTA ④	CnT ⑤	CnT ⑤
	⑥ Cooling/heating selection pulse	CnT ⑥ / CnTA ①	CnT ⑥ / CnTA ②	CnT ⑥ / CnTA ③	CnT ⑥ / CnTA ④	CnT ⑥	CnT ⑥

Note (1) Following operation commands are accepted when the operation prohibition is set with CnTA as indicated with \*.

Individual operation command from remote control, test run command from outdoor unit and operation command from optional device, CNT input.

Reference: Explanation on the codes and the combinations of codes in the table above

- In case of CnT “Number”, the CnT “Number” is adopted and CnTA is invalidated.
- In case of CnTA “Number”, the CnTA “Number” is adopted and CnT is invalidated.
- In case of CnT “Number”/CnTA “Number”, the CnT “Number” and the CnTA “Number” become independent functions each other.
- In case of CnT “Number” + CnTA “Number”, the CnT “Number” and the CnTA “Number” become competing functions each other.
- In case of CnT “Number” > CnTA “Number”, the function of CnT “Number” supersedes that of CnTA “Number”.
- In case of CnT “Number” < CnTA “Number”, the function of CnTA “Number” supersedes that of CnT “Number”.

(The “Number” above means ① - ⑥ in the table.)

**(a) Output for external control (remote display)**

Following output connectors (CnT) are provided on the indoor control PCB for monitoring operation status.

- ① Operation output:** Outputs DC12V signal for driving relay during operation
- ② Heating output:** Outputs DC12V signal for driving relay during heating operation
- ③ Thermostat ON output:** Outputs DC12V signal for driving relay when compressor is operating.
- ④ Error output:** Outputs DC12V signal for driving relay when anomalous condition occurs.

**(b) Remote operation input**


Remote operation input connector (CnT-6 or CnTA) is provided on the indoor control PCB.

However remote operation by CnT-6 or CnTA is not effective, when “Center mode” is selected by central control.

**Only the “LEVEL INPUT” is acceptable for external input**, however when the indoor function setting of “Level input (Factory default)” or “Pulse input” is selected by the function for “External input” of the wired remote control, operation status will be changed as follows.

(i) In case of “Level input” setting (Factory default)

Input signal to CnT-6 or CnTA is OFF→ON ..... unit ON  
 Input signal to CnT-6 or CnTA is ON→OFF ..... unit OFF  
 Operation is not inverted.




Note: The latest operation has priority

It is available to operate/stop by remote control or central control

(ii) In case of “Pulse input” setting (Local setting)


It is effective only when the input signal to CnT-6 or CnTA is changed OFF→ON, and at that time unit operation [ON/OFF] is inverted.



(c) Remote operation

(i) In case of multiple units (Max. 16 indoor units group) are connected to one wired remote control

When the indoor function setting of wired remote control for “External control set” is changed from “Individual (Factory default)” to “For all units”, all units connected in one wired remote control system can be controlled by external operation input.



Ex. Indoor units = ①+②+③ .....⑥ ≤16 units


	Individual operation (Factory default)		All units operation (Local setting)	
	ON	OFF	ON	OFF
	Only the unit directly connected to the remote control can be operated.	Only the unit directly connected to the remote control can be stopped operation.	All units in one remote control system can be operated.	All units in one remote control system can be stopped operation.
CnT-6 or CnTA	Unit ① only	Unit ① only	Units ① – ⑥	Units ① – ⑥

When more than one indoor unit (Max. 16 indoor units) are connected in one wired remote control system:

- (1) With the factory default, external input to CnT-6 or CnTA is effective for only the unit ①.
- (2) When setting “For all unit” (Local setting), all units in one remote control system can be controlled by external input to CnT-6 or CnTA on the indoor unit ①.
- (3) External input to CnT-6 or CnTA on the other indoor unit than the unit ① is not effective.

**(22) Operation permission/prohibition****(In case of adopting card key switches or commercially available timers)**

When the indoor function setting of wired remote control for “Operation permission/prohibition” is changed from “Invalid (Factory default)” to “Valid”, following control becomes effective.



	Normal operation (Factory default)		Operation permission/prohibition mode “Valid” (Local setting)	
	ON	OFF	ON	OFF
CnT-6 or CnTA	Operation	Stop	Operation permission*1	Operation prohibition (Unit stops)

\*1 **Only the “LEVEL INPUT” is acceptable for external input**, however when the indoor function setting of “Level input (Factory default)” or “Pulse input” is selected by the function for “External input” of the wired remote control, operation status will be changed as follows.

In case of “Level input” setting	In case of “Pulse input” setting
Unit operation from the wired remote control becomes available*(1)	Unit starts operation *(2)


\*(1) In case that “Operation permission/prohibition mode” setting is “Valid” and “External input” setting is “Level input (Factory default)”;

- ① When card key switch is ON (CnT-6 or CnTA ON: Operation permission), start/stop operation of the unit from the wired remote control becomes available.
- ② When card key switch is OFF (CnT-6 or CnTA OFF: Operation prohibition), the unit stops operation in conjunction with OFF signal, and start/stop operation of the unit from the wired remote control becomes not available.


\*(2) In case that “Operation permission/prohibition mode” setting is “Valid” and “External input” setting is “Pulse input (Local setting)”;

- ① When card key switch is ON (Operation permission), the unit starts operation in conjunction with ON signal, and also start/stop operation of the unit from the wired remote control becomes available.
- ② When card key switch is OFF (Operation prohibition), the unit stops operation in conjunction with OFF signal, and start/stop operation of the unit from the wired remote control becomes not available.


(3) This function is invalid only at “Center mode” setting done by central control.

**(a) In case of CnT ① Operation stop level > CnTA ③ Operation permission/prohibition level**


(※) CnT level input supersedes CnTA operation prohibition.

**(b) In case of CnT ③ Operation permission/prohibition level + CnTA ③ Operation permission/prohibition level**

(※) Operation prohibition zone is determined by the OR judgment between CnT Operation prohibition zone and CnTA Operation prohibition zone.

**(c) In case of CnT ③ Operation permission/prohibition level > CnTA ② Operation/stop pulse**

Note (1) If it is prohibited by CnT, all "Operation" and "Stop" commands are not accepted.

**(d) In case of CnT ② Operation/stop pulse + CnTA ③ Operation permission/prohibition level****(23) Selection of cooling/heating external input function**

- When "External input 1 setting: Cooling/heating" is set for the indoor unit function from remote control, the cooling or heating is selected with CnT-6 or CnTA.
- When the External input 1 method selection: Level input is set for the indoor unit function:
  - CnT-6 or CnTA: OPEN → Cooling operation mode
  - CnT-6 or CnTA: CLOSE → Heating operation mode
- When the External input 1 method selection: Pulse input is set for the indoor unit function:
 

If the external input is changed OPEN → CLOSE, operation modes are inverted (Cooling → Heating or Heating → Cooling).

- (d) If the cooling/heating selection signal is given by the external input, the operation mode is transmitted to the remote control.



■ Selection of cooling/heating external input function

External input selection	External input method	Operation	
External input selection Cooling/heating selection	⑤ Level	External terminal input (CnT or CnTA)	
		Cooling/heating	
		Cooling/heating (Competitive)	
	⑥ Pulse	External terminal input (CnT or CnTA)	
		Cooling/heating	
		Cooling/heating (Competitive)	

Notes (1) Regarding the priority order for combinations of CnT and CnTA, refer to Page 240.

## (24) Room temperature detection temperature compensation during heating

With the standard specification, the compressor is turned ON/OFF with the thermostat setting temperature. When the thermostat is likely to turn OFF earlier because the unit is installed at the ceiling where warm air tends to accumulate, the setting can be changed with the wired remote control indoor unit function "※ SP OFFSET". The compressor and the heater are turned ON/OFF at one of the setting temperature +3, +2 or +1°C in order to improve the feeling of heating. The setting temperature, however, has the upper limit of 30°C.



## (25) Return air temperature compensation

This is the function to compensate the deviation between the detection temperature by the return air temperature thermistor and the measured temperature after installing the unit.

- (a) It is adjustable in the unit of 0.5°C with the wired remote control indoor unit function "RETURN AIR TEMP".
- +1.0°C, +1.5°C, +2.0°C      • -1.0°C, -1.5°C, -2.0°C
- (b) Compensated temperature is transmitted to the remote control and the compressor to control them.

Note (1) The detection temperature compensation is effective on the indoor unit thermistor only.

## (26) High power operation (RC-EX1A only)

It operates at with the set temp. fixed at 16°C for cooling, 30°C for heating and maximum indoor fan speed for 15 minutes maximum.

## (27) Energy-saving operation (RC-EX1A only)

It operates with the setting temperature fixed at 28°C for cooling, 22°C for heating or 25°C for auto. (Maximum capacity is restricted at 80%.)

## (28) Warm-up control (RC-EX1A only)

Operation will be started 5 to 60 minutes before use according to the forecast made by the microcomputer which calculates when the operation should be started in order to warm up the indoor temperature near the setting temperature at the setting time of operation start.

**(29) Home leave mode (RC-EX1A only)**

When the unit is not used for a long period of time, the room temperature is maintained at a moderate level, avoiding extremely hot or cool temperature.

- (a) Cooling or heating is operated according to the outdoor temperature (factory setting 35°C for cooling, 0°C for heating) and the set temp. (factory setting 33°C for cooling, 10°C for heating)
- (b) Set temp and indoor fan speed can be set by RC-EX1A.

**(30) Auto temp. setting (RC-EX1A only)**

Setting temperature is adjusted automatically at the adequate temperature the center set temp. is 24°C by correcting the outdoor air temperature.

**(31) Fan circulator operation (RC-EX1A only)**

When the fan is used for circulation, the unit is operated as follows depending on the setting with the remote control.

- (a) If the invalid is selected with the remote control, the fan is operated continuously during the fan operation. (normal fan mode)
- (b) If the valid is selected with the remote control, the fan is operated or stopped when on the difference of the remote control temperature sensor and the indoor unit return air temperature sensor becomes bigger than 3°C.

**(32) The operation judgment is executed every 5 minutes (RC-EX1A only)**

Setting temperature  $T_s$  is changed according to outdoor temperature  
This control is valid with cooling and heating mode. (NOT auto mode)

- (a) Operate 5 minutes forcedly.
- (b) Setting temperature is adjusted every 10 minutes.
  - (i) Cooling mode.  
 $T_s = \text{outdoor temperature} - \text{offset value}$
  - (ii) Heating mode.  
 $T_s = \text{outdoor temperature} - \text{offset value}$
- (c) If the return air temperature lower than 18°C or return air temperature becomes lower than 25°C, unit goes thermo OFF.

**(33) Auto fan speed control (RC-EX1A only)**

In order to reach the room temperature to the set temperature as quickly as possible, the airflow rate is increased when the set temperature of thermostat differs largely from the return air temperature. According to temperature difference between set temperature and return air temperature, indoor fan tap are controlled automatically.

- Auto 1: Changes the indoor unit fan tap within the range of Hi ↔ Me ↔ Lo.
- Auto 2: Changes the indoor unit fan tap within the range of PHi ↔ Hi ↔ Me ↔ Lo.

**(34) IU overload alarm (RC-EX1A only)**

If the following condition is satisfied at 30 minutes after starting operation, RC-EX1A shows maintenance code "M07" and the signal is transmitted to the external output (CnT-5).

- (a) Receipt of the signal by the external output is indicated by lighting an LED or other prepared on site.
  - Cooling, Dry, Auto(Cooling) : Indoor air temperature = Set room temperature by remote control + Alarm temperature difference
  - Heating, Auto(Heating) : Indoor air temperature = Set room temperature by remote control - Alarm temperature difference
 Alarm temperature difference is selectable between 5 to 10°C.
- (b) If the following condition is satisfied or unit is stopped, the signal is disappeared.
  - Cooling, Dry, Auto(Cooling) : Indoor air temperature = Set room temperature + Alarm temperature difference - 2°C
  - Heating, Auto(Heating) : Indoor air temperature = Set room temperature - Alarm temperature difference + 2°C

**(35) Peak-cut time (RC-EX1A only)**

Power consumption can be reduced by restricting the maximum capacity.  
Set the [Start time], the [End time] and the capacity limit % (Peak-cut %).

- 4-operation patterns per day can be set at maximum.
- The setting time can be changed by 5-minutes interval.
- The selectable range of capacity limit % (Peak-cut %) is from 0% to 40-80% (20% interval).
- Holiday setting is available.

## 7.3 Outdoor units

### 7.3.1 Outline of heating operation

#### (1) Summary

##### (a) Capacity control

##### (i) Indoor unit SRK \*\* ZMX models only

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
Capacity	1.4 – 6.9 kW	1.4 – 7.4 kW	1.4 – 7.5 kW	1.5 – 7.8 kW	1.5 – 9.4 kW	1.5 – 9.8 kW

Model	SCM100ZM-S	SCM125ZM-S
Capacity	1.5 – 13.5 kW	1.5 – 14.0 kW

##### (ii) Indoor unit except SRK \*\* ZMX models

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
Capacity	1.4 – 6.7 kW	1.4 – 7.2 kW	1.4 – 7.3 kW	1.5 – 7.6 kW	1.5 – 9.1 kW	1.5 – 9.5 kW

Model	SCM100ZM-S	SCM125ZM-S
Capacity	1.5 – 13.3 kW	1.5 – 13.8 kW

Capacity control is within the range shown above. If demand capacity of the indoor units exceeds the maximum capacity of the outdoor unit, the demand capacity will be proportionally distributed.

##### (b) Outdoor compressor speed control

Indoor compressor command total speed value	Decision speed
0 rps	0 rps
A rps or less	A rps
More than A rps, but B rps or less	A rps to B rps
More than B rps	B rps

##### • Values of A, B

Item \ Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S
A	30 rps	30 rps	30 rps
B	100 rps	120 rps	120 rps

Item \ Model	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
A	Two connection	40 rps	
	More than three connection	30 rps	
B	One connection	90 rps	
	More than two connection	120 rps	

Item \ Model	SCM100ZM-S	SCM125ZM-S
A	Three connection	31 rps
	More than four connection	31 rps
B	One connection	80 rps
	More than two connection	105 rps

#### (2) Operation of major functional components in heating mode

Functional components \ Operation	Heating	Thermostat OFF (All indoor units)	Thermostat OFF (Some of indoor units)	Fan, stop, abnormal stop (Some of indoor units)	Failure (Outdoor unit)
Command speed	Multi-operation rpm calculated based on the rpm required for each indoor unit	0 (All indoor units)	0 (Thermostat off units)	0 (Fan, stop, abnormal stop units)	0 (All units)
Indoor unit fan	Fixed	According to mode switching	Hot keep	According to mode switching	Hot keep
	Automatic	According to command speed	Hot keep	According to command speed	Hot keep
Outdoor unit fan	According to outdoor unit speed	OFF	According to outdoor unit speed	OFF	OFF
Electronic expansion valve	According to decision speed	According to stop mode	According to heating stop unit control (Thermostat off units)	According to heating stop unit control (Fan, stop, abnormal stop units)	According to stop mode
Compressor	ON	OFF	ON	ON	OFF

**(3) Defrost operation**

(a) Starting conditions (Defrost operation can be started only when all of the following conditions are satisfied.)

(i) After start of heating operation

When it elapsed 40 minutes. (Accumulated compressor operation time)

(ii) After end of defrost operation

When it elapsed 40 minutes. (Accumulated compressor operation time)

(iii) Outdoor heat exchanger temperature (Tho-R)


When the temperature has been below  $-2^{\circ}\text{C}$  for 3 minutes continuously.

(iv) The condition of outdoor air temperature (Tho-A) and the outdoor heat exchanger temperature (Tho-R)

$$(\text{Tho-A}) - (\text{Tho-R}) \geq 0.44 \times (\text{Tho-A}) + A$$

Tho-A	A
$-2^{\circ}\text{C} \leq \text{Tho-A}$	4(6.5)
$-15^{\circ}\text{C} \leq \text{Tho-A} < -2^{\circ}\text{C}$	6(10.0)
$\text{Tho-A} < -15^{\circ}\text{C}$	6(10.0)

Note (1) Values in ( ) are for the model SCM100, 125.



(v) During continuous compressor operation


In addition, when the speed command from the indoor control of the indoor unit during heating operation has counted 0 rps 10 times or more and all conditions of (i), (ii), (iii) and (v) above and the outdoor air temperature is  $3^{\circ}\text{C}$  or less are satisfied (note that when the temperature for outdoor heat exchanger sensor (Tho-R) is  $-2^{\circ}\text{C}$  or less: 62 rps or more,  $-2^{\circ}\text{C}$  or less: less than 62 rps), defrost operation is started.

(b) Ending conditions (Operation returns to the heating cycle when either one of the following conditions is satisfied.)

(i) Outdoor heat exchanger sensor (Tho-R) temperature:  $20^{\circ}\text{C}$  or higher

(ii) Outdoor heat exchanger sensor (Tho-R) temperature: 2 min. as for  $10^{\circ}\text{C}$  (model SCM71, 80, 100, 125: 1 min. as for  $18^{\circ}\text{C}$ )

(iii) Continued operation time of defrost → For more than 12 minutes and 50 seconds



\* Depends on an operation condition, the time can be longer than 7 minutes.

(c) Switching to defrost operation for snowing regions (SCM100, 125 only)

Open the jumper wire (J15) on the outdoor unit control PCB. The control is changed to the defrost operation suitable to snowing regions. (The jumper wire is short-circuited at the shipment from factory.)

## 7.3.2 Outline of cooling operation

### (1) Summary

#### (a) Capacity control

##### (i) Indoor unit SRK \*\* ZMX models only

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
Capacity	1.8 – 5.9 kW	1.8 – 6.4 kW	1.8 – 7.1 kW	1.8 – 7.5 kW	1.8 – 8.8 kW	1.8 – 9.2 kW

Model	SCM100ZM-S	SCM125ZM-S
Capacity	1.8 – 12.0 kW	1.8 – 14.0 kW

##### (ii) Indoor unit except SRK \*\* ZMX models

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
Capacity	1.8 – 5.8 kW	1.8 – 6.3 kW	1.8 – 6.9 kW	1.8 – 7.3 kW	1.8 – 8.3 kW	1.8 – 8.7 kW

Model	SCM100ZM-S	SCM125ZM-S
Capacity	1.8 – 11.8 kW	1.8 – 13.8 kW

Capacity control is within the range shown above. If demand capacity of the indoor units exceeds the maximum capacity of the outdoor unit, the demand capacity will be proportionally distributed.

#### (b) Outdoor compressor speed control

Indoor compressor command total speed value	Decision speed
0 rps	0 rps
A rps or less	A rps
More than A rps, but B rps or less	A rps to B rps
More than B rps	B rps

##### ● Values of A, B

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
A	30 rps	30 rps	30 rps	20 rps	20 rps	20 rps
B	100 rps	120 rps	120 rps	120 rps	120 rps	120 rps

Model	SCM100ZM-S	SCM125ZM-S
A	20–40 rps	20–45 rps
B	110 rps	110 rps

### (2) Operation of major functional components in cooling mode

Functional components	Operation	Cooling	Thermostat OFF (All indoor units)	Thermostat OFF (Some of indoor units)	Fan, stop, abnormal stop (Some of indoor units)	Failure (Outdoor unit)
Command speed		Multi-operation rpm calculated based on the rpm required for each indoor unit	0 (All indoor units)	0 (Thermostat off units)	0 (Fan, stop, abnormal stop units)	0 (All units)
Indoor unit fan	Fixed	According to mode switching				
	Automatic	According to command speed	According to mode switching	According to command speed		
Outdoor unit fan		According to outdoor unit speed	OFF	According to outdoor unit speed		OFF
Electronic expansion valve		According to decision speed	According to stop mode	All closed (Thermostat off units)	All closed (Fan, stop, abnormal stop units)	According to stop mode
Compressor		ON	OFF	ON	ON	OFF

### 7.3.3 Protective control function


#### (1) Cooling overload protective control

- (a) **Operating conditions:** When the outdoor air temperature (Tho-A) has become continuously for 30 seconds at 41°C or more, or 47°C or more with the compressor running, the lower limit speed of compressor is brought up.

Item \ Model	SCM40, 45, 50, 60, 71, 80ZM-S	
Outdoor air temperature	41°C or more	47°C or more
Lower limit speed	30 rps	40 rps

Item \ Model	SCM100, 125ZM-S	
Outdoor air temperature	41°C or more	47°C or more
Lower limit speed	25 rps	31 rps



#### (b) Detail of operation

The lower limit of compressor command speed is set to 30 (25) or 40 (31) rps and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to 30 (25) or 40 (31) rps. However, when the thermo OFF, the speed is reduced to 0 rps.

Note (1) Values in ( ) are for the model SCM100, 125ZM-S.

- (c) **Reset conditions:** When either of the following conditions is satisfied.

- The outdoor air temperature is lower than 40°C.
- The compressor command speed is 0 rps.


#### (2) Cooling high pressure control

##### (a) Models SCM40, 45, 50, 60, 71, 80

- Purpose:** Prevents anomalous high pressure operation during cooling.
- Detector:** Outdoor heat exchanger sensor (Tho-R)

##### (iii) Detail of operation:

##### (Example) Fuzzy



- Notes
- When the outdoor heat exchanger temperature is in the range of 58–60°C, the compressor command speed is reduced by 8 rps at each 20 seconds.
  - When the temperature is 60°C or higher, the compressor is stopped.
  - When the outdoor heat exchanger temperature is in the range of 53–58°C, if the compressor command speed is been maintained and the operation has continued for more than 30 seconds at the same speed, it returns to the normal cooling operation.

##### (b) Models SCM100, 125

- Starting condition:** When the high pressure sensor (HPS) has risen to a specified pressure while the compressor is turned on.
- Compressor command speed is controlled according to the zones of high pressure sensor as shown by the following table.**

	HPS < P2	P2 ≤ HPS < P3	P3 ≤ HPS	P4 ≤ HPS
Protection control speed (NP)	Normal	Retention	NP-8rps	0rps
Sampling time (s)	Normal	30	20	Normal


Unit: MPa				
NP \ HPS	P2	P3	P4	
20 ≤ NP < 30	2.94 – 3.45	3.07 – 3.85	3.15 – 4.05	
30 ≤ NP < 90	3.45	3.85	4.05	
90 ≤ NP < 100	3.45 – 3.25	3.85 – 3.60	4.05 – 3.81	
100 ≤ NP < 110	3.25 – 3.07	3.60 – 3.33	3.81 – 3.53	
110 ≤ NP	3.07	3.33	3.53	

**(3) Cooling low outdoor temperature protective control**

**(a) Operating conditions:** When the outdoor air temperature (Tho-A) is 22°C or lower continues for 20 seconds while compressor command speed is other than 0 rps.

**(b) Detail of operation:**

- (i) The lower limit of compressor command speed is set to B or D rps and even if the speed becomes lower than B or D rps, the speed is kept to B or D rps. However, when the thermo becomes OFF, the speed is reduced to 0 rps.
- (ii) The upper limit of compressor command speed is set to A or C rps, the speed is kept to A or C rps.



## ● Values of A ~ D

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S
A	75 rps	75 rps	75 rps	75 rps	75 rps	75 rps
B	35 rps	35 rps	35 rps	30 rps	30 rps	30 rps
C	60 rps	60 rps	60 rps	60 rps	60 rps	60 rps
D	45 rps	45 rps	45 rps	40 rps	40 rps	40 rps

Model	SCM100ZM-S	SCM125ZM-S
A	75 rps	75 rps
B	20 rps	20 rps
C	60 rps	60 rps
D	31 rps	31 rps

**(c) Reset conditions:** When the either of the following conditions is satisfied

- (i) When the outdoor air temperature (Tho-A) becomes 25°C or higher.
- (ii) When the compressor command speed is 0rps.

**(4) Heating high pressure control****(a) Models SCM40, 45, 50, 60, 71, 80**

**(i) Starting condition:** When the indoor heat exchanger temperature (Th2) has risen to a specified temperature while the compressor is turned on.

**(ii) Compressor command speed is controlled according to the zones of indoor heat exchanger temperature as shown by the following table.**

	Th2 < P1	P1 ≤ Th2 < P2	P2 ≤ Th2 < P3	P3 ≤ Th2
Protection control speed (NP)	Normal	Retention	NP-4rps	NP-8rps
Sampling time (s)	Normal	20	20	20

## ● Models SCM40, 45, 50

Unit: °C

NP	Th2	P1	P2	P3
10 ≤ NP < 115		45	52	57.5
115 ≤ NP < 120		45 - 43	52 - 50	57.5 - 55
120 ≤ NP		43	50	55

## ● Models SCM60, 71, 80

Unit: °C

NP	Th2	P1	P2	P3
10 ≤ NP < 90		45	52	57
90 ≤ NP < 100		45 - 44.5	52 - 49.5	57 - 54
100 ≤ NP < 110		44.5 - 44	49.5 - 47.5	54 - 51
110 ≤ NP < 120		44 - 43	47.5 - 45	51 - 48
120 ≤ NP		43	45	48

**(b) Models SCM100, 125**

(i) **Starting condition:** When the high pressure sensor (HPS) has risen to a specified pressure while the compressor is turned on.

(ii) **Compressor command speed is controlled according to the zones of high pressure sensor as shown by the following table.**

	HPS < P1	P1 ≤ HPS < P2	P2 ≤ HPS < P3	P3 ≤ HPS < P4	P4 ≤ HPS
Protection control speed (NP)	Normal	Retention	NP-3rps	NP-6rps	0rps
Sampling time (s)	Normal	20	20	20	Normal

Unit: MPa

NP \ HPS	P1	P2	P3	P4
20 ≤ NP < 30	2.81 – 2.94	2.94 – 3.45	3.07 – 3.85	3.15 – 4.05
30 ≤ NP < 90	2.94	3.45	3.85	4.05
90 ≤ NP < 100	2.94 – 2.88	3.45 – 3.25	3.85 – 3.60	4.05 – 3.81
100 ≤ NP < 110	2.88 – 2.81	3.25 – 3.07	3.60 – 3.33	3.81 – 3.53
110 ≤ NP	2.81	3.07	3.33	3.53


**(5) Heating overload protective control**

(a) **Operating conditions :** When the outdoor air temperature (Tho-A) is 13°C (model SCM40, 45:10°C ) or higher continues for 30 seconds while the compressor command speed other than 0 rps.

**(b) Detail of operation**

- Taking the upper limit of compressor command speed range at A or C, if the output speed obtained with the fuzzy calculation exceeds the upper limit, the upper limit value is maintained.
- The lower limit of compressor command speed is set to B or D and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to B or D. However, when the thermo becomes OFF, the speed is reduced to 0 prs.
- Inching prevention control is activated and inching prevention control is carried out with the minimum speed set at B or D.

(c) **Reset conditions:** The outdoor air temperature (Tho-A) is lower than 11°C (model SMC40, 45:8°C).




Note(1) Values in ( ) are for the model SCM40, 45.

		Unit: rps			
Model	Item	A	B	C	D
SCM40, 45		90	35	75	40
SCM50		90	35	75	40
SCM60, 71, 80		90	30	75	40
SCM100, 125		90	25	75	31

**(6) Heating low outdoor temperature protective control**

(a) **Operating conditions:** When the outdoor air temperature (Tho-A) is lower than 4°C or higher continues for 30 seconds while the compressor command speed is other than 0 rps.

(b) **Detail of operation:** The lower limit compressor command speed is change as shown in the figure below.



(c) **Reset conditions:** When either of the following conditions is satisfied.

- The outdoor air temperature (Tho-A) becomes 6°C.
- The compressor command speed is 0 rps.

**(7) Refrigeration cycle system protective control**

**(a) Starting condition:** This control starts when the following conditions are satisfied.

- (i) When it has elapsed 30 minutes after the compressor was changed from OFF to ON in the cooling operation mode for more than 5 minutes.
- (ii) When the compressor command speed has satisfied the following conditions.
- (iii) When the indoor air temperature of running indoor unit (Th1) and the indoor heat exchanger temperature (Th2) have satisfied the following condition even on one unit.

Unit	Compressor command speed	Indoor air temperature (Th1, °C )	Indoor air temperature (Th1) and indoor heat exchanger temperature (Th2)	Duration
1	40 (60) rps	$10 \leq Th1 \leq 40$	Th1 - 4 < Th2	5 minute
2	50 (70) rps		Th1 - 3 < Th2	
3	60 (80) rps		Th1 - 2 < Th2	
4	70 rps			
5	80 rps			
6	90 rps			

Note (1) Values in ( ) are for the model SCM40, 45, 50.

**(b) Contents of control**

- (i) Stop the compressor and delay the start, and then restarts.
- (ii) Compressor stops by the abnormal stop when the compressor stop has occurred 3 times in one hour.

**(8) Crankcase heater**

**(a) Operating conditions:** This control starts when all the conditions below are satisfied.

- (i) After the operation mode is changed to stop and the compressor command speed becomes 0 rps continuously for 30 minutes.
- (ii) When the temperature detected by the outdoor air temperature (Tho-A) is -2°C or lower after the compressor stops.

**(b) Detail of operation**

The crankcase heater operates, warming up the compressor, then refrigerant begins circulating smoothly when the air-conditioner starts its heating operation, and heating begins.

**(c) Restoration conditions**

When the temperature detected by the outdoor air temperature (Tho-A) reaches 0°C or higher, or the operation mode changes from stop to cooling or heating.

**(9) Inching prevention**

When the compressor becomes to the thermo operation within 5 minutes since operation start or becomes dehumidifying operation, the operation is continued with the compressor command speed of minimum rps forcibly.


**(10) Compressor overheat protection**

**(a) Purpose:** It is designed to prevent deterioration of oil, burnout of motor coil and other trouble resulting from the compressor overheat.

**(b) Detail of operation**

(i) Speeds are controlled with temperature detected by the sensor (Tho-D) mounted on the discharge pipe.

**(Example) Fuzzy**



- Notes (1) When the discharge pipe temperature is in the range of 105–115°C, the speed is reduced by 4 rps.  
 (2) When the discharge pipe temperature is raised and continues operation for 20 seconds without changing, then the speed is reduced again by 4 rps.  
 (3) If the discharge pipe temperature is in the range of 95–105°C even when the compressor command speed is maintained for 3 minutes when the temperature is in the range of 95–105°C, the speed is raised by 1 rps and kept at that speed for 3 minutes. This process is repeated until the command speed is reached.  
 (4) Lower limit speed

Model	Item	Jumper wire (J2)	
		Cooling	Heating
Lower limit speed	SCM40, 45, 50	32 rps	32 rps
	SCM60, 71, 80	25 rps	32 rps
	SCM100, 125	20 rps	22 rps

- (ii) If the temperature of 115°C is detected by the sensor on the discharge pipe, then the compressor will stop immediately. When the discharge pipe temperature drops and the time delay of 3 minutes is over, the unit starts again within 1 hour but there is no start at the third time.

**(11) Current safe****(a) Models SCM40, 45, 50, 60, 71, 80**

**(i) Purpose:** Current is controlled not to exceed the upper limit of the setting operation current.

- (ii) Detail of operation:** Input current to the converter is monitored with the current sensor fixed on the printed circuit board of the outdoor unit and, if the operation current value reaches the limiting current value, the compressor command speed is reduced.  
 If the mechanism is actuated when the compressor command speed is less than 30 rps, the compressor is stopped immediately. Operation starts again after a delay time of 3 minutes.

**(iii) Current safe control value: Set this using the jumper wire (J1 or J2) on the outdoor PCB. Control starts when it exceeds the control value.**

**1) Switching with jumper wire**

		Jumper wire (J2)	
		Short-circuit (At shipping from factory)	Short-circuit
Jumper wire (J1)	Short-circuit (At shipping from factory)	Current safe ①	Current safe ②
	Open	Current safe ③	Current safe ③


**2) Control value**

Unit: A


Model	Current safe ①		Current safe ②		Current safe ③	
	Cooling	Heating	Cooling	Heating	Cooling	Heating
SCM40, 45, 50ZM - S	10.0	12.0	10.0	10.0	7.5	7.5
SCM60ZM - S	11.0	14.0	10.0	10.0	7.5	7.5
SCM71, 80ZM - S	13.0	16.0	10.0	10.0	7.5	7.5

**(b) Models SCM100, 125**

Detecting the outdoor unit inverter input (primary) current and the output (secondary) current, if the current values exceed setting values, the compressor speed (frequency) is controlled to protect the inverter.



(Fig. C) The control value "A" and the reset value vary depending on the compressor speed.



	Cooling		Heating	
	Control value A	Reset value B	Control value A	Reset value B
Primary current side	21	20	23	20
Secondary current side	Fig.C	Fig.C	Fig.C	Fig.C

**(12) Current cut**

**(a) Purpose:** Inverter is protected from overcurrent.

**(b) Detail of operation:** Output current from the inverter is monitored with a shunt resistor and, if the current exceeds the setting value, the compressor is stopped immediately. Operation starts again after a delay time of 3 minutes.

**(13) Outdoor unit failure**

This is a function for determining when there is trouble with the outdoor unit during air-conditioning.

The compressor is stopped if any one of the following in item (a), (b) is satisfied. Once the unit is stopped by this function, it is not restarted.

- (a) When the input current is measured at 1 A or less for 3 continuous minutes or more. (Model SCM40, 45, 50, 60, 71, 80 only)
- (b) If the compressor command sends a 0 rps signal to the indoor unit 3 times or more within 20 minutes of the power being turned on.

**(14) Discharge pipe sensor disconnection protection control**

(a) When the compressor command speed is other than 0 rps.

- (i) Tho-D(10)–Tho-D(0) < 8 °C, and Tho-D(10)–Tho-A(10) < 5 °C

The compressor command speed is set on A rps for 5 minutes. After 5 minutes, the compressor command speed is set on B rps for 5 minutes.

- (ii) Tho-D(20)–Tho-D(15) < 5 °C :

The compressor command speed is set on 0 rps.

Notes (1) Tho-D(X): After compressor operation, the discharge pipe temperature sensor after X minutes.

(2) Tho-A(X): After compressor operation, the outdoor air temperature sensor after X minutes.

(b) Once the unit is stopped by this function, it is not restarted.

• Values of A, B

Model	SCM40ZM-S	SCM45ZM-S	SCM50ZM-S	SCM60ZM-S	SCM71ZM-S	SCM80ZM-S	SCM100ZM-S	SCM125ZM-S
A	30 rps	30 rps	30 rps	20 rps	20 rps	20 rps	20 rps	20 rps
B	60 rps	60 rps	60 rps	60 rps	60 rps	60 rps	60 rps	60 rps

Note (1) In case of SCM71, 80, 100 or 125, when the jumper wire (J32) on the outdoor unit sub-PCB is short-circuited (factory default), this control is performed only at initial operation after turning the power source on. If the jumper wire (J32) is open, this control is not performed.

**(15) Regulation of outdoor air flow**

(a) The fan operates as follows according to the compressor command speed. (Except during defrost operation.)

**◆Models SCM40, 45, 50, 60**

	Cooling		Heating	
Compressor speed (rps)	Model SCM40: Less than 40	Model SCM40: 40 or more	Model SCM40: Less than 56	Model SCM40: 56 or more
	Model SCM45: Less than 40	Model SCM45: 40 or more	Model SCM45: Less than 56	Model SCM45: 56 or more
	Model SCM50: Less than 48	Model SCM50: 48 or more	Model SCM50: Less than 61	Model SCM50: 61 or more
	Model SCM60: Less than 48	Model SCM60: 48 or more	Model SCM60: Less than 61	Model SCM60: 61 or more
Outdoor fan speed	5th speed		6th speed	

**◆Models SCM71, 80**

	Cooling				Heating			
Compressor speed (rps)	Less than 31	More than 31 but 46 or less	More than 46 but 56 or less	56 or more	Less than 31	More than 31 but 66 or less	More than 66 but 78 or less	78 or more
Outdoor fan speed	3rd speed	4th speed	5th speed	6th speed	3rd speed	4th speed	5th speed	6th speed

**◆Models SCM100, 125**

	Cooling				Heating				
Compressor speed (rps)	Less than 31	More than 31 but 46 or less	More than 46 but 64 or less	64 or more	Less than 31	More than 31 but 66 or less	More than 66 but 85 or less	More than 85 but 96 or less	96 or more
Outdoor fan speed	4th speed	5th speed	6th speed	7th speed	4th speed	5th speed	6th speed	7th speed	8th speed

(b) If the outdoor unit's fan speed drops, the outdoor fan is run for 1 minute at that speed.

**(16) Serial signal transmission error protection**

(a) **Purpose:** Prevents malfunction resulting from error on the indoor ↔ outdoor signals.

(b) **Detail of operation:** If the compressor is operating and a serial signal cannot be received from the indoor control with outdoor control having serial signals continues for 7 minute and 35 seconds, the compressor is stopped.

After the compressor has been stopped, it will be restarted after the compressor start delay if a serial signal can be received again from the indoor control.

**(17) Rotor lock (Models SCM40, 45, 50, 60, 71, 80 only)**

If the motor for the compressor does not turn after it has been started, it is determined that a compressor lock has occurred and the compressor is stopped.

**(18) Outdoor fan motor protection**

If the outdoor fan motor has operated at 75 min<sup>-1</sup> or under for more than 30 seconds, the compressor and fan motor are stopped.

**(19) Outdoor fan control at low outdoor temperature****(a) Cooling****(i) Models SCM40, 45, 50, 60, 71, 80**

1) **Operating conditions:** When the outdoor air temperature (Tho-A) is 22°C or lower continues for 30 seconds while the compressor command speed is other than 0 rps.

2) **Detail of operation:** After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat exchanger temperature shall implement the following controls.

**● Value of A**

	Outdoor fan
Outdoor air temperature > 10°C	2nd speed
Outdoor air temperature ≤ 10°C	1st speed

a) Outdoor heat exchanger temperature (Tho-R) ≤ 22°C

After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is lower than 22°C, gradually reduce the outdoor fan speed by 1 speed.

**● Lower limit speed**

	Lower limit speed
Outdoor air temperature > 16°C	2nd speed
Outdoor air temperature ≤ 16°C	1st speed

- b)  $22^{\circ}\text{C} < \text{Outdoor heat exchanger temperature (Tho-R)} \leq 40^{\circ}\text{C}$   
After the outdoor fan speed maintains at A speed for 20 seconds; if the outdoor heat exchanger temperature is  $22^{\circ}\text{C}$ - $40^{\circ}\text{C}$ , maintain outdoor fan speed.
- c) Outdoor heat exchanger temperature (Tho-R)  $> 40^{\circ}\text{C}$   
After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is higher than  $40^{\circ}\text{C}$ , gradually increase outdoor fan speed by 1 speed. (Upper limit 4th (model SCM 71,80:3rd) speed)

**3) Reset conditions:** When either of the following conditions is satisfied

- a) The outdoor air temperature (Tho-A) is  $24^{\circ}\text{C}$  or higher.
- b) The compressor command speed is 0 rps.

**(ii) Models SCM100, 125**

**1) Operating conditions:** When the outdoor air temperature (Tho-A) is  $22^{\circ}\text{C}$  or lower continues for 30 seconds while the compressor command speed is other than 0 rps.

**2) Detail of operation:** After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat exchanger temperature shall implement the following controls.

● Value of A

	Outdoor fan
Outdoor air temperature $> 10^{\circ}\text{C}$	3rd speed
Outdoor air temperature $\leq 10^{\circ}\text{C}$	1st speed

- a) High pressure sensor (HPS)  $\leq 1.50\text{MPa}$   
After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the high pressure sensor is lower than  $1.50\text{MPa}$ , gradually reduce the outdoor fan speed by 1 speed.

● Lower limit speed

	Lower limit speed
Outdoor air temperature $> 16^{\circ}\text{C}$	3rd speed
Outdoor air temperature $\leq 16^{\circ}\text{C}$	1st speed

- b)  $1.50\text{MPa} < \text{High pressure sensor (HPS)} \leq 2.72\text{MPa}$   
After the outdoor fan speed maintains at A speed for 20 seconds; if the high pressure sensor  $1.50\text{MPa} - 2.72\text{MPa}$ , maintain outdoor fan speed.
- c) High pressure sensor (HPS)  $> 2.72\text{MPa}$   
After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the high pressure sensor is higher than  $2.72\text{MPa}$ , gradually increase outdoor fan speed by 1 speed. (Upper limit 4th speed)

**3) Reset conditions:** When either of the following conditions is satisfied

- a) The high pressure sensor (HPS) is  $2.72\text{MPa}$  or higher.
- b) The compressor command speed is 0 rps.

**(b) Heating**

**(i) Operating conditions:** When the outdoor air temperature (Tho-A) is  $3^{\circ}\text{C}$  or lower continues for 30 seconds while the compressor command speed is other than 0 rps.


**(ii) Detail of operation:** The outdoor fan is stepped up by 1 speed. [Upper limit 7th (SCM100, 125:8th) speed]

**(iii) Reset conditions:** When either of the following conditions is satisfied

- 1) The outdoor air temperature (Tho-A) is  $5^{\circ}\text{C}$  or higher.
- 2) The compressor command speed is 0 rps.

**(20) Outdoor unit fan control at overload****(a) Cooling**


- (i) Starting condition:** When the outdoor air temperature (Tho-A) has risen higher than 41°C for 30 seconds continuously while the compressor is operating.



- (ii) Contents of control:** The outdoor unit fan is stepped up by 3 speed. [Upper limit 6th (SCM100, 125:7th) speed]
- (iii) Reset condition:** When the compressor is turned off or the outdoor air temperature (Tho-A) has dropped lower than 40°C.

**(b) Heating**

- (i) Start condition:** When the outdoor heat exchanger temperature (Tho-R) has risen higher than 13°C for 30 seconds continuously while the compressor is operating.



- (ii) Contents of control:** The outdoor unit fan is stepped down by 3 speed. (Lower limit is 2nd speed)
- (iii) Reset condition:** When the compressor is turned off or the outdoor heat exchanger temperature (Tho-R) has dropped lower than 10°C.

**(21) Anomalous power transistor (SCM100, 125 only)**

When anomalous rise of the power transistor temperature is detected for 15 minutes continuously.

**(22) Power transistor overheat protection (SCM100, 125 only)**

- (a) Purpose:** Prevention of malfunction, deterioration, breakage, etc. of the control

**(b) Contents of restriction**

Restricts the speed of compressor when the temperature of power transistor (Tho-AF) rises higher than 90°C.

	Tho-AF < 80°C	80°C ≤ Tho-AF < 90°C	90°C ≤ Tho-AF < 110°C	90°C ≤ Tho-AF < 110°C	Tho-AF ≥ 110°C
Protection control speed (NP)	Normal	Retention	NP-2rps	NP-4rps	0rps
Sampling time (s)	Normal	20	20	20	—

**(c) Reset condition**

When the power transistor temperature is lower than 90°C or when the compressor has stopped.

**(d) Anomalous stop**

It stops anomalously if it occurs 2 times within 60 minutes or it has elapsed 60 minutes after the first establishment of the condition.

**(23) Control of the flowing noise of refrigerant during cooling operation (SCM100, 125 only)**

In order to suppress the flowing noise of refrigerant when operating 1 unit of indoor unit, the compressor is operated at the Max speed of 40 rps if the jumper wire (J31) on the outdoor sub-PCB is set to open.

## 8. MAINTENANCE DATA

### 8.1 SRK, SRF and SRR series

#### (1) Cautions

- (a) If you are disassembling and checking an air-conditioner, be sure to turn off the power before beginning. When working on indoor units, let the unit sit for about 1 minute after turning off the power before you begin work. When working on an outdoor unit, there may be an electrical charge applied to the main circuit (electrolytic condenser), so begin work only after discharging this electrical charge (to DC10V or lower).
- (b) When taking out printed circuit boards, be sure to do so without exerting force on the circuit boards or package components.
- (c) When disconnecting and connecting connectors, take hold of the connector housing and do not pull on the lead wires.

#### (2) Items to check before troubleshooting


- (a) Have you thoroughly investigated the details of the trouble which the customer is complaining about?
- (b) Is the air-conditioner running? Is it displaying any self-diagnosis information?
- (c) Is a power source with the correct voltage connected?
- (d) Are the control lines connecting the indoor and outdoor units wired correctly and connected securely?
- (e) Is the outdoor unit's service valve open?


#### (3) Troubleshooting procedure (If the air-conditioner does not run at all)

If the air-conditioner does not run at all, diagnose the trouble using the following troubleshooting procedure. If the air-conditioner is running but breaks down, proceed to troubleshooting step (4).

**Important** When all the following conditions are satisfied, we say that the air-conditioner will not run at all.

- (a) The RUN light does not light up.
- (b) The flaps do not open.
- (c) The indoor unit fan motors do not run.
- (d) The self-diagnosis display does not function.



**(4) Troubleshooting procedure (If the air-conditioner runs)**

Note (1) Even in cases where only intermittent stop data are generated, the air-conditioning system is normal. However, if the same protective operation recurs repeatedly (3 or more times), it will lead to customer complaints. Judge the conditions in comparison with the contents of the complaints.

## (5) Self-diagnosis table

When this air-conditioner performs an emergency stop, the reason why the emergency stop occurred is displayed by the flashing of display lights. If the air-conditioner is operated using the remote control 3 minutes or more after the emergency stop, the trouble display stops and the air-conditioner resumes operation. <sup>(1)</sup>

### (a) Models SCM40, 45, 50, 60, 71, 80

Indoor unit display panel		Outdoor main PCB Red LED	Wired <sup>(2)</sup> remote control display	Description of trouble	Cause	Display (flashing) condition
RUN light	TIMER light					
1-time flash	ON	Stays OFF	—	Heat exchanger sensor 1 error	• Broken heat exchanger sensor 1 wire, poor connector connection • Indoor PCB is faulty	When a heat exchanger sensor 1 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
2-time flash	ON	Stays OFF	—	Room temperature sensor error	• Broken room temperature sensor wire, poor connector connection • Indoor PCB is faulty	When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of -45°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
3-time flash	ON	Stays OFF	—	Heat exchanger sensor 2 error	• Broken heat exchanger sensor 2 wire, poor connector connection • Indoor PCB is faulty	When a heat exchanger sensor 2 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
4-time flash	ON	Stays OFF	E 9	Drain <sup>(3)</sup> trouble	• Defective drain pump (DM), broken drain pump wire • Anomalous float switch operation • Defective indoor PCB faulty	If the float switch OPEN is detected for 3 seconds continuously or if float switch connector or wire is disconnected.
6-time flash	ON	Stays OFF	E 16	Indoor fan motor error	• Defective fan motor, poor connector connection	When conditions for turning the indoor unit's fan motor on exist during air-conditioner operation, an indoor unit fan motor speed of 300 (SRF : 150) min <sup>-1</sup> or lower is measured for 30 seconds or longer. (The air conditioner stops.)
Keeps flashing	1-time flash	8-time flash	E 38	Outdoor air temperature sensor error	• Broken outdoor air temp. sensor wire, poor connector connection • Outdoor main PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	2-time flash	8-time flash	E 37	Outdoor heat exchanger sensor error	• Broken heat exchanger sensor wire, poor connector connection • Outdoor main PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	4-time flash	8-time flash	E 39	Discharge pipe sensor error	• Broken discharge pipe sensor wire, poor connector connection • Outdoor main PCB is faulty	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)
Keeps flashing	5-time flash	8-time flash	E 53	Outdoor suction pipe sensor error	• Broken suction pipe sensor wire, poor connector connection • Outdoor sub PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
ON	1-time flash	1-time flash	E 42	Current cut	• Compressor locking, open phase on compressor output, short circuit on power transistor, service valve is closed	The compressor output current exceeds the set value during compressor start. (The air-conditioner stops.)
ON	2-time flash	2-time flash	E 59	Trouble of outdoor unit	• Broken compressor wire • Compressor blockage	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value. (The air-conditioner stops.)
ON	3-time flash	3-time flash	E 58	Current safe stop	• Overload operation • Overcharge • Compressor locking	When the compressor command speed is lower than the set value and the current safe has operated. (the compressor stops)
ON	4-time flash	1-time flash	E 51	Power transistor error	• Broken power transistor	When the power transistor is judged breakdown while compressor starts. (The compressor is stopped.)
ON	5-time flash	5-time flash	E 36	Over heat of compressor	• Gas shortage, defective discharge pipe sensor, service valve is closed	When the value of the discharge pipe sensor exceeds the set value. (The air-conditioner stops.)
ON	6-time flash	6-time flash	E 5	Error of signal transmission	• Defective power source, Broken signal wire, defective indoor/outdoor sub PCB	When there is no signal between the indoor PCB and outdoor PCB for 10 seconds or longer (when the power is turned on), or when there is no signal for 7 minute 35 seconds or longer (during operation)(the compressor is stopped).
ON	7-time flash	ON	E 48	Outdoor fan motor error	• Defective fan motor, poor connector connection	When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 min <sup>-1</sup> or lower. (3 times) (The air conditioner stops.)
ON	Keeps flashing	2-time flash	E 35	Cooling high pressure protection	• Overload operation, overcharge • Broken outdoor heat exchange sensor wire • Service valve is closed	When the value of the outdoor heat exchanger sensor exceeds the set value.
2-time flash	2-time flash	7-time flash	E 60	Rotor lock	• Defective compressor • Open phase on compressor • Defective outdoor PCB	If the compressor motor's magnetic pole positions cannot be correctly detected when the compressor starts. (The air-conditioner stops.)
5-time flash	ON	2-time flash	E 47	Active filter voltage error	• Defective active filter	When the wrong voltage connected for the power source. When the outdoor main PCB is faulty
7-time flash	ON	2-time flash	E 57	Refrigeration cycle system protective control	• Service valve is closed. • Refrigerant is insufficient	When refrigeration cycle system protective control operates.
—	—	4-time flash	E 45	Outdoor sub PCB communication error	• Outdoor sub PCB faulty • Poor connection of wire between outdoor sub PCB – main PCB	Communication error for 15 minutes: Detected more than 15 seconds 4 times
—	—	Stays OFF	E 1	Error of wired remote control wiring	• Broken wired remote control wire, defective indoor PCB	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor PCB is faulty. (The communications circuit is faulty.)
Stays OFF	Keeps flashing	—	—	Limit switch error	• Defective limit switch • Defective suction panel set • Defective indoor control PCB	Actuation of limit switch

Notes (1)The air-conditioner cannot be restarted using the remote control for 3 minutes after operation stops.

(2)The wired remote control is option parts.

(3)SRR series only.

**(b) Models SCM100,125**

Indoor unit display panel		Outdoor main PCB Red LED	Wired remote control display	Description of trouble	Cause	Display (flashing) condition
RUN light	TIMER light					
1-time flash	ON	Stays OFF	—	Heat exchanger sensor 1 error	<ul style="list-style-type: none"> <li>Broken heat exchanger sensor 1 wire, poor connector connection</li> <li>Indoor PCB is faulty</li> </ul>	When a heat exchanger sensor 1 wire disconnection is detected while operation is stopped. (If a temperature of $-28^{\circ}\text{C}$ or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
2-time flash	ON	Stays OFF	—	Room temperature sensor error	<ul style="list-style-type: none"> <li>Broken room temperature sensor wire, poor connector connection</li> <li>Indoor PCB is faulty</li> </ul>	When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of $-45^{\circ}\text{C}$ or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
3-time flash	ON	Stays OFF	—	Heat exchanger sensor 2 error	<ul style="list-style-type: none"> <li>Broken heat exchanger sensor 2 wire, poor connector connection</li> <li>Indoor PCB is faulty</li> </ul>	When a heat exchanger sensor 2 wire disconnection is detected while operation is stopped. (If a temperature of $-28^{\circ}\text{C}$ or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
4-time flash	ON	Stays OFF	E 9	Drain <sup>(3)</sup> trouble	<ul style="list-style-type: none"> <li>Defective drain pump (DM), broken drain pump wire</li> <li>Anomalous float switch operation</li> <li>Defective indoor PCB faulty</li> </ul>	If the float switch OPEN is detected for 3 seconds continuously or if float switch connector or wire is disconnected.
6-time flash	ON	Stays OFF	E 16	Indoor fan motor error	<ul style="list-style-type: none"> <li>Defective fan motor, poor connector connection</li> </ul>	When conditions for turning the indoor unit's fan motor on exist during air-conditioner operation, an indoor unit fan motor speed of $300 (\text{SRF} : 150) \text{ min}^{-1}$ or lower is measured for 30 seconds or longer. (The air-conditioner stops.)
Keeps flashing	1-time flash	8-time flash	E 38	Outdoor air temperature sensor error	<ul style="list-style-type: none"> <li>Broken outdoor air temp. sensor wire, poor connector connection</li> <li>Outdoor main PCB is faulty</li> </ul>	$-55^{\circ}\text{C}$ or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or $-55^{\circ}\text{C}$ or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	2-time flash	8-time flash	E 37	Outdoor heat exchanger sensor error	<ul style="list-style-type: none"> <li>Broken heat exchanger sensor wire, poor connector connection</li> <li>Outdoor main PCB is faulty</li> </ul>	$-55^{\circ}\text{C}$ or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or $-55^{\circ}\text{C}$ or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps flashing	4-time flash	8-time flash	E 39	Discharge pipe sensor error	<ul style="list-style-type: none"> <li>Broken discharge pipe sensor wire, poor connector connection</li> <li>Outdoor main PCB is faulty</li> </ul>	$-25^{\circ}\text{C}$ or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)
Keeps flashing	5-time flash	8-time flash	E 53	Outdoor suction pipe sensor error	<ul style="list-style-type: none"> <li>Broken suction pipe sensor wire, poor connector connection</li> <li>Outdoor sub PCB is faulty</li> </ul>	$-55^{\circ}\text{C}$ or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or $-55^{\circ}\text{C}$ or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
ON	1-time flash	1-time flash	E 42	Current cut	<ul style="list-style-type: none"> <li>Compressor locking, open phase on compressor output, short circuit on power transistor, service valve is closed</li> </ul>	The compressor output current exceeds the set value during compressor start. (The air-conditioner stops.)
ON	2-time flash	2-time flash	E 59	Trouble of outdoor unit	<ul style="list-style-type: none"> <li>Broken compressor wire</li> <li>Compressor blockage</li> </ul>	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value. (The air-conditioner stops.)
ON	4-time flash	1-time flash	E 51	Inverter and fan motor anomaly	<ul style="list-style-type: none"> <li>Outdoor inverter PCB is faulty</li> <li>Outdoor control PCB is faulty</li> <li>Outdoor fan motor is faulty</li> </ul>	When power transistor anomaly is detected for 15 minutes continuously (The compressor is stopped.)
ON	5-time flash	5-time flash	E 36	Over heat of compressor	<ul style="list-style-type: none"> <li>Gas shortage, defective discharge pipe sensor, service valve is closed</li> </ul>	When the value of the discharge pipe sensor exceeds the set value. (The air-conditioner stops.)
ON	6-time flash	6-time flash	E 5	Error of signal transmission	<ul style="list-style-type: none"> <li>Defective power source, broken signal wire, defective indoor/outdoor sub PCB</li> </ul>	When there is no signal between the indoor PCB and outdoor PCB for 10 seconds or longer (when the power is turned on), or when there is no signal for 7 minute 35 seconds or longer (during operation) (the compressor is stopped.)
ON	7-time flash	ON	E 48	Outdoor fan motor error	<ul style="list-style-type: none"> <li>Defective fan motor, poor connector connection</li> </ul>	When the outdoor unit's fan motor speed continues for 30 seconds or longer at $75 \text{ min}^{-1}$ or lower. (3 times) (The air-conditioner stops.)
ON	Keeps flashing	2-time flash	E 35	Cooling high pressure protection	<ul style="list-style-type: none"> <li>Overload operation, overcharge</li> <li>Broken high pressure sensor wire</li> <li>Service valve is closed</li> </ul>	When anomalous rise of the high pressure sensor is detected 5 times within 1 hour. When high pressure sensor anomaly is detected for 10 minutes continuously.
7-time flash	ON	2-time flash	E 57	Refrigeration cycle system protective control	<ul style="list-style-type: none"> <li>Service valve is closed.</li> <li>Refrigerant is insufficient</li> </ul>	When refrigeration cycle system protective control operates.
—	—	1-time flash	E 41	Power transistor error	<ul style="list-style-type: none"> <li>Power transistor overheat</li> </ul>	When anomalous rise of the power transistor temperature is detected 2 times within 1 hour.
—	—	2-time flash	E 40	Heating high pressure protection	<ul style="list-style-type: none"> <li>Overload operation, overcharge</li> <li>Broken high pressure sensor wire</li> <li>Service valve is closed</li> </ul>	When anomalous rise of the high pressure sensor is detected 5 times within 1 hour. When high pressure sensor anomaly is detected for 10 minutes continuously.
—	—	4-time flash	E 45	Outdoor sub PCB communication error	<ul style="list-style-type: none"> <li>Outdoor sub PCB faulty</li> <li>Poor connection of wire between outdoor sub PCB – main PCB</li> </ul>	Communication error for 15 minutes: Detected more than 15 seconds 4 times.
—	—	8-time flash	E 54	High pressure sensor error	<ul style="list-style-type: none"> <li>Broken high pressure sensor wire</li> </ul>	If the detected for 5 second continuously within 2 minutes to 2 minutes and 20 seconds after the compressor ON, the compressor stops.
—	—	Stays OFF	E 1	Error of wired remote control wiring	<ul style="list-style-type: none"> <li>Broken wired remote control wire, defective indoor PCB</li> </ul>	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor PCB is faulty. (The communications circuit is faulty.)
Stays OFF	Keeps flashing	—	—	Limit switch error	<ul style="list-style-type: none"> <li>Defective limit switch</li> <li>Defective suction panel set</li> <li>Defective indoor control PCB</li> </ul>	Actuation limit switch

Notes (1) The air-conditioner cannot be restarted using the remote control for 3 minutes after operation stops.

(2) The wired remote control is option parts.


(3) SRR series only.

**(6) Service mode (Trouble mode access function)**


This air-conditioner is capable of recording error displays and protective stops (service data) which have occurred in the past. If self-diagnosis displays cannot be confirmed, it is possible to get a grasp of the conditions at the time trouble occurred by checking these service data.

**(a) Explanation of terms**

Term	Explanation
<b>Service mode</b>	The service mode is the mode where service data are displayed by flashing of the display lights when the operations in item (b) below are performed with the indoor control.
<b>Service data</b>	These are the contents of error displays and protective stops which occurred in the past in the air-conditioner system. Error display contents and protective stop data from past anomalous operations of the air-conditioner system are saved in the indoor unit control's non-volatile memory (memory which is not erased when the power goes off). There are two types of data, self-diagnosis data and stop data, described below.
<b>Self-diagnosis data</b>	These are the data which display the reason why a stop occurred when an error display(self-diagnosis display) occurred in an indoor unit. Data are recorded for up to 5 previous occurrences. Data which are older than the 5th previous occurrence are erased. In addition, data on the temperature of each sensor (room temperature, indoor heat exchanger, outdoor heat exchanger, outdoor air temperature, discharge pipe), remote control information (operation switching, fan speed switching) are recorded when trouble occurs, so more detailed information can be checked.
<b>Stop data</b>	These are the data which display the reason by a stop occurred when the air-conditioning system performed protective stops, etc. in the past. Even if stop data alone are generated, the system restarts automatically. (After executing the stop mode while the display is normal, the system restarts automatically.) Data for up to 10 previous occasions are stored. Data older than the 10th previous occasion are erased. ( Important) In cases where transient stop data only are generated, the air-conditioner system may still be normal. However, if the same protective stop occurs frequently (3 or more times), it could lead to customer complaints.

**(b) Service mode display procedure**

- \*3: To count the number of flashes in the service mode, count the number of flashes after the light lights up for 1.5 second initially (start signal). (The time that the light lights up for 1.5 second (start signal) is not counted in the number of flashes.)



- \*4: When in the service mode, when the wireless remote control settings (operation mode, fan speed mode, temperature setting) are set as shown in the following table and sent to the air-conditioner unit, the unit switches to display of service data.

### (i) Self-diagnosis data

What are Self-diagnosis Data?

These are control data (reasons for stops, temperature at each sensor, wireless remote control information) from the time when there were error displays (abnormal stops) in the indoor unit in the past.

Data from up to 5 previous occasions are stored in memory. Data older than the 5th previous occasion are erased.

The temperature setting indicates how many occasions previous to the present setting the error display data are and the operation mode and fan speed mode data show the type of data.

Wireless remote control setting		Contents of output data
Operation mode	Fan speed mode	
Cooling	MED	Displays the reason for stopping display in the past (error code).
	HI	Displays the room temperature sensor temperature at the time the error code was displayed in the past.
	AUTO	Displays the indoor heat exchanger sensor temperature at the time the error code was displayed in the past.
Heating	LO	Displays the wireless remote control information at the time the error code was displayed in the past.
	MED	Displays the outdoor air temperature sensor temperature at the time the error code was displayed in the past.
	HI	Displays the outdoor heat exchanger sensor temperature at the time the error code was displayed in the past.
	AUTO	Displays the discharge pipe sensor temperature at the time the error code was displayed in the past.

Wireless remote control setting	Indicates the number of occasions previous to the present the error display data are from.
Temperature setting	
21°C	1 time previous (previous time)
22°C	2 times previous
23°C	3 times previous
24°C	4 times previous
25°C	5 times previous

### Only for indoor heat exchanger sensor 2

Wireless remote control setting	Indicates the number of occasions previous to the present the error display data are from.
Temperature setting	
26°C	1 time previous (previous time)
27°C	2 times previous
28°C	3 times previous
29°C	4 times previous
30°C	5 times previous

## (Example)

Wireless remote control setting			Displayed data
Operation mode	Fan speed mode	Temperature setting	
Cooling	MED	21°C	Displays the reason for the stop (error code) the previous time an error was displayed.
		22°C	Displays the reason for the stop (error code) 2 times previous when an error was displayed.
		23°C	Displays the reason for the stop (error code) 3 times previous when an error was displayed.
		24°C	Displays the reason for the stop (error code) 4 times previous when an error was displayed.
		25°C	Displays the reason for the stop (error code) 5 times previous when an error was displayed.

## (ii) Stop data

Wireless remote control setting			Displayed data
Operation mode	Fan speed mode	Temperature setting	
Cooling	LO	21°C	Displays the reason for the stop (stop code) the previous time when the air-conditioner was stopped by protective stop control.
		22°C	Displays the reason for the stop (stop code) 2 times previous when the air-conditioner was stopped by protective stop control.
		23°C	Displays the reason for the stop (stop code) 3 times previous when the air-conditioner was stopped by protective stop control.
		24°C	Displays the reason for the stop (stop code) 4 times previous when the air-conditioner was stopped by protective stop control.
		25°C	Displays the reason for the stop (stop code) 5 times previous when the air-conditioner was stopped by protective stop control.
		26°C	Displays the reason for the stop (stop code) 6 times previous when the air-conditioner was stopped by protective stop control.
		27°C	Displays the reason for the stop (stop code) 7 times previous when the air-conditioner was stopped by protective stop control.
		28°C	Displays the reason for the stop (stop code) 8 times previous when the air-conditioner was stopped by protective stop control.
		29°C	Displays the reason for the stop (stop code) 9 times previous when the air-conditioner was stopped by protective stop control.
		30°C	Displays the reason for the stop (stop code) 10 times previous when the air-conditioner was stopped by protective stop control.

**(c) Error code, stop code table** (Assignment of error codes and stop codes is done in common for all models.)**(i) Models SCM40, 45, 50, 60, 71, 80**

Number of flashes when in service mode		Stop code or Error code	Error content	Cause	Occurrence conditions	Error display	Auto recovery
RUN light (10's digit)	TIMER light (1's digit)						
OFF	OFF	0	Normal	—	—	—	—
	5-time flash	05	Can not receive signals for 35 seconds (if communications have recovered)	Power source is faulty. Power source cables and signal lines are improperly wired. Indoor or outdoor sub PCB are faulty	When 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○	—
3-time flash	5-time flash	35	Cooling high pressure control	Cooling overload operation. Outdoor unit fan speed drops. Outdoor heat exchanger sensor is short circuit.	When the outdoor heat exchanger sensor's value exceeds the set value.	○ (5 times)	○
	6-time flash	36	Compressor overheat 115°C	Refrigerant is insufficient. Discharge pipe sensor is faulty. Service valve is closed.	When the discharge pipe sensor's value exceeds the set value.	○ (2 times)	○
	7-time flash	37	Outdoor heat exchanger sensor is abnormal	Outdoor heat exchanger sensor wire is disconnected. Connector connections are poor. Outdoor main PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times)	○
	8-time flash	38	Outdoor air temperature sensor is abnormal	Outdoor air temperature sensor wire is disconnected. Connector connections are poor. Outdoor main PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times)	○
	9-time flash	39	Discharge pipe sensor is abnormal (anomalous stop)	Discharge pipe sensor wire is disconnected. Connector connections are poor. Outdoor main PCB is faulty	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature.	○ (3 times)	○
4-time flash	2-time flash	42	Current cut	Compressor lock. Compressor wiring short circuit. Compressor output is open phase. Outdoor main PCB is faulty Service valve is closed. Electronic expansion valve is faulty. Compressor is faulty.	Compressor start fails 42 times in succession and the reason for the final failure is current cut.	○ (2 times)	○
	5-time flash	45	Anomalous outdoor sub PCB communication	Outdoor sub PCB faulty. Poor connection of wire between outdoor sub PCB-main PCB.	Communication error for 15 minutes: Detected more than 15 seconds 4 times.	○	○
	7-time flash	47	Active filter voltage error	Defective active filter.	When the wrong voltage connected for the power source. When the outdoor main PCB is faulty.	○	—
	8-time flash	48	Outdoor unit's fan motor is abnormal	Outdoor fan motor is faulty. Connector connections are poor. Outdoor main PCB is faulty.	When a fan speed of 75 min <sup>-1</sup> or lower continues for 30 seconds or longer.	○ (3 times)	○
5-time flash	1-time flash	51	Short circuit in the power transistor (high side) Current cut circuit breakdown	Outdoor main PCB is faulty Power transistor is damaged.	When it is judged that the power transistor was damaged at the time the compressor started.	○	—
	3-time flash	53	Suction pipe sensor is abnormal	Suction pipe sensor wire is disconnected. Connector connections are poor. Outdoor sub PCB is faulty.	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C higher is detected for 5 seconds continuously within 20 seconds after compressor ON.	○ (3 times)	○
	7-time flash	57	Refrigeration cycle system protective control	Service valve is closed. Refrigerant is insufficient.	When refrigeration cycle system protective control operates.	○ (3 times)	○
	8-time flash	58	Current safe	Refrigerant is overcharge. Compressor lock. Overload operation.	When there is a current safe stop during operation.	—	○
	9-time flash	59	Compressor wiring is unconnection Voltage drop	Compressor wiring is disconnected. Power transistor is damaged. Power supply construction is defective. Outdoor main PCB is faulty. Compressor is faulty.	When the current is 1A or less at the time the compressor started. When the power supply voltage drops during operation.	○	○
6-time flash	OFF	60	Rotor lock	Compressor is faulty. Compressor output is open phase. Electronic expansion valve is faulty. Overload operation. Outdoor main PCB is faulty.	After the compressor starts, when the compressor stops due to rotor lock.	○ (2 times)	○
	1-time flash	61	Connection lines between the indoor and outdoor units are faulty	Connection lines are faulty. Indoor or outdoor sub PCB are faulty.	When 10 seconds passes after the power is turned on without communications signals from the indoor or outdoor unit being detected correctly.	○	—
	2-time flash	62	Serial transmission error	Indoor or outdoor sub PCB are faulty. Noise is causing faulty operation.	When 7 minute 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○	—
8-time flash	OFF	80	Indoor unit's fan motor is abnormal	Indoor fan motor is faulty. Connector connections are poor. Indoor PCB is faulty.	When the indoor unit's fan motor is detected to be running at 300 (SRF : 150) min <sup>-1</sup> or lower speed with the fan motor in the ON condition while the air-conditioner is running.	○	—
	2-time flash	82	Indoor heat exchanger sensor is abnormal (anomalous stop)	Indoor heat exchanger sensor wire is disconnected. Connector connections are poor	When a temperature of -28°C or lower is sensed continuously for 40 minutes during heating operation. (the compressor stops).	○	—
	4-time flash	84	Anti-condensation control	High humidity condition. Humidity sensor is faulty.	Anti-condensation prevention control is operating.	—	○
	5-time flash	85	Anti-frost control	Indoor unit fan speed drops. Indoor heat exchanger sensor is broken wire.	When the anti-frost control operates and the compressor stops during cooling operation.	—	○
	6-time flash	86	Heating high pressure control	Heating overload operation. Indoor unit fan speed drops. Indoor heat exchanger sensor is short circuit.	When high pressure control operates during heating operation and the compressor stops.	—	○
	7-time flash	87	Drain trouble	Defective drain pump (DM). broken drain pump wire Anomalous float switch operation Defective indoor PCB faulty	If the float switch OPEN is detected for 3 seconds continuously or if float switch connector or wire is disconnected.	○ (4 times)	—


## (ii) Models SCM100,125

Number of flashes when in service mode		Stop code or Error code	Error content	Cause	Occurrence conditions	Error display	Auto recovery
RUN light (10's digit)	TIMER light (1's digit)						
OFF	OFF	0	Normal	—	—	—	—
	5-time flash	05	Can not receive signals for 35 seconds (if communications have recovered)	Power source is faulty. Power source cables and signal lines are improperly wired. Indoor or outdoor PCB are faulty.	When 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○	—
3-time flash	5-time flash	35	Cooling high pressure control	Cooling overload operation. Outdoor unit fan speed drops. Outdoor high pressure sensor is short circuit.	When the outdoor high pressure sensor's value exceeds the set value.	○ (5 times)	○
	6-time flash	36	Compressor overheat 115°C	Refrigerant is insufficient. Discharge pipe sensor is faulty. Service valve is closed.	When the discharge pipe sensor's value exceeds the set value.	○ (2 times)	○
	7-time flash	37	Outdoor heat exchanger sensor is abnormal	Outdoor heat exchanger sensor wire is disconnected. Connector connections are poor. Outdoor control PCB is faulty.	–55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or –55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times)	○
	8-time flash	38	Outdoor air temperature sensor is abnormal	Outdoor air temperature sensor wire is disconnected. Connector connections are poor. Outdoor control PCB is faulty.	–55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or –55°C higher is detected for 5 seconds continuously within 20 seconds after power ON.	○ (3 times)	○
	9-time flash	39	Discharge pipe sensor is abnormal (anomalous stop)	Discharge pipe sensor wire is disconnected. Connector connections are poor. Outdoor control PCB is faulty.	–25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature.	○ (3 times)	○
	OFF	40	Heating high pressure control	Heating overload operation. Outdoor unit fan speed drops. Outdoor high pressure sensor is short circuit.	When the outdoor high pressure sensor's value exceeds the set value.	○ (5 times)	○
4-time flash	1-time flash	41	Power transistor error	Power transistor overheat. Power transistor sensor is short circuit.	When anomalous rise of the power transistor temperature is detected 2 times within 1 hour.	○ (2 times)	○
	2-time flash	42	Current cut	Compressor lock. Compressor wiring short circuit. Compressor output is open phase. Outdoor inverter PCB is faulty. Service valve is closed. Electronic expansion valve is faulty. Compressor is faulty.	Compressor start fails 42 times in succession and the reason for the final failure is current cut.	○ (2 times)	○
	5-time flash	45	Anomalous outdoor sub PCB communication	Outdoor sub PCB faulty. Poor connection of wire between outdoor sub PCB-control PCB.	Communication error for 15 minutes: Detected more than 15 seconds 4 times.	○	○
	8-time flash	48	Outdoor unit's fan motor is abnormal	Outdoor fan motor is faulty. Connector connections are poor. Outdoor control PCB is faulty.	When a fan speed of 75 min <sup>-1</sup> or lower continues for 30 seconds or longer.	○ (3 times)	○
5-time flash	1-time flash	51	Inverter and fan motor anomaly	Outdoor inverter PCB is faulty. Outdoor control PCB is faulty. Outdoor fan motor is faulty.	When power transistor anomaly is detected for 15 minutes continuously.	○	—
	3-time flash	53	Suction pipe sensor is abnormal	Suction pipe sensor wire is disconnected. Connector connections are poor. Outdoor control PCB is faulty.	–55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or –55°C higher is detected for 5 seconds continuously within 20 seconds after compressor ON.	○ (3 times)	○
	4-time flash	54	High pressure sensor is abnormal	High pressure sensor wire is disconnected. Connector connections are poor. Outdoor control PCB is faulty.	If the detected for 5 second continuously within 2 minutes to 2 minutes and 20 seconds after the compressor ON, the compressor stops.	○ (3 times)	○
	7-time flash	57	Refrigeration cycle system protective control	Service valve is closed. Refrigerant is insufficient.	When refrigeration cycle system protective control operates.	○ (3 times)	○
	9-time flash	59	Compressor wiring is unconnection Voltage drop	Compressor wiring is disconnected. Power transistor is damaged. Power source construction is defective. Outdoor inverter PCB is faulty. Compressor is faulty.	When the current is 1A or less at the time the compressor started. When the power source voltage drops during operation.	○	○
6-time flash	1-time flash	61	Connection lines between the indoor and outdoor units are faulty	Connection lines are faulty. Indoor or outdoor sub PCB are faulty.	When 10 seconds passes after the power is turned on without communications signals from the indoor or outdoor unit being detected correctly.	○	—
	2-time flash	62	Serial transmission error	Indoor or outdoor sub PCB are faulty. Noise is causing faulty operation.	When 7 minute 35 seconds passes without communications signals from either the outdoor unit or the indoor unit being detected correctly.	○	—

Number of flashes when in service mode		Stop code or Error code	Error content	Cause	Occurrence conditions	Error display	Auto recovery
RUN light (10's digit)	TIMER light (1's digit)						
8-time flash	OFF	80	Indoor unit's fan motor is abnormal	Indoor fan motor is faulty. Connector connections are poor. Indoor PCB is faulty.	When the indoor unit's fan motor is detected to be running at 300 (SRF : 150) min <sup>-1</sup> or lower speed with the fan motor in the ON condition while the air-conditioner is running.	○	—
	2-time flash	82	Indoor heat exchanger sensor is abnormal (anomalous stop)	Indoor heat exchanger sensor wire is disconnected. Connector connections are poor.	When a temperature of -28°C or lower is sensed continuously for 40 minutes during heating operation. (the compressor stops).	○	—
	4-time flash	84	Anti-condensation control	High humidity condition. Humidity sensor is faulty.	Anti-condensation prevention control is operating.	—	○
	5-time flash	85	Anti-frost control	Indoor unit fan speed drops. Indoor heat exchanger sensor is broken wire.	When the anti-frost control operates and the compressor stops during cooling operation.	—	○
	6-time flash	86	Heating high pressure control	Heating overload operation. Indoor unit fan speed drops. Indoor heat exchanger sensor is short circuit.	When high pressure control operates during heating operation and the compressor stops.	—	○
	7-time flash	87	Drain trouble	Defective drain pump (DM). broken drain pump wire Anomalous float switch operation Defective indoor PCB faulty	If the float switch OPEN is defected for 3 seconds continuously or if float switch connector or wire is disconnected.	○ (4 times)	—

Notes (1) The number of flashes when in the service mode do not include the 1.5 second period when the lights light up at first (start signal). (See the example shown below.)

- In the case of current cut (example: stop code "42")  
The RUN light (10's digit) 4-time flash and the TIMER light (1's digit) 2-time flash.  
 $4 \times 10 + 2 \times 1 = 42 \rightarrow$  From the table, read the instructions for error code 42, "current cut".



- (2) Error display:
- Is not displayed. (automatic recovery only)
  - Displayed.
- If there is a ( ) displayed, the error display shows the number of times that an auto recovery occurred for the same reason has reached the number of times in ( ).
- If no ( ) is displayed, the error display shows that the trouble has occurred once.
- (3) Auto recovery:
- Does not occur
  - Auto recovery occurs.

#### (d) Operation mode, Fan speed mode information tables

(i) Operation mode

Display pattern when in service mode	Operation mode when there is an abnormal stop
RUN light (10's digit)	
—	AUTO
1-time flash	DRY
2-time flash	COOL
3-time flash	FAN
4-time flash	HEAT


(ii) Fan speed mode

Display pattern when in service mode	Fan speed mode when there is an abnormal stop
TIMER light (1's digit)	
—	AUTO
2-time flash	HI
3-time flash	MED
4-time flash	LO
5-time flash	ULO
6-time flash	HI POWER
7-time flash	ECONO

\* If no data are recorded (error code is normal), the information display in the operation mode and fan speed mode becomes as follows.

Mode	Display when error code is normal.
Operation mode	AUTO
Fan speed mode	AUTO

(Example): Operation mode: COOL, Fan speed mode: HI



## (e) Temperature information

- (i) Room temperature sensor, indoor heat exchanger sensor, outdoor air temperature sensor, outdoor heat exchanger sensor temperature.


Unit: °C

Buzzer sound	RUN light (10's digit)	TIMER light (1's digit)	0	1	2	3	4	5	6	7	8	9
			0	1	2	3	4	5	6	7	8	9
Yes (sounds for 0.1 second)	6		-60	-61	-62	-63	-64					
	5		-50	-51	-52	-53	-54	-55	-56	-57	-58	-59
	4		-40	-41	-42	-43	-44	-45	-46	-47	-48	-49
	3		-30	-31	-32	-33	-34	-35	-36	-37	-38	-39
	2		-20	-21	-22	-23	-24	-25	-26	-27	-28	-29
	1		-10	-11	-12	-13	-14	-15	-16	-17	-18	-19
	0			-1	-2	-3	-4	-5	-6	-7	-8	-9
No (does not sound)	0		0	1	2	3	4	5	6	7	8	9
	1		10	11	12	13	14	15	16	17	18	19
	2		20	21	22	23	24	25	26	27	28	29
	3		30	31	32	33	34	35	36	37	38	39
	4		40	41	42	43	44	45	46	47	48	49
	5		50	51	52	53	54	55	56	57	58	59
	6		60	61	62	63	64	65	66	67	68	69
	7		70	71	72	73	74	75	76	77	78	79
	8		80	81	82	83	84	85	86	87	88	89
	9		90	91	92	93	94	95	96	97	98	99

\* If no data are recorded (error code is normal), the display for each temperature information becomes as shown below.

Sensor name	Sensor value displayed when the error code is normal
Room temperature sensor	-64°C
Indoor heat exchanger sensor	-64°C
Outdoor air temperature sensor	-64°C
Outdoor heat exchanger sensor	-64°C

(Example) Outdoor heat exchanger temperature data: “-9°C”



## (ii) Discharge pipe sensor temperature.

Unit: °C


Buzzer sound \ RUN light (10's digit) \ TIMER light (1's digit)		0	1	2	3	4	5	6	7	8	9
		0	1	2	3	4	5	6	7	8	9
Yes (sounds for 0.1 second)	3	-60	-62	-64							
	2	-40	-42	-44	-46	-48	-50	-52	-54	-56	-58
	1	-20	-22	-24	-26	-28	-30	-32	-34	-36	-38
	0	/	-2	-4	-6	-8	-10	-12	-14	-16	-18
No (does not sound)	0	0	2	4	6	8	10	12	14	16	18
	1	20	22	24	26	28	30	32	34	36	38
	2	40	42	44	46	48	50	52	54	56	58
	3	60	62	64	66	68	70	72	74	76	78
	4	80	82	84	86	88	90	92	94	96	98
	5	100	102	104	106	108	110	112	114	116	118
	6	120	122	124	126	128	130	132	134	136	138
	7	140	142	144	146	148	150				

\* If no data are recorded (error code is normal), the display for each temperature information becomes as shown below.

Sensor name	Sensor value displayed when the error code is normal
Discharge pipe sensor	-64°C

(Example) Discharge pipe temperature data: "122°C"

\* In the case of discharge pipe data, multiply the reading value by 2. (Below,  $61 \times 2 = "122°C"$ )




## Service data record form


Customer				Model			
Date of investigation							
Machine name							
Content of complaint							
Wireless remote control settings			Content of displayed data	Display results			Display content
Temperature setting	Operation mode	Fan speed mode		Buzzer (Yes/No.)	RUN light (Times)	TIMER light (Times)	
21	Cooling	MED	Error code on previous occasion.				
		HI	Room temperature sensor on previous occasion.				
		AUTO	Indoor heat exchanger sensor 1 on previous occasion.				
	Heating	LO	Wireless remote control information on previous occasion.				
		MED	Outdoor air temperature sensor on previous occasion.				
		HI	Outdoor heat exchanger sensor on previous occasion.				
		AUTO	Discharge pipe sensor on previous occasion.				
26	Cooling	AUTO	Indoor heat exchanger sensor 2 on previous occasion.				
22	Cooling	MED	Error code on second previous occasion.				
		HI	Room temperature sensor on second previous occasion.				
		AUTO	Indoor heat exchanger sensor 1 on second previous occasion.				
	Heating	LO	Wireless remote control information on second previous occasion.				
		MED	Outdoor air temperature sensor on second previous occasion.				
		HI	Outdoor heat exchanger sensor on second previous occasion.				
		AUTO	Discharge pipe sensor on second previous occasion.				
27	Cooling	AUTO	Indoor heat exchanger sensor 2 on second occasion.				
23	Cooling	MED	Error code on third previous occasion.				
		HI	Room temperature sensor on third previous occasion.				
		AUTO	Indoor heat exchanger sensor 1 on third previous occasion.				
	Heating	LO	Wireless remote control information on third previous occasion.				
		MED	Outdoor air temperature sensor on third previous occasion.				
		HI	Outdoor heat exchanger sensor on third previous occasion.				
		AUTO	Discharge pipe sensor on third previous occasion.				
28	Cooling	AUTO	Indoor heat exchanger sensor 2 on third occasion.				
24	Cooling	MED	Error code on fourth previous occasion.				
		HI	Room temperature sensor on fourth previous occasion.				
		AUTO	Indoor heat exchanger sensor 1 on fourth previous occasion.				
	Heating	LO	Wireless remote control information on fourth previous occasion.				
		MED	Outdoor air temperature sensor on fourth previous occasion.				
		HI	Outdoor heat exchanger sensor on fourth previous occasion.				
		AUTO	Discharge pipe sensor on fourth previous occasion.				
29	Cooling	AUTO	Indoor heat exchanger sensor 2 on fourth occasion.				
25	Cooling	MED	Error code on fifth previous occasion.				
		HI	Room temperature sensor on fifth previous occasion.				
		AUTO	Indoor heat exchanger sensor 1 on fifth previous occasion.				
	Heating	LO	Wireless remote control information on fifth previous occasion.				
		MED	Outdoor air temperature sensor on fifth previous occasion.				
		HI	Outdoor heat exchanger sensor on fifth previous occasion.				
		AUTO	Discharge pipe sensor on fifth previous occasion.				
30	Cooling	AUTO	Indoor heat exchanger sensor 2 on fifth occasion.				
21	Cooling	LO	Stop code on previous occasion.				
22			Stop code on second previous occasion.				
23			Stop code on third previous occasion.				
24			Stop code on fourth previous occasion.				
25			Stop code on fifth previous occasion.				
26			Stop code on sixth previous occasion.				
27			Stop code on seventh previous occasion.				
28			Stop code on eighth previous occasion.				
29			Stop code on ninth previous occasion.				
30			Stop code on tenth previous occasion.				
Judgment							
Remarks							

Note (1) In the case of indoor heat exchanger sensor 2, match from 26 to 30 the temperature setting of wireless remote control. (Refer to page 263)



## (7) Inspection procedures corresponding to detail of trouble

**Sensor error**[Broken sensor wire,  
connector poor connection]

## ◆ Discharge pipe and power transistor sensor temperature characteristics



## ◆ Sensor temperature characteristics [Room temp., indoor heat exchanger temp., outdoor heat exchanger temp., outdoor air temp. (SCM100,125:refer to page 331), outdoor suction pipe temp.]


**Indoor fan motor error**[Defective fan motor, connector poor  
connection, defective indoor PCB]

Notes (1) See page 272 for the fan motor and indoor PCB check procedure.

(2) After making sure the fan motor and indoor PCB are normal, connect the connectors and confirm that the fan motor is turning.

(If power is turned on while one or the other is broken down, it could cause the other to break down also.)


## Limit switch anomaly (SRK20, 25, 35, 50, 60ZMX only) [Defective limit switch, defective indoor control PCB, Defective air inlet panel set]



Note(1) Check if the limit switch functions properly or not by seeing whether the lamp continues to blink or can be reset by pressing the limit switch by hand while the air inlet panel is removed.

## Current cut

[Compressor lock, Compressor wiring short circuit, Compressor output is open phase, Outdoor PCB is faulty, Service valve is closed, EEV is faulty, Compressor faulty.]




For inspection of electronic expansion valve, see page 285



\*1 If it is normal, it is the rotor lock problem.

- Check compressor wiring visually.
  - Check insulation resistance. (1 MΩ or over)
  - Check coil wire resistance.
- If check results are normal, compressor is locked.
- SCM40, 45, 50 : 1.619Ω or more at 20°C  
 SCM60, 71, 80 : 1.154Ω or more at 20°C  
 SCM100, 125 : 0.293Ω or more at 20°C

## Current safe stop


[Overload operation, compressor lock, overcharge]



**Over heat of compressor****[ Gas shortage, defective discharge pipe sensor ]****Error of signal transmission****[ Wiring error including power cable, defective indoor/outdoor PCB ]**

## Trouble of outdoor unit

[Insufficient refrigerant amount, Faulty power transistor, Broken compressor wire]  
[Service valve close, Defective EEV, Defective outdoor PCB]



Proper power source voltages are as follows.  
(At the power source outlet)  
AC 220V : AC198–242V  
AC 230V : AC 207–253V  
AC 240V : AC 216–264V

### ◆ Judgment of refrigerant quantity

(1) Phenomenon of insufficient refrigerant


- (a) Loss of capacity
- (b) Poor defrosting  
(Frost is not removed completely.)
- (c) Longer time of hot keep  
(5 minute or more)  
(Normal time: Approx. 1–1 minute and 30 seconds)

Notes (1) For inspection of electronic expansion valve, see page 285

(2) Check coil wire resistance, see page 273.




## Outdoor fan motor error

[Defective fan motor, connector poor connection, defective outdoor PCB]



Notes (1) See page 285 for the fan motor and outdoor main PCB check procedure.

- (2) After making sure the fan motor and outdoor main PCB are normal, connect the connectors and confirm that the fan motor is turning.  
(If power is turned on while one or the other is broken down, it could cause the other to break down also.)

**Rotor lock (SCM40, 45, 50, 60, 71, 80 only)****[ Defective compressor, defective outdoor PCB ]****Drain abnormality (SRR only)****[ Drain piping defective, pump defect, float switch, indoor PCB ]****Service valve (gas side) closed operation****[ Service valve (gas side) closed, Defective outdoor PCB ]**

**(8) Phenomenon observed after shortcircuit, wire breakage on sensor****(a) Indoor unit**


Sensor	Operation mode	Phenomenon	
		Shortcircuit	Disconnected wire
Room temperature sensor	Cooling	Release of continuous compressor operation command.	Continuous compressor operation command is not released.
	Heating	Continuous compressor operation command is not released.	Release of continuous compressor operation command.
Heat exchanger sensor	Cooling	Freezing cycle system protection trips and stops the compressor.	Continuous compressor operation command is not released. (Anti-frosting)
	Heating	High pressure control mode (Compressor stop command)	Hot keep (Indoor fan stop)
Humidity sensor <sup>(1)</sup>	Cooling	Refer to the table below.	Refer to the table below.
	Heating	Normal system operation is possible.	

Note (1) SRK 50, 60ZMX-S, 35, 50ZM-S, 71ZR-S, SRF only.


**■ Humidity sensor operation**

Failure mode		Control input circuit resding	Air-conditioning system operation
Disconnected wire	① Disconnected wire	Humidity reading is 0%	Anti-condensation control is not done.
	② Disconnected wire		
	①② Disconnected wire		
Short circuit	① and ② are short circuited	Humidity reading is 100%	Anti-condensation control keep doing.

Remark: Do not perform a continuity check of the humidity sensor with a tester. If DC current is applied, it could damage the sensor.

**(b) Outdoor unit**

Sensor	Operation mode	Phenomenon	
		Shortcircuit	Disconnected wire
Heat exchanger sensor	Cooling	Compressor stop.	Compressor stop.
	Heating	Defrosting is not performed.	Defrosting is performed for 10 minutes at approx. 35 minutes.
Outdoor air temperature sensor	Cooling	The compressor cannot pick up its speed owing to the current safe so that the designed capacity is not achieved.	Compressor stop.
	Heating	The compressor cannot pick up its speed owing to the heating overload protection so that the designed capacity is not achieved.	Defrosting is performed for 10 minutes at approx. 35 minutes.
Discharge pipe sensor	All modes	Compressor overload protection is disabled. (Can be operated.)	Compressor stop


**(9) Checking the indoor electrical equipment****(a) Indoor PCB check procedure****(b) Indoor unit fan motor check procedure**

This is a diagnostic procedure for determining if the indoor unit's fan motor or the indoor PCB is broken down.

**(i) Indoor PCB output check**

- 1) Turn off the power.
- 2) Remove the front panel, then disconnect the fan motor lead wire connector.
- 3) Turn on the power. If the unit operates when the ON/OFF button is pressed, if trouble is detected after the voltages in the following figure are output for approximately 30 seconds, it means that the indoor PCB is normal and the fan motor is broken down.

If the voltages in the following figure are not output at connector pins No. ①, ④ and ⑤, the indoor PCB has failed and the fan motor is normal.




Measuring point	Resistance when normal
① - ③	DC 280V
④ - ③	DC 15V
⑤ - ③	DC several V (4-6V)

**(ii) Fan motor resistance check**

Measuring point	Resistance when normal
① - ③ (Red - Black)	20 MΩ or higher
④ - ③ (White - Black)	20 kΩ or higher


Notes (1) Remove the fan motor and measure it without power connected to it.

(2) If the measured value is below the value when the motor is normal, it means that the fan motor is faulty.

**(10) How to make sure of wireless remote control**

## ◆ Simplified check method of wireless remote control

It is normal if the signal transmission section of the wireless remote control emits a whitish light at each transmission on the monitor of digital camera.

**(11) Inspection procedure for blown fuse on the indoor and outdoor PCB**

# (12) Outdoor unit inspection points Models SCM40ZM-S,45ZM-S

## ⚠ CAUTION- HIGH VOLTAGE


High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

## ◆ Power source and serial signal inspection

- ① to ②: AC 220/230/240V
- ② to ③: Normal if the voltage oscillates between DC 0 and approx. 20V

## Color Marks

Mark	Color
BK	Black
RD	Red
WH	White
OR	Orange
BR	Brown
YE	Yellow
Y/G	Yellow / Green




## ◆ Voltage check in PCB

The normal range is as follows.




Display	Voltage range
① DC280V	DC230V - DC310V
② DC 20V	DC 18V - DC 22V
③ DC 13V	DC 12V - DC 14V
④ DC 15V	DC 14V - DC 16V
⑤ DC 5V	DC 4V - DC 6V
⑥ DC 2.5V	DC 2.3V - DC 2.5V

◆ Inspection of electronic expansion valve  
See page 285.

◆ Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.



◆ Inspection power transistor  
Remove the fasten terminal and test output voltage



◆ Inspection of outdoor fan motor  
See page 285.

◆ Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.

# Models SCM50ZM-S,60ZM-S

## Color Marks


Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
OR	Orange
BR	Brown
YE	Yellow
Y/G	Yellow/Green

## CAUTION- HIGH VOLTAGE

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

## Power source and serial signal inspection

- ① to ②: AC 220/230/240V
- ② to ③: Normal if the voltage oscillates between DC 0 and approx. 20V




## Voltage check in PCB

The normal range is as follows.

- | Display  | Voltage range     |
|----------|-------------------|
| ①DC280V  | DC230V - DC310V   |
| ②DC 20V  | DC 18V - DC 22V   |
| ③DC 13V  | DC 12V - DC 14V   |
| ④DC 15V  | DC 14V - DC 16V   |
| ⑤DC 5V   | DC 4V - DC 6V     |
| ⑥DC 2.5V | DC 2.3V - DC 2.5V |

Inspection of electronic expansion valve  
See page 285.

Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.




**⚠ CAUTION- HIGH VOLTAGE**

### ◆Power source and serial signal inspection

- ① to ②: AC 220/230/240V  
② to ③ : Normal if the voltage oscillates between  
DC 0 and approx. 20V

AC220-240V 50Hz




### ◆Voltage check in PCB

The normal range is as follows.


Display	Voltage range
DC280V	DC230V - DC310V
DC 20V	DC 18V - DC 22V
DC 13V	DC 12V - DC 14V
DC 15V	DC 14V - DC 16V
DC 5V	DC 4V - DC 6V
DC 2.5V	DC 2.3V - DC 2.5V

◆ Inspection of electronic expansion valve  
See page 285.


◆ Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.



◆ **Inspection power transistor**  
Remove the fasten terminal and test output voltage



◆ **Inspection of resistance value of sensor**  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.



◆ **Inspection of outdoor fan motor**  
See page 285.


# **CAUTION- HIGH VOLTAGE**

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

## Color Marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
PK	Pink
RD	Red
WH	White
YE	Yellow
Y/G	Yellow/Green

Power source  
1 Phase AC220-240V  
50Hz



◆ Power source and serial signal inspection  
① to ②: AC 220/230/240V  
② to ③: Normal if the voltage oscillates between DC 0 and approx. 20V

◆ Inspection of electronic expansion valve  
See page 285.

◆ Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.

◆ Inspection of outdoor fan motor  
See page 285.

◆ Inspection power transistor  
Remove the fasten terminal and test output voltage

Model SCM100ZM-S


## ⚠ CAUTION- HIGH VOLTAGE

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

### Color Marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
PK	Pink
RD	Red
WH	White
YE	Yellow
Y/G	Yellow/Green

Power source  
1 Phase AC220-240V  
50Hz



◆ Power source and serial signal inspection  
① to ②: AC 220/230/240V  
② to ③: Normal if the voltage oscillates between DC 0 and approx. 20V

◆ Inspection of electronic expansion valve  
See page 285.

◆ Inspection of resistance value of sensor  
Remove the connector and check the resistance value.  
See the section of sensor characteristics on page 272.

◆ Inspection of outdoor fan motor  
See page 285.


◆ Inspection power transistor  
Remove the fasten terminal and test output voltage

Model SCM125ZM-S

**(a) Inspection of electronic expansion valve**

Electronic expansion valve operates for approx. 10 seconds after the power on, in order to determine its aperture. Check the operating sound and voltage during the period of time. (Voltage cannot be checked during operation in which only the aperture change occurs.)

- (i) If it is heard the sound of operating electronic expansion valve, it is almost normal.
- (ii) If the operating sound is not heard, check the output voltage.



(iii) If voltage is detected, the outdoor sub PCB is normal.

(iv) If the expansion valve does not operate (no operating sound) while voltage is detected, the expansion valve is defective.

**• Inspection of electronic expansion valve as a separate unit**

Measure the resistance between terminals with an analog tester.

Measuring point	Resistance when normal
1-6	46 ± 4Ω (at 20°C)
1-4	
1-3	
1-5	

**(b) Outdoor unit fan motor check procedure**



- When the outdoor unit fan motor error is detected, diagnose which of the outdoor unit fan motor or outdoor main PCB is defective.
- Diagnose this only after confirming that the indoor unit is normal.

**(i) Outdoor main PCB output check**

- 1) Turn off the power.
- 2) Disconnect the outdoor unit fan motor connector CNFAN.
- 3) When the outdoor unit is operated by inserting the power source plug and pressing (ON) the backup switch for more than 5 seconds, if the voltage of pin No. ② (SCM100,125: ⑥) in the following figure is output for 30 seconds at 20 seconds after turning "ON" the backup switch, the outdoor main PCB is normal but the fan motor is defective.

If the voltage is not detected, the outdoor main PCB is defective but the fan motor is normal.

Note (1) The voltage is output 3 times repeatedly. If it is not detected, the indoor unit displays the error message.

**Models SCM40, 45, 50, 60, 71, 80****Models SCM100,125****(ii) Fan motor resistance check****Models SCM40, 45, 50, 60, 71, 80**

Measuring point	Resistance when normal
⑥-④(Red - Blue)	20 MΩ or higher
③-④(Brown - Blue)	20 kΩ or higher

Notes(1) Remove the fan motor and measure it without power connected to it.

(2) If the measured value is below the value when the motor is normal, it means that the fan motor is faulty.

**Models SCM100,125**

Measuring point	Resistance when normal
①-④(Red - Blue)	20 MΩ or higher
⑤-④(Brown - Blue)	20 kΩ or higher

## 8.2 FDTC, FDEN and FDUM series

### 8.2.1 Diagnosing of microcomputer circuit

#### (1) Selfdiagnosis function

##### (a) Check indicator table

Whether a failure exists or not on the indoor unit and outdoor unit can be know by the contents of remote control error code, indoor/outdoor unit green LED (power pilot lamp and microcomputer normality pilot lamp) or red LED (check pilot lamp).

##### (i) Indoor unit

Remote control		Indoor control PCB		Outdoor main PCB	Location of trouble	Description of trouble	Repair method	Reference page
Error code	Red LED	Red LED	Green LED (1)	Red LED				
No-indication	Stays OFF	Stays OFF	Keeps flashing	Stays OFF	—	• <b>Normal operation</b>	—	—
		Stays OFF	Stays OFF	Stays OFF	Indoor unit power supply	• Power OFF, broken wire/blown fuse, broken transformer wire	Repair	308
		* 3-time flash	Keeps flashing	Stays OFF	Remote control wires	• Poor connection, breakage of remote control wire * For wire breaking at power ON, the LED is OFF.	Repair	309
					Remote control	• Defective remote control PCB	Replacement of remote control	
WAIT or INSPECT I/U		Stays OFF	Keeps flashing	Stays OFF	Indoor-outdoor units connection wire	• Poor connection, breakage of indoor-outdoor units connection wire	Repair	310~314
					Remote control	• Improper setting of master and slave by remote control		
E1		Stays OFF	* Keeps flashing	Stays OFF	Remote control wires (Noise)	• <b>Poor connection of remote control signal wire (White)</b> * For wire breaking at power ON, the LED is OFF	Repair	315
					Remote control indoor control PCB	* Defective remote control or indoor control PCB (defective communication circuit)?	Replacement of remote control or PCB	
E5		2-time flash	Keeps flashing	6-time flash	Indoor-outdoor units connection wire	• <b>Poor connection of wire between indoor-outdoor units during operation (disconnection, loose connection)</b> • <b>Anomalous communication between indoor-outdoor units by noise, etc.</b>	Repair	316
		2-time flash	Keeps flashing	6-time flash	(Noise)	• <b>CPU-runaway on outdoor control PCB</b>	Power reset or Repair	
		2-time flash	Keeps flashing	6-time flash	Outdoor control PCB	* Occurrence of defective outdoor control PCB on the way of power source (defective communication circuit)?	Replacement of PCB	
		2-time flash	Keeps flashing	6-time flash	Outdoor control PCB	• <b>Defective outdoor control PCB on the way of power source</b>	Replacement	
E6		1-time flash	Keeps flashing	Stays OFF	Indoor heat exchanger temperature thermistor	• <b>Defective indoor heat exchanger temperature thermistor</b> (defective element, broken wire, short-circuit) • Poor contact of temperature thermistor connector	Replacement, repair of temperature thermistor	317
					Indoor control PCB	* <b>Defective indoor control PCB (Defective temperature thermistor input circuit)?</b>	Replacement of PCB	
E7		1-time flash	Keeps flashing	Stays OFF	Indoor return air temperature thermistor	• <b>Defective indoor return air temperature thermistor</b> (defective element, broken wire, short-circuit) • Poor contact of temperature thermistor connector	Replacement, repair of temperature thermistor	318
					Indoor control PCB	* <b>Defective indoor control PCB (Defective temperature thermistor input circuit)?</b>	Replacement of PCB	
E8	Keeps flashing				Installation or operating condition	• <b>Heating over-load</b> (Anomalously high indoor heat exchanger temperature)	Repair	319
		1-time flash	Keeps flashing	Stays OFF	Indoor heat exchanger temperature thermistor	• <b>Defective indoor heat exchanger temperature thermistor (short-circuit)</b>	Replacement of temperature thermistor	
					Indoor control PCB	* <b>Defective indoor control PCB (Defective temperature thermistor input circuit)?</b>	Replacement of PCB	
E9		1-time flash	Keeps flashing	Stays OFF	Drain trouble	• <b>Defective drain pump (DM), broken drain pump wire, disconnected connector</b>	Replacement, repair of DM	320
					Float switch	• <b>Anomalous float switch operation</b> (malfunction) (In case of FDTC, FDUM)	Repair	
					Indoor control PCB	* <b>Defective indoor control PCB</b> (Defective float switch input circuit) * <b>Defective indoor control PCB</b> (Defective DM drive output circuit)?	Replacement of PCB	
					Option	• <b>Defective option parts</b> (At optional anomalous input setting)	Repair	
E10		Stays OFF	Keeps flashing	Stays OFF	Number of connected indoor units	• <b>When multi-unit control by remote control is performed, the number of units is over</b>	Repair	321
E11		Keeps flashing	Keeps flashing	Stays OFF	Address setting error	• <b>Address setting error of indoor units</b>	Repair	322
E16		1-time flash	Keeps flashing	Stays OFF	Fan motor	• <b>Defective fan motor</b> (In case of FDTC, FDUM)	Replacement, repair	323
					Indoor control PCB	• <b>Defective indoor control PCB</b>	Replacement	
E19		1-time flash	Keeps flashing	Stays OFF	Indoor control PCB	• <b>Improper operation mode setting</b>	Repair	324
E20		1-time flash	Keeps flashing	Stays OFF	Fan motor	• Indoor fan motor rotation speed anomaly (In case of FDTC, FDUM)	Replacement, repair	325
					Indoor power PCB	• Defective indoor power PCB	Replacement	
E28		Stays OFF	Keeps flashing	Stays OFF	Remote control temperature thermistor	• Broken wire of remote control temperature thermistor	Repair	326

Note (1) **Normal indicator lamp (Indoor unit: Green) extinguishes (or lights continuously) only when CPU is anomalous. It keeps flashing in any trouble other than anomalous CPU.**

(2) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

## (ii) Outdoor unit

## 1) Models SCM40, 45, 50, 60, 71, 80

Remote control		Indoor control PCB		Outdoor main PCB	Location of trouble	Description of trouble	Repair method	Reference page
Error code	Red LED	Red LED	Green LED	Red LED				
E35	Keeps flashing	Stays OFF	Keeps flashing	2-time flash	Installation, operation status	• Higher outdoor heat exchanger temperature	Repair	327
					Outdoor heat exchanger temperature sensor	• Defective outdoor heat exchanger temperature sensor	Replacement, repair of temperature sensor	
					Outdoor main PCB	*• Defective outdoor main PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E36		Stays OFF	Keeps flashing	5-time flash	Installation, operation status	• Higher discharge temperature	Repair	329
					Discharge pipe temperature sensor	• Defective discharge pipe temperature sensor	Replacement, repair of temperature sensor	
					Outdoor main PCB	*• Defective outdoor main PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E37		Stays OFF	Keeps flashing	8-time flash	Outdoor heat exchanger temperature sensor	• Defective outdoor heat exchanger temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	330
					Outdoor main PCB	*• Defective outdoor main PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E38		Stays OFF	Keeps flashing	8-time flash	Outdoor air temperature sensor	• Defective outdoor air temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	331
					Outdoor main PCB	*• Defective outdoor main PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E39		Stays OFF	Keeps flashing	8-time flash	Discharge pipe temperature sensor	• Defective discharge pipe temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	332
					Outdoor main PCB	*• Defective outdoor main PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E42		Stays OFF	Keeps flashing	1-time flash	Outdoor main PCB, compressor	• Current cut (Anomalous compressor over-current)	Replacement of PCB	335 • 336
					Installation, operation status	• Service valve closing operation	Repair	
E45		Stay OFF	Keeps flashing	4-time flash	Outdoor main PCB	• Anomalous outdoor main PCB commuication	Replacement of PCB	337
					Outdoor sub PCB	• Anomalous outdoor sub PCB commuication		
E47		Stays OFF	Keeps flashing	2-time flash	Outdoor sub PCB	• Defective active filter	Repair PCB replacement	338
E48		Stays OFF	Keeps flashing	ON	Fan motor	• Defective fan motor	Replacement	339
					Outdoor main PCB	• Defective outdoor main PCB		
E51		Stays OFF	Keeps flashing	1-time flash	Power transistor error (outdoor main PCB)	• Power transistor error	Replacement of PCB	340
E53		Stays OFF	Keeps flashing	8-time flash	Outdoor suction pipe sensor	• Defective suction pipe temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	342
					Outdoor sub PCB	• Defective outdoor sub PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E57		Stays OFF	Keeps flashing	2-time flash	Operation status	• Shortage in refrigerant quantity	Repair	344
					Installation status	• Service valve closing operation	Service valve opening check	
E58		Stays OFF	Keeps flashing	3-time flash	• Overload operation • Overcharge • Compressor locking	• Current safe stop	Replacement	345
E59		Stays OFF	Keeps flashing	2-time flash	Compressor, outdoor main PCB	• Anomalous compressor startup	Replacement	346
E60		Stays OFF	Keeps flashing	7-time flash	Compressor	• Anomalous compressor rotor lock	Replacement	347

Note (1) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

## 2) Models SCM100, 125

Remote control		Indoor control PCB		Outdoor control PCB	Location of trouble	Description of trouble	Repair method	Reference page
Error code	Red LED	Red LED	Green LED	Red LED				
E35	Keeps flashing	Stays OFF	Keeps flashing	2-time flash	Installation, cooling operation status	• Higher outdoor high pressure	Repair	328
					High pressure sensor	• Defective high pressure sensor	Replacement, repair of temperature sensor	
					Outdoor control PCB	• Defective outdoor control PCB (Defective high pressure sensor input circuit)?	Replacement of PCB	
E36		Stays OFF	Keeps flashing	5-time flash	Installation, operation status	• Higher discharge temperature	Repair	329
					Discharge pipe temperature sensor	• Defective discharge pipe temperature sensor	Replacement, repair of temperature sensor	
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E37		Stays OFF	Keeps flashing	8-time flash	Outdoor heat exchanger temperature sensor	• Defective outdoor heat exchanger temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	330
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E38		Stays OFF	Keeps flashing	8-time flash	Outdoor air temperature sensor	• Defective outdoor air temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	331
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E39		Stays OFF	Keeps flashing	8-time flash	Discharge pipe temperature sensor	• Defective discharge pipe temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	332
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E40		Stays OFF	Keeps flashing	2-time flash	Installation, Heating operation status	• Higher outdoor high pressure	Repair	333
					High pressure sensor	• Defective high pressure sensor	Replacement, repair of temperature sensor	
					Outdoor control PCB	• Defective outdoor control PCB (Defective high pressure sensor input circuit)?	Replacement of PCB	
E41		Stays OFF	Keeps flashing	1-time flash	Power transistor	• Power transistor overheat	Replacement of PCB or Repair	334
E42		Stays OFF	Keeps flashing	1-time flash	Outdoor main PCB, compressor	• Current cut (Anomalous compressor over-current)	Replacement of PCB	335•336
					Installation, operation status	• Service valve closing operation	Repair	
E45		Stay OFF	Keeps flashing	4-time flash	Outdoor control PCB	• Anomalous outdoor control PCB commuication	Replacement of PCB	337
					Outdoor sub PCB	• Anomalous outdoor sub PCB commuication		
E48		Stays OFF	Keeps flashing	ON	Fan motor	• Defective fan motor	Replacement	339
					Outdoor control PCB	• Defective outdoor control PCB		
E51		Stays OFF	Keeps flashing	1-time flash	Power transistor error (Inverter PCB)	• Inverter and fan motor anomaly	Replacement of PCB	341
E53		Stays OFF	Keeps flashing	8-time flash	Outdoor suction pipe sensor	• Defective suction pipe temperature sensor, broken wire or poor connector connection	Replacement, repair of temperature sensor	342
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E54		Stays OFF	Keeps flashing	8-time flash	High pressure sensor	• Defective high pressure sensor	Replacement of sensor	343
					Outdoor control PCB	• Defective outdoor control PCB (Defective temperature sensor input circuit)?	Replacement of PCB	
E57		Stays OFF	Keeps flashing	2-time flash	Operation status	• Shortage in refrigerant quantity	Repair	344
					Installation status	• Service valve closing operation	Service valve opening check	
E59		Stays OFF	Keeps flashing	2-time flash	Compressor, outdoor main PCB	• Anomalous compressor startup	Replacement	346

Note (1) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

## (iii) Display sequence of error codes or inspection indicator lamps

## ■ Occurrence of one kind of error

Displays are shown respectively according to errors.

## ■ Occurrence of plural kinds of error

Section	Category of display
Error code on remote control	<ul style="list-style-type: none"> <li>Displays the error of higher priority (When plural errors are persisting)</li> </ul>
Red LED on indoor control PCB	
Red LED on outdoor main (control) PCB	

*E1 E5 ..... E10 > E3 > ..... E60*

• Displays the present errors. (When a new error has occurred after the former error was reset.)

## ■ Error detecting timing

Section	Error description	Error code	Error detecting timing
Indoor	Drain trouble (Float switch activated)	<i>E9</i>	Whenever float switch is activated after 30 second had past since power ON.
	Communication error at initial operation	“ WAIT ”	No communication between indoor and outdoor units is established at initial operation.
	Remote control communication circuit error	<i>E1</i>	Communication between indoor unit and remote control is interrupted for mote than 2 minutes continuously after initial communication was established.
	Communication error during operation	<i>E5</i>	Communication between indoor and outdoor units is interrupted for mote than 2 minutes continuously after initial communication was established.
	Excessive number of connected indoor units by controlling with one remote control	<i>E10</i>	Whenever excessively connected indoor units is detected after power ON.
	Return air temperature thermistor anomaly	<i>E7</i>	-50°C or lower is detected for 5 seconds continuously within 60 minutes after initial detection of this anomalous temperature.
	Indoor heat exchanger temperature thermistor anomaly	<i>E6</i>	-50°C or lower is detected for 5 seconds continuously within 60 minutes after initial detection of this anomalous temperature. Or 70°C or higher is detected for 5 seconds continuously.
Outdoor	Outdoor air temperature sensor anomaly	<i>E38</i>	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous sensor. Or -55°C or higher is detected for 5 seconds continuously within 20 seconds after power ON.
	Outdoor heat exchanger temperature sensor anomaly	<i>E37</i>	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous sensor. Or -55°C or lower is detected for 5 seconds continuously within 20 seconds after power ON.
	Discharge pipe temperature sensor anomaly	<i>E39</i>	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous sensor.
	Suction pipe temperature sensor anomaly	<i>E53</i>	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous sensor. Or -55°C or higher is detected for 5 seconds continuously within 20 seconds after power ON.

### ■ Error log and reset

Error indicator	Memorized error log	Reset
Remote control display	• Higher priority error is memorized.	<ul style="list-style-type: none"> <li>• Stop the unit by pressing the ON/OFF switch of remote control.</li> <li>• If the unit has recovered from anomaly, it can be operated.</li> </ul>
Red LED on indoor control PCB	• Not memorized.	
Red LED on outdoor main (control) PCB	• Memorizes a mode of higher priority.	

### ■ Resetting the error log

- Resetting the memorized error log in the remote control

Holding down “CHECK” button, press “TIMER” button to reset the error log memorized in the remote control.


- Resetting the memorized error log

The remote control transmits error log erase command to the indoor unit when “VENTI” button is pressed while holding down “CHECK” button.

Receiving the command, the indoor unit erase the log and answer the status of no error.

## (2) Troubleshooting procedure

When any trouble has occurred, inspect as follows. Details of respective inspection method will be described on later pages.



## (3) Troubleshooting at the indoor unit

With the troubleshooting, find out any defective part by checking the voltage (AC, DC), resistance, etc. at respective connectors at around the indoor PCB, according to the inspection display or operation status of unit (the compressor does not run, fan does not run, the 4-way valve does not switch, etc.), and replace or repair in the unit of following part.

### (a) Replacement part related to indoor PCB's

Control PCB, power source PCB, temperature thermistor (return air, indoor heat exchanger), remote control and fuse

Note (1) With regard to parts of high voltage circuits and refrigeration cycle, judge it according to ordinary inspection methods.

### (b) Instruction of how to replace indoor control PCB

SAFETY PRECAUTIONS	
<ul style="list-style-type: none"> <li>• Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the replacement in order to protect yourself.</li> <li>• The precautionary items mentioned below are distinguished into two levels, WARNING and CAUTION.</li> </ul>	<p>Both mentions the important items to protect your health and safety so strictly follow them by any means.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <b>WARNING</b> </div>	Wrong installation would cause serious consequences such as injuries or death.
<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <b>CAUTION</b> </div>	Wrong installation might cause serious consequences depending on circumstances.
<ul style="list-style-type: none"> <li>• After completing the replacement, do commissioning to confirm there are no anomaly.</li> </ul>	
<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"> <b>WARNING</b></p> <ul style="list-style-type: none"> <li>• Replacement should be performed by the specialist. If you replace the PCB by yourself, it may lead to serious trouble such as electric shock or fire.</li> <li>• Replace the PCB correctly according to these instructions. Improper replacement may cause electric shock or fire.</li> <li>• Shut off the power before electrical wiring work. Replacement during the applying the current would cause the electric shock, unit failure or improper running. It would cause the damage of connected equipment such as fan motor, etc.</li> <li>• Fasten the wiring to the terminal securely, and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connections or hold could result in abnormal heat generation or fire.</li> <li>• Check the connection of wiring to PCB correctly before turning on the power, after replacement. Defectiveness of replacement may cause electric shock or fire.</li> </ul> </div>	
<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"> <b>CAUTION</b></p> <ul style="list-style-type: none"> <li>• In connecting connector onto the PCB, connect not to deform the PCB. It may cause breakage or malfunction.</li> <li>• Insert connector securely, and hook stopper. It may cause fire or improper running.</li> <li>• Bundle the cables together so as not to be pinched or be tensioned. It may cause malfunction or electric shock for disconnection or deformation.</li> </ul> </div>	

(i) **FDTC series**

**1) Control PCB**

Replace and set up the PCB according to this instruction.

PSB012D976B

PSB012D976C

- a) Set to an appropriate address and function using switch on PCB.

Select the same setting with the removed PCB.

item	switch	Content of control	
Address	SW2	Plural indoor units control by 1 remote control	
Test run	SW7-1	OFF	Normal
		ON	Operation check/drain motor test run

- b) Set to an appropriate capacity using the model selector switch(SW6).

Select the same capacity with the PCB removed from the unit.

SW6	-1	-2	-3	-4
25VF	ON	OFF	OFF	OFF
35VF	OFF	ON	OFF	OFF
50VF	ON	OFF	ON	OFF
60VF	ON	ON	ON	OFF




Example setting for 25VF

- c) Replace the PCB

- Fix the PCB so as not to pitch the cords.
- Connect connectors to the PCB. Connect a cable connector with the PCB connector of the same color.
- Do not pass CPU surrounding about wirings.

- d) Control PCB

Parts mounting are different by the kind of PCB.



## 2) Power PCB



PSB012D953A

This PCB is a general PCB. Replace the PCB according to this instruction.

- a) Replace the PCB (refer to right dwg.)
  - i) Unscrew terminal of the wiring(yellow/green) soldered to PCB from the box.
  - ii) Cut the band that binds the wiring (red and blue) from connector CNW1 and CNW2, and the wiring (yellow/green) from PCB (T2/T3) . (Note 1)  
(However, do not cut the band that binds only the red and blue wirings.)
  - iii) Replace the PCB only after all the wirings connected to the connector are removed.
  - iv) Fix the board such that it will not pinch any of the wires.
  - v) Reconnect the wirings to the PCB. Wiring connector color should match with the color of connector of the PCB. (Note 2)
  - vi) Let the wiring (red and blue) pass beneath the (yellow/green) wiring and bind together with band.
  - vii) Screw back the terminal of wiring (yellow/green) from PCB(T1, T2/T3), that was removed in i).

In that case, do not place the crimping part of the wiring under the PCB.  
(Note 1): It might not be applicable on some models.  
(Note 2): After replacing PCB, connection between capacitor assy and connector CNP is no longer needed.
- b) Power PCB
 

Parts mounting are different by the kind of PCB.



## (ii) FDEN series

PSB012D974C


- 1) Set to an appropriate address and function using switch on PCB.
  - a) There is a unit having plural applicable PCB depending on a model.
  - b) Set the function setting corresponding the spare PCB and the applicable model.

item	switch	Content of control	
Address	SW2	Plural indoor units control by 1 remote control	
Test run	SW7-1	OFF	Normal
		ON	Operation check/drain motor test run

- 2) Set to an appropriate capacity using the model selector switch(SW6).

Select the same capacity with the PCB removed from the unit.

SW6	-1	-2	-3	-4
50V	ON	OFF	ON	OFF




- 3) Replace the PCB

- a) Fix the PCB so as not to pitch the cords.
- b) Connect connectors to the PCB. Connect a cable connector with the PCB connector of the same color.
- c) Do not pass CPU surrounding about wirings.

- 4) Control PCB

Parts mounting are different by the kind of PCB.



## (iii) FDUM series

PSB012D990B

## 1) Control PCB

Replace and set up the PCB according to this instruction.

a) Set to an appropriate address and function using switch on PCB.

Select the same setting with the removed PCB.

item	switch	Content of control	
Address	SW2	Plural indoor units control by 1 remote control	
Test run	SW7-1	OFF	Normal
		ON	Operation check/drain motor test run

b) Set to an appropriate capacity using the model selector switch(SW6).

Select the same capacity with the PCB removed from the unit.

SW6	-1	-2	-3	-4
50V	ON	OFF	ON	OFF



c) Replace the PCB


i) Exchange PCB after detaching all connectors connected with the PCB.

ii) Fix the PCB so as not to pitch the wiring.

iii) Connect connectors to the PCB. Match the wiring connector to the connector color on the PCB and connect it.

d) Control PCB

Parts mounting are different by the kind of PCB.



**2) Power PCB**

PSB012D992


This PCB is a general PCB. Replace the PCB according to this instruction.

## a) Replace the PCB

- i) Unscrew terminal of the wiring(yellow/green) connected to Terminal block (CNW0) from the box.
- ii) Replace the PCB only after all the wirings connected to the connector are removed.
- iii) Fix the board such that it will not pinch any of the wires.
- iv) Reconnect the wirings to the PCB. Wiring connector color should match with the color of connector of the PCB.
- v) Screw back the terminal of wiring, that was removed in i).

## b) Power PCB

Parts mounting are different by the kind of PCB.



## ●DIP switch setting list

Switches	Description		Default setting		Remarks
SW2	Address No. setting at plural indoor units control by 1 R/C		0		0-F
SW6-1	Model selection		As per model		See table 1
SW6-2					
SW6-3					
SW6-4					
SW7-1	Test run, Drain motor	Normal*/Test run	OFF	Normal	
SW7-2	Reserved		OFF		Keep OFF
SW7-3	Powerful mode	Valid*/Invalid	ON	Valid	
SW7-4	Reserved		OFF		Keep OFF
SW8-1	Reserved		OFF		Keep OFF
SW8-2	Reserved		OFF		Keep OFF
SW8-3	Reserved		OFF		Keep OFF
SW8-4	Reserved		OFF		Keep OFF
JSL1	Superlink terminal spare	Normal*/switch to spare	With		

\* Default setting

Table 1: Indoor unit model selection with SW6-1-SW6-4

	0: OFF 1:ON			
	25VF	35VF	50VF	60VF
SW6-1	ON	OFF	ON	ON
SW6-2	OFF	ON	OFF	ON
SW6-3	OFF	OFF	ON	ON
SW6-4	OFF	OFF	OFF	OFF

#### (4) Check of anomalous operation data with the remote control

##### (a) In case of RC-E5 remote control

Operation data can be checked with remote control unit operation.

- ① Press the **CHECK** button.

The display change “OPER DATA ▼”

- ② Press the **(SET)** button while “OPER DATA ▼” is displayed.

- ③ When only one indoor unit is connected to remote control, “DATA LOADING” is displayed (blinking indication during data loading).

Next, operation data of the indoor unit will be displayed. Skip to step ⑦.

- ④ When plural indoor units is connected, the smallest address number of indoor unit among all connected indoor unit is displayed.

[Example]:

“SELECT I/U” (blinking 1 seconds) → “I/U000 ▲” blinking.

- ⑤ Select the indoor unit number you would like to have data displayed with the **▲ ▼** button.

- ⑥ Determine the indoor unit number with the **(SET)** button.

(The indoor unit number changes from blinking indication to continuous indication)

“I/U000” (The address of selected indoor unit is blinking for 2 seconds.)

↓

“DATA LOADING” (A blinking indication appears while data loaded.)

Next, the operation data of the indoor unit is indicated.

- ⑦ Upon operation of the **▲ ▼** button, the current operation data is displayed in order from data number 01. The items displayed are in the above table.

\*Depending on models, the items that do not have corresponding data are not displayed.

- ⑧ To display the data of a different indoor unit, press the **AIR CON NO.** button, which allows you to go back to the indoor unit selection screen.

- ⑨ Pressing the **ON/OFF** button will stop displaying data.

Pressing the **(RESET)** button during remote control unit operation will undo your last operation and allow you to go back to the previous screen.

⊙If two (2) remote controls are connected to one (1) inside unit, only the master control is available for trial operation and confirmation of operation data. (The slave remote control is not available.)

Number	Data Item
01	(Operation Mode)
02	SET TEMP  (Set Temperature)
03	RETURN AIR  (Return Air Temperature)
04	SENSOR  (Remote Control Thermistor Temperature)
05	THI-R1  (Indoor Heat Exchanger Thermistor / U Bend)
06	THI-R2  (Indoor Heat Exchanger Thermistor /Capillary)
07	THI-R3  (Indoor Heat Exchanger Thermistor /Gas Header)
08	I/U FANSPEED  (Indoor Unit Fan Speed)
09	DEMAND  (Frequency Requirements)
10	ANSWER  (Response Frequency)
11	I/U EEV  (Pulse of Indoor Unit Expansion Value)
12	TOTAL I/U RUN  (Total Running Hours of The Indoor Unit)
21	OUTDOOR  (Outdoor Air Temperature)
22	THO-R1  (Outdoor Heat Exchanger Thermistor)
23	THO-R2  (Outdoor Heat Exchanger Thermistor)
24	COMP  (Compressor Frequency)
25	HP  (High Pressure)
26	LP  (Low Pressure)
27	Td  (Discharge Pipe Temperature)
28	COMP BOTTOM  (Comp Bottom Temperature)
29	CT  (Current)
30	TARGET SH  (Target Super Heat)
31	SH  (Super Heat)
32	TDSH  (Discharge Pipe Super Heat)
33	PROTECTION No.  (Protection State No. of The Compressor)
34	O/U FANSPEED  (Outdoor Unit Fan Speed)
35	63H1 (63H1 On/Off)
36	DEFROST (Defrost Control On/Off)
37	TOTAL COMP RUN  (Total Running Hours of The Compressor)
38	O/U EEV1  (Pulse of The Outdoor Unit Expansion Valve EEVC)
39	O/U EEV2  (Pulse of The Outdoor Unit Expansion Valve EEVH)

**(b) In case of RC-EX1A remote control**

[Operating procedure]

(i) On the TOP screen, touch the buttons in the order of “Menu” → “Next” → “Service & Maintenance” → “Service password” → “Set” → “Error display” → “Error history”.

(ii) When only one indoor unit is connected to the remote control, followings will be displayed.

1. When there is any anomaly: “Loading. Wait a while” is displayed, followed by the operation data at the occurrence of anomaly. Contents of display

- Error code
- Number and data item

2. When there is no anomaly: “No anomaly” is displayed, and this mode is terminated.

(iii) When two or more indoor units are connected to the remote control, followings will be displayed.

1. When there is any anomaly: If the unit having anomaly is selected on the “Select IU” screen, “Loading. Wait a while” is displayed, followed by the operation data at the occurrence of anomaly.

Contents of display

- Indoor unit No.
- Error code
- Number and data item

2. When there is no anomaly: “No anomaly” is displayed, and this mode is terminated.

Note (1) When the number of connected units cannot be shown in a page, select “Next”.

(iv) If you press [RUN/STOP] button, the display returns to the TOP screen.

◎ If you touch “Back” button on the way of setting, the display returns to the last precious screen.

Note (1) When two remote controls are used to control indoor units, the check of anomaly operation data can be made on the master remote control only. (It cannot be operated from the slave remote control.)

■ Anomaly operation data (Corresponding data may not be provided depending on models. Such items will not be displayed.)


Number	Data Item
01	⚙ (Operation Mode)
02	SET TEMP. ℃ (Set Temperature)
03	RETURN AIR ℃ (Return Air Temperature)
04	SENSOR ℃ (Remote Control Thermistor Temperature)
05	THI-R1 ℃ (Indoor Heat Exchanger Thermistor / U Bend)
06	THI-R2 ℃ (Indoor Heat Exchanger Thermistor / Capillary)
07	THI-R3 ℃ (Indoor Heat Exchanger Thermistor / Gas Header)
08	I/U FANSPEED (Indoor Unit Fan Speed)
09	DEMAND Hz (Frequency Requirements)
10	ANSWER Hz (Response Frequency)
11	I/U EEV P (Pulse of Indoor Unit Expansion Valve)
12	TOTAL I/U RUN H (Total Running Hours of The Indoor Unit)
21	OUTDOOR ℃ (Outdoor Air Temperature)
22	THO-R1 ℃ (Outdoor Heat Exchanger Thermistor)
23	THO-R2 ℃ (Outdoor Heat Exchanger Thermistor)
24	COMP Hz (Compressor Frequency)
25	HP MPa (High Pressure)
26	LP MPa (Low Pressure)
27	Td ℃ (Discharge Pipe Temperature)
28	COMP BOTTOM ℃ (Comp Bottom Temperature)
29	CT AMP (Current)
30	TARGET SH ℃ (Target Super Heat)
31	SH ℃ (Super Heat)
32	TDSH ℃ (Discharge Pipe Super Heat)
33	PROTECTION No. (Protection State No. of The Compressor)
34	O/U FANSPEED (Outdoor Unit Fan Speed)
35	63H1 (63H1 On/Off)
36	DEFROST (Defrost Control On/Off)
37	TOTAL COMP RUN H (Total Running Hours of The Compressor)
38	O/U EEV1 P (Pulse of The Outdoor Unit Expansion Valve EEV1)
39	O/U EEV2 P (Pulse of The Outdoor Unit Expansion Valve EEV2)

**(5) Inverter checker for diagnosis of inverter output**


## ● Checking method

- (a) Setup procedure of checker.
- Power OFF (Turn off the breaker).
  - Remove the terminal cover of compressor and disconnect the wires (U, V, W) from compressor.
  - Connect the wires U (Red), V (White) and W (Black) of the checker to the terminal of disconnected wires (U, V, W) from compressor respectively.
- (b) Operation for judgment.
- Power ON and start check operation on cooling or heating mode.
  - Check ON/OFF status of 6 LED's on the checker.
  - Judge the PCB by ON/OFF status of 6 LED's on the checker.

ON/OFF status of LED	If all of LED are ON/OFF according to following pattern	If all of LED stay OFF or some of LED are ON/OFF
Outdoor main PCB	Normal	Anomalous




## 〈Inverter Checker〉



Connect to the terminal of the wires which are disconnected from compressor.



## LED ON/OFF pattern

**(6) Outdoor unit inspection points**

- See page 280 to 287

## 8.2.2 Troubleshooting flow

### (1) List of troubles

Remote control display	Description of trouble	Reference page
None	Operates but does not cool.	301
None	Operates but does not heat.	302
None	Earth leakage breaker activated	303
None	Excessive noise/vibration (1/3)	304
None	Excessive noise/vibration (2/3)	305
None	Excessive noise/vibration (3/3)	306
None	Louver motor failure (FDTC and FDEM only)	307
None	Power source system error (Power source to indoor control PCB)	308
None	Power source system error (Power source to remote control)	309
INSPECT I/U	INSPECT I/U (When 1 or 2 remote controls are connected)	310
INSPECT I/U	INSPECT I/U (Connection of 3 units or more remote controls)	311
 WAIT 	Communication error at initial operation	312–314
E1	Remote control communication circuit error	315
E5	Communication error during operation	316
E6	Indoor heat exchanger temperature thermistor anomaly	317
E7	Return air temperature thermistor anomaly	318
E8	Heating overload operation	319
E9	Drain trouble (FDTC and FDUM only)	320
E10	Excessive number of connected indoor units (more than 17 units) by controlling with one remote control	321
E11	Address setting error of indoor units	322
E16	Indoor fan motor anomaly (FDTC and FDUM only)	323
E19	Indoor unit operation check, drain motor check setting error	324
E20	Indoor fan motor rotation speed anomaly (FDTC and FDUM only)	325
E28	Remote control temperature thermistor anomaly	326
E35	Cooling high pressure operation	327, 328
E36	Discharge pipe temperature error	329
E37	Outdoor heat exchanger temperature sensor anomaly	330
E38	Outdoor air temperature sensor anomaly	331
E39	Discharge pipe temperature sensor anomaly	332
E40	Heating high pressure operation (SCM100, 125 only)	333
E41	Power transistor overheat (SCM100, 125 only)	334
E42	Current cut	335, 336
E45	Outdoor sub PCB communication error	337
E47	Active filter voltage error (SCM40, 45, 50, 60, 71, 80 only)	338
E48	Outdoor fan motor anomaly	339
E51	Power transistor anomaly (SCM40, 45, 50, 60, 71, 80 only)	340
E51	Inverter and fan motor anomaly (SCM100, 125 only)	341
E53	Suction pipe temperature error	342
E54	High pressure sensor anomaly (SCM100, 125 only)	343
E57	Insufficient refrigerant amount or detection of service valve closure	344
E58	Current safe stop (SCM40, 45, 50, 60, 71, 80 only)	345
E59	Compressor startup failure	346
E60	Anomalous compressor rotor lock (SCM40, 45, 50, 60, 71, 80 only)	347

## (2) Troubleshooting

Error code	LED	Green	Red	Content
Remote control: None	Indoor	Keeps flashing	Stays OFF	Operates but does not cool
	Outdoor	—	Stays OFF	

1. Applicable model	5. Troubleshooting
All models	Diagnosis
2. Error detection method	<p>Check the indoor unit fan operation. Check the temperature difference between return and supply air.</p> <p>Is the temperature difference between return and supply air 10-20degC at cooling?</p> <p>YES → Does the heat load increase after installation?</p> <p>NO → It is normal. (This unit is designed to start in the soft start mode by detecting the under dome temperature of compressor when it restart after power reset.)</p> <p>YES → Mistake in model selection. Calculate heat load once more. It is necessary to replace to higher capacity one or to install additional unit.</p> <p>Is the compressor operating?</p> <p>NO → "WAIT" message is displayed (for 3 seconds) when performing cooling, defrosting and heating operations from the remote control.</p> <p>YES → Compressor refrigerant oil protection control at starting is activated.</p> <p>NO → Compressor may be stopped by the error detection control. For the contents of control, refer to anomalous stop control by controlling compressor rotation speed of microcomputer control functions.</p> <p>Is the compressor rotation speed low?</p> <p>NO → Inspect the followings. • Minor clogging of filter • Minor clogging of heat exchanger • Minor short-circuit • Minor shortage of refrigerant amount • Poor compression of compressor</p> <p>YES → Check which control "Determination control of compressor rotation speed" or "Protective control by controlling compressor rotation speed" is appropriate to this phenomenon.</p> <p>Are the temperature conditions of room and outdoor air close to the rated conditions? (1)</p> <p>YES → Considering appropriate operation control, check suspicious points. Inspect the followings for reference. • Major clogging of filter • Major clogging of heat exchanger • Major short-circuit • Major shortage of refrigerant amount • Compressor protection ON • Indoor fan tap</p> <p>NO → The unit is operating normally but is operating under the control for protecting compressor or other respective parts.</p> <p>Note (1) Outdoor: 35°C, Indoor: 27°C</p>
3. Condition of error displayed	
4. Presumable cause	
<ul style="list-style-type: none"> <li>Poor compression of compressor</li> <li>Faulty expansion valve operation</li> </ul>	

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Operates but does not heat
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

1. Applicable model	5. Troubleshooting				
All models	<table> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> <tr> <td> <p>Check the indoor unit fan operation. Check the temperature difference between return and supply air.</p> <p>Is the temperature difference between return and supply air 10-30degC at heating?</p> <p>NO</p> <p>Is the compressor operating?</p> <p>NO</p> <p>Is the compressor rotation speed low?</p> <p>YES</p> <p>Check which control "Determination control of compressor rotation speed" or "Protective control by controlling compressor rotation speed" is appropriate to this phenomenon.</p> <p>Are the temperature conditions of room and outdoor air close to the rated conditions? (1)</p> <p>NO</p> <p>The unit is operating normally but is operating under the control for protecting compressor or other respective parts.</p> <p>Does the heat load increase after installation?</p> <p>NO</p> <p>Mistake in model selection. Calculate heat load once again.</p> <p>"WAIT" message is displayed (for 3 seconds) when performing cooling, defrosting and heating operations from the remote control.</p> </td><td> <p>It is normal. (This unit is designed to start in the soft start mode by detecting the under dome temperature of compressor when it restart after power reset.</p> <p>It is necessary to replace to higher capacity one or to install additional unit.</p> <p>Compressor refrigerant oil protection control at starting is activated.</p> <p>Compressor may be stopped by the error detection control. For the contents of control, refer to anomalous stop control by controlling compressor rotation speed of microcomputer control functions.</p> <p>Inspect the followings.</p> <ul style="list-style-type: none"> <li>• Minor clogging of filter</li> <li>• Minor clogging of heat exchanger</li> <li>• Minor short-circuit</li> <li>• Minor shortage of refrigerant amount</li> <li>• Poor compression of compressor</li> </ul> <p>Considering appropriate operation control, check suspicious points. Inspect the followings for reference.</p> <ul style="list-style-type: none"> <li>• Major clogging of filter</li> <li>• Major clogging of heat exchanger</li> <li>• Major short-circuit</li> <li>• Major shortage of refrigerant amount</li> <li>• Compressor protection ON</li> <li>• Indoor fan tap</li> </ul> </td></tr> </table>	Diagnosis	Countermeasure	<p>Check the indoor unit fan operation. Check the temperature difference between return and supply air.</p> <p>Is the temperature difference between return and supply air 10-30degC at heating?</p> <p>NO</p> <p>Is the compressor operating?</p> <p>NO</p> <p>Is the compressor rotation speed low?</p> <p>YES</p> <p>Check which control "Determination control of compressor rotation speed" or "Protective control by controlling compressor rotation speed" is appropriate to this phenomenon.</p> <p>Are the temperature conditions of room and outdoor air close to the rated conditions? (1)</p> <p>NO</p> <p>The unit is operating normally but is operating under the control for protecting compressor or other respective parts.</p> <p>Does the heat load increase after installation?</p> <p>NO</p> <p>Mistake in model selection. Calculate heat load once again.</p> <p>"WAIT" message is displayed (for 3 seconds) when performing cooling, defrosting and heating operations from the remote control.</p>	<p>It is normal. (This unit is designed to start in the soft start mode by detecting the under dome temperature of compressor when it restart after power reset.</p> <p>It is necessary to replace to higher capacity one or to install additional unit.</p> <p>Compressor refrigerant oil protection control at starting is activated.</p> <p>Compressor may be stopped by the error detection control. For the contents of control, refer to anomalous stop control by controlling compressor rotation speed of microcomputer control functions.</p> <p>Inspect the followings.</p> <ul style="list-style-type: none"> <li>• Minor clogging of filter</li> <li>• Minor clogging of heat exchanger</li> <li>• Minor short-circuit</li> <li>• Minor shortage of refrigerant amount</li> <li>• Poor compression of compressor</li> </ul> <p>Considering appropriate operation control, check suspicious points. Inspect the followings for reference.</p> <ul style="list-style-type: none"> <li>• Major clogging of filter</li> <li>• Major clogging of heat exchanger</li> <li>• Major short-circuit</li> <li>• Major shortage of refrigerant amount</li> <li>• Compressor protection ON</li> <li>• Indoor fan tap</li> </ul>
Diagnosis	Countermeasure				
<p>Check the indoor unit fan operation. Check the temperature difference between return and supply air.</p> <p>Is the temperature difference between return and supply air 10-30degC at heating?</p> <p>NO</p> <p>Is the compressor operating?</p> <p>NO</p> <p>Is the compressor rotation speed low?</p> <p>YES</p> <p>Check which control "Determination control of compressor rotation speed" or "Protective control by controlling compressor rotation speed" is appropriate to this phenomenon.</p> <p>Are the temperature conditions of room and outdoor air close to the rated conditions? (1)</p> <p>NO</p> <p>The unit is operating normally but is operating under the control for protecting compressor or other respective parts.</p> <p>Does the heat load increase after installation?</p> <p>NO</p> <p>Mistake in model selection. Calculate heat load once again.</p> <p>"WAIT" message is displayed (for 3 seconds) when performing cooling, defrosting and heating operations from the remote control.</p>	<p>It is normal. (This unit is designed to start in the soft start mode by detecting the under dome temperature of compressor when it restart after power reset.</p> <p>It is necessary to replace to higher capacity one or to install additional unit.</p> <p>Compressor refrigerant oil protection control at starting is activated.</p> <p>Compressor may be stopped by the error detection control. For the contents of control, refer to anomalous stop control by controlling compressor rotation speed of microcomputer control functions.</p> <p>Inspect the followings.</p> <ul style="list-style-type: none"> <li>• Minor clogging of filter</li> <li>• Minor clogging of heat exchanger</li> <li>• Minor short-circuit</li> <li>• Minor shortage of refrigerant amount</li> <li>• Poor compression of compressor</li> </ul> <p>Considering appropriate operation control, check suspicious points. Inspect the followings for reference.</p> <ul style="list-style-type: none"> <li>• Major clogging of filter</li> <li>• Major clogging of heat exchanger</li> <li>• Major short-circuit</li> <li>• Major shortage of refrigerant amount</li> <li>• Compressor protection ON</li> <li>• Indoor fan tap</li> </ul>				

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Earth leakage breaker activated
	Indoor	Stays OFF	Stays OFF	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     D1{Are OK the insulation resistance and coil resistance of compressor?} -- NO --&gt; C1[Replace compressor.*]     D1 -- YES --&gt; D2{Is insulation of respective harnesses OK? Is any harness bitten between pannel and casing or etc?}     D2 -- NO --&gt; C2[Secure insulation resistance.]     D2 -- YES --&gt; P1[Check the outdoor unit grounding wire/earth leakage breaker.]     P1 --&gt; T1[Check of the outdoor unit grounding wire/earth leakage breaker]     </pre> <p>Check of the outdoor unit grounding wire/earth leakage breaker</p> <p>① Run an independent grounding wire from the grounding screw of outdoor unit to the grounding terminal on the distribution panel. (Do not connect to another grounding wire.)</p> <p>② In order to prevent malfunction of the earth leakage breaker itself, confirm that it is conformed to higher harmonic regulation.</p> <p>* Insulation resistance of compressor</p> <ul style="list-style-type: none"> <li>Immediately after installation or when the unit has been left for long time without power source, the insulation resistance may drop to a few MΩ because of refrigerant migrated in the compressor.</li> </ul> <p>When the earth breaker is activated at lower insulation resistance, check the following points.</p> <p>① 6 hours after power ON, check if the insulation resistance recovers to normal.</p> <p>When power ON, crankcase heater heat up compressor and evaporate the refrigerant migrated in the compressor.</p> <p>② Check if the earth leakage breaker is conformed to higher harmonic regulation or not.</p> <p>Since the unit is equipped with inverter, it is necessary to use components conformed to higher harmonic regulation in order to prevent malfunction of earth leakage breaker.</p>	
3. Condition of error displayed		
4.Presumable cause	<ul style="list-style-type: none"> <li>Defective compressor</li> <li>Noise</li> </ul>	

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Excessive noise/vibration (1/3)
	Indoor	—	—	
	Outdoor	—	—	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     Q1{Does noise/vibration occur during or soon after stopping operation of air-conditioner?}     Q2{[Installation work] Does noise/vibration occur not only from the air-conditioner but also from entire building?}     Q3{Does the installation of indoor/outdoor unit loose?}     Q4{Are pipes touching the wall, etc?}     Q5{[Product] Does noise/vibration occur from operating fan (fan only)?}     Q6{Is there a fan or louver touching other components?}     Q7{To next page}      Q1 -- NO --&gt; C1[If excessive noise/vibration persists when sufficient time has elapsed after stopping the unit, it is considered that the air-conditioner is not the source.]     Q1 -- YES --&gt; Q2     Q2 -- YES --&gt; Q3     Q2 -- NO --&gt; Q4     Q3 -- YES --&gt; C2[Check the installed condition carefully, and correct the position or insert rubber cushions or others into the gap, if necessary.]     Q3 -- NO --&gt; Q4     Q4 -- YES --&gt; C3[Prevent the vibration from transmitting to wall and etc by fixing pipes on the wall or wrapping rubber cushion around the pipe which goes through the hole in the wall or applying other appropriate means.]     Q4 -- NO --&gt; C4[Strength of ceiling wall, floor, etc. may be insufficient. Review the installing position or reinforce it.]     Q5 -- YES --&gt; Q6     Q5 -- NO --&gt; Q7     Q6 -- YES --&gt; C5[Check for leaning of installed unit or anomalous mounting of fan, louver or motor and specify the contacting point and correct it.]     Q6 -- NO --&gt; C6[When the heat exchanger or filter is clogged, clean them. In case that the unit is installed at the site where background noise is very low, small noise from indoor unit can be heard, but it is normal. Before installation, check for background noise. If background noise is very low, convince client prior to installation.]     </pre>	
3. Condition of error displayed		
4.Presumable cause	<ul style="list-style-type: none"> <li>① Improper installation work <ul style="list-style-type: none"> <li>• Improper anti-vibration work at instillation</li> <li>• Insufficient strength of mounting face</li> </ul> </li> <li>② Defective product <ul style="list-style-type: none"> <li>• Before/after shipping from factory</li> </ul> </li> <li>③ Improper adjustment during commissioning <ul style="list-style-type: none"> <li>• Excess/shortage of refrigerant, etc.</li> </ul> </li> </ul>	

Note:

<div>Error code</div> <div>Remote control: None</div>	LED	Green	Red	<div>Content</div> <div>Excessive noise/vibration (2/3)</div>
	Indoor	—	—	
	Outdoor	—	—	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     Start([From previous page]) --&gt; D1{[Unit side] Does noise/vibration occur when the cooling/ heating operation is performed normally?}     D1 -- NO --&gt; NextPage([To next page])     D1 -- YES --&gt; D2{Are the pipes contacting the casing?}     D2 -- YES --&gt; C1[Rearrange the piping to avoid contact with the casing.]     D2 -- NO --&gt; D3{Is it heard continuous hissing or roaring sound?}     D3 -- YES --&gt; C2[It is noise/vibration that is generated when the refrigerant gas or liquid flow through inside of piping of air-conditioner. It is likely to occur particularly during cooling or defrosting in the heating mode. It is normal.]     D3 -- NO --&gt; D4{Are hissing sounds heard at the startup or stopping?}     D4 -- YES --&gt; C3[The noise/vibration occurs when the refrigerant starts or stops flowing. It is normal.]     D4 -- NO --&gt; D5{Is blowing sound heard at the start/stop of defrosting during heating?}     D5 -- YES --&gt; C4[When the defrosting starts or stops during heating, the refrigerant flow is reversed due to switching 4-way valve. This causes a large change in pressure which produces a blowing sound. It may accompany also the hissing sounds as mentioned above. They are normal.]     D5 -- NO --&gt; D6{Is cracking noise heard during heating operation?}     D6 -- YES --&gt; C5[After the start or stop of heating operation or during defrosting, abrupt changes in temperature cause resin parts to shrink or expand. This is normal.]     D6 -- NO --&gt; D7{Hissing noise is heard during cooling operation or after stopping.}     D7 -- YES --&gt; C6[It is the sound produced by the drain pump that discharges drain from the indoor unit. The pump continues to run for 5 minutes after stopping the cooling operation. This is normal.]     D7 -- NO --&gt; C7[Apply the damper sealant at places considered to be the sources such as the pressure reducing mechanism (expansion valve), capillary, etc.]   </pre>	
3. Condition of error displayed		
4.Presumable cause		

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Excessive noise/vibration (3/3)
	Indoor	—	—	
	Outdoor	—	—	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     A[From previous page] --&gt; B{Adjustment during commissioning Does noise/vibration occur when the cooling/heating operation is in anomalous condition?}     B -- YES --&gt; C[Countermeasure] </pre>	
3. Condition of error displayed	<p>If insufficient cooling/heating problem happens due to anomalous operating conditions at cooling/heating, followings are suspicious.</p> <ul style="list-style-type: none"> <li>• Overcharge of refrigerant</li> <li>• Insufficient charge of refrigerant</li> <li>• Intrusion of air, nitrogen, etc.</li> </ul> <p>In such occasion, it is necessary to recover refrigerant, vacuum-dry and recharge refrigerant.</p> <p>* Since there could be many causes of noise/vibration, the above do not cover all. In such case, check the conditions when, where, how the noise/vibration occurs according to following check point.</p> <ul style="list-style-type: none"> <li>• Indoor/outdoor unit</li> <li>• Cooling/heating/fan mode</li> <li>• Startup/stop/during operation</li> <li>• Operating condition (Indoor/outdoor temperatures, pressure)</li> <li>• Time it occurred</li> <li>• Operation data retained by the remote control such as compressor rotation speed, heat exchanger temperature, EEV opening degree, etc.</li> <li>• Tone (If available, record the noise)</li> <li>• Any other anomalies</li> </ul>	
4.Presumable cause		

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Louver motor failure (FDTC and FDEN series)
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
FDTC and FDEN series only	Diagnosis	Countermeasure
2.Error detection method	<p>▲ Check at the indoor unit side.</p> <pre> graph TD     Start([Operate after waiting for more than 1 minute.]) --&gt; Q1{Does the louver operate at the power on?}     Q1 -- YES --&gt; Q2{Is the louver operable with the remote control?}     Q1 -- NO --&gt; Q3{Is LM wiring broken?}     Q3 -- YES --&gt; C1[Repair wiring.]     Q3 -- NO --&gt; Q4{Is LM locked?}     Q4 -- YES --&gt; C2[Replace LM.]     Q4 -- NO --&gt; C3[Defective indoor control PCB → Replace.]     Q2 -- YES --&gt; C4[Normal]     Q2 -- NO --&gt; C5[Adjust LM lever and then check again.]           </pre> <p>LM: louver motor</p>	
3. Condition of error displayed		
4.Presumable cause	<ul style="list-style-type: none"> <li>• Defective LM</li> <li>• LM wire breakage</li> <li>• Faulty indoor control PCB</li> </ul>	

Note:

<div>Error code</div> <div>Remote control: None</div>	LED	Green	Red	<div>Content</div> <div>Power source system error (Power source to indoor control PCB)</div>
	Indoor	Stays OFF	Stays OFF	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting				
All models	<table> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> <tr> <td> <pre> graph TD     D1{Is AC220/240V detected between ① and ② on the terminal block of indoor unit?}     D2{Are fuses OK (F200, F201)?}     D3{Is the check of resistance between ①-③ of CNW0 OK?}     D4{Is the checked result of resistance of FM, LM, etc OK?}     D5{Is DCSV detected between ④-⑤ of CNW2 (FDUM:CNW1)?}     D6{Is JX1 open?}     D7{Is AC19V or higher detected between Red-Red (CNW2) at transformer secondary side?}     D8{Is JX1 open?}      D1 -- YES --&gt; D2     D1 -- NO --&gt; D1_1{Is AC220/240V for 1-phase unit detected between ① and ② on the terminal block of outdoor unit?}     D1_1 -- YES --&gt; C1[Misconnection or breakage of connecting wires]     D1_1 -- NO --&gt; C2[Defective outdoor control PCB (Noise filter)]     D2 -- YES --&gt; D3     D2 -- NO --&gt; D3     D3 -- YES --&gt; D4     D3 -- NO --&gt; C3[Defective indoor control or power PCB → Replace.]     D4 -- YES --&gt; C4[Replace fuse.]     D4 -- NO --&gt; C5[Replace FM, LM, etc.]     D5 -- YES --&gt; D6     D5 -- NO --&gt; C6[Defective indoor power PCB → Replace.]     D6 -- YES --&gt; C7[Defective indoor control PCB → Replace.]     D6 -- NO --&gt; C8[Open JX1.]     D7 -- YES --&gt; D8     D7 -- NO --&gt; C9[Replace transformer.]     D8 -- YES --&gt; C10[Defective indoor control PCB → Replace.]     D8 -- NO --&gt; C11[Open JX1.]           </pre> </td><td></td></tr> </table>	Diagnosis	Countermeasure	<pre> graph TD     D1{Is AC220/240V detected between ① and ② on the terminal block of indoor unit?}     D2{Are fuses OK (F200, F201)?}     D3{Is the check of resistance between ①-③ of CNW0 OK?}     D4{Is the checked result of resistance of FM, LM, etc OK?}     D5{Is DCSV detected between ④-⑤ of CNW2 (FDUM:CNW1)?}     D6{Is JX1 open?}     D7{Is AC19V or higher detected between Red-Red (CNW2) at transformer secondary side?}     D8{Is JX1 open?}      D1 -- YES --&gt; D2     D1 -- NO --&gt; D1_1{Is AC220/240V for 1-phase unit detected between ① and ② on the terminal block of outdoor unit?}     D1_1 -- YES --&gt; C1[Misconnection or breakage of connecting wires]     D1_1 -- NO --&gt; C2[Defective outdoor control PCB (Noise filter)]     D2 -- YES --&gt; D3     D2 -- NO --&gt; D3     D3 -- YES --&gt; D4     D3 -- NO --&gt; C3[Defective indoor control or power PCB → Replace.]     D4 -- YES --&gt; C4[Replace fuse.]     D4 -- NO --&gt; C5[Replace FM, LM, etc.]     D5 -- YES --&gt; D6     D5 -- NO --&gt; C6[Defective indoor power PCB → Replace.]     D6 -- YES --&gt; C7[Defective indoor control PCB → Replace.]     D6 -- NO --&gt; C8[Open JX1.]     D7 -- YES --&gt; D8     D7 -- NO --&gt; C9[Replace transformer.]     D8 -- YES --&gt; C10[Defective indoor control PCB → Replace.]     D8 -- NO --&gt; C11[Open JX1.]           </pre>	
Diagnosis	Countermeasure				
<pre> graph TD     D1{Is AC220/240V detected between ① and ② on the terminal block of indoor unit?}     D2{Are fuses OK (F200, F201)?}     D3{Is the check of resistance between ①-③ of CNW0 OK?}     D4{Is the checked result of resistance of FM, LM, etc OK?}     D5{Is DCSV detected between ④-⑤ of CNW2 (FDUM:CNW1)?}     D6{Is JX1 open?}     D7{Is AC19V or higher detected between Red-Red (CNW2) at transformer secondary side?}     D8{Is JX1 open?}      D1 -- YES --&gt; D2     D1 -- NO --&gt; D1_1{Is AC220/240V for 1-phase unit detected between ① and ② on the terminal block of outdoor unit?}     D1_1 -- YES --&gt; C1[Misconnection or breakage of connecting wires]     D1_1 -- NO --&gt; C2[Defective outdoor control PCB (Noise filter)]     D2 -- YES --&gt; D3     D2 -- NO --&gt; D3     D3 -- YES --&gt; D4     D3 -- NO --&gt; C3[Defective indoor control or power PCB → Replace.]     D4 -- YES --&gt; C4[Replace fuse.]     D4 -- NO --&gt; C5[Replace FM, LM, etc.]     D5 -- YES --&gt; D6     D5 -- NO --&gt; C6[Defective indoor power PCB → Replace.]     D6 -- YES --&gt; C7[Defective indoor control PCB → Replace.]     D6 -- NO --&gt; C8[Open JX1.]     D7 -- YES --&gt; D8     D7 -- NO --&gt; C9[Replace transformer.]     D8 -- YES --&gt; C10[Defective indoor control PCB → Replace.]     D8 -- NO --&gt; C11[Open JX1.]           </pre>					
2.Error detection method					
3. Condition of error displayed					
4.Presumable cause					
<ul style="list-style-type: none"> <li>Misconnection or breakage of connecting wires</li> <li>Blown fuse</li> <li>Faulty indoor control or power PCB</li> <li>Broken harness</li> <li>Faulty outdoor control PCB (Noise filter)</li> </ul>					

Note:

<div>Error code</div> Remote control: None	LED	Green	Red	<div>Content</div> Power source system error (Power source to remote control)
	Indoor	Keeps flashing	3-time flash	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     Q1{Isn't there any loose connection of remote control wires?} -- YES --&gt; C1[Correct.]     Q1 -- NO --&gt; Q2{Isn't remote control wire broken or short-circuited?}     Q2 -- YES --&gt; C2[Replace wires.]     Q2 -- NO --&gt; P1[Disconnect remote control wires.]     P1 --&gt; Q3{Is DC15V or higher detected between X-Y of indoor unit terminal block?}     Q3 -- YES --&gt; C3[Replace remote control.]     Q3 -- NO --&gt; J1(( ))     J1 -- "FDEN Series" --&gt; Q4{Is DC 24V or higher between (Brown-Brown) of transformer secondary side?}     J1 -- "FDTC, FDUM Series" --&gt; Q5{Is DC180V between ①-② of CNW2 (FDUM:CNW1)?}     Q4 -- YES --&gt; C4[Defective indoor control PCB → Replace.]     Q4 -- NO --&gt; C5[Replace transformer.]     Q5 -- YES --&gt; C6[Defective indoor control PCB → Replace.]     Q5 -- NO --&gt; C7[Defective indoor power PCB → Replace.] </pre>	
3.Condition of error displayed		
4.Presumable cause	<ul style="list-style-type: none"> <li>• Remote control wire breakage/short-circuit</li> <li>• Defective remote control</li> <li>• Malfunction by noise</li> <li>• Faulty indoor power PCB</li> <li>• Broken harness</li> <li>• Faulty indoor control PCB</li> </ul>	

Note:

Error code	LED	Green	Red	Content
Remote control: INSPECT I/U	Indoor	Keeps flashing	Stays OFF	<b>INSPECT I/U</b> (When 1 or 2 remote controls are connected)
	Outdoor	—	Stays OFF	

<b>1.Applicable model</b>  All models	<b>5.Troubleshooting</b>				
<b>2.Error detection method</b>  Communication between indoor unit and remote control is disabled for more than 30 minutes after the power on.	<table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td> <pre> graph TD     Q1{Are 2 units of remote control connected?} -- YES --&gt; S1[Set one remote control for "Master" and the other for "Slave"]     S1 -- Note (1) Use SW1 to set at master or slave. --&gt; Q2{Does it become normal?}     Q2 -- NO --&gt; Q3{Do more than one indoor units have the same address?}     Q1 -- NO --&gt; Q4{Is it set at the slave remote control?}     Q4 -- Note (2) "Slave" is displayed on the remote control LCD. -- YES --&gt; S2[Set SW1 on remote control PCB at "Master".]     Q4 -- NO --&gt; Q3     Q3 -- YES --&gt; S3[Set address again. (SW2 on indoor control PCB)]     Q3 -- NO --&gt; Q5{Are remote control wires laid along high voltage wires?}     Q5 -- YES --&gt; S4[Separate remote control wires from high voltage wires.]     Q5 -- NO --&gt; S5[Disconnect the connecting wire ③ between the indoor and outdoor unit.]     S5 --&gt; S6[Power source reset]     S6 --&gt; Q6{Does DM start 60 seconds later automatically.}     Q6 -- YES --&gt; S7[Defective indoor control PCB→Replace.]     Q6 -- NO --&gt; S8[Defective remote control→Change.]           </pre> </td><td> </td></tr> </tbody> </table>	Diagnosis	Countermeasure	<pre> graph TD     Q1{Are 2 units of remote control connected?} -- YES --&gt; S1[Set one remote control for "Master" and the other for "Slave"]     S1 -- Note (1) Use SW1 to set at master or slave. --&gt; Q2{Does it become normal?}     Q2 -- NO --&gt; Q3{Do more than one indoor units have the same address?}     Q1 -- NO --&gt; Q4{Is it set at the slave remote control?}     Q4 -- Note (2) "Slave" is displayed on the remote control LCD. -- YES --&gt; S2[Set SW1 on remote control PCB at "Master".]     Q4 -- NO --&gt; Q3     Q3 -- YES --&gt; S3[Set address again. (SW2 on indoor control PCB)]     Q3 -- NO --&gt; Q5{Are remote control wires laid along high voltage wires?}     Q5 -- YES --&gt; S4[Separate remote control wires from high voltage wires.]     Q5 -- NO --&gt; S5[Disconnect the connecting wire ③ between the indoor and outdoor unit.]     S5 --&gt; S6[Power source reset]     S6 --&gt; Q6{Does DM start 60 seconds later automatically.}     Q6 -- YES --&gt; S7[Defective indoor control PCB→Replace.]     Q6 -- NO --&gt; S8[Defective remote control→Change.]           </pre>	
Diagnosis	Countermeasure				
<pre> graph TD     Q1{Are 2 units of remote control connected?} -- YES --&gt; S1[Set one remote control for "Master" and the other for "Slave"]     S1 -- Note (1) Use SW1 to set at master or slave. --&gt; Q2{Does it become normal?}     Q2 -- NO --&gt; Q3{Do more than one indoor units have the same address?}     Q1 -- NO --&gt; Q4{Is it set at the slave remote control?}     Q4 -- Note (2) "Slave" is displayed on the remote control LCD. -- YES --&gt; S2[Set SW1 on remote control PCB at "Master".]     Q4 -- NO --&gt; Q3     Q3 -- YES --&gt; S3[Set address again. (SW2 on indoor control PCB)]     Q3 -- NO --&gt; Q5{Are remote control wires laid along high voltage wires?}     Q5 -- YES --&gt; S4[Separate remote control wires from high voltage wires.]     Q5 -- NO --&gt; S5[Disconnect the connecting wire ③ between the indoor and outdoor unit.]     S5 --&gt; S6[Power source reset]     S6 --&gt; Q6{Does DM start 60 seconds later automatically.}     Q6 -- YES --&gt; S7[Defective indoor control PCB→Replace.]     Q6 -- NO --&gt; S8[Defective remote control→Change.]           </pre>					
<b>3.Condition of error displayed</b>  Same as above					
<b>4.Presumable cause</b>  <ul style="list-style-type: none"> <li>• Improper setting</li> <li>• Surrounding environment</li> <li>• Defective remote control communication circuit</li> <li>• Faulty indoor control PCB</li> </ul>					

Note: If any error is detected 30 minutes after displaying “WAIT” on the remote control, the display changes to “INSPECT I/U”.

Error code	LED	Green	Red	Content
Remote control: INSPECT I/U	Indoor	Keeps flashing	Stays OFF	<b>INSPECT I/U</b> (Connection of 3 units or more remote control)
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting																																		
All models																																			
2.Error detection method																																			
Indoor unit cannot communicate for more than 30 minutes after the power on with remote control.																																			
3.Condition of error displayed																																			
Same as above																																			
4.Presumable cause																																			
<ul style="list-style-type: none"> <li>• Improper setting</li> <li>• Surrounding environment</li> <li>• Defective remote control communication circuit</li> <li>• Faulty indoor control or power PCB</li> <li>• Faulty outdoor sub PCB</li> </ul>	<table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td>Are more than 3 units of remote control connected?</td><td>YES → Reduce to 2 units or less.</td></tr> <tr> <td>NO</td><td></td></tr> <tr> <td>Does remote control display "Slave"?</td><td>YES → Change remote control setting to "Master". (SW1 on remote control PCB)</td></tr> <tr> <td>NO</td><td></td></tr> <tr> <td>Do more than one indoor units have the same address?</td><td>YES → Change address. (SW2 on indoor control PCB)</td></tr> <tr> <td>NO</td><td></td></tr> <tr> <td>Is it set to a slave indoor unit. SW5-1, 2?</td><td>YES → Change to master. (SW5-1, 2 on indoor control PCB)</td></tr> <tr> <td>NO</td><td></td></tr> <tr> <td>Is there loose or wrong connection at the terminal of wiring between indoor and outdoor units?</td><td>YES → Correct</td></tr> <tr> <td>NO</td><td></td></tr> <tr> <td>Is the grounding wire connected properly?</td><td>NO → Correct</td></tr> <tr> <td>YES</td><td></td></tr> <tr> <td>Is approx. DC20V detected between ②-③ on the outdoor unit terminal block?</td><td>NO → Defective outdoor sub PCB → Replace.</td></tr> <tr> <td>YES</td><td></td></tr> <tr> <td>Is approx. DC20V detected between ②-③ on the indoor unit terminal block?</td><td>NO → Broken connecting wire → Correct.</td></tr> <tr> <td>YES</td><td>Defective indoor control or power PCB → Replace.</td></tr> </tbody> </table>	Diagnosis	Countermeasure	Are more than 3 units of remote control connected?	YES → Reduce to 2 units or less.	NO		Does remote control display "Slave"?	YES → Change remote control setting to "Master". (SW1 on remote control PCB)	NO		Do more than one indoor units have the same address?	YES → Change address. (SW2 on indoor control PCB)	NO		Is it set to a slave indoor unit. SW5-1, 2?	YES → Change to master. (SW5-1, 2 on indoor control PCB)	NO		Is there loose or wrong connection at the terminal of wiring between indoor and outdoor units?	YES → Correct	NO		Is the grounding wire connected properly?	NO → Correct	YES		Is approx. DC20V detected between ②-③ on the outdoor unit terminal block?	NO → Defective outdoor sub PCB → Replace.	YES		Is approx. DC20V detected between ②-③ on the indoor unit terminal block?	NO → Broken connecting wire → Correct.	YES	Defective indoor control or power PCB → Replace.
Diagnosis	Countermeasure																																		
Are more than 3 units of remote control connected?	YES → Reduce to 2 units or less.																																		
NO																																			
Does remote control display "Slave"?	YES → Change remote control setting to "Master". (SW1 on remote control PCB)																																		
NO																																			
Do more than one indoor units have the same address?	YES → Change address. (SW2 on indoor control PCB)																																		
NO																																			
Is it set to a slave indoor unit. SW5-1, 2?	YES → Change to master. (SW5-1, 2 on indoor control PCB)																																		
NO																																			
Is there loose or wrong connection at the terminal of wiring between indoor and outdoor units?	YES → Correct																																		
NO																																			
Is the grounding wire connected properly?	NO → Correct																																		
YES																																			
Is approx. DC20V detected between ②-③ on the outdoor unit terminal block?	NO → Defective outdoor sub PCB → Replace.																																		
YES																																			
Is approx. DC20V detected between ②-③ on the indoor unit terminal block?	NO → Broken connecting wire → Correct.																																		
YES	Defective indoor control or power PCB → Replace.																																		

Note: If any error is detected 30 minutes after displaying "WAIT" on the remote control, the display changes to "INSPECT I/U".

Error code	LED	Green	Red	Content
Remote control:  WAIT	Indoor	Keeps flashing	Stays OFF	Communication error at initial operation (1/3)
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
When the remote control LCD displays “ WAIT ” 2 minutes after the power on.	<p>The remote control LCD displays “ WAIT ” 2 minutes after the power on.</p> <p>Turn the breaker off once and then back on again 3 minutes later.</p> <p>Is normal condition restored?</p> <p>YES → Normal</p> <p>NO</p> <p>Isn't blown the power source fuse (15A, 20A or 30A) on the outdoor unit controller?</p> <p>NO → Replace the power source fuse.</p> <p>YES</p> <p>Is AC220/240V detected at the secondary side of outdoor sub PCB?</p> <p>NO → Defective outdoor sub PCB → Replace.</p> <p>YES</p> <p>Is the green LED of indoor unit flashing?</p> <p>NO → Defective indoor control PCB → Replace.</p> <p>YES</p> <p>Are wires connected properly between the indoor and the outdoor units?</p> <p>NO → Replace indoor control PCB. Correct connection wires between indoor and outdoor units.</p> <p>YES</p> <p>Is approx. DC20V detected between ②-③ on the outdoor unit terminal block?</p> <p>NO → Defective outdoor sub PCB → Replace.</p> <p>YES</p> <p>Is approx. DC20V detected between ②-③ on the indoor unit terminal block?</p> <p>NO → Defective connection wire (broken wire) Noise</p> <p>YES → Defective indoor control PCB → Replace.</p>	
2.Error detection method		
3.Condition of error displayed		
4.Presumable cause	<ul style="list-style-type: none"> <li>• Blown fuse</li> <li>• Faulty outdoor sub PCB</li> <li>• Connection between PCB's</li> <li>• Faulty indoor control PCB</li> <li>• Defective remote control</li> <li>• Broken remote control wire</li> </ul>	

Note: If any anomaly is detected during communication, the error code E5 is displayed. Inspection procedure is same as above. (Excluding matters related to connection) When the power source is reset after the occurrence of E5, the LED will display “ WAIT ” if the anomaly continues. If the breaker ON/OFF is repeated in a short period of time (within 1 minute), “ WAIT ” may be displayed. In such occasion, turn the breaker off and wait for 3 minutes.

<div>Error code</div> <div>Remote control: 🖱️ WAIT 🖱️</div>	LED	Green	Red	<div>Content</div> <div>Communication error at initial operation (2/3)</div>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

1. Applicable model	5. Troubleshooting	
All models  When the fuse is blown, the method to inspect outdoor sub PCB before replacing the power source fuse	Diagnosis	Countermeasure
2. Error detection method	<pre> graph TD     Start([From previous page]) --&gt; D1{Isn't there a short-circuit between phases of outdoor sub PCB?}     D1 -- NO --&gt; A1[Replace the outdoor sub PCB]     D1 -- YES --&gt; D2{Aren't there cracks or burning on the power transistor module or diode stack?}     D2 -- NO --&gt; A2[Replace the outdoor main PCB]     D2 -- YES --&gt; D3{Isn't reactor the anomalous?}     D3 -- NO --&gt; A3[Replace the reactor.]     D3 -- YES --&gt; A4[Replace fuse.]           </pre>	
3. Condition of error displayed		
4. Presumable cause	<ul style="list-style-type: none"> <li>• Blown fuse</li> <li>• Faulty outdoor sub PCB</li> <li>• Faulty outdoor main PCB</li> <li>• Faulty reactor</li> </ul>	

Note:

Error code	LED	Green	Red	Content
Remote control:  WAIT	Indoor	Keeps flashing	Stays OFF	Communication error at initial operation (3/3)
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting
All models	
When the remote control display is extinguished after the power on.	
2.Error detection method	Diagnosis
	<pre> graph TD     Start[Remote control display is extinguished after the power on.] --&gt; Q1{Is the green LED on the indoor unit flashing?}     Q1 -- YES --&gt; Q2{Are wires connected properly between the indoor and the outdoor units?}     Q1 -- NO --&gt; Q3{Is the fuse on the indoor control PCB OK?}     Q2 -- YES --&gt; Q4{Is approx. DC20V detected between ②-③ on the outdoor unit terminal block?}     Q2 -- NO --&gt; CM1[Correct wires.]     Q4 -- YES --&gt; Q5{Is approx. DC20V detected between ②-③ on the indoor unit terminal block?}     Q4 -- NO --&gt; CM2[Defective outdoor sub PCB → Replace.]     Q5 -- YES --&gt; CM3[Defective indoor control PCB → Replace.]     Q5 -- NO --&gt; CM4[Defective connection wire (Broken wire) Noise]     Q3 -- NO --&gt; CM5[Replace fuse.]     Q3 -- YES --&gt; Q6{Is AC 19V or higher detected between Red-Red at the secondary side of indoor unit transformer?}     Q6 -- NO --&gt; CM6[Defective transformer]     Q6 -- YES --&gt; Note1[Note (1) FDEN only.]     Note1 --&gt; Q7{Is approx. DC10-11V detected between wires at the remote control side after disconnecting the remote control?}     Q7 -- YES --&gt; CM7[Defective remote control]     Q7 -- NO --&gt; CM8[Short-circuit on remote control wire] </pre>
3.Condition of error displayed	Countermeasure
	<p>Replace fuse.</p> <p>Defective transformer</p> <p>Short-circuit on remote control wire</p> <p>Defective remote control</p> <p>Correct wires.</p> <p>Defective outdoor sub PCB → Replace.</p> <p>Defective connection wire (Broken wire) Noise</p> <p>Defective indoor control PCB → Replace.</p>
4.Presumable cause	
<ul style="list-style-type: none"> <li>• Blown fuse</li> <li>• Connection between PCB's</li> <li>• Blown fuse</li> <li>• Faulty indoor control PCB</li> <li>• Defective remote control</li> <li>• Wire breakage on remote control</li> <li>• Faulty outdoor sub PCB</li> </ul>	

Note:

<div>Error code</div> Remote control: E1	LED	Green	Red	<div>Content</div>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

Remote control communication circuit error

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     A{Is it possible to reset normally by the power reset?} -- YES --&gt; B[Malfunction by noise Check peripheral environment.]     A -- NO --&gt; C[Turn SW7-1 to OFF. → ON Remove the wire ③ connecting between indoor/outdoor units.]     C --&gt; D[Power source reset]     D --&gt; E{Does the drain pump restart automatically 1 minute later?}     E -- YES --&gt; F[Defective indoor control PCB → Replace.]     E -- NO --&gt; G[Defective remote control → Replace.]     </pre> <p>Note (1) Does the remote control still display “WAIT” even after 3 minutes?</p>	
3.Condition of error displayed		
Same as above		
4.Presumable cause		
<ul style="list-style-type: none"> <li>Defective communication circuit between remote control-indoor unit</li> <li>Noise</li> <li>Defective remote control</li> <li>Faulty indoor control PCB</li> </ul>		


**Note:** If the indoor unit cannot communicate normally with the remote control for 180 seconds, the indoor control PCB starts to reset automatically.

Error code	LED	Green	Red	Content
Remote control: E5	Indoor	Keeps flashing	2-time flash	Communication error during operation
	Outdoor	—	6-time flash	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<p>Note (1) Inspect faulty connections (disconnection, looseness) on the outdoor unit terminal block.</p> <p>Is the connection of signal wires at the outdoor unit side OK?</p> <p>NO → Repair signal wires.</p> <p>YES</p> <p>Note (2) Check for faulty connection or breakage of signal wires between indoor-outdoor units.</p> <p>Is the connection of signal wires between indoor-outdoor units OK?</p> <p>NO → Repair signal wires.</p> <p>YES</p> <p>Power source reset</p> <p>Has the remote control LCD returned to normal state?</p> <p>NO → Defective outdoor sub PCB (Defective network communication circuit) → Replace.</p> <p>YES → Unit is normal. (Malfunction by temporary noise, etc.)</p>	
3.Condition of error displayed		
Same as above is detected during operation.		
4.Presumable cause	<ul style="list-style-type: none"> <li>• Unit No. setting error</li> <li>• Broken remote control wire</li> <li>• Faulty remote control wire connection</li> <li>• Faulty outdoor sub PCB</li> </ul>	

Note:

<div>Error code</div> Remote control: E6	LED	Green	Red	<div>Content</div> Indoor heat exchanger temperature thermistor anomaly
	Indoor	Keeps flashing	1-time flash	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<p>Is the connection of indoor heat exchanger temperature thermistor connector OK?</p> <p>NO → Correct. → Insert connector securely.</p> <p>YES</p> <p>Are characteristics of indoor heat exchanger temperature thermistor OK?</p> <p>NO → Defective indoor heat exchanger temperature thermistor → Replace.</p> <p>YES → Defective indoor control PCB → Replace. (Defective indoor unit heat exchanger temperature thermistor input circuit)</p>	
3.Condition of error displayed	<p>(Broken wire)</p> <p>Temperature-resistance characteristic</p>  <p>(Short circuit)</p>	
4.Presumable cause	<ul style="list-style-type: none"> <li>Defective indoor heat exchanger thermistor connector</li> <li>Indoor heat exchanger temperature thermistor anomaly</li> <li>Faulty indoor control PCB</li> </ul>	

Note:

<div>Error code</div> Remote control: E7	LED	Green	Red	<div>Content</div> Return air temperature thermistor anomaly
	Indoor	Keeps flashing	1-time flash	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     A{Is the connection of return air temperature thermistor connector OK?} -- NO --&gt; B[Correct. → Connect connector.]     A -- YES --&gt; C{Are the characteristics of return air temperature thermistor OK?}     C -- NO --&gt; D[Defective return air temperature thermistor → Replace.]     C -- YES --&gt; E[Defective indoor control PCB → Replace. (Defective return air temperature thermistor input circuit)]           </pre>	
3.Condition of error displayed	<p>• When the temperature thermistor detects -50°C or lower for 5 seconds continuously, the compressor stops. After 3-minute delay, the compressor starts again automatically, but if this error occurs again within 60 minutes after the initial detection.</p>	
4.Presumable cause	<p>• Defective return air temperature thermistor connector • Defective return air temperature thermistor • Faulty indoor control PCB</p>	
	<p>Temperature-resistance characteristic</p> <p>(Broken wire)</p> <p>(Short circuit)</p>	

Note:

Error code	LED	Green	Red	Content
Remote control: E8	Indoor	Keeps flashing	1-time flash	Heating overload operation
	Outdoor	—	Stays OFF	

<b>1.Applicable model</b>  All models	<b>5.Troubleshooting</b> <table> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> <tr> <td> <pre> graph TD     Q1{Is the air filter clogged?} -- YES --&gt; C1[Wash.]     Q1 -- NO --&gt; Q2{Is the indoor heat exchanger temperature thermistor connection OK?}     Q2 -- YES --&gt; Q3{Are the characteristics of indoor heat exchanger temperature thermistor OK?}     Q2 -- NO --&gt; C2[Defective indoor heat exchanger temperature thermistor connector → Correct.]     Q3 -- YES --&gt; P1[Check the error data with the remote control.]     Q3 -- NO --&gt; C3[Defective indoor heat exchanger temperature thermistor.]     P1 --&gt; Q4{Is the unit operating in the state of heating overload?}     Q4 -- YES --&gt; C4[Adjust]     Q4 -- NO --&gt; C5[Check refrigerant system.]           </pre> <p>Note (1) Judge if it is in the state of overload or not as follows.</p> <ul style="list-style-type: none"> <li>▲ Is there any short-circuit of air?</li> <li>▲ Isn't there any fouling or clogging on the indoor heat exchanger?</li> <li>▲ Is the outdoor fan control normal?</li> <li>▲ Isn't the indoor and outdoor air temperature too high?</li> </ul> <p>Note (2) For characteristics of indoor heat exchanger temperature thermistor, see the error display E6.</p> <p style="text-align: center;">Indoor heat exchanger temperature (°C)</p> </td><td> </td></tr> </table>	Diagnosis	Countermeasure	<pre> graph TD     Q1{Is the air filter clogged?} -- YES --&gt; C1[Wash.]     Q1 -- NO --&gt; Q2{Is the indoor heat exchanger temperature thermistor connection OK?}     Q2 -- YES --&gt; Q3{Are the characteristics of indoor heat exchanger temperature thermistor OK?}     Q2 -- NO --&gt; C2[Defective indoor heat exchanger temperature thermistor connector → Correct.]     Q3 -- YES --&gt; P1[Check the error data with the remote control.]     Q3 -- NO --&gt; C3[Defective indoor heat exchanger temperature thermistor.]     P1 --&gt; Q4{Is the unit operating in the state of heating overload?}     Q4 -- YES --&gt; C4[Adjust]     Q4 -- NO --&gt; C5[Check refrigerant system.]           </pre> <p>Note (1) Judge if it is in the state of overload or not as follows.</p> <ul style="list-style-type: none"> <li>▲ Is there any short-circuit of air?</li> <li>▲ Isn't there any fouling or clogging on the indoor heat exchanger?</li> <li>▲ Is the outdoor fan control normal?</li> <li>▲ Isn't the indoor and outdoor air temperature too high?</li> </ul> <p>Note (2) For characteristics of indoor heat exchanger temperature thermistor, see the error display E6.</p> <p style="text-align: center;">Indoor heat exchanger temperature (°C)</p>	
Diagnosis	Countermeasure				
<pre> graph TD     Q1{Is the air filter clogged?} -- YES --&gt; C1[Wash.]     Q1 -- NO --&gt; Q2{Is the indoor heat exchanger temperature thermistor connection OK?}     Q2 -- YES --&gt; Q3{Are the characteristics of indoor heat exchanger temperature thermistor OK?}     Q2 -- NO --&gt; C2[Defective indoor heat exchanger temperature thermistor connector → Correct.]     Q3 -- YES --&gt; P1[Check the error data with the remote control.]     Q3 -- NO --&gt; C3[Defective indoor heat exchanger temperature thermistor.]     P1 --&gt; Q4{Is the unit operating in the state of heating overload?}     Q4 -- YES --&gt; C4[Adjust]     Q4 -- NO --&gt; C5[Check refrigerant system.]           </pre> <p>Note (1) Judge if it is in the state of overload or not as follows.</p> <ul style="list-style-type: none"> <li>▲ Is there any short-circuit of air?</li> <li>▲ Isn't there any fouling or clogging on the indoor heat exchanger?</li> <li>▲ Is the outdoor fan control normal?</li> <li>▲ Isn't the indoor and outdoor air temperature too high?</li> </ul> <p>Note (2) For characteristics of indoor heat exchanger temperature thermistor, see the error display E6.</p> <p style="text-align: center;">Indoor heat exchanger temperature (°C)</p>					
<b>2.Error detection method</b>  Indoor heat exchanger temperature thermistor (ThI-R1, R2, R3)					
<b>3.Condition of error displayed</b>  When it is detected 5 times within 60 minutes from initial detection or when the overload condition is detected for 6 minutes continuously.					
<b>4.Presumable cause</b>  <ul style="list-style-type: none"> <li>• Clogged air filter</li> <li>• Defective indoor heat exchanger temperature thermistor connector</li> <li>• Defective indoor heat exchanger temperature thermistor</li> <li>• Anomalous refrigerant system</li> </ul>					

Note: During heating operation; After starting compressor, compressor rotation speed is decreased by detecting indoor heat exchanger temperature (ThI-R) in order to control high pressure.

Error code	LED	Green	Red	Content
Remote control: E9	Indoor	Keeps flashing	1-time flash	<b>Drain trouble</b> (FDTC and FDUM series)
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting				
FDTC and FDUM series only	<table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td> <pre> graph TD     Start([Check the error data in the remote control.]) --&gt; Q1{Is there any overflow?}     Q1 -- NO --&gt; Q2{Is DC 12V at CNI connector.}     Q2 -- YES --&gt; C1[Check float switch]     Q2 -- NO --&gt; Q3{Is the CNI connected firmly?}     Q3 -- NO --&gt; C2[Defective indoor control PCB → Replace.]     Q3 -- YES --&gt; Q4{Is there any anomaly on the optional equipment?}     Q4 -- NO --&gt; C3[Defective indoor control PCB → Replace.]     Q4 -- YES --&gt; C4[Check optional equipment]     Q1 -- YES --&gt; Q5{Is the humidifier connected?}     Q5 -- YES --&gt; Q6{Is the humidifier drain motor interlocked by the indoor unit function setting of remote control?}     Q6 -- YES --&gt; StartMotor[Drain motor ON from the remote control]     Q6 -- NO --&gt; C5[Correct setting to "Humidifier drain motor interlock".]     StartMotor --&gt; Q7{Does drain motor operate?}     Q7 -- NO --&gt; Q8{Is AC220/240V (FDUM: DC12V) detected at CNR connector?}     Q8 -- YES --&gt; C6[Check wiring of drain motor]     Q8 -- NO --&gt; C7[Defective indoor power PCB → Replace. (FDUM: Indoor control PCB)]     Q7 -- YES --&gt; Q9{Is the drain piping unclogged? Is the drain pipe slop OK?}     Q9 -- NO --&gt; C8[Correct.]     Q9 -- YES --&gt; C9[Check drain motor.]           </pre> </td><td></td></tr> </tbody> </table>	Diagnosis	Countermeasure	<pre> graph TD     Start([Check the error data in the remote control.]) --&gt; Q1{Is there any overflow?}     Q1 -- NO --&gt; Q2{Is DC 12V at CNI connector.}     Q2 -- YES --&gt; C1[Check float switch]     Q2 -- NO --&gt; Q3{Is the CNI connected firmly?}     Q3 -- NO --&gt; C2[Defective indoor control PCB → Replace.]     Q3 -- YES --&gt; Q4{Is there any anomaly on the optional equipment?}     Q4 -- NO --&gt; C3[Defective indoor control PCB → Replace.]     Q4 -- YES --&gt; C4[Check optional equipment]     Q1 -- YES --&gt; Q5{Is the humidifier connected?}     Q5 -- YES --&gt; Q6{Is the humidifier drain motor interlocked by the indoor unit function setting of remote control?}     Q6 -- YES --&gt; StartMotor[Drain motor ON from the remote control]     Q6 -- NO --&gt; C5[Correct setting to "Humidifier drain motor interlock".]     StartMotor --&gt; Q7{Does drain motor operate?}     Q7 -- NO --&gt; Q8{Is AC220/240V (FDUM: DC12V) detected at CNR connector?}     Q8 -- YES --&gt; C6[Check wiring of drain motor]     Q8 -- NO --&gt; C7[Defective indoor power PCB → Replace. (FDUM: Indoor control PCB)]     Q7 -- YES --&gt; Q9{Is the drain piping unclogged? Is the drain pipe slop OK?}     Q9 -- NO --&gt; C8[Correct.]     Q9 -- YES --&gt; C9[Check drain motor.]           </pre>	
Diagnosis	Countermeasure				
<pre> graph TD     Start([Check the error data in the remote control.]) --&gt; Q1{Is there any overflow?}     Q1 -- NO --&gt; Q2{Is DC 12V at CNI connector.}     Q2 -- YES --&gt; C1[Check float switch]     Q2 -- NO --&gt; Q3{Is the CNI connected firmly?}     Q3 -- NO --&gt; C2[Defective indoor control PCB → Replace.]     Q3 -- YES --&gt; Q4{Is there any anomaly on the optional equipment?}     Q4 -- NO --&gt; C3[Defective indoor control PCB → Replace.]     Q4 -- YES --&gt; C4[Check optional equipment]     Q1 -- YES --&gt; Q5{Is the humidifier connected?}     Q5 -- YES --&gt; Q6{Is the humidifier drain motor interlocked by the indoor unit function setting of remote control?}     Q6 -- YES --&gt; StartMotor[Drain motor ON from the remote control]     Q6 -- NO --&gt; C5[Correct setting to "Humidifier drain motor interlock".]     StartMotor --&gt; Q7{Does drain motor operate?}     Q7 -- NO --&gt; Q8{Is AC220/240V (FDUM: DC12V) detected at CNR connector?}     Q8 -- YES --&gt; C6[Check wiring of drain motor]     Q8 -- NO --&gt; C7[Defective indoor power PCB → Replace. (FDUM: Indoor control PCB)]     Q7 -- YES --&gt; Q9{Is the drain piping unclogged? Is the drain pipe slop OK?}     Q9 -- NO --&gt; C8[Correct.]     Q9 -- YES --&gt; C9[Check drain motor.]           </pre>					
2.Error detection method					
Float switch is activated					
3.Condition of error displayed					
If the float switch OPEN is detected for 3 seconds continuously or if float switch connector or wire is disconnected.					
4.Presumable cause					
<ul style="list-style-type: none"> <li>Defective indoor control or power PCB</li> <li>Float switch setting error</li> <li>Humidifier drain motor interlock setting error</li> <li>Optional equipment setting error</li> <li>Drain piping error</li> <li>Defective drain motor</li> <li>Disconnection of drain motor wiring</li> </ul>					


**Note:** When this error occurred at power ON, disconnection of wire or connector of the float switch is suspected. Check and correct it (or replace it, if necessary).

<div>Error code</div> Remote control: E10	LED	Green	Red	<div>Content</div> Excessive number of connected indoor units (more than 17 units) by controlling with one remote control
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
	<pre> graph LR     A{Aren't more than 17 indoor units connected to one remote control?} -- NO --&gt; B[Defective remote control → Replace.]     A -- YES --&gt; C[Reduce to 16 or less units.] </pre>	
2.Error detection method		
When it detects more than 17 of indoor units connected to one remote control		
3.Condition of error displayed		
Same as above		
4.Presumable cause		
<ul style="list-style-type: none"> <li>Excessive number of indoor units connected</li> <li>Defective remote control</li> </ul>		

Note:

Error code	LED	Green	Red	Content
Remote control: E11	Indoor	Keeps flashing	Keeps flashing	Address setting error of indoor units
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<p>E11 occurs</p> <p>Is "Master IU address set" function of remote control used?</p> <p>YES</p> <p>In case the wiring is below and "Master IU address set" is used, E11 is appeared.</p> 	
3.Condition of error displayed	<ul style="list-style-type: none"> <li>• In cases of RC-EX1A Menu → Next → IU settings → Select IU</li> <li>• In cases of RC-E5 Return address No. to "IU ..." using [ ▲ ] or [ ▼ ] button.</li> </ul>	
4.Presumable cause		

Note:

Error code	LED	Green	Red	Content
Remote control: E16	Indoor	Keeps flashing	1-time flash	Indoor fan motor anomaly (FDTC and FDUM series)
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting				
FDTC and FDUM series only					
2.Error detection method					
Detected by rotation speed of indoor fan motor					
3.Condition of error displayed					
When actual rotation speed of indoor fan motor drops to lower than $200\text{min}^{-1}$ for 30 seconds continuously, the compressor and the indoor fan motor stop. After 2-seconds, it starts again automatically, but if this error occurs 4 times within 60 minutes after the initial detection.					
4.Presumable cause					
<ul style="list-style-type: none"> <li>Defective indoor power PCB</li> <li>Foreign material at rotational area of fan propeller</li> <li>Defective fan motor</li> <li>Dust on control PCB</li> <li>Blown fuse</li> <li>External noise, surge</li> </ul>	<table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td> <p>Does any foreign material intervene in rotational area of fan propeller?</p> <p>YES →</p> <p>NO →</p> <p>Does the fan rotate smoothly when turned by hand?</p> <p>NO →</p> <p>YES →</p> <p>Is DC280V detected between ①-④ of fan motor connector CNM? (1)</p> <p>NO →</p> <p>Is the fuse F202 (FDUM: F3) blown?</p> <p>NO →</p> <p>YES →</p> <p>Power source reset</p> <p>Is it normalized?</p> <p>NO →</p> <p>YES →</p> </td><td> <p>Remove foreign material.</p> <p>Replace the fan motor.</p> <p>Check power voltage.</p> <p>Replace faulty fan motor and power PCB.</p> <p>Replace fan motor. (If the error persists after replacing the fan motor, replace the indoor control PCB.)</p> <p>Malfunction by temporary noise</p> </td></tr> </tbody> </table>	Diagnosis	Countermeasure	<p>Does any foreign material intervene in rotational area of fan propeller?</p> <p>YES →</p> <p>NO →</p> <p>Does the fan rotate smoothly when turned by hand?</p> <p>NO →</p> <p>YES →</p> <p>Is DC280V detected between ①-④ of fan motor connector CNM? (1)</p> <p>NO →</p> <p>Is the fuse F202 (FDUM: F3) blown?</p> <p>NO →</p> <p>YES →</p> <p>Power source reset</p> <p>Is it normalized?</p> <p>NO →</p> <p>YES →</p>	<p>Remove foreign material.</p> <p>Replace the fan motor.</p> <p>Check power voltage.</p> <p>Replace faulty fan motor and power PCB.</p> <p>Replace fan motor. (If the error persists after replacing the fan motor, replace the indoor control PCB.)</p> <p>Malfunction by temporary noise</p>
Diagnosis	Countermeasure				
<p>Does any foreign material intervene in rotational area of fan propeller?</p> <p>YES →</p> <p>NO →</p> <p>Does the fan rotate smoothly when turned by hand?</p> <p>NO →</p> <p>YES →</p> <p>Is DC280V detected between ①-④ of fan motor connector CNM? (1)</p> <p>NO →</p> <p>Is the fuse F202 (FDUM: F3) blown?</p> <p>NO →</p> <p>YES →</p> <p>Power source reset</p> <p>Is it normalized?</p> <p>NO →</p> <p>YES →</p>	<p>Remove foreign material.</p> <p>Replace the fan motor.</p> <p>Check power voltage.</p> <p>Replace faulty fan motor and power PCB.</p> <p>Replace fan motor. (If the error persists after replacing the fan motor, replace the indoor control PCB.)</p> <p>Malfunction by temporary noise</p>				

Note:

<div>Error code</div> Remote control: E19	LED	Green	Red	<div>Content</div> Indoor unit operation check, drain motor check setting error
	Indoor	Keeps flashing	1-time flash	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting		
All models	Diagnosis		Countermeasure
2.Error detection method	<pre> graph TD     Start[E19 occurs when the power ON] --&gt; Decision{Is SW7-1 on the indoor control PCB ON ?}     Decision -- NO --&gt; CM1[Defective indoor control PCB (Defective SW7) -&gt; Replace]     Decision -- YES --&gt; CM2[Turn SW7-1 on the indoor control PCB OFF and reset the power] </pre>		
3.Condition of error displayed			
Same as above			
4.Presumable cause			
Mistake in SW7-1 setting (Due to forgetting to turn OFF SW7-1 after indoor operation check)			

Note:

<div>Error code</div> Remote control: E20	LED	Green	Red	<div>Content</div> Indoor fan motor rotation speed anomaly (FDTC and FDUM series)
	Indoor	Keeps flashing	1-time flash	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting	
FDTC and FDUM series only	Diagnosis	Countermeasure
2.Error detection method	<pre> graph TD     D1{Does any foreign material intervene in rotational area of fan propeller?} -- YES --&gt; C1[Remove foreign material.]     D1 -- NO --&gt; D2{Does the fan rotate smoothly when turned by hand?}     D2 -- YES --&gt; D3{Is DC280V detected between ①-④ of fan motor connector CNM?}     D2 -- NO --&gt; C2[Replace the fan motor.]     D3 -- YES --&gt; C3[Power source reset]     D3 -- NO --&gt; D4{Is the fuse F202 (FDUM:F3) blown?}     D4 -- YES --&gt; C4[Replace faulty fan motor and power PCB.]     D4 -- NO --&gt; C5[Check power voltage.]     C3 --&gt; D5{Is it normalized?}     D5 -- YES --&gt; C6[Malfunction by temporary noise]     D5 -- NO --&gt; C7[Replace fan motor. (If the error persists after replacing the fan motor, replace the indoor control PCB.)] </pre>	
3.Condition of error displayed	<p>When the actual fan rotation speed does not reach to the speed of [required speed-50min<sup>-1</sup>] after 2 minutes have been elapsed since the fan motor rotation speed command was output, the unit stops by detecting indoor fan motor anomaly.</p>	
4.Presumable cause	<ul style="list-style-type: none"> <li>• Defective indoor power (control) PCB</li> <li>• Foreign material at rotational area of fan propeller</li> <li>• Defective fan motor</li> <li>• Dust on control PCB</li> <li>• Blown fuse</li> <li>• External noise, surge</li> </ul>	


Note:

<div>Error code</div> Remote control: E28	LED	Green	Red	<div>Content</div> Remote control temperature thermistor anomaly
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	Stays OFF	

1.Applicable model	5.Troubleshooting																																																																						
All models																																																																							
2.Error detection method																																																																							
Detection of anomalously low temperature (resistance) of remote control temperature thermistor (ThC)																																																																							
3.Condition of error displayed																																																																							
When the temperature thermistor detects -50°C or lower for 5 seconds continuously, the compressor stops. After 3-minutes delay, the compressor starts again automatically, but if this error occurs again within 60 minutes after the initial detection.																																																																							
4.Presumable cause																																																																							
<ul style="list-style-type: none"> <li>Faulty connection of remote control temperature thermistor</li> <li>Defective remote control temperature thermistor</li> <li>Defective remote control PCB</li> </ul>																																																																							
	<div>Diagnosis</div> <div>Countermeasure</div> <pre> graph TD     Q1{Is the remote control temperature thermistor connected properly?} -- NO --&gt; C1[Correct.]     Q1 -- YES --&gt; Q2{Are the characteristics of remote control temperature thermistor OK? Is the thermistor wire OK?}     Q2 -- NO --&gt; C2[Defective remote control temperature thermistor → Replace.]     Q2 -- YES --&gt; C3[Defective remote control PCB → Replace. (Defective remote control temperature thermistor input circuit)]   </pre> <div>Resistance-temperature characteristics of remote control temperature thermistor (ThC)</div> <table border="1"> <thead> <tr> <th>Temperature (°C)</th><th>Resistance value (kΩ)</th><th>Temperature (°C)</th><th>Resistance value (kΩ)</th></tr> </thead> <tbody> <tr><td>0</td><td>65</td><td>30</td><td>16</td></tr> <tr><td>1</td><td>62</td><td>32</td><td>15</td></tr> <tr><td>2</td><td>59</td><td>34</td><td>14</td></tr> <tr><td>4</td><td>53</td><td>36</td><td>13</td></tr> <tr><td>6</td><td>48</td><td>38</td><td>12</td></tr> <tr><td>8</td><td>44</td><td>40</td><td>11</td></tr> <tr><td>10</td><td>40</td><td>42</td><td>9.9</td></tr> <tr><td>12</td><td>36</td><td>44</td><td>9.2</td></tr> <tr><td>14</td><td>33</td><td>46</td><td>8.5</td></tr> <tr><td>16</td><td>30</td><td>48</td><td>7.8</td></tr> <tr><td>18</td><td>27</td><td>50</td><td>7.3</td></tr> <tr><td>20</td><td>25</td><td>52</td><td>6.7</td></tr> <tr><td>22</td><td>23</td><td>54</td><td>6.3</td></tr> <tr><td>24</td><td>21</td><td>56</td><td>5.8</td></tr> <tr><td>26</td><td>19</td><td>58</td><td>5.4</td></tr> <tr><td>28</td><td>18</td><td>60</td><td>5.0</td></tr> </tbody> </table>			Temperature (°C)	Resistance value (kΩ)	Temperature (°C)	Resistance value (kΩ)	0	65	30	16	1	62	32	15	2	59	34	14	4	53	36	13	6	48	38	12	8	44	40	11	10	40	42	9.9	12	36	44	9.2	14	33	46	8.5	16	30	48	7.8	18	27	50	7.3	20	25	52	6.7	22	23	54	6.3	24	21	56	5.8	26	19	58	5.4	28	18	60	5.0
Temperature (°C)	Resistance value (kΩ)	Temperature (°C)	Resistance value (kΩ)																																																																				
0	65	30	16																																																																				
1	62	32	15																																																																				
2	59	34	14																																																																				
4	53	36	13																																																																				
6	48	38	12																																																																				
8	44	40	11																																																																				
10	40	42	9.9																																																																				
12	36	44	9.2																																																																				
14	33	46	8.5																																																																				
16	30	48	7.8																																																																				
18	27	50	7.3																																																																				
20	25	52	6.7																																																																				
22	23	54	6.3																																																																				
24	21	56	5.8																																																																				
26	19	58	5.4																																																																				
28	18	60	5.0																																																																				

**Note:** After 10 seconds has passed since remote control thermistor was switched from valid to invalid, E28 will not be displayed even if the thermistor harness is disconnected. At same time the thermistor, which is effective, is switched from remote control thermistor to indoor return air temperature thermistor. Even though the remote control thermistor is set to be Effective, the return air temperature displayed on remote control for checking still shows the value detected by indoor return air temperature thermistor, not by remote control temperature thermistor.

Error code	LED	Green	Red	Content
Remote control: E35	Indoor	Keeps flashing	Stays OFF	<b>Cooling high pressure operation</b> (Models SCM40, 45, 50, 60, 71, 80)
	Outdoor	—	2-time flash	

<b>1.Applicable model</b>  Models SCM40, 45, 50, 60, 71, 80 only	<b>5.Troubleshooting</b> <table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td> <p>* For the characteristics of outdoor heat exchanger temperature sensor, refer to E37.</p> <pre> graph TD     Q1{Are normal the characteristics of outdoor heat exchanger temperature sensor normal?}     Q2{Is the unit operating in the state of cooling overload?}     Q3{Is the high pressure control normal?}     Q4{Is the temperature (measured actually) at direction of error correct?}     Q1 -- NO --&gt; C1[Replace outdoor heat exchanger temperature sensor.]     Q1 -- YES --&gt; Q2     Q2 -- YES --&gt; C2[Check unit side. • Isn't the air circulation of outdoor unit short-circuited? • Are installation spaces adequate? • Isn't there any fouling or clogging on heater exchanger?]     Q2 -- NO --&gt; Q3     Q3 -- NO --&gt; C3[Control operation check*]     Q3 -- YES --&gt; Q4     Q4 -- NO --&gt; C4[Defective outdoor main PCB→Replace.]     Q4 -- YES --&gt; C5[Excessive refrigerant amount: Recharge refrigerant by weighing proper amount on a scale.]           </pre> </td><td></td></tr> </tbody> </table>	Diagnosis	Countermeasure	<p>* For the characteristics of outdoor heat exchanger temperature sensor, refer to E37.</p> <pre> graph TD     Q1{Are normal the characteristics of outdoor heat exchanger temperature sensor normal?}     Q2{Is the unit operating in the state of cooling overload?}     Q3{Is the high pressure control normal?}     Q4{Is the temperature (measured actually) at direction of error correct?}     Q1 -- NO --&gt; C1[Replace outdoor heat exchanger temperature sensor.]     Q1 -- YES --&gt; Q2     Q2 -- YES --&gt; C2[Check unit side. • Isn't the air circulation of outdoor unit short-circuited? • Are installation spaces adequate? • Isn't there any fouling or clogging on heater exchanger?]     Q2 -- NO --&gt; Q3     Q3 -- NO --&gt; C3[Control operation check*]     Q3 -- YES --&gt; Q4     Q4 -- NO --&gt; C4[Defective outdoor main PCB→Replace.]     Q4 -- YES --&gt; C5[Excessive refrigerant amount: Recharge refrigerant by weighing proper amount on a scale.]           </pre>	
Diagnosis	Countermeasure				
<p>* For the characteristics of outdoor heat exchanger temperature sensor, refer to E37.</p> <pre> graph TD     Q1{Are normal the characteristics of outdoor heat exchanger temperature sensor normal?}     Q2{Is the unit operating in the state of cooling overload?}     Q3{Is the high pressure control normal?}     Q4{Is the temperature (measured actually) at direction of error correct?}     Q1 -- NO --&gt; C1[Replace outdoor heat exchanger temperature sensor.]     Q1 -- YES --&gt; Q2     Q2 -- YES --&gt; C2[Check unit side. • Isn't the air circulation of outdoor unit short-circuited? • Are installation spaces adequate? • Isn't there any fouling or clogging on heater exchanger?]     Q2 -- NO --&gt; Q3     Q3 -- NO --&gt; C3[Control operation check*]     Q3 -- YES --&gt; Q4     Q4 -- NO --&gt; C4[Defective outdoor main PCB→Replace.]     Q4 -- YES --&gt; C5[Excessive refrigerant amount: Recharge refrigerant by weighing proper amount on a scale.]           </pre>					
<b>2.Error detection method</b>   <p>Outdoor heat exchanger temperature (°C)</p>					
<b>3.Condition of error displayed</b>  When anomalous outdoor heat exchanger temperature occurs 5 times within 60 minutes or 60°C or higher continues for 10 minutes, including the compressor stop.					
<b>4.Presumable cause</b>  <ul style="list-style-type: none"> <li>• Defective outdoor heat exchanger temperature sensor</li> <li>• Defective outdoor main PCB</li> <li>• Indoor, outdoor unit installation spaces</li> <li>• Short-circuit of air on indoor, outdoor units</li> <li>• Fouling, clogging of heat exchanger</li> <li>• Excessive refrigerant quantity</li> </ul>					

Note:




Error code	LED	Green	Red	Content
Remote control: E36	Indoor	Keeps flashing	Stays OFF	Discharge pipe temperature error
	Outdoor	—	5-time flash	

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<div><div><div>Are the characteristics of discharge pipe temperature sensor normal?</div><div>NO</div><div>YES</div></div><div><div>Is the discharge pipe temperature error persisted during cooling operation?</div><div>YES</div><div>NO</div></div><div><div>Is the discharge pipe temperature control normal?</div><div>NO</div><div>YES</div></div><div><div>Is the temperature (measured actually) at detection of error correct?</div><div>NO</div><div>YES</div></div></div> <div><p>* For the characteristics of discharge pipe temperature, refer to E39.</p><p>* For the contents of control, refer to the protective control by controlling compressor rotation speed and cooling high pressure protective control of micro computer control function for corresponding models.</p></div>	
3.Condition of error displayed	Replace discharge pipe temperature sensor.	
When discharge pipe temperature anomaly is detected 2 times within 60 minutes is compressor stop.	Insufficient refrigerant amount : Recharge refrigerant by weighing proper amount on a scale.	
4.Presumable cause	Control operation check *	
• Defective outdoor main (control) PCB • Defective discharge pipe temperature sensor • Clogged filter • Indoor, outdoor unit installation spaces • Short-circuit of air on indoor, outdoor units • Fouling, clogging of heat exchanger	Defective outdoor main (control) PCB→Replace.	
	Check unit side: • Isn't filter clogged? • Are adequate indoor, outdoor unit installation spaces? • Isn't there any short-circuit of air? • Isn't there any fouling, clogging on indoor heat exchanger?	

Note:

<div>Error code</div> <div>Remote control: E37</div>	LED	Green	Red	<div>Content</div> <div>Outdoor heat exchanger temperature sensor anomaly</div>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	8-time flash	

1.Applicable model	5.Troubleshooting		
All models	Diagnosis		Countermeasure
2.Error detection method	<p>Is the outdoor heat exchanger temperature sensor connector connected properly?</p> <p>NO → Correct connector.</p> <p>YES</p> <p>For the characteristics of outdoor heat exchanger temperature sensor, see the following graph.</p> <p>Are the characteristics of outdoor heat exchanger temperature sensor OK?</p> <p>NO → Defective outdoor heat exchanger temperature sensor → Replace.</p> <p>YES → Defective outdoor main (control) PCB → Replace. (Defective outdoor heat exchanger temperature sensor input circuit)</p>		
3.Condition of error displayed	<p>Temperature-resistance characteristics</p> <p>(Broken wire)</p>  <p>Temperature sensor resistance (kΩ)</p> <p>Temperature (°C)</p> <p>5kΩ at 25°C</p> <p>(Short circuit)</p>		
4.Presumable cause	<ul style="list-style-type: none"> <li>Defective outdoor main (control) PCB</li> <li>Broken sensor harness or temperature sensing section</li> <li>Disconnected wire connection (connector)</li> </ul>		


Note:

<div>Error code</div> <div>Remote control: E38</div>	LED	Green	Red	<div>Content</div> <div>Outdoor air temperature sensor anomaly</div>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	8-time flash	

<div>1.Applicable model</div> <div>All models</div>	<div>5.Troubleshooting</div> <div> <div>Diagnosis</div> <div> <p>Is the suction pipe temperature sensor connector connected properly?</p> <p>NO → Correct connector.</p> <p>YES</p> <p>Is the characteristics of the suction pipe temperature sensor OK?</p> <p>NO → Defective outdoor air temperature sensor → Replace.</p> <p>YES → Defective outdoor main (control) PCB → Replace. (Defective outdoor air temperature sensor input circuit)</p> <p>For the characteristics of suction pipe temperature sensor, see the following graph.</p> <p>• Models SCM40-80</p> <p>Temperature-resistance characteristics</p> <p>• Models SCM100, 125</p> <p>Temperature-resistance characteristics</p> </div> </div>	<div>Countermeasure</div>
<div>2.Error detection method</div> <div>Detection of anomalously low temperature (resistance) on outdoor air temperature sensor</div>		
<div>3.Condition of error displayed</div> <div> <ul style="list-style-type: none"> <li>When the temperature sensor detects -55 °C or lower for 5 seconds continuously within 2 minutes to 2 minutes 20 seconds after the compressor ON, the compressor stops. After 3-minutes delay, the compressor starts again automatically, but if this anomalous temperature is detected 3 times within 40 minutes.</li> <li>When -55 °C or lower is detected for within 20 second after power ON.</li> </ul> </div>		
<div>4.Presumable cause</div> <div> <ul style="list-style-type: none"> <li>Defective outdoor main (control) PCB</li> <li>Broken sensor harness or temperature sensing section (Check molding.)</li> <li>Disconnected wire connection (connector)</li> </ul> </div>		

Note:

<div>Error code</div> <div>Remote control: E39</div>	LED	Green	Red	<div>Content</div> <div>Discharge pipe temperature sensor anomaly</div>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	8-time flash	

1.Applicable model	5.Troubleshooting		
All models	Diagnosis		Countermeasure
2.Error detection method	<p>Is the discharge pipe temperature sensor connector connected properly?</p> <p>YES</p> <p>Are the characteristics of discharge pipe temperature sensor OK?</p> <p>For the characteristics of discharge pipe temperature sensor, see the following graph.</p> <p>NO</p> <p>YES</p>		<p>Correct connector.</p> <p>Defective discharge pipe temperature sensor→ Replace.</p> <p>Defective outdoor main (control) PCB→Replace. (Defective temperature sensor input circuit)</p>
3.Condition of error displayed	<p>(Broken wire) Temperature-resistance characteristics</p>  <p>Temperature sensor resistance (kΩ)</p> <p>Temperature (°C)</p> <p>[T ≤ 90°C]</p> <p>(Short circuit)</p>		
4.Presumable cause	<ul style="list-style-type: none"> <li>Defective outdoor main (control) PCB</li> <li>Broken sensor harness or temperature sensing section (Check molding.)</li> <li>Disconnected wire connection (connector)</li> </ul>		

Note:

<div>Error code</div> Remote control: E40	LED	Green	Red	<div>Content</div> <b>Heating high pressure operation</b> (Models SCM100, 125)
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	2-time flash	

<div>1.Applicable model</div> Models SCM100,125 only	<div>5.Troubleshooting</div>	
<div>2.Error detection method</div> For the error detection method, refer to the protective control by controlling compressor rotation speed and heating high pressure protective control of micro computer control function for corresponding models. (Refer to 251 page)	<div>Diagnosis</div>	<div>Countermeasure</div>
<div>3.Condition of error displayed</div> <ul style="list-style-type: none"> <li>When anomalous rise of the high pressure sensor is detected 5 times within 1 hour.</li> <li>When high pressure sensor anomaly is detected for 10 minutes continuously.</li> </ul>	<pre> graph TD     Q1{Are normal the characteristics of high pressure sensor normal?} -- NO --&gt; C1[Replace high pressure sensor.]     Q1 -- YES --&gt; Q2{Is the unit operating in the state of heating overload?}     Q2 -- YES --&gt; C2["Check unit side. • Isn't the air circulation of outdoor unit short-circuited? • Are installation spaces adequate? • Isn't there any fouling or clogging on heater exchanger?"]     Q2 -- NO --&gt; Q3{Is the high pressure control normal?}     Q3 -- NO --&gt; C3[Control operation check]     Q3 -- YES --&gt; Q4{Is the pressure (measured actually) at direction of error correct?}     Q4 -- NO --&gt; C4[Defective outdoor control PCB → Replace.]     Q4 -- YES --&gt; C5[Excessive refrigerant amount: Recharge refrigerant by weighing proper amount on a scale.] </pre>	
<div>4.Presumable cause</div> <ul style="list-style-type: none"> <li>Defective high pressure sensor</li> <li>Defective outdoor control PCB</li> <li>Indoor, outdoor unit installation spaces</li> <li>Short-circuit of air on indoor, outdoor units</li> <li>Fouling, clogging of heat exchanger</li> <li>Excessive refrigerant quantity</li> </ul>		

Note:

Error code Remote control: E41	LED	Green	Red	Content
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	1-time flash	

## Power transistor overheat (Models SCM100, 125)

1.Applicable model	5.Troubleshooting	
Models SCM100, 125 only	Diagnosis	Countermeasure
2.Error detection method	<div>Is the installation space of outdoor unit enough?</div> <div>NO</div> <div>Correct.</div> <div>YES</div> <div>Is the outdoor fan running?</div> <div>NO</div> <div>Replace the fan motor or outdoor control PCB.</div> <div>YES</div> <div>Are the characteristics of power transistor temperature thermistor OK?</div> <div>NO</div> <div>Replace the power transistor temperature thermistor.</div> <div>YES</div> <div>Is the power transistor temperature thermistor connector connection OK?</div> <div>NO</div> <div>Connect.</div> <div>YES</div> <div>Is it OK the fixing to power transistor radiator fin?</div> <div>• Fixed screw</div> <div>• Application of radiation silicone</div> <div>NO</div> <div>Fix properly.</div> <div>YES</div> <div>Does it recur?</div> <div>NO</div> <div>OK</div> <div>* Characteristics of power transistor temperature thermistor</div> <div>Temperature-resistance characteristics</div> <div><div>Temperature thermistor resistance (kΩ)</div><div>200</div><div>180</div><div>160</div><div>140</div><div>120</div><div>100</div><div>80</div><div>60</div><div>40</div><div>20</div><div>0</div><div>0</div><div>20</div><div>40</div><div>60</div><div>80</div><div>100</div><div>120</div><div>140</div><div>Temperature (°C)</div></div>	
Anomalous rise of the internal power transistor temperature		
3.Condition of error displayed		
When anomalous rise of the power transistor temperature is detected 2 times within 1 hour.		
4.Presumable cause		
<div><div>• Defective inverter PCB</div><div>• Defective outdoor fan motor</div><div>• Delective power transistor temperature thermistor</div><div>• Inadequate installation space</div></div>		

Note:

Error code	LED	Green	Red	Content
Remote control: E42	Indoor	Keeps flashing	Stays OFF	Current cut (1/2)
	Outdoor	—	1-time flash	

1.Applicable model	5.Troubleshooting				
All models	<table border="1"> <thead> <tr> <th>Diagnosis</th><th>Countermeasure</th></tr> </thead> <tbody> <tr> <td> <pre> graph TD     A{Is the Power source voltage OK?} -- NO --&gt; B[Check power source.]     A -- YES --&gt; C{Are the service valves opened?}     C -- NO --&gt; D[Open the valves.]     C -- YES --&gt; E{Is the high pressure during operation OK?}     E -- NO --&gt; F[Check refrigerant amount and refrigerant circuit *In case of transitional increase of high pressure and/or test run, several times restarting may recover it, because liquid refrigerant (migrated) in the compressor is discharged from the compressor.]     E -- YES --&gt; G{Is the checked result of insulation resistance and coil wire resistance (1) of compressor motor OK?}     G -- NO --&gt; H[Replace compressor.]     G -- YES --&gt; I[To next page.]     </pre> <p>(1) SCM40, 45, 50 : 1.619Ω or more at 20°C SCM60, 71, 80 : 1.154Ω or more at 20°C SCM100, 125 : 0.293Ω or more at 20°C</p> </td><td></td></tr> </tbody> </table>	Diagnosis	Countermeasure	<pre> graph TD     A{Is the Power source voltage OK?} -- NO --&gt; B[Check power source.]     A -- YES --&gt; C{Are the service valves opened?}     C -- NO --&gt; D[Open the valves.]     C -- YES --&gt; E{Is the high pressure during operation OK?}     E -- NO --&gt; F[Check refrigerant amount and refrigerant circuit *In case of transitional increase of high pressure and/or test run, several times restarting may recover it, because liquid refrigerant (migrated) in the compressor is discharged from the compressor.]     E -- YES --&gt; G{Is the checked result of insulation resistance and coil wire resistance (1) of compressor motor OK?}     G -- NO --&gt; H[Replace compressor.]     G -- YES --&gt; I[To next page.]     </pre> <p>(1) SCM40, 45, 50 : 1.619Ω or more at 20°C SCM60, 71, 80 : 1.154Ω or more at 20°C SCM100, 125 : 0.293Ω or more at 20°C</p>	
Diagnosis	Countermeasure				
<pre> graph TD     A{Is the Power source voltage OK?} -- NO --&gt; B[Check power source.]     A -- YES --&gt; C{Are the service valves opened?}     C -- NO --&gt; D[Open the valves.]     C -- YES --&gt; E{Is the high pressure during operation OK?}     E -- NO --&gt; F[Check refrigerant amount and refrigerant circuit *In case of transitional increase of high pressure and/or test run, several times restarting may recover it, because liquid refrigerant (migrated) in the compressor is discharged from the compressor.]     E -- YES --&gt; G{Is the checked result of insulation resistance and coil wire resistance (1) of compressor motor OK?}     G -- NO --&gt; H[Replace compressor.]     G -- YES --&gt; I[To next page.]     </pre> <p>(1) SCM40, 45, 50 : 1.619Ω or more at 20°C SCM60, 71, 80 : 1.154Ω or more at 20°C SCM100, 125 : 0.293Ω or more at 20°C</p>					
2.Error detection method	<p>In order to prevent from overcurrent of inverter, if the current exceeds the specifications, it makes the compressor stopping.</p>				
3. Condition of error displayed	<ul style="list-style-type: none"> <li>• If the output current of inveter exceeds the specifications, it makes the compressor stopping.</li> </ul>				
4.Presumable cause	<ul style="list-style-type: none"> <li>• The valves closed</li> <li>• Faulty power source</li> <li>• Insufficient refrigerant amount</li> <li>• Faulty compressor</li> <li>• Faulty power transistor module</li> </ul>				

Note:

Error code Remote control: E42	LED	Green	Red	Content
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	1-time flash	

## Current cut (2/2)

1.Applicable model	5.Troubleshooting	
All models	Diagnosis	Countermeasure
2.Error detection method	<p>From previous page</p> <p>Is the checked result of power transistor module OK?</p> <p>NO → Defective outdoor main PCB → Replace.</p> <p>YES</p> <div style="border: 1px dashed black; padding: 5px;"> <ul style="list-style-type: none"> <li>• Is the space for installation of indoor and/or outdoor unit enough?</li> <li>• Is there any short circuit of air on indoor and/or outdoor unit?</li> <li>• At cooling, does the outdoor fan motor run? Are the service valves fully opened? Is the filter clogged?</li> <li>• At heating, does the indoor fan motor run? Are the service valves fully opened? Is the filter clogged?</li> <li>• Is there any liquid flooding? Is the superheat within normal range? Is the suction pipe temperature thermistor normal?</li> <li>• Is there any anomalous sound on the compressor?</li> </ul> </div> <p>YES</p> <p>After resetting power for several times does it become normal?</p> <p>NO → Defective outdoor main PCB → Replace.</p> <p>YES</p> <p>Temporary noise may cause of anomaly. If noise source can be found, take countermeasure.</p>	
3.Condition of error displayed		
<ul style="list-style-type: none"> <li>• If the output current of inveter exceeds the specifications, it makes the compressor stopping.</li> </ul>		
4.Presumable cause		
<ul style="list-style-type: none"> <li>• Defective outdoor main PCB</li> <li>• Faulty power source</li> <li>• Insufficient refrigerant amount</li> <li>• Faulty compressor</li> <li>• Faulty power transistor module</li> </ul>		

Note:

<div>Error code</div> Remote control: E45	LED	Green	Red	<div>Content</div> <h2>Outdoor sub PCB communication error</h2>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	–	4-time flash	

<h3>1.Applicable model</h3> <p>All models</p>	<h3>5.Troubleshooting</h3>	
<h3>2.Error detection method</h3> <p>Detected communication error of more than 15 seconds 4 times in 15 minutes.</p>	<h3>Diagnosis</h3> <pre> graph TD     Q1{Is the connector connection between the outdoor main PCB and the outdoor sub PCB OK?} -- NO --&gt; C1[Correct connector.]     Q1 -- YES --&gt; Q2{Is the power source voltage OK?}     Q2 -- NO --&gt; C2[Check why power is not supplied to outdoor sub PCB.]     Q2 -- YES --&gt; Q3{Is the communication wire between the main PCB and the outdoor sub PCB connected properly?}     Q3 -- NO --&gt; C3[Connect communication wire securely.]     Q3 -- YES --&gt; P1[Replace the outdoor main PCB.]     P1 --&gt; Q4{Is normal state restored?}     Q4 -- NO --&gt; C4[Defective outdoor sub PCB → Replace.]     Q4 -- YES --&gt; C5[Malfunction by temporary noise] </pre>	<h3>Countermeasure</h3>
<h3>3.Condition of error displayed</h3> <p>When communication is not established between the outdoor sub PCB and the outdoor main PCB.</p>		
<h3>4.Presumable cause</h3> <ul style="list-style-type: none"> <li>• Defective sub PCB</li> <li>• Defective connector between the outdoor main PCB and outdoor sub PCB</li> <li>• Defective outdoor main (control) PCB</li> </ul>		

Note:

<div>Error code</div> Remote control: E47	LED	Green	Red	<div>Content</div> <b>Active filter voltage error</b> (Models SCM40, 45, 50, 60, 71, 80)
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	2-time flash	

<b>1.Applicable model</b>  Models SCM40, 45, 50, 60, 71, 80 only	<b>5.Troubleshooting</b>	
<b>2.Error detection method</b>  Error is displayed if the converter voltage exceeds DC340V (3 times within 20 minutes). Remote controller may be set after 3 minutes delay.	<b>Diagnosis</b>	<b>Countermeasure</b>
<b>3.Condition of error displayed</b>  Same as above	<pre> graph TD     A{Is the power source normal?} -- NO --&gt; B[Restore normal condition.]     A -- YES --&gt; C{Is voltage within the specified range?}     C -- NO --&gt; D[Restore normal condition.]     C -- YES --&gt; E{Check soldered surfaces on the outdoor sub PCB for foreign matter like dust, fouling, etc.}     E -- NO --&gt; F[Remove foreign matter like dust, fouling, etc.]     E -- YES --&gt; G[Defective outdoor sub PCB → Replace.]           </pre>	
<b>4.Presumable cause</b>  <ul style="list-style-type: none"> <li>• Defective outdoor sub PCB</li> <li>• Dust on outdoor sub PCB</li> <li>• Anomalous power source</li> </ul>		

Note:

Error code	LED	Green	Red	Content
Remote control: E48	Indoor	Keeps flashing	Stays OFF	Outdoor fan motor anomaly
	Outdoor	—	ON	

1. Applicable model	5. Troubleshooting	
All models	Diagnosis	Countermeasure
2. Error detection method	<pre> graph TD     D1{Does any foreign material intervene in rotational area of fan propeller?} -- YES --&gt; C1[Remove foreign matter.]     D1 -- NO --&gt; D2{Does the fan rotate smoothly when turned by hand?}     D2 -- YES --&gt; D3{Is DC308-336V detected between (CNFAN ④ (blue)-⑥ (red)) [SCM100, 125: CNFAN ④ (blue)-① (red)] of fan motor connector?}     D2 -- NO --&gt; C2[Replace fan motor. If resistance between ① (Vm):white -④(GND) [SCM100, 125: ②(Vm):white-④(GND)]:blue is detected 1kΩ or lower, it is faulty.]     D3 -- YES --&gt; A1[Power source reset]     D3 -- NO --&gt; D4{Is F3 (250V1A) [SCM100, 125: F4 (250V4A)]}     A1 --&gt; D5{Is normal state restored?}     D4 -- YES --&gt; C3[Replace faulty fan motor and outdoor main PCB.]     D4 -- NO --&gt; C4[Check power source voltage.]     D5 -- YES --&gt; C5[Malfunction by temporary noise]     D5 -- NO --&gt; C6[Replace fan motor (If anomaly persists after replacing fan motor, replace outdoor main PCB.)] </pre>	
3. Condition of error displayed		
When actual rotation speed of outdoor fan motor drops to 75min <sup>-1</sup> or lower for 30 minutes continuously, the compressor and the outdoor fan motor stop. After 3-minutes delay, it starts again automatically, but if this anomaly occurs 3 times within 60 minutes after the initial detection.		
4. Presumable cause	<ul style="list-style-type: none"> <li>Defective outdoor main (control) PCB</li> <li>Foreign material at rotational area of fan propeller</li> <li>Defective fan motor</li> <li>Dust on outdoor main (control) PCB</li> <li>Blown F3 fuse</li> </ul>	

Note: When E48 error occurs, in almost cases F3 (SCM100, 125: F4) fuse on the outdoor main (control) PCB is blown. There are a lot of cases that fuse is blown and E48 occurs due to defective fan motor. And even though only the outdoor main (control) PCB ( or fuse) is replaced,, another trouble could occur. Therefore when fuse is blown, check whether the fan motor is OK or not. After confirming the fan motor normal, check by power ON. (Don't power ON without confirming the fan motor normal.)

Error code Remote control: E51	LED	Green	Red	Content <b>Power transistor anomaly</b> (Models SCM40, 45, 50, 60, 71, 80)
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	1-time flash	

<b>1.Applicable model</b>  Models SCM40, 45, 50, 60, 71, 80 only	<b>5.Troubleshooting</b>	
<b>2.Error detection method</b>  Power transistor primary current	<b>Diagnosis</b>	<b>Countermeasure</b>
<b>3.Condition of error displayed</b>  If the power transistor primary current exceeds the setting value for 3 seconds, the compressor stops.	<pre> graph TD     A{Check soldered surfaces on the outdoor main PCB for foreign matter like dust, fouling, etc.} -- NO --&gt; B[Remove foreign matter like dust, fouling, etc.]     A -- YES --&gt; C{Isn't F2 fuse (250V, 20A) blown?}     C -- YES --&gt; D[Replace fuse.]     C -- NO --&gt; E[Defective outdoor main PCB → Replace.]           </pre>	
<b>4.Presumable cause</b>  <ul style="list-style-type: none"> <li>• Faulty outdoor main PCB</li> <li>• Dust on outdoor main PCB</li> <li>• Blown F2 fuse</li> </ul>		

Note:

Error code	LED	Green	Red	Content
Remote control: E51	Indoor	Keeps flashing	Stays OFF	Inverter and fan motor anomaly (Models SCM100, 125)
	Outdoor	—	1-time flash	

1.Applicable model	5.Troubleshooting
Models SCM100, 125 only	
2.Error detection method	Diagnosis
When power transistor anomaly is detected for 15 minutes continuously	<pre> graph TD     D1{Is DC15V detected between the connector CN14 ②-③ on the inverter PCB?}     D2{Is DC15V detected between the harnesses at the control PCB side after disconnecting the connector (CN14)?}     D3{Is DC15V detected on the fan motor connector?}     C1[Defective inverter PCB → Replace.]     C2[Broken harness wire]     C3[Replace fan motor.]     C4[Defective outdoor control PCB → Replace.]      D1 -- YES --&gt; C1     D1 -- NO --&gt; D2     D2 -- YES --&gt; C2     D2 -- NO --&gt; D3     D3 -- YES --&gt; C3     D3 -- NO --&gt; C4           </pre>
3.Condition of error displayed	Countermeasure
Same as above	
4.Presumable cause	
<ul style="list-style-type: none"> <li>Defective outdoor fan motor</li> <li>Defective inverter PCB</li> <li>Defective outdoor control PCB</li> </ul>	

Note:

<div>Error code</div> Remote control: E53	LED	Green	Red	<div>Content</div> Suction pipe temperature sensor anomaly
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	8-time flash	

1.Applicable model	5.Troubleshooting		
All models			
2.Error detection method			
Detection of anomalously low temperature (resistance) on suction pipe temperature sensor			
3.Condition of error displayed			
<ul style="list-style-type: none"> <li>When the temperature sensor detects <math>-55^{\circ}\text{C}</math> or lower for 5 seconds continuously within 2 minutes to 2 minutes 20 seconds after the compressor ON, the compressor stops. After 3-minutes delay, the compressor starts again automatically, but if this anomalous temperature is detected 3 times within 40 minutes.</li> <li>When <math>-55^{\circ}\text{C}</math> or lower is detected for within 20 second after power ON.</li> </ul>			
4.Presumable cause			
<ul style="list-style-type: none"> <li>Defective outdoor sub PCB</li> <li>Broken sensor harness or temperature sensing section (Check molding.)</li> <li>Disconnected wire connection (connector)</li> </ul>			
	<div>Diagnosis</div> <div>Countermeasure</div> <div> <p>Is the suction pipe temperature sensor connector connected properly?</p> <p>NO → Correct connector.</p> <p>YES</p> <p>Is the characteristics of the suction pipe temperature sensor OK?</p> <p>NO → Defective suction pipe temperature sensor → Replace.</p> <p>YES → Defective outdoor sub PCB → Replace. (Defective suction pipe temperature sensor input circuit)</p> <p>For the characteristics of suction pipe temperature sensor, see the following graph.</p> <p>Temperature-resistance characteristics</p> <p>(Broken wire)</p> <p>(Short circuit)</p> </div>		

Note:

<div>Error code</div> Remote control: E54	LED	Green	Red	<div>Content</div> <h2>High pressure sensor anomaly</h2> <p>(Models SCM100, 125)</p>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	8-time flash	

<div>1.Applicable model</div> <div>Models SCM100, 125 only</div>	<div>5.Troubleshooting</div> <table><tr><th>Diagnosis</th><th>Countermeasure</th></tr><tr><td><div><div><div>Are the connection of high pressure sensor connectors (at sensor side and PCB side) OK?</div><div>NO</div><div>Correct high pressure sensor connector connection.</div></div><div><div>YES</div><div>Are the pressure (actual measurement) matched with the value indicated on the remote control?</div><div>YES</div><div>Is refrigerant amount charged properly? Is there any anomaly on the refrigeration circuit?</div></div><div><div>NO</div><div>Replace the high pressure sensor.</div><div>Is normal condition restored?</div><div>NO</div><div>Defective outdoor control PCB→Replace. (Defective high pressure sensor input circuit)</div><div>YES</div><div>OK</div></div></div></td></tr><tr><td><div>2.Error detection method</div><div>When anomalous voltage (pressure) is detected</div></td></tr><tr><td><div>3. Condition of error displayed</div><div>If the pressure sensor detects DC0V or lower and DC3.49V or higher for 5 seconds continuously within 2 minutes to 2 minutes 20 seconds after compressor ON, the compressor stops. When the compressor is restarted automatically after 3-minuts delay, if this anomaly occurs 3 times within 40 minutes</div></td></tr><tr><td><div>4.Presumable cause</div><div><ul style="list-style-type: none"><li>• Defective high pressure sensor connection</li><li>• Defective high pressure sensor</li><li>• Defective outdoor control PCB</li><li>• Improper amount of refrigerant</li><li>• Anomalous refrigeration circuit</li></ul></div></td></tr></table>	Diagnosis	Countermeasure	<div><div><div>Are the connection of high pressure sensor connectors (at sensor side and PCB side) OK?</div><div>NO</div><div>Correct high pressure sensor connector connection.</div></div><div><div>YES</div><div>Are the pressure (actual measurement) matched with the value indicated on the remote control?</div><div>YES</div><div>Is refrigerant amount charged properly? Is there any anomaly on the refrigeration circuit?</div></div><div><div>NO</div><div>Replace the high pressure sensor.</div><div>Is normal condition restored?</div><div>NO</div><div>Defective outdoor control PCB→Replace. (Defective high pressure sensor input circuit)</div><div>YES</div><div>OK</div></div></div>	<div>2.Error detection method</div> <div>When anomalous voltage (pressure) is detected</div>	<div>3. Condition of error displayed</div> <div>If the pressure sensor detects DC0V or lower and DC3.49V or higher for 5 seconds continuously within 2 minutes to 2 minutes 20 seconds after compressor ON, the compressor stops. When the compressor is restarted automatically after 3-minuts delay, if this anomaly occurs 3 times within 40 minutes</div>	<div>4.Presumable cause</div> <div><ul style="list-style-type: none"><li>• Defective high pressure sensor connection</li><li>• Defective high pressure sensor</li><li>• Defective outdoor control PCB</li><li>• Improper amount of refrigerant</li><li>• Anomalous refrigeration circuit</li></ul></div>
Diagnosis		Countermeasure					
<div><div><div>Are the connection of high pressure sensor connectors (at sensor side and PCB side) OK?</div><div>NO</div><div>Correct high pressure sensor connector connection.</div></div><div><div>YES</div><div>Are the pressure (actual measurement) matched with the value indicated on the remote control?</div><div>YES</div><div>Is refrigerant amount charged properly? Is there any anomaly on the refrigeration circuit?</div></div><div><div>NO</div><div>Replace the high pressure sensor.</div><div>Is normal condition restored?</div><div>NO</div><div>Defective outdoor control PCB→Replace. (Defective high pressure sensor input circuit)</div><div>YES</div><div>OK</div></div></div>							
<div>2.Error detection method</div> <div>When anomalous voltage (pressure) is detected</div>							
<div>3. Condition of error displayed</div> <div>If the pressure sensor detects DC0V or lower and DC3.49V or higher for 5 seconds continuously within 2 minutes to 2 minutes 20 seconds after compressor ON, the compressor stops. When the compressor is restarted automatically after 3-minuts delay, if this anomaly occurs 3 times within 40 minutes</div>							
<div>4.Presumable cause</div> <div><ul style="list-style-type: none"><li>• Defective high pressure sensor connection</li><li>• Defective high pressure sensor</li><li>• Defective outdoor control PCB</li><li>• Improper amount of refrigerant</li><li>• Anomalous refrigeration circuit</li></ul></div>							

<div>Error code</div> Remote control: E57	LED	Green	Red	<div>Content</div> Insufficient refrigerant amount or detection of service valve closure
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	2-time flash	

1.Applicable model	5.Troubleshooting
All models	
2.Error detection method	
<ul style="list-style-type: none"> <li>Judge insufficient refrigerant amount by detecting the temperature difference between indoor heat exchanger (ThI-R) and indoor return air (ThI-A).</li> </ul>	
3.Condition of error displayed	
When the insufficient refrigerant amount is detected 3 times within 60 minutes.	
4.Presumable cause	
<ul style="list-style-type: none"> <li>Defective indoor heat exchanger temperature thermistor</li> <li>Defective indoor return air temperature thermistor</li> <li>Defective indoor control PCB</li> <li>Insufficient refrigerant amount</li> </ul>	<div>Diagnosis</div> <div>Countermeasure</div> <div> <p>Is the service valve fully opened?</p> <p>NO → Open fully.</p> <p>YES</p> <p>Are the connections of indoor heat exchanger and/or return air temperature thermistor connectors OK?</p> <p>NO → Correct indoor heat exchanger, return air temperature thermistor connector connections.</p> <p>YES</p> <p>Are the characteristics of indoor heat exchanger and/or return air temperature thermistor OK?</p> <p>NO → Defective indoor heat exchanger, return air temperature thermistor → Replace.</p> <p>YES</p> <p>Is the low pressure during operation normal?</p> <p>NO → Charge refrigerant.</p> <p>YES → Defective indoor control PCB → Replace. (Defective indoor heat exchanger, return air temperature thermistor input circuits)</p> </div> <div> <p>Indoor heat exchanger, return air temperature thermistor Temperature-resistance characteristics</p> <p>(Broken wire)</p> <p>(Short circuit)</p> </div>

Note:

<div>Error code</div> Remote control: E58	LED	Green	Red	<div>Content</div> <h2>Current safe stop</h2> <p>(Models SCM40, 45, 50, 60, 71, 80)</p>
	Indoor	Keeps flashing	Stays OFF	
	Outdoor	—	3-time flash	

<h3>1.Applicable model</h3> <p>Models SCM40, 45, 50, 60, 71, 80 only</p>	<h3>5.Troubleshooting</h3>	
<h3>2.Error detection method</h3> <p>When the current safe control has operated at the compressor speed of 30 rps or under:</p>	<h3>Diagnosis</h3> <pre> graph TD     D1{Is the refrigerant amount normal?} -- NO --&gt; C1[Adjust the refrigerant amount properly.]     D1 -- YES --&gt; D2{Is outdoor ventilation condition good?}     D2 -- NO --&gt; C2[Secure space for inlet and outlet.]     D2 -- YES --&gt; D3{Inspect compressor}     D3 -- NO --&gt; C3[Replace compressor.]     D3 -- YES --&gt; D4{Inspect outdoor air temp. sensor}     D4 -- NO --&gt; C4[Replace sensor.]     D4 -- YES --&gt; C5[Defective outdoor main PCB→Replace. (Defective outdoor air temp. sensor input circuit)]           </pre>	<h3>Countermeasure</h3>
<h3>3. Condition of error displayed</h3> <p>Same as above</p>		
<h3>4.Presumable cause</h3> <ul style="list-style-type: none"> <li>• Excessive refrigerant amount</li> <li>• Indoor,outdoor unit installation spaces</li> <li>• Faulty compressor</li> <li>• Defective outdoor air temp. sensor</li> <li>• Defective outdoor main PCB</li> </ul>		

Note:

Error code	LED	Green	Red	Content
Remote control: E59	Indoor	Keeps flashing	Stays OFF	Compressor startup failure
	Outdoor	—	2-time flash	

1.Applicable model	5.Troubleshooting
All models	
2.Error detection method	
If it fails to change over to the rotor detection operation of compressor motor	
3.Condition of error displayed	
If compressor fails to startup for 42 times	
4.Presumable cause	
<ul style="list-style-type: none"> <li>Faulty outdoor fan motor</li> <li>Faulty outdoor main PCB</li> <li>Anomalous power source voltage</li> <li>Improper refrigerant amount and refrigerant circuit</li> <li>Faulty compressor (Motor bearing)</li> </ul>	<div> <p><b>Diagnosis</b></p> <pre> graph TD     Start([Compressor does not start at all. Neither noise nor vibration cannot be heard]) --&gt; Disconnect[Disconnect the outdoor fan motor connector and try to startup]     Disconnect --&gt; Startup1{Does compressor startup?}     Startup1 -- YES --&gt; ReplaceFan[Replace outdoor fan motor]     Startup1 -- NO --&gt; Power{Is power source voltage OK?}     Power -- NO --&gt; CheckVoltage[Check power source voltage]     Power -- YES --&gt; Pressure{Is the pressure balance at starting OK?}     Pressure -- NO --&gt; CheckRefrigerant[Check refrigerant amount and refrigerant circuit]     Pressure -- YES --&gt; Insulation{Is the insulation resistance and coil resistance of compressor OK?}     Insulation -- NO --&gt; ReplaceComp1[Repalce compressor]     Insulation -- YES --&gt; Transistor{Is power transistor module OK?}     Transistor -- NO --&gt; ReplacePCB1[Defective outdoor main PCB→Replace]     Transistor -- YES --&gt; Inverter{Is the output of inverter checker OK?}     Inverter -- NO --&gt; ReplacePCB2[Defective outdoor main PCB→Replace]     Inverter -- YES --&gt; TryStartup[Try to startup several times]     TryStartup --&gt; Note[Note: Several times restarting may resolve it, because migrated liquid refrigerant in the compressor is discharged from the compressor.]     TryStartup --&gt; Startup2{Does it start?}     Startup2 -- NO --&gt; ReplaceComp2[Repalce compressor]           </pre> </div> <p><b>Countermeasure</b></p>

Note: Insulation resistance

- The unit is left for long period without power source or soon after installation, migrated liquid refrigerant may dissolve in the refrigerant oil in the compressor. In such case insulation resistance decreases upto several MΩ or lower. If the electric leakage breaker is activated due to low insulation resistance, check followings.

- Check whether the electric leakage breake conforms to high-hermonic specifications  
(As units has inverter, in order to prevent from improper operation, be sure to use high-hermonic one.)

Error code	LED	Green	Red	Content
Remote control: E60	Indoor	Keeps flashing	Stays OFF	Compressor rotor lock error (Models SCM40, 45, 50, 60, 71, 80)
	Outdoor	—	7-time flash	

1.Applicable model	5.Troubleshooting
Models SCM40, 45, 50, 60, 71, 80 only	
2.Error detection method	Diagnosis
Compressor rotor position	
3.Condition of error displayed	Countermeasure
If it fails again to detect the rotor position after shifting to the compressor rotor position detection operation, the compressor stops.	
4.Presumable cause	
<ul style="list-style-type: none"> <li>Defective outdoor main PCB</li> <li>Anomalous power source voltage</li> <li>Improper refrigerant amount and refrigerant circuit</li> <li>Defective compressor (motor, bearing)</li> </ul>	<pre> graph TD     Q1{Is the power source voltage OK?} -- NO --&gt; C1[Check and correct the power source voltage]     Q1 -- YES --&gt; R1[Reset the power source and restart operation.]     R1 --&gt; Q2{Does the compressor start?}     Q2 -- NO --&gt; Q3{Does E59 occur?}     Q3 -- YES --&gt; C2[Correct it based on the troubleshooting of E59]     Q3 -- NO --&gt; Q4{Does the compressor run without occurrence of E42?}     Q4 -- NO --&gt; C3[Correct it based on the troubleshooting of E42]     Q2 -- YES --&gt; Q5{Is the output from inverter checker OK?}     Q5 -- NO --&gt; C4[Defective outdoor main PCB→Replace.]     Q5 -- YES --&gt; Q6{Is the noise or vibration of compressor normal?}     Q6 -- NO --&gt; C5[Replace compressor.]     Q6 -- YES --&gt; Q7{Does it start up normally without recurrence of E60.}     Q7 -- NO --&gt; C6[Check compressor for insulation, resistance. Replace compressor if necessary.]     Q7 -- YES --&gt; C7[Defective outdoor main PCB→Replace.]           </pre>

Note: Insulation resistance

- The unit is left for long period without power source or soon after installation, migrated liquid refrigerant may dissolve in the refrigerant oil in the compressor. In such case insulation resistance decreases upto several MΩ or lower. If the electric leakage breaker is activated due to low insulation resistance, check followings.
- ① Check whether the electric leakage breaker conforms to high-hermonic specifications  
(As units has inverter, in order to prevent from improper operation, be sure to use high-hermonic one.)

## 9. TABLE OF FUNCTIONS CONNECTED WIRED REMOTE CONTROL (RC-E5)

If wired remote control (option part) is connected to the following indoor units, some of the functions cannot be used. Please see following table for details.

- Wall mounted type : SRK\*\*ZMX-S, ZM-S, ZR-S
- Floor standing type : SRF\*\*ZMX-S
- Ceiling concealed type : SRR\*\*ZM-S

○ : OK, △ : Conditionally OK, × : N/A

NO.	Functions	SRK	SRR	SRF	Outline of function	Remarks
1	Several remote controls for 1 unit	○	○	○	Indoor unit can be connected max. 2 remote controls.	
2	Control of several indoor units	○	○	○	One remote control can be connected to a max. of 16 indoor unit.	
3	Plural control	△	×	×	One outdoor unit can be connected to a max. of 4 indoor units.	Only SRK50,60ZMX-S
4	Central control	○	○	○	Signal of center mode from central control can be restricted to operation of remote control.	
5	Run/Stop	○	○	○		
6	Change operation mode	○	○	○	Display of operation mode range is automatically decided from the indoor unit's information.	
7	Adjust fan speed	○	○	○	Display of airflow range is automatically decided from the indoor unit's information.	
8	Auto swing of flap	○	×	○	Display of airflow direction ON/OFF is automatically decided from the indoor unit's information.	Flap control only. Louver cannot be controlled.
9	Setting of air flow direction	×	×	×	Setting of air flow direction for indoor unit that can be changed airflow direction.	
10	Setting of temperature	△	△	△		Temperature range can be set from 18 degree to 30 degree. Carving 0.5°C is rounded up.
11	Timer operation	○	○	○	Sleep timer mode, Off timer mode, On timer mode, Weekly timer mode.	Warm up timer and sleep control of on timer mode is impossible.
12	Ventilation control	×	×	×	Air infiltration can be controlled by the indoor unit that has this function.	RAC unit does not have this function.
13	Display of unit number	○	○	○	Display address number of remote control.	Address set by SC-BIKN-E for RAC
14	Service switch-1: Display of error data	△	△	△	Display and memorize the error code data that are checked finally.	Only error code is used in the RAC unit.
15	Service switch -2 display of operation data	△	△	△	Display operation data.	RAC unit can be displayed some data.
16	Trial run	○	○	○	Cooling operation signal is sent to the indoor unit.	
17	Forced operation of drain pump	×	×	×	Forced operation of drain pump is sent to the indoor unit.	
18	Setting of compressor frequency	○	○	○	Fixing compressor frequency.	
19	Quiet mode	×	×	×	On timer in order to start quiet mode.	RAC unit does not have this function.
20	Auto address change from remote control	×	×	×	Auto address can be changed from remote control.	RAC unit does not have this function.
21	Indoor unit's address set of master	×	×	×	Adapt controller for 3 pipe system.	RAC unit does not have this function.
22	Filter reset	×	×	×	Turning off signal display of filter sign and sending reset signal of operating time.	RAC unit does not have this function.
23	Clear memory of error code in remote control	○	○	○	Reset memory that remote control has the error code.	
24	Clear memory of error code in the indoor unit	○	○	○	Reset memory of error for the indoor unit.	
25	Clear address in indoor unit	×	×	×	Reset memory of address for the indoor unit.	RAC unit does not have this function.
26	Reset CPU	○	○	○	Reset outdoor or indoor CPU.	
27	Function setting	△	△	△	It is possible to set the function of remote control and indoor unit.	RAC unit can be set a part of function.
28	Setting of temperature range	△	△	△	Set Max and Min temperature.	For RAC models, only the range from 18°C to 30°C is available.
29	External input	○	○	○	External input from CNT terminal can be switched between all unit operation and individual operation.	
30	Auto adjustment of static pressure	×	×	×	Change auto adjustment of static pressure.	RAC unit does not have this function.
31	Setting of static pressure	×	×	×	Displayed part blinks on and off when it receives a signal about auto adjustment of static pressure mode.	RAC unit does not have this function.
32	Filter sign	×	×	×	Displays filter sign via signal from indoor unit when counting time achieves target time.	RAC unit does not have this function.



NO.	Functions	SRK	SRR	SRF	Outline of function	Remarks
33	Preparation of display of heating operation	○	○	○	Display of preparative heating operation from indoor unit.	Starting time of heating, thermo operation
34	Display of defrost operation	○	○	○	Display of defrost operation from indoor unit.	Defrost operation
35	Display of compressor protection operation	×	×	×	Display of compressor protection operation from outdoor unit during compressor soft starting.	RAC unit does not have this function.
36	Mismatch operation mode	×	×	×	Display it when cooling only outdoor unit is received signal of heating operation.	RAC unit does not have this function. ( RAC unit operates by fan mode.)
37	Periodic check	×	×	×	Displays when periodic check signal is received.	RAC unit does not have this function.
38	Display of check	○	○	○	Display of checking in case of signal of error code address from remote control.	RAC unit does not have this function.
39	Display of auto cleaning operation	×	×	×	Displays it when it is received auto cleaning signal from indoor unit.	RAC unit does not have this function.
40	Display of room temperature	○	○	○	Display room temperature.	
41	Display of demand control operation	×	×	×	Display of demand operation from indoor unit.	RAC unit does not have this function.
42	Display of operation on auto adjusting static pressure	×	×	×	Display checking when it receives signal of auto adjusting static pressure operation.	RAC unit does not have this function.
43	External static pressure setting	×	×	×	It is available to select manual setting or automatic setting for setting external static pressure by remote control.	RAC unit does not have this function.

## 10. COMPONENT REPLACEMENT


### 10.1 Models SCM71ZM-S, 80ZM-S

#### Fan and fan motor (FMo)


1. Loosen 6 screws and remove the top panel.
2. Loosen 3 screws and remove the service panel.
3. After removal of service panel, loosen a screw.




4. And then loosen 4 screws and remove the front panel together with the fan guard.



5. Loosen a nut and remove the fan propeller.




6. Disconnect the connector of CNFAN.




**Fan and fan motor (FMo)**

7. Detach the clamps.
8. Pull out the cable.
9. Loose 4 nuts.
10. Remove the fan motor (FMo).


**Compressor (CM)**

1. Loosen screws and remove the service panel and top panel.




2. Loosen screws and remove the cover and the terminal cover.
3. Loosen screws and disconnect all power cables locally installed

**Caution**  
Be sure to do above work after turning the power OFF by breaker.




## Compressor (CM)

4. Loosen screws and remove the side panel.




5. Untie the string and remove rear and front insulation cover.  
6. Disconnect the connector of crankcase heater.





## Compressor (CM)

7. Remove the top cover and the side jacket of compressor.



8. Remove the crankcase heater.  
(It is available to remove the crankcase heater after removing the compressor)
9. Loosen 3 nuts of compressor fixing bolts.






**Compressor (CM)**


10. Loosen a nut and remove the terminal cover.
11. Disconnect the faston connectors from compressor.  
 U: Red cable  
 V: White cable  
 W: Black cable

Note : Be sure to do above work after elapsing 3 minutes from power OFF.

12. Disconnect the pipes for suction and discharge by brazing.  
 (It is available to cut suction and discharger pipes to remove the compressor)




W: Black cable U: Red cable V: White cable



〈Caution〉

When brazing, do not forget to disconnect suction pipe temperature sensor (Tho-S) and discharge pipe temperature sensor (Tho-D) from sockets. Without disconnecting sensors, sensors may have damage by the heat during brazing.



## Main PCB (PCB1) on the upper layer


1. Loosen the screws and remove the top panel and service panel.
2. Unlatch the cover and remove the cover of control box.

3. Disconnect the connector of CNFAN.


Note: Be sure to do following work after elapsing 3 minutes from power OFF.

4. Loosen 6 screws and lift up the main PCB.

[Top view]




[Front view]



2 Latches on front side  
2 more Latches on rear side  
Totally 4 Latches

Disconnect the connector of CNFAN.


[Top view of PCB after removing the cover]



Screws

Screws

[Side view after lifting]



**Main PCB (PCB1) on the upper layer**

5. Disconnect all connectors on the main PCB side.

- ① Disconnect the faston connectors for power supply to compressor.

U : Red cable  
V : White cable  
W : Black cable






- ② Disconnect the faston connectors of reactor which is located just above the 4-way valve.

- ③ Disconnect the connector of fan motor (CNFAN).

- ④ Disconnect the connector of CNSUB.  
(Going to Sub PCB)

- ⑤ Disconnect the connector of CNTH.  
For  
Tho-A (Outdoor air temp.)  
Tho-R (Heat exchanger temp.)  
Tho-D (Discharge pipe temp.)

- ⑥ Disconnect the connector of CN20V.  
(Going to Sub PCB)

**[Main PCB]****[Sub PCB]**

S0 : White

R0 : Black

S-1 : White

C-1 : Red

6. Disconnect all connectors on the Sub PCB side.


- ① Disconnect the faston connectors of power line.  
(Going to Main PCB)

## Main PCB (PCB1) on the upper layer


Layout of Main PCB

〈Main PCB〉

〔Part side〕



〔Pattern side〕



**Sub PCB (PCB2) on the lower layer**

1. After removing the Main PCB, disconnect all connectors on Sub PCB.

① Disconnect the connector of CNEEV1.  
(for EEVA & EEVB)

② Disconnect the connector of CNEEV2.  
(for EEVC & EEVD)

③ Disconnect the connector of CNTH.  
(for suction pipe temp.)

④ Disconnect the connector of CNMAIN.  
(Going to Main PCB)

⑤ Disconnect the connector of CNHEAT.  
(for crankcase heater)

⑥ Disconnect the connector of CN20S.  
(for 4-way valve)

⑦ Disconnect the connector of CN20V.  
(Going to Main PCB)

⑧ Disconnect the connectors of CNA, CNB, CNC and CND.


2. Loosen screws and disconnect the grounding cables.

3. Disconnect the fasten connector of the black cable.


Note : Be sure to do above work after elapsing 3 minutes from power OFF.

4. Loosen a screw and pull up the right side of the upper TB to unlatch from the left side square hole.

5. Loosen the screw of N-terminal and disconnect the white cable.



[Front view]




Grounding cable (G-1)      Grounding cable (G-2)


[Disconnect the black cable]



[Side view]



Grounding cable (G)




Screw

Square hole      Disconnect the white cable




## Sub PCB (PCB2) on the lower layer

6. Loosen 4 screws and remove Sub PCB.



Layout of Sub PCB.





## EEV coils

1. Remove the faulty EEV coil and disconnect the connector.


Note:

- 1) When disconnecting the connector, be sure to check the color marked on the top of coil and the color of the connector.
- 2) When replace to a new coil, be sure to insert the socket attached to the coil to the pipe correctly.




Marking color

EEVD



GREEN

EEVC



BLUE

EEVB





RED

EEVA




WHITE

Socket



### 4-way valve coil


1. Disconnect the connector.
2. Loosen a screw and remove the coil.




## 10.2 Models SCM100ZM-S, 125ZM-S

### Fan and fan motor (FMo)


1. Loosen 4 screws and remove the fan grille.



2. Loosen the nut and remove the fan propeller.




3. Remove the service panel.
4. Detach the clamps and cut off the strap.
5. Disconnect the connector of CNFAN1.
6. Pull out the cable of fan motor through the grommet on the partition.




**Fan and fan motor (FMo)**

7. Loosen 4 nuts.
8. Remove the fan motor (FMo).


**Compressor (CM)**

1. Loosen screws and remove the service panel and top panel.




2. Loosen screws and remove the cover and the terminal cover.
3. Loosen screws and disconnect all cables locally installed.

〈Caution〉  
Be sure to do above work after turning the power OFF by breaker.



**Compressor (CM)**


4. Loosen screws and remove the side panel.



5. Remove the top cover.
6. Remove the terminal cover.
7. Disconnect the faston connectors from compressor.
- U : Red cable  
V : White cable  
W : Blue cable

Note: Be sure to do above work after elapsing 3 minutes from power OFF.


8. Cut off the strap and pull out the sensors of discharge pipe temp. (Tho-D) and suction pipe temp. (Tho-S) from sockets.



**Compressor (CM)**


9. Remove the control unit for easy replacement work of compressor according to following procedure.

- 1) Disconnect all connectors shown in the photo.



10. Remove the control unit.  
(Continue)

- 2) Loosen the screws (5 pieces) shown in the photo.
- 3) Remove the control unit.




**Compressor (CM)**

11. Remove the partition for easy replacement work of compressor according to following procedure.


- 1) Loosen the screws (4 pieces) shown in the photo.
- 2) Disconnect the connector of CNFAN1 and pull out the cable for fan motor through the hole on the partition.
- 3) Remove the partition as shown in photo.

[Front view]



Screws

[Side view]




[Top view]




Screw

Pull out the cable for fan motor

Remove the partition in this way



12. Untie the strings and remove the upper and the lower jackets for compressor.





Upper jacket



Lower jacket

Remove the jackets in this way




Crankcase heater

Note : Be sure to remove the wires of crankcase heater from the jacket before removing the jacket

**Compressor (CM)**

13. Loosen 3 nuts of compressor fixing bolts.

14. Remove the crankcase heater.




15. Disconnect the pipes for suction and discharge by brazing.  
(It is available to cut suction and discharger pipes to remove the compressor)


16. Remove the compressor.

17. Replace to new compressor.

Note: Before placing the new compressor, be sure to mount the crankcase heater onto the new compressor properly.

**Control PCB (PCB1) on the 1st layer**


1. Cut the straps of the white cable passing through the CT.




**Control PCB (PCB1) on the 1st layer**

2. Loosen a screw and dismount the first layer by pulling upward.
3. Loosen a screw on the fixing bracket for the capacitor and slide the capacitor to the right slightly in order to disconnect the connector 3 from the diode stack.
4. Disconnect the connector 3 (White cable) from the diode stack on the 2nd layer.


Note: Be sure to do this work after elapsing 3 minutes from power OFF.



5. Take the white cable out from CT hole as shown in the photo.




6. Disconnect all connectors.
7. Pinch the head of locking supports (7 pieces) and remove the control PCB.



## Control PCB (PCB1) on the 1st layer

Layout of control PCB.




## Sub PCB (PCB4) on the 1st layer


1. Disconnect all connectors from Sub PCB.

Note: Be sure to do this work after elapsing 3 minutes from power OFF.

〔Before disconnecting connectors〕



〔After disconnecting connectors〕




**Sub PCB (PCB4) on the 1st layer**


2. Disconnect the cables (Red & White) connected to the terminal TB3 & TB4 of N/F PCB (PCB3), after dismantling the 1st layer as follows.

1) Dismount the 1st layer according to the dismantling procedure for control PCB after loosening 2 screws and disconnect the power cables on secondary side of TB1.


2) Loosen 2 screws and remove the cables (Red & White) from TB3 & TB4 on the N/F PCB (PCB3) located on back side of the 1st layer.




Disconnect power cables




Screws



TB1




[PCB3]




TB4 (White)

TB3 (Red)


3. Pinch the head of locking supports (4 pieces) and remove the Sub PCB (PCB4).



Locking supports



Disconnected cables



### Inverter PCB (PCB2) on the 2nd layer

1. Dismount the 1st layer according to the procedure for control PCB (PCB1) and Sub PCB (PCB4).

2. Loosen 3 screws and disconnect the cables for compressor.



Note: Be sure to do this work after elapsing 3 minutes from power OFF.

3. Loosen 6 screws and disconnect the cables of P1, P2, P3 and N1, N2, N3.

4. Disconnect 3 connectors of CNI2, CNI4 and CNACT1.


5. Loosen 2 screws for fixing IPM and radiation fin.

6. Pinch the head of locking supports (8 pieces) and remove the Inverter PCB (PCB2).



### Noise filter PCB (PCB3 & PCB5) on the back side of the 1st layer


Layout



**Noise filter PCB (PCB3) on the back side lower of the 1st layer**


1. Dismount the 1st layer according to the procedure for control PCB (PCB1) and Sub PCB (PCB4).
2. Loosen 5 screws and disconnect the cables of TB3 - TB7.
3. Pinch the head of locking supports (4 pieces) and remove the N/F PCB (PCB3).

Note: Be sure to do this work after elapsing 3 minutes from power OFF.


**Noise filter PCB (PCB5) on the back side upper of the 1st layer**

1. Dismount the 1st layer according to the procedure for control PCB (PCB1) and Sub PCB (PCB4).
2. Loosen 5 screws and disconnect the cables of TB3 - TB7.
3. Pinch the head of locking supports (4 pieces) and remove the N/F PCB (PCB5).

Note: Be sure to do this work after elapsing 3 minutes from power OFF.

**Active filter (LACT) and diode stack (DS) on the 2nd layer**

1. Active filter  
Disconnect the faston connectors (6 pieces) and sensor (1 piece). And then loosen 2 screws and remove LACT.
2. Diode stack  
Disconnect all connectors (4 pieces) and loosen 2 screws. And then remove diode stack.




## EEV coils

1. Remove the faulty EEV coil and disconnect the connector.

Note:


- 1) When disconnecting the connector, be sure to check the color marked on the top of coil and the color of the connector.
- 2) When replace to a new coil, be sure to insert the socket attached to the coil to the pipe correctly.




## 11. CHECKING PROCEDURE

### 11.1 Models SCM71ZM-S, 80ZM-S

<Fan motor>





CNFAN1 on PCB1




NO.	Output
①	DC280V
②	DC15V
③	DC0-6V
④	DC0-5V


<Compressor>




<EEV A - EEV D>




MARKING




GREEN



BLUE




RED




WHITE

Input : DC12V




<Sensor>





Suction pipe  
temp. sensor  
(Tho-S)

Discharge pipe  
temp. sensor  
(Tho-D)




Heat exchanger  
sensor (Tho-R)

Outdoor air  
temp. sensor  
(Tho-A)




Name	Color	Resistance(k $\Omega$ )	
		25°C	90°C
Tho-R	Black	5.0	
Tho-A	Black	5.0	
Tho-D	Black		4.6
Tho-S	Black	5.0	

## &lt;Main PCB:PCB1&gt;



Connector	Connected to	Normal value	Remark
CNFAN	Fan motor		
CNSUB(1-4)	CNMAIN of SUB PCB	DC13V	
CNSUB(2-4)		DC0-1V	When 20S is ON
CNSUB(3-4)		DC0-1V	When CH is ON
CNSUB(5-4)		DC5V	
R-S	RO, SO of SUB PCB	AC220-240V	
C-2 - S-2	C-1,S-1 of SUB PCB	DC20V	
CN20V	CN20V of SUB PCB	DC20V	
CNTH	Sensor		Tho-R, Tho-A, Tho-D
U	Compressor	AC300V	
V	Compressor		
U	Compressor		


## &lt;SUB PCB:PCB2&gt;



Connector	Connected to	Normal value	Remark
R <sub>IN</sub>	TB1(L)	AC220-240V	Power source
S <sub>IN</sub>	TB1(N)	AC0V	Power source
SO	R of Main PCB	AC220-240V	
RO	S of Main PCB	AC0V	
S-1 - C-1	S-2,C-2 of Main PCB	DC20V	
CN20V	CN20V of Main PCB	DC20V	
CNA(Black-White)	Indoor unit A	AC220-240V	Power source
CNA(Red)	Indoor unit A	AC0V	Earth
CNB(Black-White)	Indoor unit B	AC220-240V	Power source
CNB(Brown)	Indoor unit B	AC0V	Earth
CNC(Black-White)	Indoor unit C	AC220-240V	Power source
CNC(Blue)	Indoor unit C	AC0V	Earth
CND(Black-White)	Indoor unit D	AC220-240V	Power source
CND(Yellow)	Indoor unit D	AC0V	Earth
CN20S	20S	AC220-240V	For solenoid coil of 4 way valve
CNHEAT	Crankcase heater	AC220-240V	For crankcase heater
CNEEV1	EEV A(WH) and EEV B(RD)		
CNMAIN(1-4)	CNSUB of Main PCB	DC13V	
CNMAIN(2-4)		DC0-1V	When 20S is ON
CNMAIN(3-4)		DC0-1V	When CH is ON
CNMAIN(5-4)		DC5V	
CNEEV2	EEV C(BL) and EEV D(GN)		
CNTH	Sensor for suction pipe		Tho-S


## 11.2 Models SCM100ZM-S, 125ZM-S

### <Fan motor>



NO.	Output
①	DC280V
②	DC15V
③	DC0-6V
④	DC0-5V


### <EEVA - EEVF>




#### MARKING




YELLOW




BLACK




GREEN




BLUE





RED




WHITE



### <EEV-H>




# <Temp. sensor>




Discharge pipe temp. sensor (Tho-D)

Suction pipe temp. sensor (Tho-S)




Heat exchanger sensor (Tho-R)

Power transistor sensor (Tho-AF)




Outdoor air temp. sensor (Tho-A)



Name	Color	Resistance(kΩ)			
		0℃	25℃	50℃	90℃
Tho-R	Black	16.4	5.0	1.8	
Tho-D	Black		54.8		
Tho-S	Black	16.4	5.0	1.8	
Tho-A	Yellow	32.8	10.0		
Tho-AF	Black				
					5.0





# <Compressor>



Resistance	0.293 $\Omega$
------------	----------------




# <Diode stack>



Check a diode stack (DS) by a mutimeter set on diode mode.


## &lt;Control PCB:PCB1&gt;



Connector	Connected to	Normal value	Remark
CNX1	CNX2 on PCB4		Signal of SL
CNI3	CNI4 on PCB2	1-3 DC18V 2-3 DC15V	
CNA1	Power transistor	DC280V	
CNW		AC220-240V	PCB5 (N/F PCB)
CNN1	20S	AC220-240V	For solenoid coil of 4 way valve
CNR1	Crankcase heater	AC220-240V	For crankcase heater
CNA2		DC280V	green->P, white->N
CNFAN1	fan motor		
CNI1	CNI2 on PCB2	1-2 DC5V 1-3 DC0-5V 1-4 DC0-5V	
CNS1	CNS2 on PCB4	DC13V	
CNL1	High preassure sensor		
CNP1	Temp. sensor		Tho-AF
CNTH	Temp. sensor		Tho-R,Tho-D,Tho-S,Tho-A
CNEEV1	EEVH		
※ CNE	For RAM checker		For RAM checker
※ CNV	For Mente PC		For Mente PC


Note(1) ※ used only at our factory.

## &lt; Inverter PCB:PCB2 &gt;





Connector	Connected to	Normal value	Remark
P1-N1	Diode stack	DC280V	
P2-N2	Active filter module	DC280V	
P3-N3	Contactor	DC280V	COMP ON DC300V
CNI2	CNI1 on PCB1	1-2 DC5V 1-3 DC0-5V 1-4 DC0-5V	
CNI4	CNI3 on PCB1	1-3 DC18V 2-3 DC15V	
CNACT1	Active filter module	1-2 DC15V 1-3 DC0-5V 1-4 DC0-3V	
U	Compressor	DC300V	
V	Compressor		
W	Compressor		

## &lt; Noise filter PCB: PCB3 &gt;




Connector	Connected to	Normal value	Remark
TB3	TB5 on PCB5, L-IN on PCB4	AC220-240V	
TB4	TB6 on PCB5, N-IN on PCB4		
TB5	Diode stack (DS)	AC220-240V	
TB6	Diode stack (DS)		
TB7	Earth on control box		

## &lt;SUB PCB: PCB4&gt;



Connector	Connected to	Normal value	Remark
CNEEV1	EEV A(WH) and EEV B(RD)		
CNEEV2	EEV C(BL) and EEV D(GN)		
CNEEV3	EEV E(BK)		
CNEEV4	EEV F(YE)		
CNS2	CNS1 on PCB1	DC13V	
CNX2	CNX1 on PCB1		Signal of SL
CNF	For indoor unit F (125 only)		※1
CNE	For indoor unit E		※1
CND	For indoor unit D		※1
CNC	For indoor unit C		※1
CNB	For indoor unit B		※1
CNA	For indoor unit A		※1
CNDRM	TB8		※2
CNTRO	Trance former	AC30V	
CNTRI	Trance former	DC0-21V	
L-IN,N-IN	TB3,TB4 on PCB3	AC220-240V	

## &lt;Noise filter PCB: PCB5&gt;



Connector	Connected to	Normal value	Remark
TB3	TB1(L)	AC220-240V	
TB4	TB1(N)		
TB5	CNW on PCB1,TB3 on PCB3	AC220-240V	
TB6	CNW on PCB1,TB4 on PCB3		
TB7	Earth		

## 12. OPTION PARTS



### 12.1 Wired remote control

PJA012D730

#### (1) Model RC-E5

Read together with indoor unit's installation manual.



#### ⚠ WARNING

- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.  
Loose connection or hold will cause abnormal heat generation or fire. 
- Make sure the power source is turned off when electric wiring work.  
Otherwise, electric shock, malfunction and improper running may occur. 

#### ⚠ CAUTION

- DO NOT install the remote control at the following places in order to avoid malfunction.
 


(1) Places exposed to direct sunlight	(4) Hot surface or cold surface enough to generate condensation
(2) Places near heat devices	(5) Places exposed to oil mist or steam directly
(3) High humidity places	(6) Uneven surface


- DO NOT leave the remote control without the upper case.  
In case the upper case needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust. 

Accessories	Remote control, wood screw (ø3.5×16) 2 pieces
Prepare on site	Remote control cord (2 cores) the insulation thickness in 1mm or more. [In case of embedding cord] Electrical box, M4 screw (2 pieces) [In case of exposing cord] Cord clamp (if needed)


#### Installation procedure

- ① Open the cover of remote control, and remove the screw under the buttons without fail.
- ② Remove the upper case of remote control.  
Insert a flat-blade screwdriver into the dented part of the upper part of the remote control, and wrench slightly.





#### [In case of embedding cord]


- ③ Embed the electrical box and remote control cord beforehand.




- ④ Prepare two M4 screws (recommended length is 12-16mm) on site, and install the lower case to electrical box. Choose either of the following two positions in fixing it with screws.



- ⑤ Connect the remote control cord to the terminal block.  
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)




- ⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.




#### [In case of exposing cord]

- ③ You can pull out the remote control cord from left upper part or center upper part.  
Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.




- ④ Install the lower case to the flat wall with attached two wooden screws.

- ⑤ Connect the remote control cord to the terminal block.  
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y).  
(X and Y are no polarity)  
Wiring route is as shown in the right diagram depending on the pulling out direction.



The wiring inside the remote control case should be within  $0.3\text{mm}^2$  (recommended) to  $0.5\text{mm}^2$ .  
The sheath should be peeled off inside the remote control case.  
The peeling-off length of each wire is as below.

Pulling out from upper left	Pulling out from upper center
X wiring : 215mm	X wiring : 170mm
Y wiring : 195mm	Y wiring : 190mm




- ⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.  
⑦ In case of exposing cord, fix the cord on the wall with cord clamp so as not to slack.

#### Installation and wiring of remote control

- ① Wiring of remote control should use  $0.3\text{mm}^2 \times 2$  core wires or cables. (on-site configuration)  
② Maximum prolongation of remote control wiring is 600 m.  
If the prolongation is over 100m, change to the size below.  
But, wiring in the remote control case should be under  $0.5\text{mm}^2$ . Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.
- |            |                                  |
|------------|----------------------------------|
| 100 - 200m | $0.5\text{mm}^2 \times 2$ cores  |
| Under 300m | $0.75\text{mm}^2 \times 2$ cores |
| Under 400m | $1.25\text{mm}^2 \times 2$ cores |
| Under 600m | $2.0\text{mm}^2 \times 2$ cores  |

#### Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Set SW1 to "Slave" for the slave remote control. It was factory set to "Master" for shipment.

Note: The setting "Remote control thermistor enabled" is only selectable with the master remote control in the position where you want to check room temperature.

The air-conditioner operation follows the last operation of the remote control regardless of the master/ slave setting of it.


#### The indication when power source is supplied

When power source is turned on, the following is displayed on the remote control until the communication between the remote control and indoor unit settled.

Master remote control : " WAIT " M  
Slave remote control : " WAIT " S

At the same time, a mark or a number will be displayed for two seconds first.


This is the software's administration number of the remote control, not an error cord.



※ The left mark is only an example. Other marks may appear.

When remote control cannot communicate with the indoor unit for half an hour, the below indication will appear.

Check wiring of the indoor unit and the outdoor unit etc.



### The range of temperature setting

When shipped, the range of set temperature differs depending on the operation mode as below.

Heating : 16~30°C (55~86°F)

Except heating (cooling, fan, dry, automatic) : 18~30°C (62~86°F)

### ●Upper limit and lower limit of set temperature can be changed with remote control.

Upper limit setting: valid during heating operation. Possible to set in the range of 20 to 30°C (68 to 86°F).

Lower limit setting: valid except heating (automatic, cooling, fan, dry) Possible to set in the range of 18 to 26°C (62 to 79°F).

When you set upper and lower limit by this function, control as below.

- When ⑫ TEMP RANGE SET, remote control function of function setting mode is "INDN CHANGE" (factory setting),

【 If upper limit value is set 】

During heating, you cannot set the value exceeding the upper limit.

【 If lower limit value is set 】

During operation mode except heating, you cannot set the value below the lower limit.

- When ⑫ TEMP RANGE SET, remote control function of function setting mode is "NO INDN CHANGE"

【 If upper limit value is set 】

During heating, even if the value exceeding the upper limit is set, upper limit value will be sent to the indoor unit.

But, the indication is the same as the temperature set.

【 If lower limit value is set 】


During except heating, even if the value lower than the lower limit is set, lower limit value will be sent to the indoor unit.

But, the indication is the same as the temperature set.

### ●How to set upper and lower limit value

- Stop the air-conditioner, and press (SET) and (MODE) button at the same time for over three seconds .  
The indication changes to "FUNCTION SET ▼".
- Press button once, and change to the "TEMP RANGE ▲" indication.
- Press (SET) button, and enter the temperature range setting mode.
- Select "UPPER LIMIT ▼" or "LOWER LIMIT ▲" by using button.
- Press (SET) button to fix.
- When "UPPER LIMIT ▼" is selected (valid during heating)
  - ① Indication: " ▼ ^ SET UP" → "UPPER 30°C ▼"
  - ② Select the upper limit value with temperature setting button . Indication example: "UPPER 26°C ▼ ^" (blinking)
  - ③ Press (SET) button to fix. Indication example: "UPPER 26°C" (Displayed for two seconds)  
After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".
- When "LOWER LIMIT ▲" is selected (valid during cooling, dry, fan, automatic)
  - ① Indication: " ▼ ^ SET UP" → "LOWER 18°C ^"
  - ② Select the lower limit value with temperature setting button . Indication example: "LOWER 24°C ▼ ^" (blinking)
  - ③ Press (SET) button to fix. Indication for example: "LOWER 24°C" (Displayed for two seconds)  
After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".
- Press button to finish.

- It is possible to finish by pressing button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.



## The functional setting

● The initial function setting for typical using is performed automatically by the indoor unit connected, when remote control and indoor unit are connected.

As long as they are used in a typical manner, there will be no need to change the initial settings.

If you would like to change the initial setting marked "○", set your desired setting as for the selected item.

The procedure of functional setting is shown as the following diagram.

## [Flow of function setting]

Start : Stop air-conditioner and press "○" (SET) and "MODE" buttons at the same time for over three seconds.

Finalize : Press "○" (SET) button.

Reset : Press "RESET" button.

Select : Press "▲" "▼" button.

End : Press "ON/OFF" button.

It is possible to finish above setting on the way, and unfinished change of setting is unavailable.

\* ○ : Initial settings

\* ※ : Automatic criterion

Record and keep the setting

Consult the technical data etc. for each control details

Stop air-conditioner and press "○" (SET) + "MODE" buttons at the same time for over three seconds.

FUNCTION SET ▼

To next page

FUNCTION ▼ (Remote control function)

Function	setting		
* 01   ESP SET	ESP VALID	○	Validate setting of ESP: External Static Pressure
	ESP INVALID		Invalidate setting of ESP
02   AUTO RUN SET	AUTO RUN ON	※	Automatic operation is impossible
	AUTO RUN OFF	※	
03   TEMP SW	TEMP VALID	○	Temperature setting button is not working
	TEMP INVALID		
04   MODE SW	MODE VALID	○	Mode button is not working
	MODE INVALID		
05   ON/OFF SW	ON/OFF VALID	○	On/Off button is not working
	ON/OFF INVALID		
06   FAN SPEED SW	FAN SPEED VALID	※	Fan speed button is not working
	FAN SPEED INVALID	※	
07   LOUVER SW	LOUVER VALID	※	Louver button is not working
	LOUVER INVALID	※	
08   TIMER SW	TIMER VALID	○	Timer button is not working
	TIMER INVALID		
* 09   SENSOR SET	SENSOR OFF	○	Remote thermistor is not working.
	SENSOR ON		Remote thermistor is working.
	SENSOR +3.0℃		Remote thermistor is working, and to be set for producing +3.0℃ increase in temperature.
	SENSOR +2.0℃		Remote thermistor is working, and to be set for producing +2.0℃ increase in temperature.
	SENSOR +1.0℃		Remote thermistor is working, and to be set for producing +1.0℃ increase in temperature.
	SENSOR -1.0℃		Remote thermistor is working, and to be set for producing -1.0℃ increase in temperature.
	SENSOR -2.0℃		Remote thermistor is working, and to be set for producing -2.0℃ increase in temperature.
	SENSOR -3.0℃		Remote thermistor is working, and to be set for producing -3.0℃ increase in temperature.
10   AUTO RESTART	INVALID	○	In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
	VALID		
	NO VENT LINK		
* 11   VENT LINK SET	NO VENT	○	In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), you can operate /stop the ventilation device independently by (VENT) button.
	VENT LINK		
	NO VENT LINK		
12   TEMP RANGE SET	INDIC CHANGE	○	If you change the range of set temperature, the indication of set temperature will vary following the control.
	NO INDIC CHANGE		If you change the range of set temperature, the indication of set temperature will not vary following the control, and keep the set temperature.
13   FAN	HI-MID-LO	※	Airflow of fan becomes of    or the four speed of    .
	HI-LO	※	
	HI-MID	※	
	1 FAN SPEED	※	
* 14   POSITION	POSITION STOP	○	If you change the remote control function "14 POSITION" you must change the indoor function "04 POSITION" accordingly.
	FREE STOP		
15   MODEL TYPE	HEAT PUMP	※	The louver can stop at any position.
	COOLING ONLY	※	
16   EXTERNAL CONTROL SET	INDIVIDUAL	○	If you input signal into CNT of the indoor printed circuit board from external, the indoor unit will be operated independently according to the input from external.
	FOR ALL UNITS		
17   ROOM TEMP INDICATION SET	INDICATION OFF	○	In normal working indication, indoor unit temperature is indicated instead of airflow. (Only the master remote control can be indicated.)
	INDICATION ON		
18   INDICATION	INDICATION ON	○	Heating preparation indication should not be indicated.
	INDICATION OFF		
19   SET	℃	○	Temperature indication is by degree C
	℉		Temperature indication is by degree F

Note (1)\*The mark cannot use SRK, SRF and SRR series.

ON/OFF button  
(finished)

To next page

Note 1: The initial setting marked "※" is decided by connected indoor and outdoor unit, and is automatically defined as following table.

Function No.	Item	Default	Model
Remote control function02	AUTO RUN SET	AUTO RUN ON	"Auto-RUN" mode selectable indoor unit.
		AUTO RUN OFF	Indoor unit without "Auto-RUN" mode
Remote control function06	FAN SPEED SW	2 SPEED VALID	Indoor unit with two or three step of air flow setting
		1 SPEED INVALID	Indoor unit with only one of air flow setting
Remote control function07	LOUVER SW	2 POSITION VALID	Indoor unit with automatically swing louver
		1 POSITION INVALID	Indoor unit without automatically swing louver
Remote control function13	I/U FAN	HI-MID-LO	Indoor unit with three step of air flow setting
		HI-LO	Indoor unit with two step of air flow setting
		HI-MID	
		1 FAN SPEED	Indoor unit with only one of air flow setting
Remote control function15	MODEL TYPE	HEAT PUMP	Heat pump unit
		COOLING ONLY	Exclusive cooling unit

Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit.

But only master indoor unit is received the setting change of indoor unit function "05 EXTERNAL INPUT" and "06 PERMISSION / PROHIBITION".

From previous page

Indoor unit No. are indicated only when  
(Indoor unit function) I/U FUNCTION ▲ plural indoor units are connected.

To set other indoor unit, press  
[AIRCON NO.] button, which  
allows you to go back to the indoor  
unit selection screen  
(for example: I/U 000 ▲).

Function	setting
*02 FAN SPEED SET	STANDARD ※ HIGH SPEED 1 ※ HIGH SPEED 2
*03 FILTER SIGN SET	INDICATION OFF TYPE 1 ○ TYPE 2 TYPE 3 TYPE 4
*04 POSITION	4 POSITION STOP ○ FREE STOP
*05 EXTERNAL INPUT	LEVEL INPUT ○ PULSE INPUT
*06 PERMISSION/PROHIBITION	INVALID ○ VALID
*07 EMERGENCY STOP	INVALID ○ VALID
*08 ※ SP OFFSET	OFFSET +3.0℃ OFFSET +2.0℃ OFFSET +1.0℃ NO OFFSET ○
*09 RETURN AIR TEMP	OFFSET +2.0℃ OFFSET +1.5℃ OFFSET +1.0℃ NO OFFSET ○ OFFSET -1.0℃ OFFSET -1.5℃ OFFSET -2.0℃
*10 ※ FAN CONTROL	LOW FAN SPEED ○ SET FAN SPEED INTERMITTENCE FAN OFF
*11 FROST PREVENTION TEMP	TEMP HIGH TEMP LOW ○
*12 FROST PREVENTION CONTROL	FAN CONTROL ON ○ FAN CONTROL OFF
*13 DRAIN PUMP LINK	○ AND ※ ○ AND ※ AND ※ ○ AND ※ AND ※ AND ※ ○ AND ※
*14 ※ FAN REMAINING	NO REMAINING ○ 0.5 HOUR 1 HOUR 6 HOUR
*15 ※ FAN REMAINING	NO REMAINING ○ 0.5 HOUR 2 HOUR 6 HOUR
*16 ※ FAN INTERMITTENCE	NO REMAINING ○ 2min OFF 5min ON 5min OFF 5min ON
*17 PRESSURE CONTROL	STANDARD ※ TYPE 1 ※

Note2: Fan setting of "HIGH SPEED"					
Fan tap		Indoor unit air flow setting			
FAN SPEED SET	STANDARD	UH - Hi - Me - Lo	Hi - Me - Lo	Hi - Lo	Hi - Me
	HIGH SPEED1, 2	UH - UH - Hi - Me	UH - Hi - Me	UH - Me	UH - Hi

Initial function setting of some indoor unit is "HIGH SPEED".

4 speed is not able to be set with wireless remote control.

The filter sign is indicated after running for 180 hours.  
The filter sign is indicated after running for 600 hours.  
The filter sign is indicated after running for 1000 hours.  
The filter sign is indicated after running for 1000 hours, then the indoor unit will be stopped by compulsion after 24 hours.

If you change the indoor function "04 POSITION",  
you must change the remote control function "14 POSITION" accordingly.  
You can select the louver stop position in the four.  
The louver can stop at any position.

Permission/prohibition control of operation will be valid.

With the VRF series, it is used to stop all indoor units connected with the same outdoor unit immediately.  
When stop signal is inputted from remote on-off terminal "CNT-6", all indoor units are stopped immediately.

To be reset for producing +3.0℃ increase in temperature during heating.  
To be reset for producing +2.0℃ increase in temperature during heating.  
To be reset for producing +1.0℃ increase in temperature during heating.

To be reset producing +2.0℃ increase in return air temperature of indoor unit.  
To be reset producing +1.5℃ increase in return air temperature of indoor unit.  
To be reset producing +1.0℃ increase in return air temperature of indoor unit.

To be reset producing -1.0℃ increase in return air temperature of indoor unit.  
To be reset producing -1.5℃ increase in return air temperature of indoor unit.  
To be reset producing -2.0℃ increase in return air temperature of indoor unit.

When heating thermostat is OFF, fan speed is low speed.  
When heating thermostat is OFF, fan speed is set speed.  
When heating thermostat is OFF, fan speed is operated intermittently.  
When heating thermostat is OFF, the fan is stopped.  
When the remote thermostat is working, "FAN OFF" is set automatically.  
Do not set "FAN OFF" when the indoor unit's thermostat is working.

Change of indoor heat exchanger temperature to start frost prevention control.

Working only with the Single split series.  
To control frost prevention, the indoor fan tap is raised.

Drain pump is run during cooling and dry.  
Drain pump is run during cooling, dry and heating.  
Drain pump is run during cooling, dry, heating and fan.  
Drain pump is run during cooling, dry and fan.

After cooling is stopped, the fan does not perform extra operation.  
After cooling is stopped, the fan perform extra operation for half an hour.  
After cooling is stopped, the fan perform extra operation for an hour.  
After cooling is stopped, the fan perform extra operation for six hours.

After heating is stopped or heating thermostat is OFF, the fan does not perform extra operation.  
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for half an hour.  
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for two hours.  
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for six hours.

During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after twenty minutes' OFF.  
During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after five minutes' OFF.

Connected "OA Processing" type indoor unit, and is automatically defined.


From previous page

# **How to set function**

1. Stop air-conditioner and press (SET) (MODE) buttons at the same time for over three seconds, and the "FUNCTION SET ▼" will be displayed.




2. Press (SET) button.
3. Make sure which do you want to set, "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).
4. Press or button.  
Select "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).




5. Press (SET) button.

## **6. 【On the occasion of remote control function selection】**


- ① "DATA LOADING" (Indication with blinking)  
↓  
Display is changed to "01 ESP SET".
- ② Press or button.  
"No. and function" are indicated by turns on the remote control function table, then you can select from them.  
(For example)



- ③ Press (SET) button.  
The current setting of selected function is indicated.  
(for example) "AUTO RUN ON" ← If "02 AUTO RUN SET" is selected




- ④ Press or button.  
Select the setting.



- ⑤ Press (SET)  
"SET COMPLETE" will be indicated, and the setting will be completed.  
Then after "No. and function" indication returns, Set as the same procedure if you want to set continuously, and if to finish, go to 7.



7. Press (ON/OFF) button.  
Setting is finished.




## **【On the occasion of indoor unit function selection】**

- ① "DATA LOADING" (Blinking for 2 to 23 seconds to read the data)  
↓  
Indication is changed to "02 FAN SPEED SET".  
Go to ②.

### **[Note]**


- (1) If plural indoor units are connected to a remote control, the indication is "I/U 000" (blinking) ← The lowest number of the indoor unit connected is indicated.



- (2) Press or button.  
Select the number of the indoor unit you are to set  
If you select "ALL UNIT ▼", you can set the same setting with all units.

- (3) Press (SET) button.

- ② Press or button.  
"No. and function" are indicated by turns on the indoor unit function table, then you can select from them.  
(For example)



- ③ Press (SET) button.  
The current setting of selected function is indicated.  
(For example) "STANDARD" ← If "02 FAN SPEED SET" is selected.



- ④ Press or button.  
Select the setting.

- ⑤ Press (SET) button.  
"SET COMPLETE" will be indicated, and the setting will be completed.  
Then after "No. and function" indication returns, set as the same procedure if you want to set continuously, and if to finish, go to 7.




※ When plural indoor units are connected to a remote control, press the (AIRCON NO.) button, which allows you to go back to the indoor unit selection screen. (example "I/U 000 ▲")

- It is possible to finish by pressing (ON/OFF) button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.
- Setting is memorized in the control and it is saved independently of power failure.


## **【How to check the current setting】**

When you select from "No. and function" and press set button by the previous operation, the "Setting" displayed first is the current setting.  
(But, if you select "ALL UNIT ▼", the setting of the lowest number indoor unit is displayed.)

(2) Model RC-EX1A

PJZ012D077 

# eco touch REMOTE CONTROL RC-EX1A INSTALLATION MANUAL





# 1 . Safety precautions

This installation manual describes the installation methods and precautions related to the remote control. Use this manual together with the user's manuals for the indoor unit, outdoor unit and other option equipment. Please read this manual carefully before starting the installation work to install the unit properly.

## Safety precautions

- Please read this manual carefully before starting installation work to install the unit properly. Every one of the followings is important information to be observed strictly.

 <b>WARNING</b>	Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc..
 <b>CAUTION</b>	Failure to follow these instructions properly may cause injury or property damage.

It could have serious consequences depending on the circumstances.

- The following pictograms are used in the text.

	Never do.		Always follow the instructions given.
---	-----------	---	---------------------------------------

- Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, the "Installation Manual" should be given to a new owner.

## WARNING

**Ask a professional contractor to carry out installation work according to the installation manual.**  
Improper installation work may result in electric shocks, fire or break-down.



**Shut OFF the main power source before starting electrical work.**  
Otherwise, it could result in electric shocks, break-down or malfunction.



**Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.**

If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.



**Do not install the unit where water vapor is generated excessively or condensation occurs.**  
It could cause electric shocks, fire or break-down.



**Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.**

Improper connections or fixing could cause heat generation, fire, etc.



**Seal the inlet hole for remote control cable with putty.**

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.



---

**When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.**

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.

The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.



---

** CAUTION****Do not install the remote control at following places.**

It could cause break-down or deformation of remote control.

- (1) Where it is exposed to direct sunlight
- (2) Near the equipment to generate heat
- (3) Where the surface is not flat



---

**Do not leave the remote control with its upper case removed.**

When the upper case is removed, put it in a packing box or packing bag to protect internal PCBs or other parts from dust, moisture, etc.



## 2 . Accessories & prepare on site

Accessories	R/C main unit, wood screw (ø3.5 x 16) 2 pcs User's Manual, Installation Manual
-------------	---

Parts procured at site

Item name	Q'ty	Remark
Switch box For 1 piece or 2 pieces (JIS C 8340 or equivalent)	1	These are not required when installing directly on a wall.
Thin wall steel pipe for electric appliance (JIS C 8305 or equivalent)	As required	
Lock nut, bushing (JIS C 8330 or equivalent)	As required	
Lacing (JIS C 8425 or equivalent)	As required	Necessary to run R/C cable on the wall.
Putty	Suitably	For sealing gaps
Molly anchor	As required	
R/C cable (0.3 mm <sup>2</sup> x 2 pcs)	As required	See right table when longer than 100 m

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm<sup>2</sup>. Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

< 200 m	0.5 mm <sup>2</sup> x 2-core
< 300 m	0.75 mm <sup>2</sup> x 2-core
< 400 m	1.25 mm <sup>2</sup> x 2-core
< 600 m	2.0 mm <sup>2</sup> x 2-core


## 3. Remote control installation procedure

### Determine where to install the remote control

Installation	"Using a switch box"
	"Installed directly on a wall"
Wiring direction	"Backward"
	"Upper center", "Upper left"

### Cautions for selecting installation place

- (1) Installation surface must be flat and sufficiently strong.  
R/C case must not be deformed.
- (2) Where the R/C can detect room temperatures accurately.  
This is a must when detecting room temperatures with the temperature sensor of R/C.
  - Install the R/C where it can detect the average temperature in the room.
  - Install the R/C separated from a heat source sufficiently.
  - Install the R/C where it will not be influenced by the turbulence of air when the door is opened or closed.
 Select a place where the R/C is not exposed to direct sunlight or blown by winds from the air-conditioner or temperatures on the wall surface will not deviate largely from actual room temperature.



**Request**

Be sure not to install R/C at a place where temperatures around the installation surface of R/C may differ largely from actual room temperature.

Difference between detected temperature and actual room temperature could cause troubles.

The correction for detected temperature by the R/C cannot offset such temperature difference because it corrects the detected temperatures itself.

**Request**


Do not install the R/C at a place where it is exposed to direct sunlight or where surrounding air temperature exceeds 40°C or drops below 0°C.

It could cause discoloration, deformation, malfunction or breakdown.




## Installation procedure

Dimensions (Viewed from front)



PCB side (Viewed from rear)



- ① To remove the upper case from the bottom cases of R/C
  - Insert the tip of flat head screwdriver or the like in the recess at the lower part of R/C and twist it lightly to remove.

Take care to protect the removed upper case from moisture or dust.




- ② Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit.  
R/C wires (X, Y) have no polarity.

In case of embedding wiring (When the wiring is retrieved "Backward")



- ③ Embed the switch box and the R/C wires beforehand.

**Seal the inlet hole for the R/C wiring with putty.**

● If dust or insect enters, it could cause electric shocks, fire or breakdown.



- ④ When wires are passed through the bottom case, fix the bottom case at 2 places on the switch box.





- ⑤ When fixing the bottom case diagonally at 2 places, cut out the thin wall section on the case.  
 ⑥ Fix wires such that the wires will run around the terminal screws on the top case of R/C.

#### Cautions for wire connection

Use wires of no larger than 0.5 mm<sup>2</sup> for wiring running through the remote control case. Take care not to pinch the sheath.


Tighten by hand (0.7 N·m or less) the wire connection. If the wire is connected using an electric driver, it may cause failure or deformation.



- ⑦ Install the upper case with care not to pinch wires of R/C.


In case of exposing wiring (When the wiring is taken out from the “upper center” or “upper left” of R/C)

- ③ Cut out the thin wall sections on the cases for the size of wire.



When taking the wiring out from the upper center, open a hole before separating the upper and bottom cases. This will reduce risk of damaging the PCB and facilitate subsequent work.

When taking the wiring out from the upper left, take care not to damage the PCB and not to leave any chips of cut thin wall inside.




If the hole is cut too large, moisture, dust or insects may enter.

Seal gaps with putty or the like.



- ④ Fix the bottom R/C case on a flat surface with wood screws.
- ⑤ In case of the upper center, pass the wiring behind the bottom case. (Hatched section)
- ⑥ Fix wires such that the wires will run around the terminal screw of the case of R/C.
- ⑦ Install the top case with care not to pinch wires of R/C.




## Main/Sub setting when more than one remote control are used

### Main-Sub setting for use of two or more R/C

Up to two units of R/C can be used at the maximum for 1 indoor unit or 1 group.


One is main R/C and the other is sub R/C.

Operating range is different depending on the main or sub R/C.



Set the "Main" and "Sub" as described at Section 7 of installation manual attached to the remote control.

R/C function	Main	Sub
Run/Stop, setting temperature, fan speed and flap direction operations	<input type="radio"/>	<input type="radio"/>
High power and energy-saving operations	<input type="radio"/>	<input type="radio"/>
Energy-saving setting	<input type="radio"/>	—
R/C sensor	<input type="radio"/>	—
Test run menu operation	<input type="radio"/>	—
Room temperature range setting	<input type="radio"/>	—
Indoor unit settings	<input type="radio"/>	—
Individual flap control	<input type="radio"/>	—
Operation data display	<input type="radio"/>	—
Error history display	<input type="radio"/>	<input type="radio"/>



**Note: Connection to personal computer**

It can be set from a personal computer via the USB port (mini-B).  
Connect after removing the cover for USB port of upper case.

**Replace the cover after use.**

If dust, insect, etc. enters, it could cause electric shocks or breakdown.




Special software is necessary for the connection.

For details, view the web site or refer to the engineering data.

**Do not connect to a personal computer without using the special software.**


Do not connect the personal computer to the USB simultaneously with other USB devices.

It could cause malfunction or breakdown of R/C or personal computer.

**Note: Initializing of password**

Administrator password (for daily setting items) and service password (for installation, test run and maintenance) are used.

- The administrator password at factory default is "0000". This setting can be changed (Refer to User's Manual). When the administrator password is forgotten, it can be initialized, if the [Highpower] and the [Energy-saving] buttons are pushed simultaneously for 5 seconds on the administrator password input screen.
- Service password is "9999", which cannot be changed.  
When the administrator password is input, the service password is also accepted.



## 12.2 Wireless kit

### (1) FDTC series (RCN-TC-24W-ER)

#### Notes :

Following functions of FDTC Type-F indoor unit series are not able to be set with this wireless remote control (RCN-TC-24W-ER).

1. Individual flap control system
2. 4-fan speed setting (PHI/Hi/Me/Lo) → 3-fan speed setting (Hi/Me/Lo)

PJA012D758

#### WARNING

- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.  
Loose connection or hold will cause abnormal heat generation or fire.
- Make sure the power source is turned off when electric wiring work.  
Otherwise, electric shock, malfunction and improper running may occur.

#### CAUTION







- DO NOT install the wireless kit at the following places in order to avoid malfunction.
  - (1) Places exposed to direct sunlight
  - (2) Places near heat devices
  - (3) High humidity places
  - (4) Hot surface or cold surface enough to generate condensation
  - (5) Places exposed to oil mist or steam directly
  - (6) Uneven surface
  - (7) Places affected by the direct airflow of the AC unit.
  - (8) Places where the receiver is influenced by the fluorescent lamp (especially inverter type) or sunlight.
  - (9) Places where the receiver is affected by infrared rays of any other communication devices
  - (10) Places where some object may obstruct the communication with the remote control
- DO NOT leave the wireless kit without the cover.  
In case the cover needs to be detached, protect the receiver with a packaging box or bag in order to keep it away from water and dust.

#### Note

- Instruct the customer how to operate it correctly referring to the instruction manual.
- For the installation method of the air-conditioner itself, refer to the installation manual enclosed in the package.

### ① Accessories

Please make sure that you have all of the following accessories.


Receiver		1	Remote control holder		1
Wireless remote control		1	Wood screw for holder		2
Parts set		1	AAA dry cell battery (RO3)		2

### ② How to install the receiver

The receiver can be installed by replacing with a corner panel on the applicable decorative panel.

#### Preparation before installation

- ① Attach the decorative panel onto the air-conditioner according to the installation manual for the panel.
- ② Remove the air return grille.
- ③ Remove a corner panel located on the refrigerant pipes side.
- ④ Remove two screws and detach the lid from the control box of the air-conditioner.




#### Setting on site

- ① PCB on the receiver has the following switches to set the functions. Default setting is shown with ☐ mark.

SW 1	Customized signal setting to avoid mixed communication	ON : Normal OFF : Remote
SW 2	Receiver master/slave setting	ON : Master OFF : Slave
SW 3	Buzzer valid/invalid	ON : Valid OFF : Invalid
SW 4	Auto restart	ON : Valid OFF : Invalid

#### <To change the settings>

- ② Remove the cover by unscrewing two screws from the back of receiver.
- ③ Change the setting by the switch on PCB.



- ④ When SW1 is turned to OFF position, change the corresponding remote control setting as follows:

#### How to change the remote control setting


Pressing [ACL] switch with [AIR FLOW] button kept pressing or inserting the batteries with pressing [AIR FLOW] button will customize the signal.

#### Note

- ※ When the batteries are removed, the setting will return to the default setting.  
Please make sure to reset it when the batteries are replaced.

#### Caution

Instruct the customer to set the mentioned above when replacing the batteries.  
(How to set is also mentioned in the user's manual attached on the air-conditioner.)





Radio interference prevention mode

#### Installation of the receiver

- ① Attach the receiver to the panel according to the panel installation manual.
- ② Remove two screws and detach the lid from the control box.
- ③ Put the wiring in the control box with other wiring as shown below.
- ④ Connect the wiring to the terminal block (X,Y) provided in the control box. (Non-polarized)
- ⑤ Fix the wiring with the clamp as shown below.
- ⑥ Reattach the control box lid with 2 screws removed.

- ※ Note: Make sure wires not to be pinched by any other parts like panel and control box.




### ③ Remote control

#### Installation of the control holder

##### Caution

- DO NOT install it on the following places
1. Places exposed to direct sunlight
  2. Places near heat devices
  3. High humidity places
  4. Hot surface or cold surface enough to generate condensation
  5. Places exposed to oil mist or steam directly.
  6. Uneven surface




#### Installation tips for the remote control holder

- Adjust and keep the holder upright.
- Tighten the screw to the end to avoid scratching the remote control.
- DO NOT attach the holder on plaster wall.

#### How to insert batteries

- ① Detach the back lid.
- ② Insert the batteries. (two AAA batteries)
- ③ Reattach the back lid.




#### Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

- ① Connect the XY terminal with 2-core wire. As for the size, refer to the following note.
- ② For Single packaged air-conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximum total extension 600m.)	
Standard	Within 100m x 0.3 mm <sup>2</sup>
	Within 200m x 0.5 mm <sup>2</sup>
	Within 300m x 0.75mm <sup>2</sup>
	Within 400m x 1.25mm <sup>2</sup>
	Within 600m x 2.0 mm <sup>2</sup>



- ③ For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.

#### Master/Slave setting when using plural remote controls


Up to two receivers can be installed in one indoor unit group. When two receivers are used, it is necessary for a receiver to turn OFF SW2 on the receiver PCB to set it as slave.

(For the method of switching, please see **Setting on site** in the section of

- ② **How to install the receiver** in this manual.)


#### Wireless remote control's operable area

- ① Standard reachable area of the signal  
[condition] Illuminance at the receiver: 300lux  
(when no lighting is installed within 1m of the receiver in an ordinary office.)



- ② Correlation between illuminance at the receiver and reachable area of the signal in a plain view.

The drawing in the right shows the correlation between the reachable area of the signal and illuminance at the receiver when the remote control is operated at 1m high under the condition of ceiling height of 2.4m.



- ③ Installation tips when several receivers are installed close  
Minimum distance between the indoor units which can avoid cross communication is 5m under the condition of 300lux of illuminance at the receiver.  
(When no lighting is installed within 1m of the receiver in an ordinary office )

#### ④ How to disable the Auto mode operation

VRF series (except heat recovery 3-pipe systems) cannot be operated in Auto mode.  
Make sure to set the remote control for the models so as not to be able to choose Auto mode.


Pressing **[ACL]** switch with **[MODE]** button kept pressing or inserting the batteries with pressing **[MODE]** button will make auto mode operation.

##### Note

※ When the batteries are removed, the setting will return to the default setting (Auto mode is valid).

##### Caution


Instruct the customer to set the mentioned above when replacing the batteries. (How to set is also mentioned in the user's manual attached on the air-conditioner.)



#### ⑤ Backup button

A Backup button is provided on the receiver. Even when the operation from the wireless remote control is not possible (due to flat batteries, control lost, or control failure), still it possible to operate as temporary means. Press the button directly when operating it.

- (1) The air-conditioner starts the operation with the condition of Auto mode, 23°C of set point, High fan speed and horizontal louver position.
- (2) The air-conditioner stops the operation when the button is pressed when in operation.



#### ⑥ Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with wireless remote control, while the backup button on the receiver is pressed.
- If the backup button on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check by consulting with inspection guides on the wiring diagram of outdoor units.

#### ⑦ How to read the two-digit display

On the receiver of a wireless kit, a two-digit (7-segment) display is provided.

- (1) An indication will be displayed for one hour after power on.
- (2) An indication will be displayed for 3.5 seconds after transmitting a "STOP" command from the wireless remote control or the operation of the backup button to stop the unit.
- (3) An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
- (4) When there are no error records to indicate, addresses of all the connected units are displayed.
- (5) When there are some error records remaining, the error records are displayed.
- (6) Error records can be cleared by transmitting a "STOP" command from the wireless remote control, while the backup button is pressed.

**(2) FDEN series (RCN-E1R)**



PFA012D620

**Notes:**

Following functions of FDEN Type -F indoor unit series are not able to be set with this wireless remote control (RCN-E1R).

1. Flap control system
2. 4-fan speed setting (PHi/Hi/Me/Lo) → 3-fan speed setting (Hi/Me/Lo)

**⚠ WARNING**





- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connection or hold will cause abnormal heat generation or fire. 
- Make sure the power source is turned off when electric wiring work. Otherwise, electric shock, malfunction and improper running may occur. 

**⚠ CAUTION**

- Install a receiver unit where it is not exposed to direct sunrays or intense light from lighting fixtures. 

**① Accessories**

Please make sure that you have all of the following accessories.

Remoto control holder	AAA dry cell battery (RO3)	Wood screw for holder	Wireless remote control
			
1	2	2	1

**② Installation of the control holder****⚠ CAUTION DO NOT install it on the following places.**



1. Places exposed to direct sunlight
2. Hot surface or cold surface enough to generate condensation
3. Places near heat devices
4. Places exposed to oil mist or steam directly.
5. High humidity places
6. Uneven surface

**Installation tips for the remote control holder**

- Adjust and keep the holder up right.
- Tighten the screw to the end to avoid scratching the remote control.
- DO NOT attach the holder on plaster wall.

**How to insert batteries**

- ① Detach the back lid.
- ② Insert the batteries. (two AAA batteries)
- ③ Reattach the back lid.



### ③ FDEN

#### Setting on site


PCB on the receiver has the following switches to set the function.

Default setting is shown with ☐ mark.

SW1	Prevents interference during plural setting	<input type="checkbox"/> ON : Normal (1ch) <input type="checkbox"/> OFF : Customized (2ch)
SW2	Receiver master/slave setting	<input type="checkbox"/> ON : Master <input type="checkbox"/> OFF : Slave
SW3	Buzzer valid/Invalid	<input type="checkbox"/> ON : Valid <input type="checkbox"/> OFF : Invalid
SW4	Auto restart	<input type="checkbox"/> ON : Valid <input type="checkbox"/> OFF : Invalid

#### To change setting

1. Remove the front panel.
2. Remove four screws located on the back of the receiver and detach the board.
3. Change the setting by the switch on PCB.



4. When switch 1 is turned to off position, change the wireless remote control setting.  
(For the method of changing the setting, refer to **Setting to avoid mixed communication** on page 403)

Refer to **Wireless remote control unit operation distance** of **⑤ FDEN** in case of plural setting.

#### Master/Slave setting when using plural remote controls

Up to two receiver or wired remote control can be installed in one indoor unit group.


When two receivers or wired remote control are used, it is necessary to change SW on the PCB to set it as slave.

#### Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

- ① Connect indoor units with each other with 2-core wires. As for size, refer to the following note.
- ② The receiver wires must be connected only with the indoor unit that will be operated by the remote control directly.
- ③ Set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximum total extension 600m.)	
Standard	Within 100m x 0.3 mm <sup>2</sup> Within 200m x 0.5 mm <sup>2</sup> Within 300m x 0.75 mm <sup>2</sup> Within 400m x 1.25 mm <sup>2</sup> Within 600m x 2.0 mm <sup>2</sup>



#### ※ATTENTION

In a system configured as shown above, up to two receivers are usable. If two receivers are used, it is necessary to designate one of them as a slave by setting SW2. (For the method of changing the setting, refer to **Setting on site**.) Since other receivers are not usable, do not couple the connectors for them. (Unless the connector is coupled for a receiver, the LED will not be able to make any indication)

### ③ FDEN (continued)



#### Wireless remote control unit operation distance

##### ① Standard signal receiving range

###### [Condition]

Illuminance at the receiver area: 360 lux.

(When no lighting fixture is located within 1m of indoor unit in an ordinary office)




##### ② Points for attention in connecting a plural number of indoor units

###### [Condition]

Illuminance at the receiver area: 360 lux.

(When no lighting fixture is located within 1m of indoor unit in an ordinary office)

When the remote control unit is used with the aforementioned interference-prevention setting, a minimum distance guaranteeing the prevention of unintended unit responses is 5m.



- Please operate remote control unit switches with the unit faced correctly toward the indoor unit's receiver section.
- Effective operation distance can vary with the luminance around the receiver and the reflection from walls of the room.
- When the receiver is exposed to intensive light such as from the direct sun or a strong light, it may become operable only from a short distance or unable to receive signals at all.

#### Backup button


A backup switch is provided on the receiver section of the panel surface.

When operation from the wireless remote control unit is not possible (due to flat batteries, a mislaid unit, a unit failure), you can use it as an emergency means. You should operate this switch manually.

- (1) If pressed while the air-conditioner is in a halt, it will cause the air-conditioner to start operation in the automatic mode.

Wind speed: Hi fan, Temperature setting: 23°C, Louver: horizontal

- (2) If pressed while the air-conditioner is in operation, it will stop the air-conditioner.



#### Cooling test run operation

- After safety confirmation, turn on the power.
  - Transmit a cooling operation command with the wireless remote control unit, while the backup switch on the receiver is depressed.
  - If the backup switch on the receiver is pressed during a test run, it will end the test run.
- ※ If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

### ③ FDEN (continued)

#### How to read the two-digit display

A two-digit indicator (7-segment indicator) is provided on the receiver section.

- (1) An indication will be displayed for one hour after power on.
- (2) An indication appears for 3.5 seconds when a "Stop" command is sent from the wireless remote control unit while the air-conditioner is not running.
- (3) An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
- (4) When there are no error records to indicate, addresses are displayed for all of the connected units.
- (5) When there are some error records remaining, the error records are displayed.
- (6) Error records can be cleared by transmitting a "Stop" command from the wireless remote control unit, while the backup switch is depressed.

### ④ Remote control

#### Setting to avoid mixed communication

Pressing **ACL** and **AIR FLOW** button at the same time or inserting the batteries with pressing **AIR FLOW** button will customize the signal.


#### Setting to disable the Auto mode operation

VRF system (except heat recovery 3-pipe system) cannot be operated in Auto mode.

Make sure to set the remote control for the models so as not to be able to choose Auto mode.

Pushing **ACL** and **MODE** button at the same time or inserting the batteries with pressing **MODE** button will make auto mode operation.

Radio prevention mode



Auto mode operation setting

#### ※ATTENTION

When the batteries are removed, the setting will return to the default setting.  
Please make sure to reset it when the batteries are replaced.

#### ⚠ Caution

Instruct the customer to set the mentioned above when replacing the batteries.  
(How to set is also mentioned in the user's manual attached on the air-conditioner.)

### (3) FDUM series (RCN-KIT3-E)

#### Notes:

Following functions of FDUM indoor unit series are not able to be set with this wireless remote control (RCN-KIT3-E).

1. 4-fan speed setting (PHI/Hi/Me/Lo) → 3-fan speed setting (Hi/Me/Lo)

Read this manual together with the installation manual attached to the air-conditioner.

PJZ012D060A

#### ⚠ WARNING

- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connection or hold will cause abnormal heat generation or fire.
- Make sure the power source is turned off when electric wiring work. Otherwise, electric shock, malfunction and improper running may occur.

#### ⚠ CAUTION

- DO NOT install the wireless kit at the following places in order to avoid malfunction.
 

(1) Places exposed to direct sunlight	(8) Places where the receiver is influenced by the fluorescent lamp (especially inverter type) or sunlight.
(2) Places near heat devices	(9) Places where the receiver is affected by infrared rays of any other communication devices.
(3) High humidity places	(10) Places where some object may obstruct the communication with the remote control
(4) Hot surface or cold surface enough to generate condensation	
(5) Places exposed to oil mist or steam directly	
(6) Uneven surface	
(7) Places affected by the direct airflow of the AC unit.	
- DO NOT leave the wireless kit without the cover. In case the cover needs to be detached, protect the receiver with a packaging box or bag in order to keep it away from water and dust.

#### Attention

- Instruct the customer how to operate it correctly referring to the instruction manual.
- User's manual of a wireless remote control is attached to a indoor unit or a outside unit.
- Read this together with a manual attached to this kit.

### ① Accessories

Please make sure that you have all of the following accessories.


① Receiver	1	① Remote control holder	1
② Wiring (3m)	1	② Screw for holder	2
③ Parts set (A)	1	③ AAA dry cell battery (R03)	2
④ Parts set (B)	1	① Screw for receiver	2
⑤ Parts set (C)	1	② Fixing band	1
⑥ Wireless remote control	1	③ Clamp	5
⑦ User's manual	1	④ Screw for clamp	5
		① Receiver installation bracket	1
		② Screw for the bracket	2
		③ Installation fitting	2

### ② Wireless remote control's operable area

#### (1) When installed on ceiling


- ① Standard reachable area of the signal

**Condition** Illuminance at the receiver : 300lux (when no lighting is installed within 1m of the receiver in an ordinary office.)




- ② Correlation between illuminance at the receiver and reachable area of the signal in a plain view.

**Condition** Correlation between the reachable area of the signal and illuminance at the receiver when the remote control is operated at 1m high under the condition of ceiling height of 2.4m. When the illuminance becomes double, the area is narrowed down to two third.



#### (2) When installed on wall

**Condition** Illuminance at the receiver : 800lux.



### ③ How to install the receiver

The following two methods can be used to install the receiver onto a ceiling or a wall. Select a method according to the installation position.

#### <Installation position>

- (A) Direct installation onto the ceiling with wood screws.
- (B) Installation with accessory's bracket

#### (1) Drilling of the ceiling (ceiling opening)


Drill the receiver installation holes with the following dimensions at the ceiling position where wires can be connected.

(A) Direct installation onto the ceiling with wood screws.	88mm(H)×101mm(W)
(B) Installation with enclosed bracket	108mm(H)×108mm(W)

#### (2) Wiring connection of receiver

##### Caution

Do not connect the wiring to the power source of the terminal block. If it is connected, printed board will be damaged.




#### (3) Installation of the receiver

Remove the screw on the side of the receiver and split it into the upper case and lower case. Install the receiver with one of the two installation methods (A) to (C) shown below.

#### (A) Direct installation onto the ceiling with screws


► Use this installation method when the ceiling is wooden, and there is no problem for strength in installing directly with wood screws.



- ① Put through the wiring from the back side to the hole of the lower case.
- ② Fit the lower case into the ceiling opening. Make sure that the clearance between the convex part of the back of the lower case and the ceiling opening must be as equal as possible on both sides.
- ③ Using the two installation holes shown above, fix the lower case onto the ceiling with the enclosed wood screws. (The other four holes are not used.)
- ④ Connect the wiring with the wiring from the upper case by the connector.
- ⑤ Take out the connector to the backside from the hole of the lower case putting through the wiring at 1.
- ⑥ Fit the upper case and the lower case, and tighten the screws.

#### (B) Installation with enclosed bracket


Use this method when installing onto a gypsum board (7 to 18mm), etc.



- ① Catch the two protrusion of the enclosed bracket onto the fitting as shown above, and temporarily fix with the screws. (The bracket has an Upper/Lower and front/back orientation. Confirm the Upper/Lower protrusion positions and the positional relation of the ø 10 holes on the bracket and the installation hole on the lower case with the above drawing.)
- ② Insert the end of the installation fitting into the back of the ceiling from the opening, and tighten the screws to fix the bracket onto the ceiling.
- ③ Pass the wiring from the rear side through the hole on the lower case.
- ④ Fit the lower case onto the bracket, and fix the lower case to the bracket using the two installation holes shown above. (The other four holes are not used.)
- ⑤ Follow step 1 to 6 for (A) to complete the installation.

### (C) Exposed installation

Use the following procedure when installing the case with the wiring exposed.



- 1 Cut off the thin section on the side of the upper case with a pair of nippers or a knife, and remove the burrs with a file, etc. (The wiring is passed through this section.)
- 2 Pass the enclosed band through the wiring outlet hole on the lower case.
- 3 Use one of the light detection adaptor installation methods (A) or (B) explained in section 3, and fix the lower case onto the wall. Do not pass the wiring through the hole on the lower case.
- 4 Fix the wiring using the band while leaving the wiring length from the band fixing section to the end of the wiring connector at 100mm or more.
- 5 Connect the wiring with the wiring protruding from the upper case using a connector.
- 6 Pass the connected connector and the excess wiring through the hole on the lower case.
- 7 Fit the upper case onto the lower case, and tighten the screws.
- 8 Adequately fix the wiring with the enclosed cord clamp.

### ④ Remote control

#### Installation of the control holder

##### Caution

**DO NOT install it on the following places**



- 1) Places exposed to direct sunlight
- 2) Places near heat devices
- 3) High humidity places
- 4) Hot surface or cold surface enough to generate condensation
- 5) Places exposed to oil mist or steam directly
- 6) Uneven surface

#### Installation tips for the remote control holder

- Adjust and keep the holder upright.
- Tighten the screw to the end to avoid scratching the remote control.
- DO NOT attach the holder to plaster wall.


#### How to insert batteries

- 1 Detach the back lid.
- 2 Insert the batteries. (two AAA batteries)
- 3 Reattach the back lid.



### ⑤ Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with wireless remote control, while the backup button on the receiver is pressed.
- If the backup button on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check by consulting with inspection guides on the wiring diagram of outdoor units.



### ⑥ Setting of wireless remote control and receiver

#### (A) Methods of avoiding the malfunction due to the mixed communication

Do both procedures ① and ②.

This setting is to avoid the mixed communication with other household electric appliances or the mixed communication when two receivers are located closely.

##### ① Setting change of the wireless remote control


Pressing **ACL** and **AIRFLOW** button at the same time or inserting the batteries with pressing **AIRFLOW** button will customize the signal.

**Note** \*When the batteries are removed, the setting will return to the default setting. Make sure to reset it when the batteries are replaced.


##### ② Setting the PCB of the receiver

Turn SW1-1 off.

#### ● Wireless remote control



#### ● PCB of the receiver



- SW1-1 (Customized signal setting to avoid mixed communication)
- SW1-2 (Receiver master/slave setting)
- SW1-4 (Auto restart)

SW1-1	Customized signal setting to avoid mixed communication	ON : Normal OFF : Remote
SW1-2	Receiver master/slave setting	ON : Master OFF : Slave
SW1-4	Auto restart	ON : Valid OFF : Invalid

□ : Default setting

#### (B) Control plural indoor units with one remote control


Up to 16 indoor units can be connected.

① Connect the XY terminal with 2-core wire.

As for the size, refer to the following note.

② For Packaged air-conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.


Restrictions on the thickness and length of wire (Maximum total extension 600m.)	
Standard	Within 100m x 0.3 mm <sup>2</sup> Within 200m x 0.5 mm <sup>2</sup> Within 300m x 0.75mm <sup>2</sup> Within 400m x 1.25mm <sup>2</sup> Within 600m x 2.0 mm <sup>2</sup>



③ For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.

#### (C) Master/Slave setting when using plural remote control

Up to two receivers can be installed in one indoor unit group.



Switch	Setting	Function
SW1-2	ON	Master
	OFF	Slave


## 12.3 Simple wired remote control (RCH-E3)

### Notes:

Following functions of Type-F indoor unit series are not able to be set with this simple wired remote control (RCH-E3).

1. Individual flap control system (for FDTG)
2. Flap control system (for FDEN)
3. 4-fan speed setting (PHi/Hi/Me/Lo) → 3-fan speed setting (Hi/Me/Lo) (for FDTG/FDEN/FDUM)

### Names and functions of sections




### Installation of remote control

DO NOT install the remote control at the following places in order to avoid malfunction.

- (1) Places exposed to direct sunlight
- (2) Places near heat devices
- (3) High humidity places
- (4) Hot surface or cold surface enough to generate condensation
- (5) Places exposed to oil mist or steam directly
- (6) Uneven surface


PJZ000Z272

## Remote control installation dimensions




Note: Installation screw for remote control  
M4 Screw (2 pieces)


## In case of embedding wiring



## In case of exposing wiring




The remote control wiring can be extracted from the upper center.  
After the thin part in the upper side of the remote control upper case is scraped with a nipper or knife, remove burr with a file.



The peeling length of each wiring is as follows:

X wiring : 160mm  
Y wiring : 150mm



## Wiring specifications

- (1) Wiring of remote control should use 0.3mm² × 2 core wires or cables. (on-site configuration)
- (2) Maximum prolongation of remote control wiring is 600m.  
If the prolongation is over 100m, change to the size below.  
But, the wiring in the remote control case should be 0.3mm² (recommended) to 0.5mm².  
Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Length	Wiring thickness
100 to 200m	0.5mm² × 2 cores
Under 300m	0.75mm² × 2 cores
Under 400m	1.25mm² × 2 cores
Under 600m	2.0mm² × 2 cores

Unit:mm

Adapted to **RoHS** directive

# Simple Remote Control Installation Manual

PJZ012D069

Read together with indoor unit's installation manual.

## WARNING

- **Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.**



Loose connection or hold will cause abnormal heat generation or fire.

- **Make sure the power source is turned off when electric wiring work.**



Otherwise, electric shock, malfunction and improper running may occur.

## CAUTION

- **DO NOT install the remote control at the following places in order to avoid malfunction.**

- |                                       |   |
|---------------------------------------|---|
| (1) Places exposed to direct sunlight | (4) Hot surface or cold surface enough to generate condensation |
| (2) Places near heat devices          | (5) Places exposed to oil mist or steam directly                |
| (3) High humidity places              | (6) Uneven surface  |



- **DO NOT leave the remote control without the upper case.**

In case the upper case needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust.




Accessories	Remote control, wood screw (φ 3.5× 16) 2 pieces
Prepare on site	Remote control cord (2 cores) (Refer to [2. Installation and wiring of remote control]) [In case of embedding cord] Electrical box, M4 screw (2 pieces) [In case of exposing cord] Cord clamp (if needed)


## 1. Installation procedure

### In case of embedding cord


- (1) **Make certain to remove** the screw on the bottom surface of the remote control.




- (2) Remove the upper case of the remote control.  
Insert a flat-blade screwdriver to a concave portion of the bottom surface of the remote control and slightly twist it, and the case is removed.



- (3) Pre-bury the electrical box and remote control cord.



- (4) Prepare two M4 screws (recommended length: 12 – 16mm), and install the lower case to the electrical box. Do not use a screw whose screw head is larger than the height of the wall around the screw hole.




- (5) Connect the remote control cord to the terminal block.  
Connect the terminals (X and Y) of the remote control and the terminals (X and Y) of the indoor unit. (No polarity of X and Y)


- (6) Mount the upper case for restoring to its former state so as not to crimp the remote control cord, and secure with the removed screw.

### In case of exposing cord

- (1) **Make certain to remove** a screw on the bottom surface of the remote control.




- (2) Remove the upper case of the remote control.  
Insert a flat-blade screwdriver to a concave portion of the bottom surface of the remote control and slightly twist it, and the case is removed.




- (3) The remote control cord can be extracted from the upper center.


After the thin part in the upper side of the remote control upper case is scraped with a nipper or knife, remove burr with a file.



- (4) The lower case of the remote control is mounted to a flat wall with two accessory wood screws.



- (5) Connect the remote control cord to the terminal block.  
Connect the terminals (X and Y) of the remote control and the terminals (X and Y) of the indoor unit. (No polarity of X and Y)  
The wiring route is as shown in the right.



The wiring in the remote control case should be 0.3 mm<sup>2</sup> (recommended) to 0.5 mm<sup>2</sup> at maximum.

Further, peel off the sheath.

The peeling length of each wiring is as follows:

X wiring : 160mm  
Y wiring : 150mm



- (6) Mount the upper case for restoring to its former state so as not to crimp the remote control cord, and secure with the removed screw.

- (7) In the case of exposing installation, secure the remote control cord to the wall surface with a cord clamp so as not to loosen the remote control cord.

## 2. Installation and wiring of remote control

- (1) Wiring of remote control should use 0.3mm<sup>2</sup> × 2 core wires or cables. (on-site configuration)

- (2) Maximum prolongation of remote control wiring is 600 m.

If the prolongation is over 100m, change to the size below.

But, the wiring in the remote control case should be 0.3mm<sup>2</sup> (recommended) to 0.5mm<sup>2</sup>.

Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

100 - 200m ······ 0.5mm<sup>2</sup> × 2 cores


Under 300m ······ 0.75mm<sup>2</sup> × 2 cores

Under 400m ······ 1.25mm<sup>2</sup> × 2 cores

Under 600m ······ 2.0mm<sup>2</sup> × 2 cores


### 3. Master/ slave setting when more than one remote control are used

- (1) Up to two remote controls can be connected to one unit (or one group) of indoor unit.



- (2) Set the switch SW1-1 of the slave remote control is "Slave" (ON). The factory default is set as "Master" (OFF).


(Note) • The remote control thermistor enabled setting can be set only to the master remote control.  
• Install the master remote control at the position to detect room temperature.  
• The air-conditioner operation follows the last operation of the remote control in case of the master / slave setting.



### 4. The indication when power source is supplied

- (1) At the time of turning the power source on, after the light is on for the first 2 seconds, the display becomes as shown below.

The number displayed on the upper side of LCD in the remote control is the software number, and this is not an error code.



- (2) Then, "88.0 °C" blinks on the remote control until the communication between the remote control and the indoor unit is established.  
(3) In the case of connecting one remote control with one unit (or one group) of indoor unit, make certain to set the master remote control (factory default). If the slave remote control is set, a communication cannot be established.  
(4) If a state where the communication between the remote control and the indoor unit cannot be established continues about for 30 minutes, "E" is displayed. Confirm the wiring of the indoor unit and the outdoor unit and master/slave setting of the remote control.



### 5. Confirmation method for return air temperature

Return air temperature can be confirmed by the remote control operation.

- (1) Press **AIR CON NO.** button for over 5 seconds.

"88" blinks on the temperature setting indicator.

("88" blinks for approximately 2 seconds while data are read.)

Then, the return air temperature is displayed.

(Example) return air temperature: "27 °C" (blinking)

(Note) For the return air temperature, in the normal case, the return air temperature of the indoor unit is displayed; however, in the case that the remote control thermistor is effective, detected temperature by the remote control thermistor is displayed.



- (2) Press **ON/OFF** button.

End.

[In the case that the remote thermistor is ineffective and plural indoor units are connected to one remote control]

- (1) Press **AIR CON NO.** button for over 5 seconds.

indoor unit No. indicator: "U 000" (blinking)

(Among the connected indoor units, the lowest number is displayed.)

- (2) Press **TEMP△** or **TEMP▽** button.

Select the indoor unit No.

- (3) Press **MODE** button.

Decider the indoor unit No.

(Example) indoor unit No. indicator: "U 000"

"88" blinks on the temperature setting indicator. (blinking for approximately 2 to 10 seconds while data are read) Then, the return air temperature is displayed. When **AIR CON NO.** is pressed, return to the indoor unit selection display (example, "U 000").

- (4) Press **ON/OFF** button.

End.




## 6. Function setting

Each function of the remote control and the indoor unit is automatically set to the initial setting, which is the standard use, on the occasion of connecting the remote control with the indoor unit. In the case of the standard use, the setting change is unnecessary. However, if you would like to change the initial setting "○", change the setting for only the item of the function number. **Record the setting contents and stored them.**

### (1) Function setting item by switch on PCB

Switch No.	Setting	Setting detail	Initial setting
SW1-1	ON	Slave remote control	
	OFF	Master remote control	○
SW1-2	ON	Remote control thermistor enabled	
	OFF	Remote control thermistor disabled	○
SW1-3	ON	"MODE" button prohibited	
	OFF	"MODE" button enabled	○
SW1-4	ON	"ON/OFF" button prohibited	
	OFF	"ON/OFF" button enabled	○

Switch No.	Setting	Setting detail	Initial setting
SW1-5	ON	"TEMP" button prohibited	
	OFF	"TEMP" button enabled	○
SW1-6	ON	"FAN SPEED" button prohibited	※ Note 1
	OFF	"FAN SPEED" button enabled	※ Note 1
SW1-7	ON	Auto restart function enabled	
	OFF	Auto restart function disabled	○
SW1-8, 9, 0	ON	Not used	
	OFF		



- As for the slave remote control, function setting is impossible other than SW1-1.
- In the indoor unit with only one fan speed, "FAN SPEED" button cannot be enabled.

### (2) Function setting item by button operation

Classification	Function No.	Function	Setting No.	Setting	Initial setting	Remarks
Remote control function	01	Indoor unit fan speed	01	Fan speed: three steps	※ Note 1	The fan speed is three steps, <b>*** - ** - *</b> .
			02	Fan speed: two steps (Hi-Lo)	※ Note 1	The fan speed is two steps, <b>** - *</b> .
			03	Fan speed: two steps (Hi-Me)		The fan speed is two steps, <b>** - *</b> .
			04	Fan: one step	※ Note 1	The fan speed is fixed to one step.
	03	Remote control thermistor at the time of cooling	01	Remote control thermistor: no offset	○	
			02	Remote control thermistor: +3.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +3.0°C.
			03	Remote control thermistor: +2.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +2.0°C.
			04	Remote control thermistor: +1.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +1.0°C.
			05	Remote control thermistor: -1.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at -1.0°C.
			06	Remote control thermistor: -2.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at -2.0°C.
			07	Remote control thermistor: -3.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at -3.0°C.
	04	Remote control thermistor at the time of heating	01	Remote control thermistor: no offset	○	
			02	Remote control thermistor: +3.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +3.0°C.
			03	Remote control thermistor: +2.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +2.0°C.
			04	Remote control thermistor: +1.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +1.0°C.
			05	Remote control thermistor: -1.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -1.0°C.
			06	Remote control thermistor: -2.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -2.0°C.
			07	Remote control thermistor: -3.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -3.0°C.
Indoor unit function	05	Ventilation setting	01	No ventilator connection	○	
			02	Ventilator links air-conditioner		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
	06	"Auto" operation setting	01	"Auto" operation enabled	※ Note 1	
			02	"Auto" operation disabled	※ Note 1	"Auto" operation disabled
	07	Operation permission/prohibition	01	Disabled	○	
			02	Enabled		Operation permission/prohibition controller is enabled.
	08	External input	01	Level input	○	
			02	Pulse input		
	09	Fan speed setting	01	Standard	Note2	
			02	High speed 1	Note2	
			03	High speed 2	Note2	
	10	Fan remaining operation at the time of cooling	01	No remaining operation	○	After cooling stopped, no fan remaining operation
			02	0.5 hours		After cooling stopped, fan remaining operation for 0.5 hours
			03	1 hour		After cooling stopped, fan remaining operation for 1 hour
			04	6 hours		After cooling stopped, fan remaining operation for 6 hours
	11	Fan remaining operation at the time of heating	01	No remaining operation	○	After heating stopped or after heating thermostat OFF, no fan remaining operation
			02	0.5 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 0.5 hours
			03	2 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 2 hours
			04	6 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 6 hours
	12	Setting temperature offset at the time of heating	01	No offset	○	
			02	Setting temperature offset + 3.0 °C		The setting temperature at the time of heating is offset by +3.0 °C.
			03	Setting temperature offset + 2.0 °C		The setting temperature at the time of heating is offset by +2.0 °C.
			04	Setting temperature offset + 1.0 °C		The setting temperature at the time of heating is offset by +1.0 °C.
	13	Heating fan control	01	Low fan speed	※ Note 1	At the time of heating thermostat OFF, operate with low fan speed.
			02	Setting fan speed		At the time of heating thermostat OFF, operate with the setting fan speed.
			03	Intermittent operation	※ Note 1	At the time of heating thermostat OFF, intermittently operate.
			04	Fan off		At the time of heating thermostat OFF, a fan will be stopped. When the remote control thermistor is enabled, automatically set to "Fan off". Do not set at the time of the indoor unit thermistor.
	14	Return air temperature offset	01	No offset	○	
			02	Return air temperature offset +2.0 °C		Offset the return air temperature of the indoor unit by +2.0 °C.
			03	Return air temperature offset +1.5 °C		Offset the return air temperature of the indoor unit by +1.5 °C.
			04	Return air temperature offset +1.0 °C		Offset the return air temperature of the indoor unit by +1.0 °C.
			05	Return air temperature offset -1.0 °C		Offset the return air temperature of the indoor unit by -1.0 °C.
			06	Return air temperature offset -1.5 °C		Offset the return air temperature of the indoor unit by -1.5 °C.
			07	Return air temperature offset -2.0 °C		Offset the return air temperature of the indoor unit by -2.0 °C.

Note 1: The symbol "※" in the initial setting varies depending upon the indoor unit and the outdoor unit to be connected, and this is automatically determined as follows:

Switch No. Function No.	Function	Setting	Product model
SW1-6	"FAN SPEED" button	"FAN SPEED" button prohibited	Product model whose indoor fan speed is only one step
		"FAN SPEED" button enabled	Product model whose indoor fan speed is two steps or three steps
Remote control function 01	Indoor unit fan speed	Fan speed: three steps	Product model whose indoor unit fan speed is three steps
		Fan speed: two steps (Hi-Lo)	Product model whose indoor unit fan speed is two steps
		Fan speed: two steps (Hi-Me)	
		Fan: one step	Product model whose indoor unit fan speed is only one step
Remote control function 06	"Auto" operation setting	"Auto" operation enabled	Product model where "Auto" mode is selectable
		"Auto" operation disabled	Product model without "Auto" mode
Indoor unit function 13	Heating fan control	Low fan speed	Product model except FDUS
		Intermittent operation	FDUS

Note 2: Fan speed of "High speed" setting

Fan speed setting	Indoor unit fan speed setting		
	<b>*** - ** - *</b>	<b>** - *</b>	<b>** - *</b>
Standard	Hi — Mid — Lo	Hi — Lo	Hi — Mid
High speed 1・2	UHi — Hi — Mid	UHi — Mid	UHi — Hi

Initial setting of some indoor unit is "High speed".


Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit.

But only master indoor unit is received the setting change of indoor unit function "07 Operation permission/prohibition" and "08 External input".

## 7. How to set functions by button operation

- (1) Stop air-conditioning, and simultaneously press **AIR CON NO.** and **MODE** buttons at the same time for over three seconds.

The function number "01" blinks in the upper right.



- (2) Press **TEMP▲** or **TEMP▼** button.  
Select the function number.

- (3) Press **MODE** button.  
Decide the function number.


- (4) [In the case of selecting the remote control function (01-06)]

- ① The current setting number of the selected function number blinks

(Example)

Function number: "01" (lighting)

Setting number: "01" (blinking)



- ② Press **TEMP▲** or **TEMP▼** button.  
Select the setting number.

- ③ Press **MODE** button.


The setting is completed.

Light is on for approximately 3 to 20 seconds while data of the decided function No. and setting No. is transmitted.

(Example)


Function number: "01" (lighting for 3 to 20 seconds)

Setting number: "01" (lighting for 3 to 20 seconds)



Then, the screen goes back to the function number blinking indication (1), if the setting is sequentially conducted, continue with the same procedures. If the setting is finished, proceed to (5).

- (5) Press **ON/OFF** button.  
The setting is completed.



- [In the case of selecting the indoor unit function (07-14)]

- ① "88" blinks on the temperature setting indicators.

(blinking for approximately 2 to 10 seconds while data are read)




After that, the current setting number of the selected function number blinks.

(Example)

Function number: "07" (lighting)

Setting number: "01" (blinking)




Proceed to ②.

[Note]

- a. In the case of connecting one remote control to plural indoor units, the display will be as follows:

Indoor unit No. display: "U 000" (blinking)

(Display the lowest number among the connected indoor units.)



- b. Press **TEMP▲** or **TEMP▼** button.

Select the indoor unit No. to be set.

If "U ALL" is selected, the same setting can be set to all units.

- c. Press **MODE** button.

Decide the indoor unit No.

"88" blinks on the temperature setting indicators. (blinking for 2 to 10 seconds while data are read)

When **AIR CON NO.** button is pressed, go back to the indoor unit selection display (for example, "U 000" blinking).

- ② Press **TEMP▲** or **TEMP▼** button.  
Select the setting number

- ③ Press **MODE** button.

The setting is completed.


Light is on for approximately 3 to 20 seconds while data of the decided function No. and setting No. is transmitted.

(Example)

Indoor unit No.: "U 000" (lighting for 3 to 20 seconds)

Function number: "07" (lighting for 3 to 20 seconds)

Setting number: "01" (lighting for 3 to 20 seconds)



Then, the screen goes back to the function number blinking indication (1), if the setting is sequentially conducted, continue with the same procedures. If the setting is finished, proceed to (5).

- Even if **ON/OFF** button is pressed during setting, the setting is ended. However, any details where the setting has not been completed will be ineffective.
- The setting contents are stored in the controller, and even if the power failure occur, this will not be lost.

[Confirmation method for current setting]

According to the operation, the "setting number" displayed first after selecting "function number" and pressing **MODE** button is the currently set content. (However, in the case of selecting "U ALL" (all units), the setting number of the lowest number among the indoor units is displayed.)

## 12.4 Interface kit (SC-BIKN-E)

RKZ012A088B

### Accessories included in package

Be sure to check all the accessories included in package.

No.	Part name	Quantity
①	Indoor unit's connection cable (cable length: 1.8m)	1
②	Wood screws (for mounting the interface: $\phi 4 \times 25$ )	2
③	Tapping screws (for the cable clamp and the interface mounting bracket)	3
④	Interface mounting bracket	1
⑤	Cable clamp (for the indoor unit's connection cable)	1
⑥*	CNT terminal connection cable (total cable length: 0.5m)	1

\* SC-BIKN-EA only

### Safety precautions

Before use, please read these Safety Precautions thoroughly before installation.

- All the cautionary items mentioned below are important safety related items to be taken into consideration, so be sure to observe them at all times.

**Warning** Incorrect installation could lead to serious consequences such as death, major injury or environmental destruction.

- Symbols used in these precautions



Always go along these instruction.

- After completed installation, carry out trial operation to confirm no anomaly, and ask the user to keep this installation manual in a good place for future reference.




## Warnings




- **Installation must be carried out by a qualified installer.**  
If you install it by yourself, it may cause an electric shock, fire and personal injury, as a result of a system malfunction.
- **Install it in full accordance with the instruction manual.**  
Incorrect installation may cause an electric shock, fire and personal injury.
- **Electrical work must be carried out by a qualified electrician in accordance with the technical standard for electrical equipment, the indoor wiring standard and this instruction manual.**  
Incorrect installation may cause an electric shock, fire and personal injury.
- **Use the specific cables for wiring. And connect all the cables to terminals or connectors securely and clamp them with cable clamps in order for external forces not to be transmitted to the terminals directly.**  
Incomplete connection may cause malfunction, and lead to heat generation and fire.
- **Use the original accessories and specified components for installation.**  
If the parts other than those prescribed by us are used, it may cause an electric shock, fire and personal injury.

### Connecting the indoor unit's connection cable to the interface

- ① Remove the upper case of the interface.
  - Remove 2 screws from the interface casing before removal of upper casing.
- ② Connect the indoor unit's connection cable to the interface.
  - Connect the connector of the indoor unit connection cable to the connector on the interface's circuit board.
- ③ Fix the indoor unit's connection cable with the cable clamp.
  - Cable can be brought in from the top or from the back.
  - Cut out the punch-outs for the connection cables running into the casing with cutter.
- ④ Connect the indoor unit's connection cable to the indoor control PCB.
  - Connect the indoor unit's connection cable to the indoor control PCB securely.
  - Clamp the connection cable to the indoor control box securely with the cable clamp provided as an accessory.
  - Regarding the cable connection to the indoor unit, refer to the instruction manual for indoor unit.



### Name of each part of the interface



\*Either the connection cables of Superlink E board (SC-ADNA-E) or of wired remote control is connectable.

Switch	Setting	Function	Switch	Setting	Function
SW2-1	ON**	CNT level input	SW2-3	ON**	External input (CNT input)
	OFF	CNT Pulse input		OFF	Operation permission/prohibition (CNT input)
SW2-2	ON**	Wired remote control : Enable	SW2-4	ON**	Annual cooling : Enable***
	OFF	Wired remote control : Disable		OFF	Annual cooling : Disable***

\*\* Factory setting

\*\*\* Indoor fan control at low outdoor air temperature in cooling

## Installation of the interface



- Install the interface within the range of the connection cable length from the indoor unit. (approximately 1.3m)
- Be sure not to extend the connection cable on site. If the connection cable is extended, malfunction may occur.
- Fix the interface on the wall, pillar or the like.

● DO NOT install the interface and wired remote control at the following places.

- Places exposed to direct sunlight
- Places near heating devices
- High humidity places
- Surfaces where are enough hot or cold to generate condensation
- Places exposed to oil mist or steam directly
- Uneven surface


### Mounting the interface directly on a wall

- ① Mount the lower casing of the interface on a flat surface with wood screws provided as standard accessory.
- ② Mount the upper casing.




### Recessing the interface in the wall

- ① Recess the electrical box (procured locally) and connection cables in the wall.
- ② Mount the lower casing of the interface to the electrical box with M4 screws (procured locally).
- ③ Mount the upper casing.



### Mounting the interface with the mounting bracket

- ① Mount the mounting bracket to the interface with tapping screws provided as standard accessory.
- ② Mount the mounting bracket on wall or the like with wood screws provided as standard accessory.
- ③ Mount the mounting bracket to a wall surface, etc. using the wood screws provided.




## Installation check items

- ☐ Are the connection cables connected securely to the terminal blocks and connectors?
- ☐ Are the thickness and length of the connection cables conformed with the standard?

## Functions of CNT connector

It is available to operate the air-conditioning unit and to monitor the operation status with the external control unit (remote display) by sending the input/output signal through CNT connector on the indoor control PCB.

- ① Connect a external remote control unit (procured locally) to CNT terminal.
- ② In case of the pulse input, switch OFF the DIP switch SW2-1 on the interface PCB.
- ③ When setting operation permission/prohibition mode, switch OFF the DIP switch SW2-3 on the interface PCB.




Input/Output	Function	Output signal		Content
		Relay	ON/OFF	
Output 1	Operation output	XR1	ON	During air-conditioner operation
Output 2	Heating output	XR2	ON	During heating operation
Output 3	Compressor operation output	XR3	ON	During compressor running
Output 4	Malfunction output	XR4	ON	During anomalous stop

- XR1~4 are for the DC 12V relay
- XR5 is a DC 12/24V or AC 220~240V relay
- CNT connector (local) maker, model

Connector	Molex	5264-06
Terminals	Molex	5263T

Input/ Output	Function	SW2-1		SW2-3			Air- Conditioner	Operation by Remote Control	
		Setting		Setting	Input signal Level/Pulse	Content			
Input	External control input	ON*	Level input	ON*	Level	OFF→ON	External input	ON	Allowed
				ON→OFF		OFF→ON	OFF		
				OFF→ON		Operation permission	OFF		
				ON→OFF	Operation prohibition	OFF	Not allowed		
		OFF	Pulse input	ON*	Pulse	OFF→ON	External input	OFF→ON	Allowed
						ON→OFF	Operation permission	ON	
OFF	Level			ON→OFF	Operation prohibition	OFF	Not allowed		

\* Factory setting




## Connection of Superlink E board

Regarding the connection of Superlink E board, refer to the instruction manual of Superlink E board.


For electrical work, power source for all of units in the Superlink system must be turned OFF.

- ① Switch ON the DIP switch SW2-2 (Factory setting: ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, Temperature Setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.



- ② Wiring connection between the interface and the Superlink E board.



No.	Names of recommended signal wires
1	Shielded wire
2	Vinyl cabtyre round cord
3	Vinyl cabtyre round cable
4	Vinyl insulated wire/vinyl sheathed cable for control

Within 200 m 0.5 mm² × 2 cores  
 Within 300 m 0.75 mm² × 2 cores  
 Within 400 m 1.25 mm² × 2 cores  
 Within 600 m 2.0 mm² × 2 cores

- ③ Clamp the connection cables with cable clamps.

## Connection of wired remote control

Regarding the connection of wired remote control, refer to the instruction manual of wired remote control.

- ① Switch ON the DIP switch SW2-2 (Factory setting : ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, Temperature Setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.

- ② Wiring connection between the interface and the wired remote control.

### Installation and wiring of wired remote control

- ① Install the wired remote control with reference to the attached instruction manual of wired remote control.

- ② 0.3mm<sup>2</sup> × 2-core cable should be used for the wiring of wired remote control.

- ③ Maximum length of wiring is 600m.

If the length of wiring exceeds 100m, change the size of cable as mentioned below.

100m-200m: 0.5mm<sup>2</sup> × 2-core, 300m or less: 0.75mm<sup>2</sup> × 2-core, 400m or less: 1.25mm<sup>2</sup> × 2-core, 600m or less: 2.0mm<sup>2</sup> × 2-core


However, cable size connecting to the terminal of wired remote control should not exceed 0.5mm<sup>2</sup>. Accordingly if the size of connection cable exceeds 0.5mm<sup>2</sup>, be sure to downsize it to 0.5mm<sup>2</sup> at the nearest section of the wired remote control and waterproof treatment should be done at the connecting section in order to avoid contact failure.

- ④ Don't use the multi-core cable to avoid malfunction.

- ⑤ Keep the wiring of wired remote control away from grounding (Don't touch it to any metal frame of building, etc.).

- ⑥ Connect the connection cables to the terminal blocks of the wired remote control and the interface securely (no polarity).

- ③ Clamp the connection cables with cable clamps.



### Control of multiple units by a single wired remote control

Multiple units (up to 16) can be controlled by a single wired remote control.

In this case, all units connected with a single wired remote control will operate under the same mode and same setting temperature.

- ① Connect all the interface with 2-core cables of wired remote control line.

- ② Set the address of indoor unit for remote control communication from "0" to "F" with the rotary switch SW1 on the interface PCB.

- ③ After turning the power ON, the address of indoor unit can be displayed by pressing [AIR CON] button on the wired remote control.

Make sure all indoor units connected are displayed in order by pressing


▲ or ▼ button.

### Master/Slave setting wired when 2 of wired remote control are used

Maximum two wired remote control can be connected to one indoor unit (or one group of indoor units)

- ① Set the DIP switch SW1 on the wired remote control to "Slave" for the slave remote control. (Factory setting : Master)

○ Caution : Remote control sensor is invalid.



- When using the wireless remote control in parallel with the wired remote control;

Since temperature setting range of wired remote control is different from that of wireless remote control, please adjust the setting range of wired remote control to be the same setting range of wireless remote control by following procedure. (The set temperature may not be displayed correctly on the wireless remote control, unless change of temperature setting range is done.)

Changing procedure of temperature setting range is as follows.

### How to set upper and lower limit of temperature sting range

1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for 3 seconds or more.

The indication changes to "FUNCTION SET ▼"

2. Press (▼) button once, and change to the "TEMP RANGE ▲" indication.

3. Press (SET) button, and enter the temperature range setting mode.

4. Confirm that the "Upper limit ▼" is shown on the display.

5. Press (SET) button to fix.

6. ① Indication: "UPPER 28°C ▲" → "UPPER 28°C ▼"

- ② Select the upper limit value 30°C with temperature setting button [▲]. "UPPER 30°C ▼" (blinking)

- ③ Press (SET) button to fix. "UPPER 30°C" (Displayed for two seconds)

After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".

7. Press (▼) button once, "LOWER LIMIT ▲" is selected, press (SET) button to fix.

- ① Indication: "UPPER 30°C ▼" → "LOWER 20°C ▲"

- ② Select the lower limit value 18°C with temperature setting button [▲]. "LOWER 18°C ▲" (blinking)


- ③ Press (SET) button to fix. "LOWER 18°C" (Displayed for two seconds)

After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".

8. Press [ON/OFF] button to finish.

Temperature setting range

Mode	Temperature setting range
Cooling, Heating, Dry, Auto	18-30°C



- It is possible to quit in the middle by pressing [ON/OFF] button, but the change of setting is incomplete.
- During setting, if pressing (RESET) button, it returns to the previous screen.

## 12.5 Superlink E board (SC-ADNA-E)

PJZ012D029F

- Read and understand the instructions completely before starting installation.
- Refer to the instructions for both indoor and outdoor units.

### Safety precautions

- Carefully read "Safety precautions" first. Follow the instructions for installation.
- Precautions are grouped into "Warning⚠" and "Caution⚠". The "Warning⚠" group includes items that may lead to serious injury or death if not observed. The items included in the "Caution⚠" group also may lead to serious results under certain conditions. Both groups are crucial for safety installation. Read and understand them carefully.
- After installation, conduct the test operation of the device to check for any abnormalities. Describe how to operate the device to the customer following the installation instruction manual. Instruct the customer to keep this installation instruction for future reference.

#### ⚠ Warning

- This device should be installed by the dealer where you purchase the device or a licensed professional shop. If the device is incorrectly installed by the customer, it may result in electric shock or fire.
- Install the device carefully following the installation instruction. If the device is incorrectly installed, it may result in electric shock or fire.
- Use the accessory parts and specified parts for installation. If any parts that do not match the specifications are used, it may result in electric shock or fire.
- A person with the electrical service certification should conduct the service based on the "Technical standards for electrical facilities", "Electrical Wiring Code", and the installation instruction. If the work is done incorrectly, it may result in electric shock or fire.
- Wiring should be securely connected using the specified types of wire. No external force on the wire should be applied to any terminals. If a secure connection is not achieved, it may result in electric shock or fire.






#### ⚠ Caution

- Provide ground connection.  
The ground line should never be connected to the gas supply piping, the water supply piping, the lightning conductor rod, nor the telephone ground. If the grounding is improper, it may result in electric shock.
- Do not install the device in the following locations.
  1. Where there is mist/spray of oil or steam such as kitchens.
  2. Where there is corrosive gases such as sulfurous acid gas.
  3. Where there is a device generating electromagnetic waves.  
These may interfere with the control system resulting in the device becoming uncontrollable.
  4. Where flammable volatile materials such as paint thinner and gasoline may exist or where they are handled. This may cause a fire.

### 1 Application

Indoor-to-outdoor three core communication specification type 3 (since October 2007)


### 2 Accessories

SL E board	Metal box	Metal cover	Screw for Ground
			M4x8L 2 pieces
Pan head screws	Locking supports	Binding band	Grommet
φ4x8L 2 pieces	To secure the print board and the metal box Made of nylon 4 pieces		

### 5 Connection Outline

#### Note for setting the address

- Set the address between 00 and 47 for the previous Superlink connection and between 000 and 127 for the new Superlink connection. (\*1)
- Do not set the address overlapping with those of the other devices in the network. (The default is 000)



(\*1) Whether the actual link is either the new Superlink or the previous Superlink depends on the models of the connected outdoor and indoor units. Consult the agent or the dealer.

### 3 Function

Allowing the center console SL1N-E, SL2NA-E, and SL4-AE/BE to control and monitor the commercial air-conditioning unit.

### 4 Control switching

Settings can be changed by the switch SW3 on the SL E board as in the following.

Switch	Symbol	Switch	Remarks
SW3	1	ON	Master
		OFF (default)	Slave
	2	ON	Fixed previous protocol
		OFF (default)	Automatic adjustment of Superlink protocol
	3	ON	Indicates the forced operation stop when abnormality has occurred.
		OFF (default)	Indicates the status of running/stop as it is, when abnormality has occurred.
	4	ON	The hundredth address activated "1"
		OFF (default)	The hundredth address activated "0"


#### Signal line specification

Communication method	Previous Superlink	New Superlink
Line type	MVVS	MVVS
Line diameter	0.75 - 1.25mm <sup>2</sup>	0.75/1.25mm <sup>2</sup>
Signal line (total length)	up to 1000m	up to 1500/1000m (*2)
Signal line (maximum length)	up to 1000m	up to 1000m

(\*2) Up to 1500 m for 0.75 mm<sup>2</sup>, and up to 1000 m for 1.25 mm<sup>2</sup>. Do not use 2.0 mm<sup>2</sup>. It may cause an error.


(\*3) Connect grounding on both ends of the shielding wire. For the grounding method, refer to the section "6 Installation".

- (1) Set the Superlink network address with SW1 (tens place), SW2 (ones place), and SW3 (hundreds place).
- (2) Set the SL E board SW3-1 to be ON (Master) when using this without any remote control (no wired remote control nor wireless remote control).
- (3) Set up the plural master/slave device using the dip switches on the indoor unit board.
- (4) Set up the remote control master/slave device using the slide switch on the remote control board.
- (5) Set up "0" to "F" using the address rotary switch on the indoor unit board when controlling the indoor unit with the multiple remote control.




## 6 Installation


- When using the metal box (mounted on the indoor unit / mounted on the back of the remote control):
  - (1) Mount the SL E board in the metal box using the locking supports.
  - (2) Wiring should go through the provided grommet since then through the wiring to the hole on the Metal box.  
Secure the grommet after inserting the grommet into the Metal box as shown in below figure, then tie the wiring at the outlet of the unit using a binding band.




- ▲ When installed outside the indoor unit, put the metal cover on.



- ▲ When installed on the back of the remote control, mount it directly on the remote control bottom case.




Connect grounding. Connect grounding for the power line to Ground ①, and grounding for the signal line to Ground ② or to the Ground on the indoor unit control box.



- When connecting to the indoor unit control box (ceiling-concealed type and FDT type only):

- (1) Mount the SL E board in the control box using the locking supports.
- (2) Remove 6 bands from the box and put the wiring through the bands to be secured.



Electrical shock hazard! Make sure to turn the power off for servicing. Be cautious so that no abnormal force should be applied to the wiring. Do not let the SL E board hung by the wiring. Do not damage the board with a screw driver.  
The board is sensitive to static electricity. Release the static electricity of your body before servicing.  
(you can do this by touching the control board which is grounded).

### Location of installation

Install the device at the location where there are no electromagnetic waves nor where there is water and dust. The specified temperature range of the device is 0 to 40°C. Install the device at the location where the ambient temperature stays within the range. If it exceeds the specification, make sure to provide solution such as installing a cooling fan. When used outside of the range, it may cause abnormal operation.

## 7 Indicator display

Check the LED 3 (green) and LED 2 (red) on the SL E board for flashing.

SL E board LEDs		Inspection mode	Display on the integrated network control device
Red	Green		
Off	Flashing	Normal communication	
Off	Off	<ul style="list-style-type: none"> <li>Disconnection in the remote control communication line (X or Y)</li> <li>Short-circuit in the remote control communication line (between X and Y)</li> <li>Faulty indoor unit remote control power</li> <li>Faulty remote control communication circuit</li> <li>Faulty CPU on SL E board</li> </ul>	No corresponding unit number
One flash	Flashing	<ul style="list-style-type: none"> <li>Disconnection in the Superlink signal line (A or B)</li> <li>Short-circuit in the Superlink signal line (between A and B)</li> <li>Faulty Superlink signal circuit</li> </ul>	
Two flashes	Flashing	<ul style="list-style-type: none"> <li>Faulty address setting for the SL E board (Set up the address for previous SL E board : more than 48 new SL E board : more than 128)</li> </ul>	
Three flashes	Flashing	<ul style="list-style-type: none"> <li>SL E board parent not set up when used without a remote control</li> <li>Faulty remote control communication circuit</li> </ul>	E1
Four flashes	Flashing	<ul style="list-style-type: none"> <li>Address overlapping for the SL E board and the Superlink network connected indoor unit</li> </ul>	E2
Off	Flashing	<ul style="list-style-type: none"> <li>Number of connected devices exceeds the specification for the multiple indoor unit control</li> </ul>	E10

PJZ012D029C

## 12.6 Ceiling concealed type (SRR) option pats

### (1) Bottom air inlet kit

This manual contains installation points for BOTTOM AIR INLET KIT manufactured by MHI.

Carry out the work following the instructions below.

Keep this manual properly with USER'S MANUAL provided with the indoor unit.



#### CAUTION

- After unpacking, carry out this work on the ground.
- Do not carry out the work during operation, or there is a danger of being entangled in the rotating parts and getting injured.
- Be sure to cut off the power and stop the unit before maintenance.

#### 1. Applicable model of unit and type of BOTTOM AIR INLET KIT

BOTTOM AIR INLET KIT		UT-BAT1EF	UT-BAT2EF	UT-BAT3EF
Model	for FDUT	15,22,28,36	45,56	71
	for SRR	25,35	50,60	

#### 2. Parts list of BOTTOM AIR INLET KIT


Rear panel	Fan guard	Parts set (Tapping screw)
 1pc.	 1pc.	4mm(dia)X12mm(length)  UT-BAT1EF 12pcs. UT-BAT2EF 12pcs. UT-BAT3EF 14pcs.

#### 3. Installation Points

(Figure shows the state that the unit is placed on a floor. Top and bottom are inverted after installing the unit.)

(1) Place the unit as shown below.


(2) Remove the bottom plate and duct flange plate of rear from the unit. Keep the removed tapping screws to reuse later.



◆ The number of tapping screws to be removed

	Model	Bottom	Rear
FDUT	15,22,28,36	10 pcs.	8 pcs.
	45,56	10 pcs.	9 pcs.
	71	12 pcs.	8 pcs.
SRR	25,35	10 pcs.	8 pcs.
	50,60	10 pcs.	9 pcs.

(3) Install rear panel by using removed tapping screws in process(2). Install fan guard by using tapping screws in parts set.



◆ The number of tapping screws to be tightened

	Model	Fan guard	Rear panel
FDUT	15,22,28,36	12 pcs.	8 pcs.
	45,56	12 pcs.	9 pcs.
	71	14 pcs.	8 pcs.
SRR	25,35	12 pcs.	8 pcs.
	50,60	12 pcs.	9 pcs.

## (2) Remote sensor kit (SC-THB-E3)

Sensor for return air temperature detection is located in the air inlet of the indoor unit.

Use the remote sensor kit SC-THB-E3, and install it on the suitable wall so the temperature of the room can be accurately detected.

This remote sensor kit is to be used as an alternative to the pre-installed sensor of the indoor unit.

### 1. Accessory parts

No.	Part name	Q'ty	No.	Part name	Q'ty
①	Sensor box	1	④	Band	1
②	Cable (8m)	1	⑤	Screw (4X16)	2
③	Tape (Double -stick)	1			

※Installation manual in the SC-THB-E3 is not it for SRR\_ZM-S.


### 2. Selection of installation position

- The thermistor for detecting room temperature is located inside the remote sensor box.
- DO NOT install the remote sensor in places where.
  - Average room temperature can not be detected.
  - A heat source is located nearby.
  - The wall temperature is different from average room temperature.
  - Affected by the outdoor air when opening / closing the door, etc.
  - The discharge air from indoor unit blows directly.
  - Covered by curtains or other obstacles.
  - Exposed to the sun.
  - Exposed to water, humidity or dew.
- Mount the remote sensor vertically on the wall surface, etc.
- Run the sensor cable in a place where the power cable or electrical noise will not cause any abnormal operation.


### 3. Installation procedure

- (a) Insert the tip of slotted screwdriver to the gap between the cover and base of the sensor box (①), and twist it to disassemble.
- (b) Fix the base to the wall with screws (⑤).
- (c) Connect the cable (②) to the terminal block in the base. (Non polarity)
- (d) Attach the cover to the base.


Remote sensor box



- (e) Remove the control lid of the indoor unit. Take off CNG connector from PCB of the indoor unit .




- (f) Cut wiring from 1 & 2 pins of CNG connector. (wiring length : about 100 mm from the connector)  
If the pre-installed return air temperature sensor ASSY is not removed, the end of the sensor wiring should prevent a short circuit by insulating tape etc.



- (g) Insert the cable from remote sensor box to the control box of the indoor unit through the grommet of the remote control signal receiver side.  
(h) Adjust the length of the cable and cut it off. (Connector cable is not need. )  
(i) Connect the cable from remote sensor box and the cut wiring (procedure (6)) of CNG connector.  
(Non polarity)

**Be sure to connect the wirings by solder separately. Then, wirings should prevent a short circuit separately by insulating tapes etc. In case of faulty wiring connection, it can cause electrical shock and fire.**



- (j) Put CNG connector back on the indoor unit PCB.  
(k) Attach the control lid of the indoor unit.

## 12.7 OA spacer (FDTC only)

This manual describes the installation methods for OA spacer (TC-OAS-E) and the duct joint (TC-OAD-E).

◎This OA spacer is designed for assembling on the indoor unit (FDTC Series), not for be using independently.

PJZ012D074

B

Application model	FDTCA151R, 201R, FDTCA22~56KXE4R, FDTCA22~56KXE6 FDTC22~56KXE6A, FDTCA22~56KXE6B, FDTCA22~56KXE6D FDTC40V, 50V, FDTCA40~60VB, FDTCA25~60VD
-------------------	--

◎Prepare the duct (size: ø75) and the booster fan at site.

◎For the installation of indoor unit, refer to the installation manual attached to the indoor unit.

### SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.

#### ⚠ WARNING

- **Installation should be performed by the specialist.**

If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.



- **Install the system correctly according to these installation manuals.**

Improper installation may cause explosion, injury, water leakage, electric shock, and fire.



- **Use the genuine accessories and the specified parts for installation.**

If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.



- **Turn off the power source during servicing or inspection work.**

If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.



- **Shut off the power before electrical wiring work.**

It could cause electric shock, unit failure and improper running.



#### ⚠ CAUTION

- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**







It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.







### ① Before installation

- Confirm the following parts are included:

OA spacer (TC-OAS-E)

Spacer	Bracket 1	Bracket 2	Bracket 3	Bracket 4	Bolt
					
1	2	2	2	2	8

Duct joint (TC-OAD-E)

Duct Joint	Screw	Insulation 1 (120 × 54)	Insulation 2 (40 × 60)
			
1	6	1	2

## ② Prior study before installation (Usage limitation)

### (1) Temperature conditions for OA spacer

- Adjust the temperature conditions of mixed air with outdoor air and indoor air within the usage range of suction air temperature for the air-conditioner.
- The usage temperature conditions of intake outdoor air and indoor air around the ducts are shown in the following table.
- If the temperature conditions of intake outdoor air do not meet, process the outdoor air before intaking.

Operation mode	Usage temperature conditions	
	Intake outdoor air	Indoor air around the ducts
In heating	5°C DB or higher	18.5°C WB or lower and 60% RH or lower
In cooling	29°C DB or lower and 80% RH or lower	20°C DB or higher

### (2) Intake outdoor air volume




- Intake outdoor air volume is 2.6 m<sup>3</sup>/min at the maximum (when two sets of duct joints are used). Up to two sets of duct joint can be installed on OA spacer.
- In case one set of duct joint is installed: 1.3 m<sup>3</sup>/min max.
- In case two sets of duct joint is installed: 2.6 m<sup>3</sup>/min max.

### (3) Selection of booster fan

- Select the booster fan based on the duct resistance plus the pressure loss at the duct joint. (See the figure)

### (4) Other conditions

- Determine the capacity of air-conditioner based on the calculation of air-conditioning load including the heat load of intake outdoor air.
- Install the filter for the intake outdoor air and the reverse flow prevention dumper during the duct work at site.
- Insulate the duct and duct joint in order to prevent dewing.
- Interlock the operation of booster fan with ON/OFF operation of the indoor unit. (See Section 7.)




## ③ Installation of duct joint (TC-OAD-E) onto OA spacer


- There are two places where the duct joint can be installed.

### When installing one duct joint

Install OA spacer at either one of two installation places on the duct joint.




To install the duct joint, screw it in as shown at left.



When installing the duct joint at the lid side, remove the lid and reinstall it at the other end before installing the duct joint.

### When installing two duct joints




Remove the lid and then install two pieces of duct joint.

## ④ Installation of OA spacer on the indoor unit


OA spacer can be installed regardless whether the indoor unit has already been hanged or not.  
(It is recommended to install before hanging the unit for convenience of installation.)

### 1-1. When installing OA spacer before hanging the indoor unit

- ① Placing OA spacer on the indoor unit, fix the brackets 1 and 2 (2 pieces each) with bolts.  
Install OA spacer in the appropriate position that the duct joint side of OA spacer becomes opposite to the control box of indoor unit (FDTC).



- ② Fix the brackets 3 and 4 (2 pieces each) with bolts.





### 2. Applying insulation

Applying the insulation attached to duct joint set (TC-OAD-E)

- ① Applying the insulation 1 as shown in the figure.  
② Applying the insulation 2 as shown in the figure.


\* Be sure to cover the entire surface of sheet metal of the duct joint with the insulation.




A-A

### 1-2. When installing OA spacer after hanging the indoor unit


- ① After hanging the indoor unit (\*), fix the bracket 1 (2 pieces) temporarily with bolt by 2 turns as shown in the figure.  
\* For the height (position) of hanging the indoor unit, refer to Section 5.



- ② Install OA spacer.  
i. Install it in the way that the recess of OA spacer will fit on the bracket 1 fixed temporarily at the step ①.  
ii. Tighten the bolt of bracket 1.  
iii. Fix the bracket 2 with bolt. (Tighten up)



- ③ Fix the brackets 3 and 4 (2 pieces each) with bolts.









## 12.8 Duct joint (FDTC only)

PJZ012D073

### ● This product is used by assembling on the spacer (TC-OAS-E)


#### 1.Before installation

- Confirm the following parts are included:

Duct joint	Screw	Insulation 1 (120 × 54)	Insulation 2 (40 × 60)
			
1	6	1	2

#### 2.Regarding the use of this product

- Fix the product on the spacer (TC-OAS-E) as shown below.
- For the installation method, refer to the installation manual of the spacer.



## 12.9 Filter kit (FDUM only)

PJZ012D076A

This manual contains installation points and operating instructions for the filter kit manufactured by MHI. Carry out the work following the instructions below.

This manual also contains information on the usage after installation, so keep this manual properly with USER'S MANUAL provided with the indoor unit.









### CAUTION

- After unpacking, carry out this work on the ground.
- Do not carry out the work during operation, or there is a danger of being entangled in the rotating parts and getting injured.
- Clean the air filter regularly.
- Be sure to entrust qualified serviceman to performance on the air filter.
- Be sure to cut off the power and stop the unit before performing maintenance.

### 1. Table of filter kit parts No. and corresponding object models


	Small model	Medium model	Large model
Single type	40, 50	60, 71	100 - 140
Multi type	22 - 56	71, 90	112 - 160
Filter Kit	UM-FL1EF	UM-FL2EF	UM-FL3EF

### 2. Parts list of filter kit

Filter	Rail	Insulation
		
1pc	2pc	2pc
Bracket	Parts set (screw)	
	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>( small and medium model : 5pcs. )</p> </div> <div style="border-left: 1px dashed black; width: 1px; height: 100px; margin: 0 10px;"></div> <div style="text-align: center;">  <p>( large model : 7pcs. )</p> </div> </div>	
1pc	1pc	


### 3. Installation Points

- (1) Stick the insulation on both inner sides of the duct, leaving no space up and down.





(\*) After unpacking, bottom side of the unit is located at the upper side.

- (2) Install the rail on both inner sides of the duct with the screw.




- (3) Install the air filter on the rails.



Installation procedure

- (4) Install the bracket on the rail with the screw.



(\*\*) When the unit is installed, bottom side of the unit is located at the lower side.

# 13. TECHNICAL INFORMATION

## (1) Model SCM40ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S x 2		Average(mandatory)		Yes	
Outdoor unit model name		SCM40ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	4.00	kW	cooling	SEER	5.92	A+
heating / Average	Pdesignh	5.20	kW	heating / Average	SCOP/A	4.05	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	4.41 kW	heating / Average (-10°C)		elbu	0.79 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	4.00 kW	Tj=35°C		EERd	4.76 -
Tj=30°C		Pdc	3.00 kW	Tj=30°C		EERd	7.20 -
Tj=25°C		Pdc	3.30 kW	Tj=25°C		EERd	8.90 -
Tj=20°C		Pdc	3.60 kW	Tj=20°C		EERd	7.40 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	4.60 kW	Tj=-7°C		COPd	2.80 -
Tj=2°C		Pdh	2.80 kW	Tj=2°C		COPd	3.90 -
Tj=7°C		Pdh	2.20 kW	Tj=7°C		COPd	5.50 -
Tj=12°C		Pdh	3.10 kW	Tj=12°C		COPd	6.90 -
Tj=bivalent temperature		Pdh	4.60 kW	Tj=bivalent temperature		COPd	2.80 -
Tj=operating limit		Pdh	4.10 kW	Tj=operating limit		COPd	2.50 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPcyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	13 W	cooling		Qce	237 kWh/a
standby mode		Psb	13 W	heating / Average		Qhe	1798 kWh/a
thermostat-off mode		Pto	25 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	53 dB(A)
staged		No		Sound power level(outdoor)		Lwa	60 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	690 m3/h
				Rated air flow(outdoor)		-	2400 m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A	RWC000Z284
---	------------

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S x 2		Average(mandatory)		Yes	
Outdoor unit model name		SCM40ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	4.00	kW	cooling	SEER	5.72	A+
heating / Average	Pdesignh	5.20	kW	heating / Average	SCOP/A	3.84	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pd h 4.41 kW		heating / Average (-10°C)		elbu 0.79 kW	
heating / Warmer (2°C)		Pd h - kW		heating / Warmer (2°C)		elbu - kW	
heating / Colder (-22°C)		Pd h - kW		heating / Colder (-22°C)		elbu - kW	
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc 4.00 kW		Tj=35°C		EERd 4.54 -	
Tj=30°C		Pdc 3.00 kW		Tj=30°C		EERd 6.90 -	
Tj=25°C		Pdc 3.30 kW		Tj=25°C		EERd 8.50 -	
Tj=20°C		Pdc 3.60 kW		Tj=20°C		EERd 7.20 -	
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pd h 4.60 kW		Tj=-7°C		COPd 2.60 -	
Tj=2°C		Pd h 2.80 kW		Tj=2°C		COPd 3.60 -	
Tj=7°C		Pd h 2.20 kW		Tj=7°C		COPd 5.50 -	
Tj=12°C		Pd h 3.10 kW		Tj=12°C		COPd 6.90 -	
Tj=bivalent temperature		Pd h 4.60 kW		Tj=bivalent temperature		COPd 2.60 -	
Tj=operating limit		Pd h 4.10 kW		Tj=operating limit		COPd 2.40 -	
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pd h - kW		Tj=2°C		COPd - -	
Tj=7°C		Pd h - kW		Tj=7°C		COPd - -	
Tj=12°C		Pd h - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pd h - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pd h - kW		Tj=operating limit		COPd - -	
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pd h - kW		Tj=-7°C		COPd - -	
Tj=2°C		Pd h - kW		Tj=2°C		COPd - -	
Tj=7°C		Pd h - kW		Tj=7°C		COPd - -	
Tj=12°C		Pd h - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pd h - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pd h - kW		Tj=operating limit		COPd - -	
Tj=-15°C		Pd h - kW		Tj=-15°C		COPd - -	
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv -7 °C		heating / Average		Tol -15 °C	
heating / Warmer		Tbiv - °C		heating / Warmer		Tol - °C	
heating / Colder		Tbiv - °C		heating / Colder		Tol - °C	
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc - kW		for cooling		EERcyc - -	
for heating		Pcyh - kW		for heating		COPcyc - -	
Degradation coefficient				Degradation coefficient			
cooling		Cdc 0.25 -		heating		Cdh 0.25 -	
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff 13 W		cooling		Qce 245 kWh/a	
standby mode		Psb 13 W		heating / Average		Qhe 1897 kWh/a	
thermostat-off mode		Pto 25 W		heating / Warmer		Qhe - kWh/a	
crankcase heater mode		Pck 0 W		heating / colder		Qhe - kWh/a	
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa 49 dB(A)	
staged		No		Sound power level(outdoor)		Lwa 60 dB(A)	
variable		Yes		Global warming potential		GWP 1975 kgCO2eq.	
				Rated air flow(indoor)		- 468 m3/h	
				Rated air flow(outdoor)		- 2400 m3/h	
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284 

## (2) Model SCM45ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S + SRK25ZMX-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM45ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	4.50	kW	cooling	SEER	5.98	A+
heating / Average	Pdesignh	5.80	kW	heating / Average	SCOP/A	4.03	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	4.95	kW	heating / Average (-10°C)	elbu	0.85	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	4.50	kW	Tj=35°C	EERd	4.33	-
Tj=30°C	Pdc	3.30	kW	Tj=30°C	EERd	7.00	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	8.90	-
Tj=20°C	Pdc	3.60	kW	Tj=20°C	EERd	7.40	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	5.10	kW	Tj=-7°C	COPd	2.40	-
Tj=2°C	Pdh	3.10	kW	Tj=2°C	COPd	4.00	-
Tj=7°C	Pdh	2.20	kW	Tj=7°C	COPd	5.50	-
Tj=12°C	Pdh	3.10	kW	Tj=12°C	COPd	6.90	-
Tj=bivalent temperature	Pdh	5.10	kW	Tj=bivalent temperature	COPd	2.40	-
Tj=operating limit	Pdh	4.70	kW	Tj=operating limit	COPd	2.10	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyhc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	13	W	cooling	Qce	264	kWh/a
standby mode	Psb	13	W	heating / Average	Qhe	2014	kWh/a
thermostat-off mode	Pto	25	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	55	dB(A)
staged		No		Sound power level(outdoor)	Lwa	60	dB(A)
variable		Yes		Global warming potential	GWp	1975	kgCO2eq.
				Rated air flow(indoor)	-	750	m3/h
				Rated air flow(outdoor)	-	2400	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		<b>SRK20ZM-S+SRK25ZM-S</b>		Average(mandatory)		<b>Yes</b>	
Outdoor unit model name		<b>SCM45ZM-S</b>		Warmer(if designated)		<b>No</b>	
Function(indicate if present)				Colder(if designated)			
cooling		<b>Yes</b>					
heating		<b>Yes</b>					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	<b>4.50</b>	kW	cooling	SEER	<b>5.80</b>	A+
heating / Average	Pdesignh	<b>5.80</b>	kW	heating / Average	SCOP/A	<b>3.82</b>	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	<b>4.95</b>	kW	heating / Average (-10°C)	elbu	<b>0.85</b>	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	<b>4.50</b>	kW	Tj=35°C	EERd	<b>4.12</b>	-
Tj=30°C	Pdc	<b>3.30</b>	kW	Tj=30°C	EERd	<b>6.85</b>	-
Tj=25°C	Pdc	<b>3.30</b>	kW	Tj=25°C	EERd	<b>8.50</b>	-
Tj=20°C	Pdc	<b>3.60</b>	kW	Tj=20°C	EERd	<b>7.20</b>	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	<b>5.10</b>	kW	Tj=-7°C	COPd	<b>2.30</b>	-
Tj=2°C	Pdh	<b>3.10</b>	kW	Tj=2°C	COPd	<b>3.65</b>	-
Tj=7°C	Pdh	<b>2.20</b>	kW	Tj=7°C	COPd	<b>5.50</b>	-
Tj=12°C	Pdh	<b>3.10</b>	kW	Tj=12°C	COPd	<b>6.85</b>	-
Tj=bivalent temperature	Pdh	<b>5.10</b>	kW	Tj=bivalent temperature	COPd	<b>2.30</b>	-
Tj=operating limit	Pdh	<b>4.70</b>	kW	Tj=operating limit	COPd	<b>2.10</b>	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	<b>-7</b>	°C	heating / Average	Tol	<b>-15</b>	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcyc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	<b>0.25</b>	-	heating	Cdh	<b>0.25</b>	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	<b>13</b>	W	cooling	Qce	<b>272</b>	kWh/a
standby mode	Psb	<b>13</b>	W	heating / Average	Qhe	<b>2128</b>	kWh/a
thermostat-off mode	Pto	<b>25</b>	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	<b>0</b>	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		<b>No</b>		Sound power level(indoor)	Lwa	<b>50</b>	dB(A)
staged		<b>No</b>		Sound power level(outdoor)	Lwa	<b>60</b>	dB(A)
variable		<b>Yes</b>		Global warming potential	GWP	<b>1975</b>	kgCO2eq.
Contact details for obtaining more information				Rated air flow(indoor)			
Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom				Rated air flow(outdoor)			
				-			


A RWC000Z284

## (3) Model SCM50ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZMX-S*2		Average(mandatory)		Yes	
Outdoor unit model name		SCM50ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	5.00	kW	cooling	SEER	5.61	A+
heating / Average	Pdesignh	5.80	kW	heating / Average	SCOP/A	3.82	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	4.90	kW	heating / Average (-10°C)	elbu	0.90	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	5.00	kW	Tj=35°C	EERd	3.70	-
Tj=30°C	Pdc	3.70	kW	Tj=30°C	EERd	5.75	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	8.15	-
Tj=20°C	Pdc	3.60	kW	Tj=20°C	EERd	7.40	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	5.20	kW	Tj=-7°C	COPd	2.50	-
Tj=2°C	Pdh	3.20	kW	Tj=2°C	COPd	3.71	-
Tj=7°C	Pdh	2.10	kW	Tj=7°C	COPd	5.20	-
Tj=12°C	Pdh	2.30	kW	Tj=12°C	COPd	5.90	-
Tj=bivalent temperature	Pdh	5.20	kW	Tj=bivalent temperature	COPd	2.50	-
Tj=operating limit	Pdh	4.40	kW	Tj=operating limit	COPd	1.90	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyhc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	12	W	cooling	Qce	312	kWh/a
standby mode	Psb	12	W	heating / Average	Qhe	2125	kWh/a
thermostat-off mode	Pto	30	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	50	dB(A)
staged		No		Sound power level(outdoor)	Lwa	62	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	474	m3/h
				Rated air flow(outdoor)	-	2460	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		<b>SRK20ZMX-S x 3</b>		Average(mandatory)		<b>Yes</b>	
Outdoor unit model name		<b>SCM50ZM-S</b>		Warmer(if designated)		<b>No</b>	
Function(indicate if present)				Colder(if designated)			
cooling		<b>Yes</b>					
heating		<b>Yes</b>				<b>No</b>	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	<b>5.00</b>	kW	cooling	SEER	<b>6.62</b>	A++
heating / Average	Pdesignh	<b>5.90</b>	kW	heating / Average	SCOP/A	<b>3.95</b>	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	<b>4.90</b>	kW	heating / Average (-10°C)	elbu	<b>1.00</b>	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	<b>5.00</b>	kW	Tj=35°C	EERd	<b>4.63</b>	-
Tj=30°C	Pdc	<b>3.70</b>	kW	Tj=30°C	EERd	<b>7.10</b>	-
Tj=25°C	Pdc	<b>3.60</b>	kW	Tj=25°C	EERd	<b>9.90</b>	-
Tj=20°C	Pdc	<b>3.90</b>	kW	Tj=20°C	EERd	<b>9.00</b>	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	<b>5.20</b>	kW	Tj=-7°C	COPd	<b>2.60</b>	-
Tj=2°C	Pdh	<b>3.20</b>	kW	Tj=2°C	COPd	<b>3.90</b>	-
Tj=7°C	Pdh	<b>2.00</b>	kW	Tj=7°C	COPd	<b>5.10</b>	-
Tj=12°C	Pdh	<b>2.30</b>	kW	Tj=12°C	COPd	<b>6.30</b>	-
Tj=bivalent temperature	Pdh	<b>5.20</b>	kW	Tj=bivalent temperature	COPd	<b>2.60</b>	-
Tj=operating limit	Pdh	<b>4.40</b>	kW	Tj=operating limit	COPd	<b>2.20</b>	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	<b>-7</b>	°C	heating / Average	Tol	<b>-15</b>	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcyc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	<b>0.25</b>	-	heating	Cdh	<b>0.25</b>	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	<b>13</b>	W	cooling	Qce	<b>265</b>	kWh/a
standby mode	Psb	<b>13</b>	W	heating / Average	Qhe	<b>2091</b>	kWh/a
thermostat-off mode	Pto	<b>28</b>	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	<b>0</b>	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		<b>No</b>		Sound power level(indoor)	Lwa	<b>53</b>	dB(A)
staged		<b>No</b>		Sound power level(outdoor)	Lwa	<b>62</b>	dB(A)
variable		<b>Yes</b>		Global warming potential	GWp	<b>1975</b>	kgCO2eq.
				Rated air flow(indoor)	-	<b>690</b>	m3/h
				Rated air flow(outdoor)	-	<b>2460</b>	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

B RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZM-Sx2		Average(mandatory)		Yes	
Outdoor unit model name		SCM50ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	5.00	kW	cooling	SEER	5.60	A+
heating / Average	Pdesignh	6.10	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.14	kW	heating / Average (-10°C)	elbu	0.96	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	5.00	kW	Tj=35°C	EERd	3.40	-
Tj=30°C	Pdc	3.70	kW	Tj=30°C	EERd	5.70	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	8.10	-
Tj=20°C	Pdc	3.60	kW	Tj=20°C	EERd	7.40	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	5.40	kW	Tj=-7°C	COPd	2.40	-
Tj=2°C	Pdh	3.30	kW	Tj=2°C	COPd	3.73	-
Tj=7°C	Pdh	2.20	kW	Tj=7°C	COPd	5.20	-
Tj=12°C	Pdh	2.80	kW	Tj=12°C	COPd	5.90	-
Tj=bivalent temperature	Pdh	5.40	kW	Tj=bivalent temperature	COPd	2.40	-
Tj=operating limit	Pdh	4.70	kW	Tj=operating limit	COPd	1.90	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	11	W	cooling	Qce	313	kWh/a
standby mode	Psb	11	W	heating / Average	Qhe	2247	kWh/a
thermostat-off mode	Pto	25	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	50	dB(A)
staged		No		Sound power level(outdoor)	Lwa	62	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	474	m3/h
				Rated air flow(outdoor)	-	2460	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S×3		Average(mandatory)		Yes	
Outdoor unit model name		SCM50ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes				No	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	5.00	kW	cooling	SEER	6.52	A++
heating / Average	Pdesignh	6.30	kW	heating / Average	SCOP/A	3.88	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.19	kW	heating / Average (-10°C)	elbu	1.11	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	5.00	kW	Tj=35°C	EERd	4.50	-
Tj=30°C	Pdc	3.70	kW	Tj=30°C	EERd	7.00	-
Tj=25°C	Pdc	3.50	kW	Tj=25°C	EERd	9.60	-
Tj=20°C	Pdc	4.00	kW	Tj=20°C	EERd	8.80	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	5.60	kW	Tj=-7°C	COPd	2.40	-
Tj=2°C	Pdh	3.40	kW	Tj=2°C	COPd	3.60	-
Tj=7°C	Pdh	2.20	kW	Tj=7°C	COPd	5.60	-
Tj=12°C	Pdh	2.80	kW	Tj=12°C	COPd	7.10	-
Tj=bivalent temperature	Pdh	5.60	kW	Tj=bivalent temperature	COPd	2.40	-
Tj=operating limit	Pdh	4.50	kW	Tj=operating limit	COPd	2.20	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	12	W	cooling	Qce	269	kWh/a
standby mode	Psb	12	W	heating / Average	Qhe	2276	kWh/a
thermostat-off mode	Pto	32	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	49	dB(A)
staged		No		Sound power level(outdoor)	Lwa	62	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	2460	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					


B RWC000Z284 A

**(4) Model SCM60ZM-S**


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		<b>SRK25ZMX-S+SRK35ZMX-S</b>		Average(mandatory)		<b>Yes</b>	
Outdoor unit model name		<b>SCM60ZM-S</b>		Warmer(if designated)		<b>No</b>	
Function(indicate if present)				Colder(if designated)			
cooling		<b>Yes</b>					
heating		<b>Yes</b>					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	<b>6.00</b>	kW	cooling	SEER	<b>5.61</b>	A+
heating / Average	Pdesignh	<b>7.00</b>	kW	heating / Average	SCOP/A	<b>3.82</b>	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	<b>6.56</b>	kW	heating / Average (-10°C)	elbu	<b>0.44</b>	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	<b>6.00</b>	kW	Tj=35°C	EERd	<b>3.15</b>	-
Tj=30°C	Pdc	<b>4.42</b>	kW	Tj=30°C	EERd	<b>4.75</b>	-
Tj=25°C	Pdc	<b>3.19</b>	kW	Tj=25°C	EERd	<b>8.62</b>	-
Tj=20°C	Pdc	<b>4.20</b>	kW	Tj=20°C	EERd	<b>7.38</b>	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	<b>6.41</b>	kW	Tj=-7°C	COPd	<b>2.37</b>	-
Tj=2°C	Pdh	<b>3.88</b>	kW	Tj=2°C	COPd	<b>3.85</b>	-
Tj=7°C	Pdh	<b>3.24</b>	kW	Tj=7°C	COPd	<b>5.25</b>	-
Tj=12°C	Pdh	<b>3.83</b>	kW	Tj=12°C	COPd	<b>5.97</b>	-
Tj=bivalent temperature	Pdh	<b>6.41</b>	kW	Tj=bivalent temperature	COPd	<b>2.37</b>	-
Tj=operating limit	Pdh	<b>6.82</b>	kW	Tj=operating limit	COPd	<b>2.3</b>	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	<b>-7</b>	°C	heating / Average	Tol	<b>-15</b>	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	<b>0.25</b>	-	heating	Cdh	<b>0.25</b>	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	<b>12</b>	W	cooling	Qce	<b>375</b>	kWh/a
standby mode	Psb	<b>12</b>	W	heating / Average	Qhe	<b>2569</b>	kWh/a
thermostat-off mode	Pto	<b>25</b>	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	<b>0</b>	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		<b>No</b>		Sound power level(indoor)	Lwa	<b>58</b>	dB(A)
staged		<b>No</b>		Sound power level(outdoor)	Lwa	<b>63</b>	dB(A)
variable		<b>Yes</b>		Global warming potential	GWP	<b>1975</b>	kgCO2eq.
				Rated air flow(indoor)	-	<b>810</b>	m3/h
				Rated air flow(outdoor)	-	<b>2520</b>	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284 A


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S×3		Average(mandatory)		Yes	
Outdoor unit model name		SCM60ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	6.00	kW	cooling	SEER	6.55	A++
heating / Average	Pdesignh	7.10	kW	heating / Average	SCOP/A	4.01	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.37	kW	heating / Average (-10°C)	elbu	0.73	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	6.00	kW	Tj=35°C	EERd	4.08	-
Tj=30°C	Pdc	4.47	kW	Tj=30°C	EERd	6.32	-
Tj=25°C	Pdc	3.27	kW	Tj=25°C	EERd	9.63	-
Tj=20°C	Pdc	4.55	kW	Tj=20°C	EERd	9.19	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.50	kW	Tj=-7°C	COPd	2.30	-
Tj=2°C	Pdh	4.04	kW	Tj=2°C	COPd	4.14	-
Tj=7°C	Pdh	2.65	kW	Tj=7°C	COPd	5.25	-
Tj=12°C	Pdh	2.93	kW	Tj=12°C	COPd	6.11	-
Tj=bivalent temperature	Pdh	6.50	kW	Tj=bivalent temperature	COPd	2.30	-
Tj=operating limit	Pdh	6.14	kW	Tj=operating limit	COPd	2.56	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pccyc	-	kW	for cooling	EERcyc	-	-
for heating	Pchyc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	14	W	cooling	Qce	321	kWh/a
standby mode	Psb	14	W	heating / Average	Qhe	2480	kWh/a
thermostat-off mode	Pto	30	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	53	dB(A)
staged		No		Sound power level(outdoor)	Lwa	63	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	690	m3/h
				Rated air flow(outdoor)	-	2520	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZM-S+SRK35ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM60ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes				No	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	6.00	kW	cooling	SEER	5.55	A
heating / Average	Pdesignh	7.20	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.56	kW	heating / Average (-10°C)	elbu	0.64	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	6.00	kW	Tj=35°C	EERd	3.03	-
Tj=30°C	Pdc	4.42	kW	Tj=30°C	EERd	4.72	-
Tj=25°C	Pdc	3.19	kW	Tj=25°C	EERd	8.62	-
Tj=20°C	Pdc	4.20	kW	Tj=20°C	EERd	7.38	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.41	kW	Tj=-7°C	COPd	2.37	-
Tj=2°C	Pdh	3.88	kW	Tj=2°C	COPd	3.83	-
Tj=7°C	Pdh	3.24	kW	Tj=7°C	COPd	5.19	-
Tj=12°C	Pdh	3.83	kW	Tj=12°C	COPd	5.95	-
Tj=bivalent temperature	Pdh	6.41	kW	Tj=bivalent temperature	COPd	2.37	-
Tj=operating limit	Pdh	6.82	kW	Tj=operating limit	COPd	2.14	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcych	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	12	W	cooling	Qce	379	kWh/a
standby mode	Psb	12	W	heating / Average	Qhe	2656	kWh/a
thermostat-off mode	Pto	35	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	58	dB(A)
staged		No		Sound power level(outdoor)	Lwa	63	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	606	m3/h
				Rated air flow(outdoor)	-	2520	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S×3		Average(mandatory)		Yes	
Outdoor unit model name		SCM60ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes				No	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	6.00	kW	cooling	SEER	6.21	A++
heating / Average	Pdesignh	7.10	kW	heating / Average	SCOP/A	3.91	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.46	kW	heating / Average (-10°C)	elbu	0.64	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	6.00	kW	Tj=35°C	EERd	3.98	-
Tj=30°C	Pdc	4.47	kW	Tj=30°C	EERd	6.10	-
Tj=25°C	Pdc	3.27	kW	Tj=25°C	EERd	9.10	-
Tj=20°C	Pdc	4.55	kW	Tj=20°C	EERd	8.50	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.65	kW	Tj=-7°C	COPd	2.37	-
Tj=2°C	Pdh	4.04	kW	Tj=2°C	COPd	3.90	-
Tj=7°C	Pdh	2.65	kW	Tj=7°C	COPd	5.25	-
Tj=12°C	Pdh	2.93	kW	Tj=12°C	COPd	6.11	-
Tj=bivalent temperature	Pdh	6.65	kW	Tj=bivalent temperature	COPd	2.37	-
Tj=operating limit	Pdh	6.14	kW	Tj=operating limit	COPd	2.56	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	14	W	cooling	Qce	338	kWh/a
standby mode	Psb	14	W	heating / Average	Qhe	2544	kWh/a
thermostat-off mode	Pto	40	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	49	dB(A)
staged		No		Sound power level(outdoor)	Lwa	63	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	2520	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWC000Z284 

## (5) Model SCM71ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK35ZMX-Sx2		Average(mandatory)		Yes	
Outdoor unit model name		SCM71ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.10	kW	cooling	SEER	5.85	A+
heating / Average	Pdesignh	7.30	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.98	kW	heating / Average (-10°C)	elbu	1.32	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	3.34	-
Tj=30°C	Pdc	5.29	kW	Tj=30°C	EERd	5.25	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	7.85	-
Tj=20°C	Pdc	4.31	kW	Tj=20°C	EERd	9.25	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.62	kW	Tj=-7°C	COPd	2.45	-
Tj=2°C	Pdh	3.95	kW	Tj=2°C	COPd	3.99	-
Tj=7°C	Pdh	2.49	kW	Tj=7°C	COPd	4.57	-
Tj=12°C	Pdh	2.63	kW	Tj=12°C	COPd	5.58	-
Tj=bivalent temperature	Pdh	6.62	kW	Tj=bivalent temperature	COPd	2.45	-
Tj=operating limit	Pdh	4.90	kW	Tj=operating limit	COPd	1.80	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyhc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	15	W	cooling	Qce	425	kWh/a
standby mode	Psb	15	W	heating / Average	Qhe	2682	kWh/a
thermostat-off mode	Pto	40	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	58	dB(A)
staged		No		Sound power level(outdoor)	Lwa	65	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	810	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S+SRK25ZMX-Sx2		Average(mandatory)		Yes	
Outdoor unit model name		SCM71ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes		Colder(if designated)		No	
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.10	kW	cooling	SEER	6.09	A+
heating / Average	Pdesignh	7.30	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.98	kW	heating / Average (-10°C)	elbu	1.32	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	3.85	-
Tj=30°C	Pdc	5.29	kW	Tj=30°C	EERd	5.55	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	8.05	-
Tj=20°C	Pdc	4.31	kW	Tj=20°C	EERd	9.35	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.62	kW	Tj=-7°C	COPd	2.45	-
Tj=2°C	Pdh	3.95	kW	Tj=2°C	COPd	3.99	-
Tj=7°C	Pdh	2.49	kW	Tj=7°C	COPd	4.57	-
Tj=12°C	Pdh	2.63	kW	Tj=12°C	COPd	5.58	-
Tj=bivalent temperature	Pdh	6.62	kW	Tj=bivalent temperature	COPd	2.45	-
Tj=operating limit	Pdh	4.90	kW	Tj=operating limit	COPd	1.80	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcych	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	15	W	cooling	Qce	409	kWh/a
standby mode	Psb	15	W	heating / Average	Qhe	2682	kWh/a
thermostat-off mode	Pto	40	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	55	dB(A)
staged		No		Sound power level(outdoor)	Lwa	65	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	750	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 A


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S × 4		Average(mandatory)		Yes	
Outdoor unit model name		SCM71ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.10	kW	cooling	SEER	6.41	A++
heating / Average	Pdesignh	7.30	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.98	kW	heating / Average (-10°C)	elbu	1.32	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	4.14	-
Tj=30°C	Pdc	5.29	kW	Tj=30°C	EERd	5.94	-
Tj=25°C	Pdc	3.30	kW	Tj=25°C	EERd	8.28	-
Tj=20°C	Pdc	4.31	kW	Tj=20°C	EERd	10.19	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.62	kW	Tj=-7°C	COPd	2.45	-
Tj=2°C	Pdh	3.95	kW	Tj=2°C	COPd	3.99	-
Tj=7°C	Pdh	2.49	kW	Tj=7°C	COPd	4.57	-
Tj=12°C	Pdh	2.63	kW	Tj=12°C	COPd	5.58	-
Tj=bivalent temperature	Pdh	6.62	kW	Tj=bivalent temperature	COPd	2.45	-
Tj=operating limit	Pdh	4.90	kW	Tj=operating limit	COPd	1.80	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	15	W	cooling	Qce	388	kWh/a
standby mode	Psb	15	W	heating / Average	Qhe	2682	kWh/a
thermostat-off mode	Pto	40	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	53	dB(A)
staged		No		Sound power level(outdoor)	Lwa	65	dB(A)
variable		Yes		Global warming potential	GWp	1975	kgCO2eq.
				Rated air flow(indoor)	-	690	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

B RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK35ZM-S×2		Average(mandatory)		Yes	
Outdoor unit model name		SCM71ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.10	kW	cooling	SEER	5.67	A+
heating / Average	Pdesignh	7.40	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.83	kW	heating / Average (-10°C)	elbu	0.57	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	2.91	-
Tj=30°C	Pdc	5.26	kW	Tj=30°C	EERd	4.71	-
Tj=25°C	Pdc	3.36	kW	Tj=25°C	EERd	8.65	-
Tj=20°C	Pdc	4.14	kW	Tj=20°C	EERd	9.13	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.65	kW	Tj=-7°C	COPd	2.21	-
Tj=2°C	Pdh	3.86	kW	Tj=2°C	COPd	4.19	-
Tj=7°C	Pdh	3.04	kW	Tj=7°C	COPd	4.64	-
Tj=12°C	Pdh	3.58	kW	Tj=12°C	COPd	5.35	-
Tj=bivalent temperature	Pdh	6.65	kW	Tj=bivalent temperature	COPd	2.21	-
Tj=operating limit	Pdh	7.12	kW	Tj=operating limit	COPd	1.99	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	18	W	cooling	Qce	439	kWh/a
standby mode	Psb	18	W	heating / Average	Qhe	2726	kWh/a
thermostat-off mode	Pto	50	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	58	dB(A)
staged		No		Sound power level(outdoor)	Lwa	65	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	606	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		<b>SRK20ZM-S+SRK25ZM-Sx2</b>		Average(mandatory)		<b>Yes</b>	
Outdoor unit model name		<b>SCM71ZM-S</b>		Warmer(if designated)		<b>No</b>	
Function(indicate if present)				Colder(if designated)			
cooling		<b>Yes</b>					
heating		<b>Yes</b>					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	<b>7.10</b>	kW	cooling	SEER	<b>5.81</b>	A+
heating / Average	Pdesignh	<b>7.40</b>	kW	heating / Average	SCOP/A	<b>3.80</b>	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	<b>6.83</b>	kW	heating / Average (-10°C)	elbu	<b>0.57</b>	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	<b>7.10</b>	kW	Tj=35°C	EERd	<b>3.73</b>	-
Tj=30°C	Pdc	<b>5.26</b>	kW	Tj=30°C	EERd	<b>4.71</b>	-
Tj=25°C	Pdc	<b>3.36</b>	kW	Tj=25°C	EERd	<b>8.65</b>	-
Tj=20°C	Pdc	<b>4.14</b>	kW	Tj=20°C	EERd	<b>9.13</b>	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	<b>6.65</b>	kW	Tj=-7°C	COPd	<b>2.21</b>	-
Tj=2°C	Pdh	<b>3.86</b>	kW	Tj=2°C	COPd	<b>4.19</b>	-
Tj=7°C	Pdh	<b>3.04</b>	kW	Tj=7°C	COPd	<b>4.64</b>	-
Tj=12°C	Pdh	<b>3.58</b>	kW	Tj=12°C	COPd	<b>5.35</b>	-
Tj=bivalent temperature	Pdh	<b>6.65</b>	kW	Tj=bivalent temperature	COPd	<b>2.21</b>	-
Tj=operating limit	Pdh	<b>7.12</b>	kW	Tj=operating limit	COPd	<b>1.99</b>	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	<b>-7</b>	°C	heating / Average	Tol	<b>-15</b>	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	<b>0.25</b>	-	heating	Cdh	<b>0.25</b>	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	<b>19</b>	W	cooling	Qce	<b>429</b>	kWh/a
standby mode	Psb	<b>19</b>	W	heating / Average	Qhe	<b>2726</b>	kWh/a
thermostat-off mode	Pto	<b>52</b>	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	<b>0</b>	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		<b>No</b>		Sound power level(indoor)	Lwa	<b>50</b>	dB(A)
staged		<b>No</b>		Sound power level(outdoor)	Lwa	<b>65</b>	dB(A)
variable		<b>Yes</b>		Global warming potential	GWP	<b>1975</b>	kgCO2eq.
				Rated air flow(indoor)	-	<b>474</b>	m3/h
				Rated air flow(outdoor)	-	<b>3360</b>	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-Sx4		Average(mandatory)		Yes	
Outdoor unit model name		SCM71ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.10	kW	cooling	SEER	5.94	A+
heating / Average	Pdesignh	7.40	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.83	kW	heating / Average (-10°C)	elbu	0.57	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	3.94	-
Tj=30°C	Pdc	5.26	kW	Tj=30°C	EERd	5.03	-
Tj=25°C	Pdc	3.36	kW	Tj=25°C	EERd	8.65	-
Tj=20°C	Pdc	4.14	kW	Tj=20°C	EERd	9.27	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.65	kW	Tj=-7°C	COPd	2.21	-
Tj=2°C	Pdh	3.86	kW	Tj=2°C	COPd	4.19	-
Tj=7°C	Pdh	3.04	kW	Tj=7°C	COPd	4.64	-
Tj=12°C	Pdh	3.58	kW	Tj=12°C	COPd	5.35	-
Tj=bivalent temperature	Pdh	6.65	kW	Tj=bivalent temperature	COPd	2.21	-
Tj=operating limit	Pdh	7.12	kW	Tj=operating limit	COPd	1.99	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcyc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	19	W	cooling	Qce	419	kWh/a
standby mode	Psb	19	W	heating / Average	Qhe	2726	kWh/a
thermostat-off mode	Pto	52	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	46	dB(A)
staged		No		Sound power level(outdoor)	Lwa	65	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information				Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom			

A RWC000Z284 A

## (6) Model SCM80ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK35ZMX-S+SRK50ZMX-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM80ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	8.00	kW	cooling	SEER	5.74	A+
heating / Average	Pdesignh	7.50	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	5.98	kW	heating / Average (-10°C)	elbu	1.52	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	8.00	kW	Tj=35°C	EERd	3.23	-
Tj=30°C	Pdc	5.94	kW	Tj=30°C	EERd	5.01	-
Tj=25°C	Pdc	3.70	kW	Tj=25°C	EERd	7.20	-
Tj=20°C	Pdc	4.31	kW	Tj=20°C	EERd	9.51	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.62	kW	Tj=-7°C	COPd	2.45	-
Tj=2°C	Pdh	3.95	kW	Tj=2°C	COPd	3.99	-
Tj=7°C	Pdh	2.57	kW	Tj=7°C	COPd	4.57	-
Tj=12°C	Pdh	2.63	kW	Tj=12°C	COPd	5.58	-
Tj=bivalent temperature	Pdh	6.62	kW	Tj=bivalent temperature	COPd	2.45	-
Tj=operating limit	Pdh	4.90	kW	Tj=operating limit	COPd	1.80	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	14	W	cooling	Qce	489	kWh/a
standby mode	Psb	14	W	heating / Average	Qhe	2755	kWh/a
thermostat-off mode	Pto	35	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	60	dB(A)
staged		No		Sound power level(outdoor)	Lwa	66	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	810	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S+SRK25ZMX-S+SRK35ZMX-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM80ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	8.00	kW	cooling	SEER	5.95	A+
heating / Average	Pdesignh	7.50	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				unit			
heating / Average (-10°C)	Pdh	5.98	kW	Back up heating capacity at outdoor temperature Tdesignh			
heating / Warmer (2°C)	Pdh	-	kW	heating / Average (-10°C)	elbu	1.52	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
				heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	8.00	kW	Tj=35°C	EERd	3.52	-
Tj=30°C	Pdc	5.94	kW	Tj=30°C	EERd	5.12	-
Tj=25°C	Pdc	3.70	kW	Tj=25°C	EERd	7.65	-
Tj=20°C	Pdc	4.31	kW	Tj=20°C	EERd	9.85	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.62	kW	Tj=-7°C	COPd	2.45	-
Tj=2°C	Pdh	3.95	kW	Tj=2°C	COPd	3.99	-
Tj=7°C	Pdh	2.57	kW	Tj=7°C	COPd	4.57	-
Tj=12°C	Pdh	2.63	kW	Tj=12°C	COPd	5.58	-
Tj=bivalent temperature	Pdh	6.62	kW	Tj=bivalent temperature	COPd	2.45	-
Tj=operating limit	Pdh	4.90	kW	Tj=operating limit	COPd	1.80	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcycc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	15	W	cooling	Qce	471	kWh/a
standby mode	Psb	15	W	heating / Average	Qhe	2755	kWh/a
thermostat-off mode	Pto	40	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	58	dB(A)
staged		No		Sound power level(outdoor)	Lwa	66	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	810	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S × 4					
Outdoor unit model name		SCM80ZM-S					
Function(indicate if present)				Average(mandatory)			
cooling		Yes		Warmer(if designated)		No	
heating		Yes		Colder(if designated)		No	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	8.00	kW	cooling	SEER	6.29	A++
heating / Average	Pdesignh	7.50	kW	heating / Average	SCOP/A	3.81	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh 5.98 kW		heating / Average (-10°C)		elbu 1.52 kW	
heating / Warmer (2°C)		Pdh - kW		heating / Warmer (2°C)		elbu - kW	
heating / Colder (-22°C)		Pdh - kW		heating / Colder (-22°C)		elbu - kW	
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc 8.00 kW		Tj=35°C		EERd 3.80 -	
Tj=30°C		Pdc 5.94 kW		Tj=30°C		EERd 5.50 -	
Tj=25°C		Pdc 3.70 kW		Tj=25°C		EERd 8.15 -	
Tj=20°C		Pdc 4.31 kW		Tj=20°C		EERd 10.19 -	
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh 6.62 kW		Tj=-7°C		COPd 2.45 -	
Tj=2°C		Pdh 3.95 kW		Tj=2°C		COPd 3.99 -	
Tj=7°C		Pdh 2.57 kW		Tj=7°C		COPd 4.57 -	
Tj=12°C		Pdh 2.63 kW		Tj=12°C		COPd 5.58 -	
Tj=bivalent temperature		Pdh 6.62 kW		Tj=bivalent temperature		COPd 2.45 -	
Tj=operating limit		Pdh 4.90 kW		Tj=operating limit		COPd 1.80 -	
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh - kW		Tj=-7°C		COPd - -	
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Tj=-15°C		Pdh - kW		Tj=-15°C		COPd - -	
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv -7 °C		heating / Average		Tol -15 °C	
heating / Warmer		Tbiv - °C		heating / Warmer		Tol - °C	
heating / Colder		Tbiv - °C		heating / Colder		Tol - °C	
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc - kW		for cooling		EERcyc -	
for heating		Pcyh - kW		for heating		COPcyc -	
Degradation coefficient				Degradation coefficient			
cooling		Cdc 0.25 -		heating		Cdh 0.25 -	
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff 15 W		cooling		Qce 446 kWh/a	
standby mode		Psb 15 W		heating / Average		Qhe 2755 kWh/a	
thermostat-off mode		Pto 40 W		heating / Warmer		Qhe - kWh/a	
crankcase heater mode		Pck 0 W		heating / colder		Qhe - kWh/a	
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa 53 dB(A)	
staged		No		Sound power level(outdoor)		Lwa 66 dB(A)	
variable		Yes		Global warming potential		GWP 1975 kgCO2eq.	
				Rated air flow(indoor)		- 690 m3/h	
				Rated air flow(outdoor)		- 3360 m3/h	
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK35ZM-S+SRK50ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM80ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.50	kW	cooling	SEER	5.66	A+
heating / Average	Pdesignh	7.60	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh 6.69 kW		heating / Average (-10°C)		elbu 0.91 kW	
heating / Warmer (2°C)		Pdh - kW		heating / Warmer (2°C)		elbu - kW	
heating / Colder (-22°C)		Pdh - kW		heating / Colder (-22°C)		elbu - kW	
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc 7.50 kW		Tj=35°C		EERd 2.79 -	
Tj=30°C		Pdc 5.54 kW		Tj=30°C		EERd 4.74 -	
Tj=25°C		Pdc 3.52 kW		Tj=25°C		EERd 8.46 -	
Tj=20°C		Pdc 4.19 kW		Tj=20°C		EERd 9.27 -	
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh 6.80 kW		Tj=-7°C		COPd 2.29 -	
Tj=2°C		Pdh 3.99 kW		Tj=2°C		COPd 4.12 -	
Tj=7°C		Pdh 3.04 kW		Tj=7°C		COPd 4.64 -	
Tj=12°C		Pdh 3.58 kW		Tj=12°C		COPd 5.35 -	
Tj=bivalent temperature		Pdh 6.80 kW		Tj=bivalent temperature		COPd 2.29 -	
Tj=operating limit		Pdh 6.50 kW		Tj=operating limit		COPd 2.14 -	
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh - kW		Tj=-7°C		COPd - -	
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Tj=-15°C		Pdh - kW		Tj=-15°C		COPd - -	
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv -7 °C		heating / Average		Tol -15 °C	
heating / Warmer		Tbiv - °C		heating / Warmer		Tol - °C	
heating / Colder		Tbiv - °C		heating / Colder		Tol - °C	
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc - kW		for cooling		EERcyc - -	
for heating		Pcyh - kW		for heating		COPcyc - -	
Degradation coefficient				Degradation coefficient			
cooling		Cdc 0.25 -		heating		Cdh 0.25 -	
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff 18 W		cooling		Qce 464 kWh/a	
standby mode		Psb 18 W		heating / Average		Qhe 2803 kWh/a	
thermostat-off mode		Pto 52 W		heating / Warmer		Qhe - kWh/a	
crankcase heater mode		Pck 0 W		heating / colder		Qhe - kWh/a	
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa 61 dB(A)	
staged		No		Sound power level(outdoor)		Lwa 66 dB(A)	
variable		Yes		Global warming potential		GWP 1975 kgCO2eq.	
				Rated air flow(indoor)		- 678 m3/h	
				Rated air flow(outdoor)		- 3360 m3/h	
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S+SRK25ZM-S+SRK35ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM80ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.50	kW	cooling	SEER	5.76	A+
heating / Average	Pdesignh	7.60	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.69	kW	heating / Average (-10°C)	elbu	0.91	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.50	kW	Tj=35°C	EERd	3.52	-
Tj=30°C	Pdc	5.54	kW	Tj=30°C	EERd	4.74	-
Tj=25°C	Pdc	3.52	kW	Tj=25°C	EERd	8.46	-
Tj=20°C	Pdc	4.19	kW	Tj=20°C	EERd	9.27	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.80	kW	Tj=-7°C	COPd	2.29	-
Tj=2°C	Pdh	3.99	kW	Tj=2°C	COPd	4.12	-
Tj=7°C	Pdh	3.04	kW	Tj=7°C	COPd	4.64	-
Tj=12°C	Pdh	3.58	kW	Tj=12°C	COPd	5.35	-
Tj=bivalent temperature	Pdh	6.80	kW	Tj=bivalent temperature	COPd	2.29	-
Tj=operating limit	Pdh	6.50	kW	Tj=operating limit	COPd	2.14	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	20	W	cooling	Qce	456	kWh/a
standby mode	Psb	20	W	heating / Average	Qhe	2803	kWh/a
thermostat-off mode	Pto	52	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	58	dB(A)
staged		No		Sound power level(outdoor)	Lwa	66	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	606	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information				Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom			


A RWC000Z284 A

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S x 4		Average(mandatory)		Yes	
Outdoor unit model name		SCM80ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	7.50	kW	cooling	SEER	5.85	A+
heating / Average	Pdesignh	7.60	kW	heating / Average	SCOP/A	3.80	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	6.69	kW	heating / Average (-10°C)	elbu	0.91	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	7.50	kW	Tj=35°C	EERd	3.57	-
Tj=30°C	Pdc	5.54	kW	Tj=30°C	EERd	5.03	-
Tj=25°C	Pdc	3.52	kW	Tj=25°C	EERd	8.68	-
Tj=20°C	Pdc	4.19	kW	Tj=20°C	EERd	9.27	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	6.80	kW	Tj=-7°C	COPd	2.29	-
Tj=2°C	Pdh	3.99	kW	Tj=2°C	COPd	4.12	-
Tj=7°C	Pdh	3.04	kW	Tj=7°C	COPd	4.64	-
Tj=12°C	Pdh	3.58	kW	Tj=12°C	COPd	5.35	-
Tj=bivalent temperature	Pdh	6.80	kW	Tj=bivalent temperature	COPd	2.29	-
Tj=operating limit	Pdh	6.50	kW	Tj=operating limit	COPd	2.14	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyhc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	22	W	cooling	Qce	449	kWh/a
standby mode	Psb	22	W	heating / Average	Qhe	2803	kWh/a
thermostat-off mode	Pto	52	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	46	dB(A)
staged		No		Sound power level(outdoor)	Lwa	66	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	3360	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					


A RWC000Z284 A

## (7) Model SCM100ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZMX-Sx2+SRK50ZMX-S		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM—S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	4.95	B
heating / Average	Pdesignh	10.10	kW	heating / Average	SCOP/A	3.89	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	8.62	kW	heating / Average (-10°C)	elbu	1.48	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	10.00	kW	Tj=35°C	EERd	3.51	-
Tj=30°C	Pdc	7.65	kW	Tj=30°C	EERd	5.45	-
Tj=25°C	Pdc	8.10	kW	Tj=25°C	EERd	6.98	-
Tj=20°C	Pdc	7.81	kW	Tj=20°C	EERd	7.55	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	8.93	kW	Tj=-7°C	COPd	2.43	-
Tj=2°C	Pdh	5.49	kW	Tj=2°C	COPd	3.88	-
Tj=7°C	Pdh	4.61	kW	Tj=7°C	COPd	5.35	-
Tj=12°C	Pdh	5.34	kW	Tj=12°C	COPd	6.72	-
Tj=bivalent temperature	Pdh	8.93	kW	Tj=bivalent temperature	COPd	2.43	-
Tj=operating limit	Pdh	8.11	kW	Tj=operating limit	COPd	2.29	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	39	W	cooling	Qce	707	kWh/a
standby mode	Psb	39	W	heating / Average	Qhe	3633	kWh/a
thermostat-off mode	Pto	48	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	60	dB(A)
staged		No		Sound power level(outdoor)	Lwa	68	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	810	m3/h
				Rated air flow(outdoor)	-	4500	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

RWC000Z284 


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		<b>SRK25ZMX-S×4</b>		Average(mandatory)		<b>Yes</b>	
Outdoor unit model name		<b>SCM100ZM – S</b>		Warmer(if designated)		<b>No</b>	
Function(indicate if present)				Colder(if designated)			
cooling		<b>Yes</b>					
heating		<b>Yes</b>					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	<b>10.00</b>	kW	cooling	SEER	<b>5.01</b>	B
heating / Average	Pdesignh	<b>10.10</b>	kW	heating / Average	SCOP/A	<b>3.95</b>	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	<b>8.62</b>	kW	heating / Average (-10°C)	elbu	<b>1.48</b>	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	<b>10.00</b>	kW	Tj=35°C	EERd	<b>3.57</b>	-
Tj=30°C	Pdc	<b>7.65</b>	kW	Tj=30°C	EERd	<b>5.55</b>	-
Tj=25°C	Pdc	<b>8.10</b>	kW	Tj=25°C	EERd	<b>7.04</b>	-
Tj=20°C	Pdc	<b>7.81</b>	kW	Tj=20°C	EERd	<b>7.65</b>	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	<b>8.93</b>	kW	Tj=-7°C	COPd	<b>2.45</b>	-
Tj=2°C	Pdh	<b>5.49</b>	kW	Tj=2°C	COPd	<b>3.90</b>	-
Tj=7°C	Pdh	<b>4.61</b>	kW	Tj=7°C	COPd	<b>5.55</b>	-
Tj=12°C	Pdh	<b>5.34</b>	kW	Tj=12°C	COPd	<b>6.82</b>	-
Tj=bivalent temperature	Pdh	<b>8.93</b>	kW	Tj=bivalent temperature	COPd	<b>2.45</b>	-
Tj=operating limit	Pdh	<b>8.11</b>	kW	Tj=operating limit	COPd	<b>2.29</b>	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	<b>-7</b>	°C	heating / Average	Tol	<b>-15</b>	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	<b>0.25</b>	-	heating	Cdh	<b>0.25</b>	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	<b>39</b>	W	cooling	Qce	<b>699</b>	kWh/a
standby mode	Psb	<b>39</b>	W	heating / Average	Qhe	<b>3584</b>	kWh/a
thermostat-off mode	Pto	<b>48</b>	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	<b>0</b>	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		<b>No</b>		Sound power level(indoor)	Lwa	<b>55</b>	dB(A)
staged		<b>No</b>		Sound power level(outdoor)	Lwa	<b>68</b>	dB(A)
variable		<b>Yes</b>		Global warming potential	GWP	<b>1975</b>	kgCO2eq.
				Rated air flow(indoor)	-	<b>750</b>	m3/h
				Rated air flow(outdoor)	-	<b>4500</b>	m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

RWC000Z284 


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZMX-S×5		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	5.10	A
heating / Average	Pdesignh	10.10	kW	heating / Average	SCOP/A	4.02	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	8.62 kW	heating / Average (-10°C)		elbu	1.48 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	10.00 kW	Tj=35°C		EERd	3.57 -
Tj=30°C		Pdc	7.65 kW	Tj=30°C		EERd	5.76 -
Tj=25°C		Pdc	8.10 kW	Tj=25°C		EERd	7.14 -
Tj=20°C		Pdc	7.81 kW	Tj=20°C		EERd	7.82 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	8.93 kW	Tj=-7°C		COPd	2.52 -
Tj=2°C		Pdh	5.49 kW	Tj=2°C		COPd	3.97 -
Tj=7°C		Pdh	4.61 kW	Tj=7°C		COPd	5.64 -
Tj=12°C		Pdh	5.34 kW	Tj=12°C		COPd	6.89 -
Tj=bivalent temperature		Pdh	8.93 kW	Tj=bivalent temperature		COPd	2.52 -
Tj=operating limit		Pdh	8.11 kW	Tj=operating limit		COPd	2.29 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPcyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	39 W	cooling		Qce	687 kWh/a
standby mode		Psb	39 W	heating / Average		Qhe	3519 kWh/a
thermostat-off mode		Pto	48 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	53 dB(A)
staged		No		Sound power level(outdoor)		Lwa	68 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	690 m3/h
				Rated air flow(outdoor)		-	4500 m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

A RWC000Z284 A


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK71ZR-S x 2		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM-S		Warmer(if designated)		No	
Cooler(if designated)				Colder(if designated)		No	
Function(indicate if present)							
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	4.88	B
heating / Average	Pdesignh	10.10	kW	heating / Average	SCOP/A	3.83	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	8.62 kW	heating / Average (-10°C)		elbu	1.48 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	10.00 kW	Tj=35°C		EERd	3.50 -
Tj=30°C		Pdc	7.65 kW	Tj=30°C		EERd	5.40 -
Tj=25°C		Pdc	8.10 kW	Tj=25°C		EERd	6.78 -
Tj=20°C		Pdc	7.81 kW	Tj=20°C		EERd	7.45 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	8.93 kW	Tj=-7°C		COPd	2.40 -
Tj=2°C		Pdh	5.49 kW	Tj=2°C		COPd	3.80 -
Tj=7°C		Pdh	4.61 kW	Tj=7°C		COPd	5.30 -
Tj=12°C		Pdh	5.34 kW	Tj=12°C		COPd	6.70 -
Tj=bivalent temperature		Pdh	8.93 kW	Tj=bivalent temperature		COPd	2.40 -
Tj=operating limit		Pdh	8.11 kW	Tj=operating limit		COPd	2.20 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPcyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	39 W	cooling		Qce	718 kWh/a
standby mode		Psb	39 W	heating / Average		Qhe	3689 kWh/a
thermostat-off mode		Pto	48 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	58 dB(A)
staged		No		Sound power level(outdoor)		Lwa	68 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	1230 m3/h
				Rated air flow(outdoor)		-	4500 m3/h
Contact details for obtaining more information				Name and address of the manufacturer or of its authorised representative.			
				Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd.			
				7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom			

RWC000Z284 


Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZMX-Sx2+FDEN50VF		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)			
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	4.85	B
heating / Average	Pdesignh	10.20	kW	heating / Average	SCOP/A	3.83	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh 8.92 kW		heating / Average (-10°C)		elbu 1.28 kW	
heating / Warmer (2°C)		Pdh - kW		heating / Warmer (2°C)		elbu - kW	
heating / Colder (-22°C)		Pdh - kW		heating / Colder (-22°C)		elbu - kW	
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc 10.00 kW		Tj=35°C		EERd 3.10 -	
Tj=30°C		Pdc 7.37 kW		Tj=30°C		EERd 4.91 -	
Tj=25°C		Pdc 6.86 kW		Tj=25°C		EERd 7.14 -	
Tj=20°C		Pdc 6.80 kW		Tj=20°C		EERd 8.08 -	
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh 9.02 kW		Tj=-7°C		COPd 2.35 -	
Tj=2°C		Pdh 5.49 kW		Tj=2°C		COPd 3.97 -	
Tj=7°C		Pdh 4.61 kW		Tj=7°C		COPd 5.19 -	
Tj=12°C		Pdh 5.44 kW		Tj=12°C		COPd 5.39 -	
Tj=bivalent temperature		Pdh 9.02 kW		Tj=bivalent temperature		COPd 2.35 -	
Tj=operating limit		Pdh 8.75 kW		Tj=operating limit		COPd 2.62 -	
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh - kW		Tj=-7°C		COPd - -	
Tj=2°C		Pdh - kW		Tj=2°C		COPd - -	
Tj=7°C		Pdh - kW		Tj=7°C		COPd - -	
Tj=12°C		Pdh - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pdh - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pdh - kW		Tj=operating limit		COPd - -	
Tj=-15°C		Pdh - kW		Tj=-15°C		COPd - -	
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv -7 °C		heating / Average		Tol -15 °C	
heating / Warmer		Tbiv - °C		heating / Warmer		Tol - °C	
heating / Colder		Tbiv - °C		heating / Colder		Tol - °C	
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc - kW		for cooling		EERcyc - -	
for heating		Pcyh - kW		for heating		COPcyc - -	
Degradation coefficient				Degradation coefficient			
cooling		Cdc 0.25 -		heating		Cdh 0.25 -	
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff 45 W		cooling		Qce 723 kWh/a	
standby mode		Psb 45 W		heating / Average		Qhe 3730 kWh/a	
thermostat-off mode		Pto 55 W		heating / Warmer		Qhe - kWh/a	
crankcase heater mode		Pck 0 W		heating / colder		Qhe - kWh/a	
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa 60 dB(A)	
staged		No		Sound power level(outdoor)		Lwa 68 dB(A)	
variable		Yes		Global warming potential		GWP 1975 kgCO2eq.	
				Rated air flow(indoor)		- 780 m3/h	
				Rated air flow(outdoor)		- 4500 m3/h	
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZM-S×4		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	4.85	B
heating / Average	Pdesignh	10.20	kW	heating / Average	SCOP/A	3.83	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pd h 8.92 kW		heating / Average (-10°C)		elbu 1.28 kW	
heating / Warmer (2°C)		Pd h - kW		heating / Warmer (2°C)		elbu - kW	
heating / Colder (-22°C)		Pd h - kW		heating / Colder (-22°C)		elbu - kW	
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc 10.00 kW		Tj=35°C		EERd 3.10 -	
Tj=30°C		Pdc 7.37 kW		Tj=30°C		EERd 4.91 -	
Tj=25°C		Pdc 6.86 kW		Tj=25°C		EERd 7.14 -	
Tj=20°C		Pdc 6.80 kW		Tj=20°C		EERd 8.08 -	
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pd h 9.02 kW		Tj=-7°C		COPd 2.35 -	
Tj=2°C		Pd h 5.49 kW		Tj=2°C		COPd 3.97 -	
Tj=7°C		Pd h 4.61 kW		Tj=7°C		COPd 5.19 -	
Tj=12°C		Pd h 5.44 kW		Tj=12°C		COPd 5.39 -	
Tj=bivalent temperature		Pd h 9.02 kW		Tj=bivalent temperature		COPd 2.35 -	
Tj=operating limit		Pd h 8.75 kW		Tj=operating limit		COPd 2.62 -	
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pd h - kW		Tj=2°C		COPd - -	
Tj=7°C		Pd h - kW		Tj=7°C		COPd - -	
Tj=12°C		Pd h - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pd h - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pd h - kW		Tj=operating limit		COPd - -	
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pd h - kW		Tj=-7°C		COPd - -	
Tj=2°C		Pd h - kW		Tj=2°C		COPd - -	
Tj=7°C		Pd h - kW		Tj=7°C		COPd - -	
Tj=12°C		Pd h - kW		Tj=12°C		COPd - -	
Tj=bivalent temperature		Pd h - kW		Tj=bivalent temperature		COPd - -	
Tj=operating limit		Pd h - kW		Tj=operating limit		COPd - -	
Tj=-15°C		Pd h - kW		Tj=-15°C		COPd - -	
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv -7 °C		heating / Average		Tol -15 °C	
heating / Warmer		Tbiv - °C		heating / Warmer		Tol - °C	
heating / Colder		Tbiv - °C		heating / Colder		Tol - °C	
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc - kW		for cooling		EERcyc - -	
for heating		Pcyh - kW		for heating		COPcyc - -	
Degradation coefficient				Degradation coefficient			
cooling		Cdc 0.25 -		heating		Cdh 0.25 -	
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff 45 W		cooling		Qce 723 kWh/a	
standby mode		Psb 45 W		heating / Average		Qhe 3730 kWh/a	
thermostat-off mode		Pto 55 W		heating / Warmer		Qhe - kWh/a	
crankcase heater mode		Pck 0 W		heating / colder		Qhe - kWh/a	
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa 50 dB(A)	
staged		No		Sound power level(outdoor)		Lwa 68 dB(A)	
variable		Yes		Global warming potential		GWP 1975 kgCO2eq.	
				Rated air flow(indoor)		- 474 m3/h	
				Rated air flow(outdoor)		- 4500 m3/h	
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

RWC000Z284 

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S*5		Average(mandatory)		Yes	
Outdoor unit model name		SCM100ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	10.00	kW	cooling	SEER	4.85	B
heating / Average	Pdesignh	10.20	kW	heating / Average	SCOP/A	3.83	A
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	8.92	kW	heating / Average (-10°C)	elbu	1.28	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	10.00	kW	Tj=35°C	EERd	3.10	-
Tj=30°C	Pdc	7.37	kW	Tj=30°C	EERd	4.91	-
Tj=25°C	Pdc	6.86	kW	Tj=25°C	EERd	7.14	-
Tj=20°C	Pdc	6.80	kW	Tj=20°C	EERd	8.08	-
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	9.02	kW	Tj=-7°C	COPd	2.35	-
Tj=2°C	Pdh	5.49	kW	Tj=2°C	COPd	3.97	-
Tj=7°C	Pdh	4.61	kW	Tj=7°C	COPd	5.19	-
Tj=12°C	Pdh	5.44	kW	Tj=12°C	COPd	5.39	-
Tj=bivalent temperature	Pdh	9.02	kW	Tj=bivalent temperature	COPd	2.35	-
Tj=operating limit	Pdh	8.75	kW	Tj=operating limit	COPd	2.62	-
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyhc	-	kW	for heating	COPcyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	45	W	cooling	Qce	723	kWh/a
standby mode	Psb	45	W	heating / Average	Qhe	3731	kWh/a
thermostat-off mode	Pto	60	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)	Lwa	46	dB(A)
staged		No		Sound power level(outdoor)	Lwa	68	dB(A)
variable		Yes		Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	4500	m3/h
Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						

RWC000Z284 

---

## **INVERTER MULTI-SPLIT SYSTEM RESIDENTIAL AIR-CONDITIONERS**

---



---

**MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.**

16-5 Konan 2-chome, Minato-ku, Tokyo, 108-8215, Japan  
<http://www.mhi-mth.co.jp/>

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice.

© Copyright MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.